

SIEMENS

Hob

EH9..LV...


[en] Instruction manual






Register your product on My Siemens and discover exclusive services and offers.
siemens-home.bsh-group.com/welcome

The future moving in.

























Siemens Home Appliances



| | | g* | b* |
|--------------|--|-----------|--------------|
| A / B | Ø 18 | 1.800 W | 3.100 W |
| C | Ø 21  | 2.200 W | 3.700 W |
| | Ø 26  | 2.600 W | max. 4.400 W |
| | Ø 32  | 3.300 W | max. 5.500 W |
| D | Ø 14,5 | 1.400 W | 2.200 W |
| E | Ø 21 | 2.200 W | 3.700 W |

*  IEC 60335-2-6

Table of contents

| | | | |
|--|----|---|----|
|  Intended use | 4 |  Wipe protection | 22 |
|  Important safety information | 5 |  Automatic safety cut-out | 22 |
|  Causes of damage | 6 |  Basic settings | 23 |
| Overview | 6 | To access the basic settings: | 24 |
|  Environmental protection | 7 |  Energy consumption indicator | 24 |
| Energy-saving advice | 7 |  Cookware check | 25 |
| Environmentally-friendly disposal | 7 |  Power manager | 25 |
|  Induction cooking | 7 |  Cleaning | 26 |
| Advantages of induction cooking | 7 | Hob | 26 |
| Cookware | 7 | Hob surround | 26 |
|  Getting to know your appliance | 9 |  Frequently Asked Questions (FAQ) | 27 |
| The control panel | 9 |  Trouble shooting | 29 |
| The hotplates | 10 |  Customer service | 30 |
| Residual heat indicator | 10 | E number and FD number | 30 |
|  Operating the appliance | 11 |  Test dishes | 31 |
| Switching the hob on and off | 11 | | |
| Setting a hotplate | 11 | | |
| Chef's recommendations | 11 | | |
|  Time-setting options | 14 | | |
| Programming the cooking time | 14 | | |
| The kitchen timer | 14 | | |
| Stopwatch function | 15 | | |
|  PowerBoost function | 15 | | |
| Activating | 15 | | |
| Deactivating | 15 | | |
|  ShortBoost function | 16 | | |
| Recommendations for use | 16 | | |
| Activating | 16 | | |
| Deactivating | 16 | | |
|  Keep warm function | 16 | | |
| Activating | 16 | | |
| Deactivating | 16 | | |
|  Frying Sensor | 17 | | |
| Advantages when frying | 17 | | |
| Frying pans for the frying sensor | 17 | | |
| Temperature settings | 18 | | |
| Table | 18 | | |
| Setting procedure | 21 | | |
|  Childproof lock | 21 | | |
| Activating and deactivating the childproof lock | 21 | | |
| Childproof lock | 21 | | |

Additional information on products, accessories, replacement parts and services can be found at www.siemens-home.bsh-group.com and in the online shop www.siemens-home.bsh-group.com/eshops

Intended use

Read these instructions carefully. Please keep the instruction and installation manual, as well as the appliance certificate, in a safe place for later use or for subsequent owners.

Check the appliance after removing it from the packaging. If it has suffered any damage in transport, do not connect the appliance, contact the Technical Assistance Service and provide written notification of the damage caused, otherwise you will lose your right to any type of compensation.

Only a licensed professional may connect appliances without plugs. Damage caused by incorrect connection is not covered under warranty.

This appliance must be installed according to the installation instructions included.

This appliance is intended for private domestic use and the household environment only. The appliance must only be used for the preparation of food and beverages. The cooking process must be supervised. A short cooking process must be supervised without interruption. Only use the appliance in enclosed spaces.

This appliance is intended for use up to a maximum height of 4000 metres above sea level.

Do not use covers. These can cause accidents, for example due to overheating, catching fire or materials shattering.

Only use safety devices or child protection grilles approved by ourselves. Unsuitable safety devices or child protection grilles may result in accidents.

This appliance is not intended for operation with an external clock timer or a remote control.

This appliance may be used by children over the age of 8 years old and by persons with reduced physical, sensory or mental capabilities or by persons with a lack of experience or knowledge if they are supervised or are instructed by a person responsible for their safety how to use the appliance safely and have understood the associated hazards.

Children must not play with, on, or around the appliance. Children must not clean the appliance or carry out general maintenance unless they are at least 15 years old and are being supervised.

Keep children below the age of 8 years old at a safe distance from the appliance and power cable.

If you wear an active implantable medical device (e.g. a pacemaker or defibrillator), check with your doctor that it complies with Council Directive 90/385/EEC of 20th June 1990, DIN EN 45502-2-1 and DIN EN 45502-2-2, and that it has been chosen, implanted and programmed in accordance with VDE-AR-E 2750-10. If these conditions are satisfied, and if, in addition, non-metal cooking utensils and cookware with non-metal handles are used, it is safe to use this induction hob as intended.

Important safety information

Warning – Risk of fire!

- Hot oil and fat can ignite very quickly. Never leave hot fat or oil unattended. Never use water to put out burning oil or fat. Switch off the hotplate. Extinguish flames carefully using a lid, fire blanket or something similar.
- The hotplates become very hot. Never place combustible items on the hob. Never place objects on the hob.
- The appliance gets hot. Do not keep combustible objects or aerosol cans in drawers directly underneath the hob.
- The hob switches off automatically and can no longer be operated. It may switch on unintentionally at a later point. Switch off the circuit breaker in the fuse box. Contact the after-sales service.
- Do not use hob covers here. They can cause accidents, for example due to overheating, catching fire or materials shattering.

Warning – Risk of burns!

- The hotplates and surrounding area (particularly the hob surround, if fitted) become very hot. Never touch the hot surfaces. Keep children at a safe distance.
- The hotplate heats up but the display does not work. Switch off the circuit breaker in the fuse box. Contact the after-sales service.
- Metal objects on the hob quickly become very hot. Never place metal objects (such as knives, forks, spoons and lids) on the hob.
- After each use, always turn off the hob at the main switch. Do not wait until the hob turns off automatically after the pan is removed.

Warning – Risk of electric shock!

- Incorrect repairs are dangerous. Repairs may only be carried out and damaged power cables replaced by one of our trained after-sales technicians. If the appliance is defective, unplug the appliance from the mains or switch off the circuit breaker in the fuse box. Contact the after-sales service.
- Do not use any high-pressure cleaners or steam cleaners, which can result in an electric shock.
- A defective appliance may cause electric shock. Never switch on a defective appliance. Unplug the appliance from the mains or switch off the circuit breaker in the fuse box. Contact the after-sales service.
- Cracks or fractures in the glass ceramic may cause electric shocks. Switch off the circuit breaker in the fuse box. Contact the after-sales service.

Warning – Risk of fault!

A fan is located on the underside of this hob. If a drawer is located on the underside of the hob, do not store any small or sharp objects, paper or tea towels in it. These may be sucked in and damage the fan or impair the cooling. There must be a clearance of at least 2 cm between the contents of the drawer and the fan entry point.

Warning – Risk of injury!

- When cooking in a bain marie, the hob and cooking container could shatter due to overheating. The cooking container in the bain marie must not directly touch the bottom of the water-filled pot. Only use heat-resistant cookware.
- Saucepans may suddenly jump due to liquid between the pan base and the hotplate. Always keep the hotplate and saucepan bases dry.

Causes of damage

Caution!

- Rough pan bases may scratch the hob.
- Avoid leaving empty pots and pans on the hotplate. Doing so may cause damage.
- Do not place hot pans on the control panel, the indicator area, or the hob frame. Doing so may cause damage.
- Hard or pointed objects dropped on the hob may damage it.
- Aluminium foil and plastic containers will melt if placed on the hotplate while it is hot. The use of laminated sheeting is not recommended on the hob.

Overview

You will find the most frequently caused damage in the following table:

| Damage | Cause | Measure |
|----------------|--|--|
| Stains | Boiled over food. | Remove boiled over food immediately with a glass scraper. |
| | Unsuitable cleaning agent. | Only use cleaning agents that are suitable for this type of hob. |
| Scratches | Salt, sugar and sand. | Do not use the hob as a work surface or storage space. |
| | Cookware with rough bases scratch the hob. | Check the cookware. |
| Discolouration | Unsuitable cleaning agent. | Only use cleaning agents that are suitable for this type of hob. |
| | Pan abrasion. | Lift pots and pans when moving them. |
| Chips | Sugar, food with a high sugar content. | Remove boiled over food immediately with a glass scraper. |

Environmental protection

In this section, you can find information about saving energy and disposing of the appliance.

Energy-saving advice

- Always use the correct lid for each pan. Cooking without a lid uses a lot more energy. Use a glass lid to provide visibility and avoid having to lift the lid.
- Use pans with flat bases. Bases that are not flat use a lot more energy.
- The diameter of the pan base must match the size of the hotplate. Please note: pan manufacturers usually provide the diameter for the top of the pan, which is usually larger than the diameter of the pan base.
- Use a small pan for small amounts of food. A large pan which is not full uses a lot of energy.
- Use little water when cooking. This saves energy and preserves all the vitamins and minerals in vegetables.
- Select the lowest power level to maintain cooking. If the power level is too high, energy is wasted.

Environmentally-friendly disposal

Dispose of packaging in an environmentally-friendly manner.



This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE). The guideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.

Induction cooking

Advantages of induction cooking

Induction cooking is very different from traditional cooking methods, as heat builds up directly in the item of cookware. This offers numerous advantages:

- Saves time when boiling and frying.
- Saves energy.
- Easier to care for and clean. Spilled food does not burn on as quickly.
- Heat control and safety – the hob increases or decreases the heat supply as soon as the user changes the setting. The induction hotplate stops the heat supply as soon as the cookware is removed from the hotplate, without having to switch it off first.


Cookware

Only use ferromagnetic cookware for induction cooking, such as:

- Cookware made from enamelled steel
- Cookware made from cast iron
- Special induction-compatible cookware made from stainless steel.


To check whether your cookware is suitable for induction cooking, refer to the section on → "Cookware check".

To achieve a good cooking result, the ferromagnetic area on the base of the pan should match the size of the hotplate. If a hotplate does not detect an item of cookware, try placing it on another hotplate with a smaller diameter.



Some induction cookware does not have a fully ferromagnetic base:

- If the base of the cookware is only partially ferromagnetic, only the area that is ferromagnetic will heat up. This may mean that heat will not be distributed evenly. The non-ferromagnetic area may not heat up to a sufficient temperature for cooking.



- The ferromagnetic area will also be reduced if the material from which the base of the cookware is made contains aluminium, for example. This may mean that the cookware will not become sufficiently hot or even that it will not be detected.



Unsuitable pans


Never use diffuser hobs or pans made from:

- common thin steel
- glass
- earthenware
- copper
- aluminium

Properties of the base of the cookware

The material(s) from which the base of the cookware is made can affect the cooking result. Using pots and pans made from materials that distribute heat evenly through them, such as stainless-steel pans with a three-layer base, saves time and energy.

Use cookware with a flat base; if the base of the cookware is uneven, this may impair the heat supply.



Absence of pan or unsuitable size

If no pan is placed on the selected hotplate, or if it is made of unsuitable material or is not the correct size, the power level displayed on the hotplate indicator will flash. Place a suitable pan on the hotplate to stop the flashing. If this takes more than 90 seconds, the hotplate will switch off automatically.

Empty pans or those with a thin base

Do not heat empty pans, nor use pans with a thin base. The hob is equipped with an internal safety system. However, an empty pan may heat up so quickly that the "automatic switch off" function may not have time to react and the pan may reach very high temperatures. The base of the pan could melt and damage the glass on the hob. In this case, do not touch the pan and switch the hotplate off. If it fails to work after it has cooled down, please contact the Technical Assistance Service.

Pan detection

Each hotplate has a lower limit for pan detection. This depends on the diameter of the ferromagnetic area of the cookware and the material from which its base is made. For this reason, you should always use the hotplate that best matches the diameter of the base of the pan.

Automatic detection in two-ring and three-ring hotplates


These hotplates can detect cookware of different sizes. Depending on the material and the properties of the cookware, the hotplate automatically activates the one-, two- or three-ring hotplate in order for the correct heat output to be supplied to achieve good cooking results.










Getting to know your appliance













You can find information on the dimensions and power of the hotplates in → *Page 2*

Note: . Depending on the appliance model, individual details and colours may differ.

The control panel



| Controls | |
|--|--|
|  | Main switch |
|  | Selecting a hotplate |
|  | Settings area |
|  | PowerBoost and ShortBoost function |
|  | Locking the control panel for cleaning and childproof lock |
|  | Keep warm function |
|  | Frying sensor |
|  | Programming the cooking time and kitchen timer |
|  | Stopwatch function |

| Indicators | |
|---|------------------------------|
|  | Operating status |
|  | Heat settings |
|  | Residual heat |
|  | PowerBoost function |
|  | ShortBoost function |
|  | Keep warm function |
|  | Frying sensor |
|  | Childproof lock |
|  | Timer function |
|  | Programming the cooking time |
|  | Kitchen timer |
|  | Timer displays |

Controls

When the hob heats up, the symbols for the controls available at this time light up.

Touching a symbol activates the respective function.

Notes

- The corresponding symbols for the controls light up depending on whether they are available. The displays for the hotplates or the selected functions get brighter.
- Always keep the control panel clean and dry. Moisture can prevent it from working properly.
- Do not place any cookware near the indicators or sensors. The electronics could overheat.

The hotplates

| Hotplates | | |
|-----------|----------------------|---|
| ○ | Simple hotplate | Use cookware that is a suitable size |
| ◎ | Tri-circuit hotplate | The hotplate switches on automatically when you use cookware with a base that covers the outer edge of the zone (◎ or ◎). |

Only use cookware that is suitable for induction cooking; see section → "Induction cooking"

Residual heat indicator

The hob has a residual heat indicator for each hotplate. This indicates that a hotplate is still hot. Do not touch a hotplate while the residual heat indicator is lit up.

The following indicators are shown depending on the amount of residual heat:

- Display **H**: High temperature
- Display **h**: Low temperature

If you remove the cookware from the hotplate during cooking, the residual heat indicator and the selected heat setting will flash alternately.


When the hotplate is switched off, the residual heat indicator will light up. Even after the hob has been switched off, the residual heat indicator will stay lit for as long as the hotplate is still warm.


Operating the appliance

This chapter explains how to set a hotplate. The table shows heat settings and cooking times for various meals.

Switching the hob on and off

Switch the hob on and off using the main switch.

To switch on: Touch the  symbol. An audible signal sounds. The symbols for the hotplates and the functions available at this time light up. The hob is ready to use.

To switch off: Touch the  symbol until the indicators go out. The residual heat indicator remains lit until the hotplates have cooled down sufficiently.

Notes


- The hob switches off automatically if all hotplates have been switched off for more than 20 seconds.
- The selected settings are stored for four seconds after the hob has been switched off. If you switch it on again during this time, the hob will operate using the previously stored settings.

Setting a hotplate

Set the desired heat setting in the settings area.

Heat setting 1 = lowest setting.

Heat setting 9 = highest setting.

Every heat setting has an intermediate setting. This is marked with .



Note: The left-hand hotplates are set in the settings area on the left and the right-hand and central hotplates are set in the settings area on the right.


Notes

- To protect the fragile parts of your appliance from overheating and electrical overloading, the hob may temporarily reduce the power.
- In order to prevent the appliance from producing excess noise, the hob may temporarily reduce the power.

Selecting a hotplate and heat setting

The hob must be switched on.

1. Touch the  symbol for the required hotplate. The  indicator gets brighter.
2. Swipe your finger over the relative settings area until the required heat setting lights up.




The heat setting is set.

Changing the power level

Select the hotplate and set the desired power level in the programming zone.

Switch off the hotplate

Select the hotplate and set it to  in the programming panel. The hotplate turns off and the residual heat indicator appears.

Notes

- If no pan has been placed on the hotplate, the selected power level flashes. After a certain time has elapsed, the hotplate switches off.
- If a pan has been placed on the hotplate before switching on the hob, it will be detected within 20 seconds of pressing the main switch and the hotplate will be selected automatically. Once detected, select the power level within the next 20 seconds or the hotplate will switch off.

Chef's recommendations

Recommendations

- When heating up puree, cream soups and thick sauces, stir occasionally.
- Set heat setting 8 to 9 for preheating.
- When cooking with the lid on, turn the heat setting down as soon as steam escapes between the lid and the cookware. Steam does not need to escape for a good cooking result.
- After cooking, keep the lid on the cookware until you serve the food.
- To cook with the pressure cooker, observe the manufacturer's instructions.
- Do not cook food for too long, otherwise the nutrients will be lost. The kitchen clock can be used to set the optimum cooking time.
- For a more healthy cooking result, smoking oil should be avoided.
- To brown food, fry small portions in succession.
- Cookware may reach high temperatures while the food is cooking. We recommend that you use oven gloves.
- You can find recommendations for energy-efficient cooking in section → "Environmental protection"

Cooking table

The table shows which heat setting is suitable for each type of food. The cooking time may vary depending on the type, weight, thickness and quality of the food.

| | Heat setting | Cooking time (mins) |
|---|--------------|---------------------|
| Melting | | |
| Chocolate coating | 1 - 1.5 | - |
| Butter, honey, gelatine | 1 - 2 | - |
| Heating and keeping warm | | |
| Stew, e.g. lentil stew | 1.5 - 2 | - |
| Milk* | 1.5 - 2.5 | - |
| Heating sausages in water* | 3 - 4 | - |
| Defrosting and heating | | |
| Spinach, frozen | 3 - 4 | 15 - 25 |
| Goulash, frozen | 3 - 4 | 35 - 55 |
| Poaching, simmering | | |
| Potato dumplings* | 4.5 - 5.5 | 20 - 30 |
| Fish* | 4 - 5 | 10 - 15 |
| White sauces, e.g. Béchamel sauce | 1 - 2 | 3 - 6 |
| Whisked sauces, e.g. sauce béarnaise, hollandaise | 3 - 4 | 8 - 12 |
| Boiling, steaming, braising | | |
| Rice (with double the volume of water) | 2.5 - 3.5 | 15 - 30 |
| Rice pudding*** | 2 - 3 | 30 - 40 |
| Unpeeled boiled potatoes | 4.5 - 5.5 | 25 - 35 |
| Boiled potatoes | 4.5 - 5.5 | 15 - 30 |
| Pasta, noodles* | 6 - 7 | 6 - 10 |
| Stew | 3.5 - 4.5 | 120 - 180 |
| Soups | 3.5 - 4.5 | 15 - 60 |
| Vegetables | 2.5 - 3.5 | 10 - 20 |
| Vegetables, frozen | 3.5 - 4.5 | 7 - 20 |
| Cooking in a pressure cooker | 4.5 - 5.5 | - |
| Braising | | |
| Roulades | 4 - 5 | 50 - 65 |
| Pot roast | 4 - 5 | 60 - 100 |
| Goulash*** | 3 - 4 | 50 - 60 |

* Without lid

** Turn several times

*** Preheat to heat setting 8 - 8.5

| | Heat setting | Cooking time (mins) |
|--|--------------|---------------------|
| Roasting/frying with little oil* | | |
| Escalope, plain or breaded | 6-7 | 6-10 |
| Escalope, frozen | 6-7 | 6-12 |
| Chop, plain or breaded** | 6-7 | 8-12 |
| Steak (3 cm thick) | 7-8 | 8-12 |
| Poultry breast (2 cm thick)** | 5-6 | 10-20 |
| Poultry breast, frozen** | 5-6 | 10-30 |
| Rissoles (3 cm thick)** | 4.5-5.5 | 20-30 |
| Hamburgers (2 cm thick)** | 6-7 | 10-20 |
| Fish and fish fillet, plain | 5-6 | 8-20 |
| Fish and fish fillet, breaded | 6-7 | 8-20 |
| Fish, breaded and frozen, e.g. fish fingers | 6-7 | 8-15 |
| Scampi, prawns | 7-8 | 4-10 |
| Sautéing fresh vegetables and mushrooms | 7-8 | 10-20 |
| Stir-fry, vegetables, meat cut in Asian-style strips | 7-8 | 15-20 |
| Stir fry, frozen | 6-7 | 6-10 |
| Pancakes (baked in succession) | 6.5-7.5 | - |
| Omelette (cooked in succession) | 3.5-4.5 | 3-10 |
| Fried eggs | 5-6 | 3-6 |
| Deep-fat frying* (150-200 g per portion in 1-2 l oil, deep-fat fried in portions) | | |
| Frozen products, e.g. chips, chicken nuggets | 8-9 | - |
| Croquettes, frozen | 7-8 | - |
| Meat, e.g. chicken portions | 6-7 | - |
| Fish, breaded or in beer batter | 6-7 | - |
| Vegetables, mushrooms, breaded or battered, tempura | 6-7 | - |
| Small baked items, e.g. doughnuts, fruit in batter | 4-5 | - |
| * Without lid | | |
| ** Turn several times | | |
| *** Preheat to heat setting 8 - 8.5 | | |

Time-setting options





Your hob has three timer functions:


- Programming the cooking time
- Kitchen timer
- Stopwatch function


Programming the cooking time


The hotplate automatically switches off after the time that is set has elapsed.

Setting procedure:

1. Touch the  symbol twice.  and the  indicator light up in the timer display.
2. Select the hotplate. The  indicator lights up.
3. Within the next 10 seconds, set the required cooking time in the settings range.



4. Touch the  symbol to confirm the selected setting.
5. Select the required heat setting.



The cooking time begins to elapse.


Note: The same cooking time can be set automatically for all hotplates. The set time for each of the hotplates counts down independently.


You can find information on automatically programming the cooking time in section → "Basic settings"

Frying sensor

If a cooking time has been programmed for a hotplate and the frying sensor has been activated, the cooking time will not begin to count down until the selected temperature setting has been reached.



Changing or deleting the time



Touch the  symbol twice and then select the hotplate.


Change the cooking time in the settings area or set  to delete the programmed cooking time.

Touch the  symbol to confirm the selected setting.


When the time has elapsed

The hotplate switches itself off, the  indicator flashes and the hotplate displays . An audible signal sounds.

 and the  indicator flash in the timer display.

When the  symbol is touched, the indicators go out and the acoustic signal ceases.

Notes





- If a cooking time has been programmed for several hotplates, the shortest cooking time appears in the timer display.
- To query a hotplate's remaining cooking time, touch the  symbol twice and select the hotplate.
- You can set a cooking time of up to **99** minutes.

The kitchen timer

You can use the kitchen timer to set a time of up to 99 minutes.


This functions independently from the hotplates and from other settings. This function does not automatically switch off a hotplate.

Setting procedure

1. Touch the  symbol.  and the  indicator light up in the timer display.
2. Select the required time in the settings area and confirm this setting by touching the  symbol. After a few seconds, the time begins to elapse.



Changing or deleting the time

Touch the  symbol.

Change the cooking time in the settings area or set  to delete the programmed cooking time.

Touch the  symbol to confirm the selected setting.

When the time has elapsed

An audible signal sounds once the time has elapsed.  and the  symbol flash in the timer display.



The indicators go out after touching the  symbol.

Stopwatch function

The stopwatch function displays the time that has elapsed since activation.

This functions independently from the hotplates and from other settings. This function does not automatically switch off a hotplate.

Activating

Touch the  symbol.  light up in the timer display. The cooking time begins to elapse.


Deactivating

Touch the  symbol.  appear in the timer display and then go out.


The function is deactivated.

Note: This function must be selected in order to deactivate the stopwatch.

PowerBoost function

The PowerBoost function enables you to heat up large quantities of water faster than when using heat setting .


This function can always be activated for a hotplate, provided the other hotplate in the same group is not in use (see illustration).



Activating

1. Select a hotplate.
2. Touch the **b** symbol.
The **b** indicator lights up.
The function has now been activated.

Deactivating

1. Select a hotplate.
2. Touch the **b** symbol.
The **b** indicator goes out and the hotplate switches back to the  heat setting.
The function is deactivated.


Note: In certain circumstances, the PowerBoost function can switch itself off automatically in order to protect the electronic elements inside the hob.

ShortBoost function

The ShortBoost function enables you to heat cookware faster than when using heat setting **5**.

After deactivating the function, select the appropriate heat setting for your food.

This function can always be activated for a hotplate, provided the other hotplate in the same group is not in use (see illustration).



Recommendations for use

- Always use cookware that has not been pre-heated.
- Use pots and pans with a flat base. Do not use cookware with a thin base.
- Never leave empty cookware, oil, butter or lard to heat up unattended.
- Do not place a lid on the cookware.
- Place the cookware on the centre of the hotplate. Ensure that the diameter of the base of the cookware corresponds to the size of the hotplate.
- You can find information on the type, size and positioning of the cookware in section → "Induction cooking"

Activating

1. Select a hotplate.
2. Touch the **b** symbol twice.
The **b** indicator lights up.
The function has now been activated.

Deactivating



1. Select a hotplate.
2. Touch the **b** symbol.
The **b** indicator goes out and the hotplate switches back to the **5** heat setting.
The function is deactivated.

Note: After 30 seconds, this function will automatically switch off.



Keep warm function

This function is suitable for melting chocolate or butter and for keeping food warm.

Activating

1. Touch the  symbol.
2. Select the required hotplate within the next 10 seconds.
The  indicator lights up.
The function has now been activated.

Deactivating

1. Touch the  symbol.
2. Select a hotplate.
The  indicator goes out. The hotplate switches itself off and the residual heat indicator lights up.
The function is deactivated.

Frying Sensor

This function can be used to fry food while maintaining the suitable frying pan temperature.

The cooking zones that have this function are identified by the roasting function symbol.

Advantages when frying

- The hotplate only heats up if this is required to maintain the temperature. This saves energy and prevents the oil or fat from overheating.
- The frying function reports when the empty frying pan has reached the optimum temperature for adding oil and then for adding the food.

Notes

- Do not place a lid on the pan. Otherwise, the function does not activate correctly. You can use a splash guard to prevent splashes of grease.
- Use suitable oil or fat for frying. If butter, margarine, extra virgin olive oil or lard is used, set heat setting 1 or 2.
- Never leave a frying pan, with or without food, unattended when it is being heated.
- If the hotplate is a higher temperature than the cookware or vice versa, the frying sensor will not be activated correctly.

Frying pans for the frying sensor

Frying pans specifically suited for use with the frying sensor are available. These optional accessories can be purchased from specialist retailers or through our technical after-sales service. Quote the relevant reference number:

- HZ390210 15 cm frying pan.
- HZ390220 19 cm frying pan.
- HZ390230 21 cm frying pan.
- HZ390250 28 cm frying pan.

These frying pans have a non-stick coating so that you can fry food with only a small amount of oil.

Notes

- The roasting function was set especially for this type of frying pan.
- Other frying pans may overheat. The temperature can be set higher or lower. Try the lowest heat setting first and then change this according to your requirements.
- Ensure that the diameter of the base of the frying pan corresponds to the size of the hotplate. Put the pan in the centre of the hotplate.

Temperature settings

| Temperature level | Suitable for |
|-------------------|---|
| 1 very low | Preparing and reducing sauces, stewing vegetables and frying food in extra virgin olive oil, butter or margarine. |
| 2 low | Frying food in extra virgin olive oil, butter or margarine, e.g. omelettes. |
| 3 medium - low | Frying fish and thick food such as meatballs and sausages. |
| 4 medium - high | Frying steaks (well done), breaded frozen products, and thin food such as schnitzel, strips of meat and vegetables. |
| 5 high | Frying food at high temperatures, e.g. rare steaks (rare or medium), potato fritters and fried potatoes. |

Table

The table shows which heat setting is suitable for each type of food. The roasting time may vary depending on the type, weight, size and quality of the food.

The set heat setting varies depending on the frying pan that is used.

Preheat the empty pan; add oil and food after the acoustic signal has sounded.

| | Temperature setting | Total frying time after the signal tone sounds (min) |
|--|---------------------|--|
| Meat | | |
| Escalope, plain ¹ | 4 | 6 - 10 |
| Escalope, breaded ¹ | 4 | 6 - 10 |
| Fillet ² | 4 | 6 - 10 |
| Chops ¹ | 3 | 10 - 15 |
| Cordon bleu ¹ | 4 | 10 - 15 |
| Viennese schnitzel ¹ | 4 | 10 - 15 |
| Steak, rare (3 cm thick) ² | 5 | 6 - 8 |
| Steak, medium (3 cm thick) ² | 5 | 8 - 12 |
| Steak, well done (3 cm thick) ¹ | 4 | 8 - 12 |
| Poultry breast (2 cm thick) ¹ | 3 | 10 - 20 |
| Stripes of meat ³ | 4 | 7 - 12 |
| Gyros ³ | 4 | 7 - 12 |
| Bacon ¹ | 2 | 5 - 8 |
| Minced meat ³ | 4 | 6 - 10 |
| Hamburgers (1,5 cm thick) ¹ | 3 | 6 - 15 |
| Meatballs (2 cm thick) ¹ | 3 | 10 - 20 |
| Rissoles ¹ | 3 | 10 - 20 |
| Pre-boiled sausages ¹ | 3 | 8 - 20 |
| Raw sausages ¹ | 3 | 8 - 20 |

¹ Turn frequently.

² Add the oil and the food after the signal tone.

³ Stir frequently.

⁴ Add the butter and the food after the signal tone.

⁵ Time indicated per portion. Fry individually.

⁶ Add water after the signal tone. Add the food when the water boils.

⁷ Add the food after the signal tone.

| | Temperature setting | Total frying time after the signal tone sounds (min) |
|--|---------------------|--|
| Fish | | |
| Fish fillet, plain ¹ | 4 | 10 - 20 |
| Fish fillet, breaded ¹ | 3 | 10 - 20 |
| Prawns ¹ | 4 | 4 - 8 |
| Scampi ¹ | 4 | 4 - 8 |
| Frying fish, whole ¹ | 3 | 10 - 20 |
| Egg dishes | | |
| Fried eggs in butter ⁴ | 2 | 2 - 6 |
| Fried eggs in oil ² | 4 | 2 - 6 |
| Scrambled eggs ³ | 2 | 4 - 9 |
| Omelettes ⁵ | 2 | 3 - 6 |
| Pancakes ⁵ | 5 | 1,5 - 2,5 |
| French toast ⁵ | 3 | 4 - 8 |
| Shredded raisin pancake ⁵ | 3 | 10 - 15 |
| Vegetables and legumes | | |
| Garlic ³ | 2 | 2 - 10 |
| Glazed onion ³ | 2 | 2 - 10 |
| Onion rings ³ | 3 | 5 - 10 |
| Courgette ¹ | 3 | 4 - 12 |
| Aubergine ¹ | 3 | 4 - 12 |
| Pepper ¹ | 3 | 4 - 15 |
| Green asparagus ¹ | 3 | 4 - 15 |
| Mushrooms ³ | 4 | 10 - 15 |
| Sautéing vegetables in oil ³ | 1 | 10 - 20 |
| Glazed vegetables ³ | 3 | 6 - 10 |
| Potatoes | | |
| Potatoes boiled in their skin ³ | 5 | 6 - 12 |
| Fried potatoes made from raw potatoes ³ | 4 | 15 - 25 |
| Potato pancakes ⁵ | 5 | 2,5 - 3,5 |
| Swiss rösti ⁴ | 2 | 50 - 55 |
| Glazed potatoes ³ | 3 | 10 - 15 |

¹ Turn frequently.

² Add the oil and the food after the signal tone.

³ Stir frequently.

⁴ Add the butter and the food after the signal tone.

⁵ Time indicated per portion. Fry individually.

⁶ Add water after the signal tone. Add the food when the water boils.

⁷ Add the food after the signal tone.

| | Temperature setting | Total frying time after the signal tone sounds (min) |
|---|---------------------|--|
| Sauces | | |
| Tomato sauce with vegetables ³ | 1 | 25 - 35 |
| Béchamel sauce ³ | 1 | 10 - 20 |
| Cheese sauce ³ | 1 | 10 - 20 |
| Reducing sauces ³ | 1 | 25 - 35 |
| Sweet sauces ³ | 1 | 15 - 25 |
| Frozen products | | |
| Escalope ¹ | 4 | 15 - 20 |
| Cordon bleu ¹ | 4 | 10 - 30 |
| Poultry breast ¹ | 4 | 10 - 30 |
| Chicken nuggets ¹ | 4 | 10 - 15 |
| Gyros ³ | 4 | 10 - 15 |
| Kebab ³ | 4 | 10 - 15 |
| Fish fillet, plain ¹ | 3 | 10 - 20 |
| Fish fillet, breaded ¹ | 3 | 10 - 20 |
| Fish fingers ¹ | 4 | 8 - 12 |
| French fries ³ | 5 | 4 - 6 |
| Stir-fries ³ | 3 | 6 - 10 |
| Spring rolls ¹ | 4 | 10 - 30 |
| Camembert ¹ | 3 | 10 - 15 |
| Miscellaneous | | |
| Camembert ¹ | 3 | 7 - 10 |
| Croûtons ³ | 3 | 6 - 10 |
| Dried ready meals ⁶ | 1 | 5 - 10 |
| Toasting almonds ⁷ | 4 | 3 - 15 |
| Toasting nuts ⁷ | 4 | 3 - 15 |
| Toasting pine nuts ⁷ | 4 | 3 - 15 |

¹ Turn frequently.

² Add the oil and the food after the signal tone.

³ Stir frequently.

⁴ Add the butter and the food after the signal tone.



⁵ Time indicated per portion. Fry individually.


⁶ Add water after the signal tone. Add the food when the water boils.

⁷ Add the food after the signal tone.


Setting procedure

Select the appropriate temperature level from the table. Set an empty item of cookware down on the cooking zone.


1. Touch the  symbol.
2. Select the hotplate. The  indicator lights up in the hotplate display.



3. Within the next 10 seconds, select the required temperature setting from the settings range.




The function has now been activated.

The  temperature symbol flashes until the frying temperature is reached. A signal sounds and the temperature symbol stops flashing.

4. Once the frying temperature has been reached, add the fat and then the food to the pan.

Note: Turn the food so that it does not burn.

Switching off the frying sensor

Touch the  symbol and select the hotplate. The hotplate switches itself off and the residual heat indicator lights up.


Childproof lock

You can use the childproof lock to prevent children from switching on the hob.

Activating and deactivating the childproof lock

The hob must be off.


To activate:

1. Switch on the hob using the main switch.
2. Touch and hold the  symbol for approx. 4 seconds.

The  indicator lights up for 10 seconds.

The hob is locked.

To deactivate:

1. Switch on the hob using the main switch.
2. Touch and hold the  symbol for approx. 4 seconds.

The lock is released.

Childproof lock

With this function, the childproof lock automatically activates when a hob is switched off.


Switching on and off


You can find out how to switch the automatic childproof lock on in the → *"Basic settings"* section



Wipe protection

If you wipe over the control panel while the hob is switched on, settings may be altered. To avoid doing this, you can use the hob's "Lock control panel for cleaning" function.

To activate: Touch the  symbol. An audible signal sounds. The control panel is locked for 35 seconds. You can now wipe over the surface of the control panel without altering any settings.

To deactivate: The control panel will be unlocked once 35 seconds have elapsed. To release the function early, touch the  symbol.

Notes

- An audible signal sounds 30 seconds after activation. This indicates that the function is about to finish.
- The cleaning lock does not lock the main switch. The hob can be switched off at any time.



Automatic safety cut-out

If a hotplate operates for an extended period and no settings are changed, the automatic safety shut-off is activated.

The hotplate stops heating. **F**, **B** and the residual heat indicator **h** or **H** flash alternately in the hotplate display.

When you touch any symbol, the display switches off. The hotplate can now be set again.

The point at which the safety shut-off becomes active depends on which heat setting has been set (after 1 to 10 hours).

Basic settings

The appliance has various basic settings. These basic settings can be altered to suit your individual requirements.


| Indicator/ symbol | Function |
|----------------------|--|
| <i>c 1</i> | Childproof lock <i>0</i> Manual*. <i>1</i> Automatic. <i>2</i> Function deactivated. |
| <i>c 2</i> | Signal tones <i>0</i> Confirmation and fault signals are switched off. <i>1</i> Only the fault signal is switched on. <i>2</i> Only the confirmation signal is switched on. <i>3</i> All signal tones are switched on.* |
| <i>c 3</i> | Display energy consumption <i>0</i> Deactivated.* <i>1</i> Activated. |
| <i>c 5</i> | Automatically programming the cooking time <i>00</i> Switched off.* <i>0 1-99</i> Time until automatic switch-off. |
| <i>c 6</i> | Audible signal duration for the timer function <i>1</i> 10 seconds.* <i>2</i> 30 seconds. <i>3</i> 1 minute. |
| <i>c 7</i> | Power management function. Limiting the total power of the hob The available settings depend on the maximum power of the hob. <i>0</i> Deactivated. Maximum power of the hob.*/** <i>1</i> 1000 W minimum power. <i>1.5</i> 1500 W ... <i>3</i> 3000 W recommended for 13 A. <i>3.5</i> 3500 W recommended for 16 A. <i>4</i> 4000 W <i>4.5</i> 4500 W recommended for 20 A. ... <i>9</i> or <i>9.5</i> Maximum power of the hob.** |
| <i>c 12</i> | Check the cookware and the cooking results <i>0</i> Not suitable <i>1</i> Not perfect <i>2</i> Suitable |
| <i>c 0</i> | Restore to standard settings <i>0</i> Individual settings.* <i>1</i> Restore factory settings. |

*Factory setting




**The hob's maximum power output is shown on the rating plate.

To access the basic settings:


The hob must be off.


1. Switch on the hob.
2. Within ten seconds, touch and hold the  symbol for approximately four seconds. The first four displays provide product information. Touch the settings area to view the individual displays.


| Product information | Display screen |
|----------------------------------|----------------|
| After-sales service index (ASSI) | 01 |
| Production number | Fd |
| Production number 1 | 95. |
| Production number 2 | 05 |

3. Touching the  symbol again takes you to the basic settings.  and  light up as a presetting in the displays.



4. Touch the  symbol repeatedly until the required function is displayed.
5. Then select the required setting from the settings area.



6. Touch the  symbol for at least four seconds.

The settings have been saved.

Leaving the basic settings

Turn off the hob with the main switch.

Energy consumption indicator

This function indicates the total amount of energy consumed by this hob the last time it was used for cooking.

Once the hob is switched off, the energy consumption is displayed in kilowatt hours (e.g. **1.08** kWh) for 10 seconds.

The accuracy of the information displayed depends on the voltage quality of the mains power supply, among other factors.

You can find out how to switch this function on in the section on → "Basic settings"

Cookware check


This function can be used to check the speed and quality of the cooking process depending on the cookware.

The result is a reference value and depends on the properties of the cookware and the hotplate being used.




1. Correctly position the pot with approximately 200 ml of water, at room temperature, on the most suitable cooking zone for the diameter of the bottom of the pot.
2. Go to the basic settings and select the setting **c 12**.
3. Press the programming area. **—** flashes in the cooking zone displays.

The function has now been activated.

After 10 seconds, the cooking result and the speed of the cooking process appear in the visual displays for the cooking zone.



Check the result using the following table:

| Result | |
|--|--|
|  | The cookware is not suitable for the hotplate and will therefore not heat up.* |
|  | The cookware is taking longer to heat up than expected and the cooking process is not going as well as it should.* |
|  | The cookware is heating up correctly and the cooking process is going well. |
| * If there is a smaller hotplate available, test the cookware again on the smaller hotplate. | |

To reactivate this function, touch the settings range.

Notes

- If the diameter of the hotplate used is much smaller than the diameter of the cookware, only the middle of the cookware can be expected to heat up. This may result in the cooking results not being as good as expected or being less than satisfactory.
- You can find information on this function in the section on → *"Basic settings"*.
- You can find information on the type, size and positioning of the cookware in the section on → *"Induction cooking"*.

Power manager

You can use the power manager to set the total power of the hob.

The hob is preset at the factory. Its maximum performance is specified on the rating plate. You can use the power manager to change the value in accordance with the requirements for the relevant electrical installation.

In order not to exceed this set value, the hob automatically distributes the power available between the cooking zones that are switched on.

As long as the power manager function is activated, the output of a cooking zone may temporarily fall below the nominal value. If a cooking zone is switched on and the power limit is reached, **_** appears in the heat setting display for a short time. The appliance automatically regulates and selects the highest possible power level.

For more information about how the total power of the hob is changed, see section → *"Basic settings"*

Cleaning

Suitable maintenance and cleaning products can be purchased from the after-sales service or in our e-Shop.

Hob

Cleaning

Always clean the hob after cooking. This will prevent food deposits from becoming burned on. Only clean the hob after the residual heat indicator has gone out.

Clean the hob with a damp dish cloth and dry it with a cloth or towel to prevent limescale build-up.

Only use cleaning agents that are suitable for this type of hob. Observe the manufacturer's instructions on the product packaging.

Never use:

- Undiluted washing-up liquid
- Cleaning agents designed for dishwashers
- Abrasive cleaners
- Harsh cleaning agents, such as oven spray and limescale remover
- Scouring pads
- High-pressure cleaners or steam jet cleaners

Stubborn dirt is best removed with a glass scraper, available from retailers. Observe the manufacturer's instructions.

You can obtain a suitable glass scraper from customer services or through our online shop.

Using a special sponge for cleaning glass-ceramic hobs achieves a great cleaning result.

| Potential marks | |
|--|---|
| Limescale and water marks | Clean the hob as soon as it has cooled down. You can use a cleaning agent suitable for glass-ceramic hobs.* |
| Sugar, rice starch or plastic | Clean immediately. Use a glass scraper. Caution: Risk of burns.* |
| * Then clean with a damp dish cloth and dry with a cloth or towel. | |

Note: Do not use any cleaning agents while the hob is still hot. This may mark the surface. Make sure that any residue left by cleaning agents is removed.

Hob surround

To prevent damage to the hob surround, observe the following instructions:

- Only use warm soapy water
- Wash new dish cloths thoroughly before use.
- Do not use harsh or abrasive cleaning agents.
- Do not use a glass scraper or sharp objects.

Frequently Asked Questions (FAQ)

Use

Why can't I switch on the hob and why is the childproof lock symbol lit?

The childproof lock is now active.
You can find information about this function in section → *"Childproof lock"*

Why are the indicators flashing and why can I hear a signal tone?

Remove any liquid or remnants of food from the control panel. Remove any objects from the control panel.
You can find instructions on how to deactivate the audible signal in the section on → *"Basic settings"*

Why can the frying sensor not be activated?

The appliance's maximum power consumption is achieved or the power manager function has been activated. Switch off or reduce the power levels of the active hotplates.
You can find further information about this function in section → *"Power manager" on page 25*

Noises

Why I can hear noises while I'm cooking?

Noises may be generated while using the hob depending on the base material of the cookware. These noises are a normal part of induction technology. They do not indicate a defect.

Possible noises:

A low humming noise like the one a transformer makes:

Occurs when cooking at a high heat setting. The noise disappears or becomes quieter when the heat setting is reduced.

Low whistling noise:

Occurs when the cookware is empty. This noise disappears when water or food is added to the cookware.

Crackling:

Occurs when using cookware made from different layers of material or when using cookware of different sizes and different materials at the same time. The loudness of the noise can vary depending on the quantity of food being cooked or the cooking method.

High-pitched whistling noises:

Can occur when two hotplates are used at the highest heat setting at the same time. The whistling noises disappear or become quieter when the heat setting is reduced.

Fan noise:

The hob is equipped with a fan that switches on automatically at high temperatures. The fan may continue to run even after you have switched off the hob if the temperature detected is still too high.

Cookware

Which types of cookware can be used with an induction hob?

You can find information on which types of cookware can be used with an induction hob in the section on → *"Induction cooking"*

Why is the hotplate not heating up and why is the heat setting flashing?

The hotplate on which the cookware is standing is not switched on.
Check that you have switched on the correct hotplate.

The cookware is too small for the hotplate that is switched on or it is not suitable for induction cooking.
You can find information on the type, size and positioning of the cookware in the section on → *"Induction cooking"*

Cookware

Why is it taking so long for the cookware to heat up or why is it not heating up sufficiently despite being on a high heat setting?

The cookware is too small for the hotplate that is switched on or it is not suitable for induction cooking.

You can find information on the type, size and positioning of the cookware in the section on → *"Induction cooking"*

How do you switch on two-ring and three-ring hotplates?

These hotplates can detect cookware of different sizes. Depending on the material and the properties of the cookware, the hotplate automatically activates the one-, two- or three-ring hotplate in order for the appropriate heat output to be supplied to achieve good cooking results.

Cookware that corresponds to the size of the hotplate as closely as possible and has a fully ferromagnetic base is most suitable. You can find information on which types of cookware can be used with an induction hob in the section on → *"Induction cooking"*

Cleaning

How do I clean the hob?

Using a special glass-ceramic cleaning agent produces the best results. We advise against using harsh or abrasive cleaning agents, dishwasher detergent (concentrated) or scouring pads.

You can find more information on cleaning and caring for your hob in the section on → *"Cleaning"*

Trouble shooting

Usually, faults are small matters that are easy to eliminate. Please read the information in the table before calling the after-sales service.

| Display | Possible cause | Solution |
|---|--|--|
| None | The power supply has been disconnected. The device has not been connected in accordance with the circuit diagram. Electronics fault. | Use other electrical devices to check whether a short-circuit has occurred in the power supply. Ensure that the device has been connected in accordance with the circuit diagram. If the fault cannot be eliminated, inform the technical after-sales service. |
| The displays flash | The control panel is damp or an object is covering it. | Dry the control panel or remove the object. |
| The — indicator flashes in the hotplate displays | A fault has occurred in the electronics. | To acknowledge the fault, cover the control panel with your hand. |
| F2 | The electronics have overheated and have switched off the corresponding hotplate. | Wait until the electronics have cooled down sufficiently. Then touch any symbol on the hob. |
| F4 | The electronics have overheated and have switched off all hotplates. | |
| F5 + heat setting and acoustic signal | There is a hot pan in the area of the control panel. There is a risk that the electronics will overheat. | Remove the pan. The fault display goes out shortly afterwards. You can continue to cook. |
| F5 and acoustic signal | There is a hot pan in the area of the control panel. To protect the electronics, the hotplate has been switched off. | Remove the pan. Wait for a few seconds. Touch any control. If the fault display goes out, you can continue to cook. |
| F 1/F6 | The hotplate has overheated and switched itself off to protect the work surface. | Wait until the electronics have cooled down sufficiently and switch the hotplate on again. |
| F8 | The hotplate was operating for an extended period without interruption. | The automatic safety switch-off function has been activated. See section |
| E9000 E90 10 | The supply voltage is faulty; outside of the normal operating range. | Contact your electricity provider. |
| U400 | The hob is not connected properly | Disconnect the hob from the power supply. Ensure that it has been connected in accordance with the circuit diagram. |
| dE | The demo mode is activated | Disconnect the hob from the power supply. Wait 30 seconds and reconnect it. Touch any touch control in the next three minutes. The demo mode is deactivated. |

Do not place hot pans on the control panel.

Notes

- If **E** appears on the display, press and hold the button for the relevant cooking zone in order to read the fault code.
- If the fault code is not listed in the table, disconnect the hob from the mains power supply and wait 30 seconds before reconnecting it. If this code is displayed again, contact the technical after-sales service and specify which fault code has appeared.
- If a fault occurs, the appliance will not switch to standby mode.

Customer service

Our after-sales service is there for you if your appliance needs to be repaired. We will always find an appropriate solution, also in order to avoid after-sales personnel having to make unnecessary visits.

E number and FD number

Please quote the E number (product number) and the FD number (production number) of your appliance when contacting the after-sales service.

The rating plate bearing these numbers can be found:

- On the appliance certificate.
- On the lower section of the hob.

The E-number can also be found on the glass surface of the hob. You can check the customer index (KI) and FD number by going to the basic settings. Look up section → *"Basic settings"* for this.

Please note that a visit from an after-sales service engineer is not free of charge in the event of misuse of the appliance, even during the warranty period.

Please find the contact data of all countries in the enclosed customer service list.

To book an engineer visit and product advice

GB 0344 892 8999

Calls charged at local or mobile rate.

IE 01450 2655

0.03 € per minute at peak. Off peak 0.0088 € per minute.

Rely on the professionalism of the manufacturer. You can therefore be sure that the repair is carried out by trained service technicians who carry original spare parts for your appliances.

Test dishes

This table has been produced for test institutes to facilitate the testing of our appliances.

The data in the table refers to our Schulte-Ufer cookware accessories (4 piece cookware set for the HZ 390042 induction hob) with the following measurements:

- Saucepan Ø 16 cm, 1.2 l for hotplates of Ø 14.5 cm
- Pot Ø 16 cm, 1.7 l for hotplates of Ø 14.5 cm
- Pot Ø 22 cm, 4.2 l for hotplates of Ø 18 cm
- Frying pan Ø 24 cm, for hotplates of Ø 18 cm

| Test dishes | Cookware | Heat setting | Preheating | | Cooking | |
|--|-----------------------------|--------------|---|-----|--------------|-----|
| | | | Cooking time (min:sec) | Lid | Heat setting | Lid |
| Melting chocolate | | | | | | |
| Chocolate coating (e.g. Dr. Oetker brand, dark chocolate 55% cocoa, 150 g) | Saucepan, 16 cm diameter | - | - | - | 1.5 | No |
| Heating and keeping lentil stew warm | | | | | | |
| Lentil stew* | | | | | | |
| Initial temperature 20 °C | | | | | | |
| Amount: 450 g | Cooking pot, 16 cm diameter | 9 | 1:30 (without stirring) | Yes | 1.5 | Yes |
| Amount: 800 g | Saucepan, 22 cm diameter | 9 | 2:30 (without stirring) | Yes | 1.5 | Yes |
| Lentil stew from a tin | | | | | | |
| E.g lentils with Erasco sausages. | | | | | | |
| Initial temperature 20 °C | | | | | | |
| Amount: 500 g | Cooking pot, 16 cm diameter | 9 | Approx. 1:30 (stir after approx. 1 minute) | Yes | 1.5 | Yes |
| Amount: 1 kg | Saucepan, 22 cm diameter | 9 | Approx. 2:30 (stir after approx. 1 minute) | Yes | 1.5 | Yes |
| Preparing Béchamel sauce | | | | | | |
| Temperature of the milk: 7 °C | | | | | | |
| Ingredients: 40 g butter, 40 g flour, 0.5 l milk (3.5% fat content) and a pinch of salt | | | | | | |
| 1. Melt the butter, stir in the flour and salt, and heat up the mixture. | Saucepan, 16 cm diameter | 2 | Approx. 6:00 | No | - | - |
| 2 Add the milk to the roux and bring to the boil, stirring continuously. | | 7 | Approx. 6:30 | No | - | - |
| 3. Once the Béchamel sauce comes to the boil, leave it on the hotplate for a further two minutes, stirring continuously. | | - | - | - | 2 | No |
| *Recipe in accordance with DIN 44550 | | | | | | |
| **Recipe in accordance with DIN EN 60350-2 | | | | | | |

| Test dishes | Cookware | Heat setting | Preheating | | Cooking | |
|---|-----------------------------|--------------|--|-----|------------------------------|-----|
| | | | Cooking time (min:sec) | Lid | Heat setting | Lid |
| Cooking rice pudding | | | | | | |
| Rice pudding, cooked with the lid on Temperature of the milk: 7 °C Heat the milk until it starts to rise up. Set the recommended heat setting and add rice, sugar and salt to the milk. The cooking time, including preheating, is approx. 45 minutes. | | | | | | |
| Ingredients: 190 g short-grain rice, 90 g sugar, 750 ml milk (3.5% fat content) and 1 g salt | Cooking pot, 16 cm diameter | 8.5 | Approx. 5:30 | No | 3 (stir after 10 minutes) | Yes |
| Ingredients: 250 g short-grain rice, 120 g sugar, 1 l milk (3.5% fat content) and 1.5 g salt | Saucepan, 22 cm diameter | 8.5 | Approx. 5:30 | No | 3 (stir after 10 minutes) | Yes |
| Rice pudding, cooked without lid Temperature of the milk: 7 °C Add the ingredients to the milk and heat the mixture up while stirring continuously. Once the milk has reached approx. 90 °C, select the recommended heat setting and leave it to simmer on a low heat for approx. 50 minutes. | | | | | | |
| Ingredients: 190 g short-grain rice, 90 g sugar, 750 ml milk (3.5% fat content) and 1 g salt | Cooking pot, 16 cm diameter | 8.5 | Approx. 5:30 | No | 3 | No |
| Ingredients: 250 g short-grain rice, 120 g sugar, 1 l milk (3.5% fat content) and 1.5 g salt | Saucepan, 22 cm diameter | 8.5 | Approx. 5:30 | No | 2.5 | No |
| Cooking rice* | | | | | | |
| Water temperature: 20 °C | | | | | | |
| Ingredients: 125 g long grain rice, 300 g water and a pinch of salt | Cooking pot, 16 cm diameter | 9 | Approx. 2:30 | Yes | 2 | Yes |
| Ingredients: 250 g long grain rice, 600 g water and a pinch of salt | Saucepan, 22 cm diameter | 9 | Approx. 2:30 | Yes | 2.5 | Yes |
| Roasting a pork loin | | | | | | |
| Initial temperature of the loin: 7 °C | | | | | | |
| Amount: 3 pork loins (total weight approx. 300 g, 1 cm thick) and 15 ml sunflower oil | Frying pan, 24 cm diameter | 9 | Approx. 1:30 | No | 7 | No |
| Preparing pancakes** | | | | | | |
| Amount: 55 ml batter for each pancake | Frying pan, 24 cm diameter | 9 | Approx. 1:30 | No | 7 | No |
| Deep-fat frying chips | | | | | | |
| Amount: 2 l sunflower oil, per portion: 200 g frozen chips (e.g. McCain 123 Original fries) | Saucepan, 22 cm diameter | 9 | Until the oil temperature reaches 180 °C | No | 9 | No |
| *Recipe in accordance with DIN 44550 | | | | | | |
| **Recipe in accordance with DIN EN 60350-2 | | | | | | |

BSH Hausgeräte GmbH

Carl-Wery-Str. 34
81739 München

GERMANY

Manufactured by BSH Hausgeräte GmbH under Trademark License of Siemens AG

siemens-home.bsh-group.com



9001063843 (991129)