

en Instruction manual

Register your product online

Table of contents

| Intended use4 |
|--------------------------------------------------------------------------------------------------------------|
| Important safety information 5 General information 5 Microwave 6 Meat thermometer 7 Cleaning function 7 |
| Causes of damage |
| Environmental protection |
| Getting to know your appliance |
| Accessories |
| Before using for the first time |
| Operating the appliance |
| Time-setting options 17 Timer 17 Cooking time 17 End time 17 |
| Childproof lock. 18 Activating and deactivating . 18 The appliance door is locked. 18 |
| Basic settings |

| Microwave1 |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Cookware |
| Microwave power settings2 |
| Setting the microwave combined with a type of |
| heating |
| Setting the microwave |
| Dry |
| Meat thermometer |
| Types of heating |
| Inserting the meat probe into the food |
| Setting the core temperature |
| Core temperatures of different foods |
| |
| Sabbath mode2 |
| Starting Sabbath mode2 |
| M |
| Cleaning function2 |
| Prior to initiating the cleaning function |
| Setting the self-cleaning function |
| Once the cleaning function has ended2 |
| The state of the s |
| Home Connect |
| Setting up |
| Remote Start |
| Home Connect settings |
| Declaration of Conformity2 |
| Documentation of Conformity |
| Cleaning agent |
| Suitable cleaning agents2 |
| Keeping the appliance clean |
| |
| Rails2 |
| Detaching and refitting the rails |
| |
| Appliance door3 |
| Removing the door cover |
| Removing and fitting the door panels3 |
| 7 Trouble shooting |
| 3 |
| Fault table |
| Maximum operating time exceeded |
| Cooking compartment builds |
| Customer service3 |
| E number and FD number |
| |
| Dishes3 |
| Information on the settings |
| Selecting a dish |
| Baking sensor |
| Applying settings for dishes |
| |

| Tested for you in our cooking studio35 |
|----------------------------------------|
| Do not use silicone moulds |
| Baking |
| Roasting and braising38 |
| Grilling |
| Convenience products |
| Microwave |
| Yogurt47 |
| Eco types of heating48 |
| Acrylamide in foodstuffs49 |
| Slow cook |
| Drying |
| Preserving51 |
| Prove dough |
| Defrosting |
| Heating food in a microwave |
| Keeping warm |
| Test dishes |

Additional information on products, accessories, replacement parts and services can be found at **www.siemens-home.bsh-group.com** and in the online shop **www.siemens-home.bsh-group.com/eshops**

Intended use

Read these instructions carefully. Only then will you be able to operate your appliance safely and correctly. Retain the instruction manual and installation instructions for future use or for subsequent owners.

This appliance is only intended to be fully fitted in a kitchen. Observe the special installation instructions.

Check the appliance for damage after unpacking it. Do not connect the appliance if it has been damaged in transport.

Only a licensed professional may connect appliances without plugs. Damage caused by incorrect connection is not covered under warranty.

This appliance is intended for domestic use only. The appliance must only be used for the preparation of food and drink. The appliance must be supervised during operation. Only use this appliance indoors.

This appliance is intended for use up to a maximum height of 4000 metres above sea level.

This appliance may be used by children over the age of 8 years old and by persons with reduced physical, sensory or mental capabilities or by persons with a lack of experience or knowledge if they are supervised or are instructed by a person responsible for their safety how to use the appliance safely and have understood the associated hazards.

Children must not play with, on, or around the appliance. Children must not clean the appliance or carry out general maintenance unless they are at least 15 years old and are being supervised.

Keep children below the age of 8 years old at a safe distance from the appliance and power cable.

Always slide accessories into the cooking compartment the right way round.

→ "Accessories" on page 13

Important safety information

General information

▲ Warning – Risk of fire!

- Combustible items stored in the cooking compartment may catch fire. Never store combustible items in the cooking compartment. Never open the appliance door if there is smoke inside. Switch off the appliance and unplug it from the mains or switch off the circuit breaker in the fuse box.
- Loose food remnants, fat and meat juices may catch fire. Before using the appliance, remove the worst of the food remnants from the cooking compartment, heating elements and accessories.
- A draught is created when the appliance door is opened. Greaseproof paper may come into contact with the heating element and catch fire. Do not place greaseproof paper loosely over accessories during preheating. Always weight down the greaseproof paper with a dish or a baking tin. Only cover the surface required with greaseproof paper. Greaseproof paper must not protrude over the accessories.

⚠ Warning – Risk of burns!

- The appliance becomes very hot. Never touch the interior surfaces of the cooking compartment or the heating elements. Always allow the appliance to cool down. Keep children at a safe distance.
- Accessories and ovenware become very hot. Always use oven gloves to remove accessories or ovenware from the cooking compartment.
- Alcoholic vapours may catch fire in the hot cooking compartment. Never prepare food containing large quantities of drinks with a high alcohol content. Only use small quantities of drinks with a high alcohol content. Open the appliance door with care.

Marning – Risk of scalding!

- The accessible parts become hot during operation. Never touch the hot parts. Keep children at a safe distance.
- When you open the appliance door, hot steam can escape. Steam may not be visible, depending on its temperature. When opening, do not stand too close to the appliance. Open the appliance door carefully. Keep children away.

 Water in a hot cooking compartment may create hot steam. Never pour water into the hot cooking compartment.

⚠ Warning – Risk of injury!

- Scratched glass in the appliance door may develop into a crack. Do not use a glass scraper, sharp or abrasive cleaning aids or detergents.
- The hinges on the appliance door move when opening and closing the door, and you may be trapped. Keep your hands away from the hinges.

⚠ Warning – Risk of electric shock!

- Incorrect repairs are dangerous. Repairs may only be carried out and damaged power cables replaced by one of our trained after-sales technicians. If the appliance is defective, unplug the appliance from the mains or switch off the circuit breaker in the fuse box. Contact the aftersales service.
- The cable insulation on electrical appliances may melt when touching hot parts of the appliance. Never bring electrical appliance cables into contact with hot parts of the appliance.
- Do not use any high-pressure cleaners or steam cleaners, which can result in an electric shock.
- A defective appliance may cause electric shock. Never switch on a defective appliance. Unplug the appliance from the mains or switch off the circuit breaker in the fuse box. Contact the after-sales service.

▲ Warning – Hazard due to magnetism! Permanent magnets are used in the control panel or in the control elements. They may affect electronic implants, e.g. heart pacemakers or insulin pumps. Wearers of electronic implants must stay at least 10 cm away from the control panel.

Microwave

▲ Warning – Risk of fire!

- Using the appliance for anything other than its intended purpose is dangerous and may cause damage.
 - The following is not permitted: drying out food or clothing, heating slippers, grain or cereal pillows, sponges, damp cleaning cloths or similar.
 - For example, heated slippers and grain or cereal pillows may catch fire, even several hours after they have been heated. The appliance must only be used for the preparation of food and drinks.
- Food may catch fire. Never heat food in heat-retaining packages.
 Do not leave food heating unattended in containers made of plastic, paper or other combustible materials.
 - Do not select a microwave power or time setting that is higher than necessary. Follow the information provided in this instruction manual.
 - Never use the microwave to dry food. Never defrost or heat food with a low water content, e.g. bread, at too high a microwave power or for too long.
- Cooking oil may catch fire. Never use the microwave to heat cooking oil on its own.

⚠ Warning – Risk of explosion!

Liquids and other food may explode when in containers that have been tightly sealed. Never heat liquids or other food in containers that have been tightly sealed.


Marning – Risk of burns!

- Foods with peel or skin may burst or explode during, or even after, heating. Never cook eggs in their shells or reheat hard-boiled eggs. Never cook shellfish or crustaceans. Always prick the yolk when baking or poaching eggs. The skin of foods that have a peel or skin, such as apples, tomatoes, potatoes and sausages, may burst. Before heating, prick the peel or skin.
- Heat is not distributed evenly through baby food. Never heat baby food in closed containers. Always remove the lid or teat. Stir or shake well after the food has been heated. Check the temperature of the food before it is given to the child.
- Heated food gives off heat. The ovenware may become hot. Always use oven gloves to remove ovenware or accessories from the cooking compartment.

- Airtight packaging may burst when food is heated. Always observe the instructions on the packaging. Always use oven gloves to remove dishes from the cooking compartment.
- The accessible parts become very hot when in operation. Never touch hot parts. Keep children at a safe distance.
- Using the appliance for anything other than its intended purpose is dangerous. You are not permitted to use it to dry food or clothing or to warm slippers, grain or cereal pillows, sponges, damp cleaning cloths or the like.
 - This is because, for instance, overheated slippers, grain or cereal pillows, sponges and damp cleaning cloths, etc., may cause burns to the skin.

Marning – Risk of scalding!

There is a possibility of delayed boiling when a liquid is heated. This means that the liquid reaches boiling temperature without the usual steam bubbles rising to the surface. Even if the container only vibrates a little, the hot liquid may suddenly boil over and spatter. When heating, always place a spoon in the container. This will prevent delayed boiling.



⚠ Warning – Risk of injury!

- Unsuitable ovenware may crack. Porcelain or ceramic ovenware can have small perforations in the handles or lids. These perforations conceal a cavity below. Any moisture that penetrates this cavity could cause the ovenware to crack. Only use microwave-safe ovenware.
- If using the appliance in microwave mode only, placing cookware and containers made of metal or featuring metal detailing inside the appliance may cause sparks when the appliance is operating. This may damage the appliance. Never use metal containers when using the appliance in microwave mode only.

Marning – Risk of electric shock!

The appliance is a high-voltage appliance. Never remove the casing.

⚠ Warning – Risk of serious damage to health!

- The surface of the appliance may become damaged if it is not cleaned properly. Microwave energy may escape. Clean the appliance on a regular basis, and remove any food residue immediately. Always keep the cooking compartment, door seal, door and door stop clean.
- Microwave energy may escape if the cooking compartment door or the door seal is damaged. Never use the appliance if the cooking compartment door, the door seal or the plastic door frame is damaged. Call the after-sales service.
- Microwave energy will escape from appliances that do not have any casing. Never remove the casing. For any maintenance or repair work, contact the after-sales service.

Meat thermometer

∧ Warning – Risk of electric shock!

The insulation of an incompatible meat thermometer may be damaged. Only use the meat thermometer which is recommended for this appliance.

Cleaning function

⚠ Warning – Risk of fire!

- Loose food residues, grease and meat juices may catch fire during the cleaning function. Before starting the cleaning function, remove coarse dirt from the cooking compartment and from the accessories.
- The appliance will become very hot on the outside during the cleaning function. Never hang combustible objects, e.g. tea towels, on the door handle. Do not place anything against the front of the appliance. Keep children away from the appliance.

⚠ Warning – Risk of serious damage to health!

The appliance will become very hot during the cleaning function. The non-stick coating on baking trays and tins is destroyed and noxious gases are released. Never clean non-stick baking trays and baking tins using the

cleaning function. Only clean enamelled accessories using the cleaning function.

⚠ Warning – Risk of burns!

- The cooking compartment becomes extremely hot during the cleaning function. Never open the appliance door. Allow the appliance to cool down. Keep children away from the appliance.
- The appliance will become very hot on the outside during the cleaning function. Never touch the appliance door. Allow the appliance to cool down. Keep children away from the appliance.

Causes of damage

General information


Caution!


- Accessories, foil, greaseproof paper or ovenware on the cooking compartment floor: do not place accessories on the cooking compartment floor. Do not cover the cooking compartment floor with any sort of foil or greaseproof paper. Do not place ovenware on the cooking compartment floor if a temperature of over 50 °C has been set. This will cause heat to accumulate. The baking and roasting times will no longer be correct and the enamel will be damaged.
- Aluminium foil: Aluminium foil in the cooking compartment must not come into contact with the door glass. This could cause permanent discolouration of the door glass.
- Silicone pans: Do not use any silicone pans, or any mats, covers or accessories that contain silicone.
 The oven sensor may be damaged.
- Water in a hot cooking compartment: do not pour water into the cooking compartment when it is hot. This will cause steam. The temperature change can cause damage to the enamel.
- Moisture in the cooking compartment: Over an extended period of time, moisture in the cooking compartment may lead to corrosion. Allow the cooking compartment to dry after use. Do not keep moist food in the closed cooking compartment for extended periods of time. Do not store food in the cooking compartment.
- Cooling with the appliance door open: Following operation at high temperatures, only allow the cooking compartment to cool down with the door closed. Do not trap anything in the appliance door. Even if the door is only left open a crack, the front of nearby furniture may become damaged over time. Only leave the cooking compartment to dry with the door open if a lot of moisture was produced whilst the oven was operating.
- Fruit juice: when baking particularly juicy fruit pies, do not pack the baking tray too generously. Fruit juice dripping from the baking tray leaves stains that cannot be removed. If possible, use the deeper universal pan.
- Extremely dirty seal: If the seal is very dirty, the appliance door will no longer close properly during operation. The fronts of adjacent units could be damaged. Always keep the seal clean.
- Appliance door as a seat, shelf or worktop: Do not sit on the appliance door, or place or hang anything on it. Do not place any cookware or accessories on the appliance door.
- Inserting accessories: depending on the appliance model, accessories can scratch the door panel when closing the appliance door. Always insert the accessories into the cooking compartment as far as they will go.
- Carrying the appliance: do not carry or hold the appliance by the door handle. The door handle cannot support the weight of the appliance and could break.

Microwave

Caution!

- Creation of sparks: Metal e.g. a spoon in a glass must be kept at least 2 cm from the cooking compartment walls and the inside of the door.
 Sparks can irreparably damage the glass on the inside of the door.
- Combining accessories: Do not combine the wire rack with the universal pan. Sparks may be created if they are inserted directly on top of one another. Only insert them into their own shelf level.
- Microwave only: The universal pan and baking tray are unsuitable when using the microwave only. If you use either of these, this may create sparks, which may damage the cooking compartment. Place cookware on the wire rack provided, or place it in the microwave and set a type of heating.
- Foil containers: Do not use foil containers in the appliance. They damage the appliance by producing sparks.
- Operating the microwave without food: Operating the appliance without food in the cooking compartment may lead to overloading. Never switch on the microwave unless there is food inside. The short crockery test is the exception to this rule.
 - → "Microwave" on page 19





Microwave popcorn: Never set the microwave output too high. Use a maximum microwave output of 600 watts. Always place the popcorn bag on a glass plate. The door panels may jump if overloaded.

Environmental protection

Your new appliance is particularly energy-efficient. Here you can find tips on how to save even more energy when using the appliance, and how to dispose of your appliance properly.


Saving energy


- Only preheat the appliance if this is specified in the recipe or in the tables in the operating instructions.
- Leave frozen food to defrost before placing it in the cooking compartment.






 Use baking tins that are dark-coloured, painted black or have an enamel coating. These absorb the heat particularly well.






Remove any unnecessary accessories from the cooking compartment.







 Open the appliance door as infrequently as possible when the appliance is in use.





It is best to bake several cakes one after the other. The cooking compartment stays warm. This reduces the baking time for the second cake. You can place two cake tins next to each other in the cooking compartment.





 For longer cooking times, you can switch the appliance off 10 minutes before the end of the cooking time and use the residual heat to finish cooking.

Environmentally-friendly disposal

Dispose of packaging in an environmentally-friendly manner.



This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE). The guideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.

Getting to know your appliance

In this chapter, we will explain the indicators and controls. You will also find out about the various functions of your appliance.

Note: Depending on the appliance model, individual details and colours may differ.

Control panel

In the control panel, you can use the various buttons and the rotary selector to set the required function of the appliance. The current settings are shown on the display.



1 Buttons

The buttons to the left and right of the rotary selector have a pressure point. Press these buttons to activate them.

2 Rotary selector

You can turn the rotary selector clockwise and anti-clockwise.

3 Touch display

You can see the current adjustment values, options or notes in the touch display. To implement settings, touch the appropriate text field. The text fields change depending on the selection.

Controls

The individual controls are adapted for the various functions of your appliance. You can set your appliance simply and directly.

Buttons

Here you can find a short explanation of the various buttons.

| Buttons | | Meaning |
|------------------|--------------------------------|------------------------------------------------------------|
| on/off | | Switches the appliance on and off |
| menu | Menu | Opens the operating modes menu |
| ij⊸⊙ | Information Childproof lock | Displays notes Activates/deactivates the child- proof lock |
| (| Time-setting options | Opens the time-setting options menu |
| » \$\$\$ | Rapid heat up | Switches rapid heat up on and off |

| Start/Stop | Starts, pauses or cancels opera- |
|------------|-----------------------------------|
| Start/Stup | otarto, pauses di Cariceis opera- |
| • | |
| | tion |
| | |

Rotary selector

Use the rotary selector to change the adjustment values shown in the display.

In most selection lists, e.g. types of heating, the first selection follows the last. For temperature, for example, you must turn the rotary selector back when the minimum or maximum temperature is reached.

Display

The display is structured so that the information can be read at a glance.

The value that you can currently set is in focus. It is displayed in white lettering with a dark background.

Status bar

The status bar is at the top of the display. The time and set time functions are displayed here.

Progress line

The progress line shows you how much the oven has already heated up or how much time has elapsed, for example. The straight line below the in-focus value progresses from left to right, the longer the operation continues to run.

Countdown

If you have started your appliance without a cooking time, you can see how long the operation has already been running for at the top right in the status bar.

If you had set a cooking time and it was deleted, the countdown applies the time that has already elapsed and continues to count down from this time. You can therefore always check how long the operation has already been running.

Temperature indicator

The temperature indicator bars show the heating phases or residual heat in the cooking compartment.

| Heating indicator | The heating indicator displays the rising temperature in the cooking compartment. When all bars are filled, the optimum time for placing the dish in the oven has been reached. The bars do not appear when settings are applied for grilling and cleaning. |
|-------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Residual heat indicator | When the appliance is switched off, the temperature indicator shows the residual heat in the cooking compartment. Once the temperature has dropped to approximately 60 °C, the display goes out. |

Note: Due to thermal inertia, the temperature displayed may be slightly different to the actual temperature inside the oven. You can use the i button to check the current heating temperature when heating up.

Types of heating

In order for you to find the correct type of heating for your dish, we have explained the differences and scopes of application here.

Operating modes menu

The menu is divided into different operating modes. In this way, you can quickly access the required function.

| Operating mode | Use |
|-------------------------------------------------|-----------------------------------------------------------------------------------------------|
| Types of heating | There are several finely tuned types of heating for you to prepare your dishes. |
| Dishes → "Dishes" on page 33 | Here you can find preprogrammed setting values which are suitable for many dishes. |
| Microwave → "Microwave" on page 19 | Using the microwave you can cook, heat up or defrost your dishes more quickly. |
| Microwave combination → "Microwave" on page 19 | Using microwave combination, you can activate a type of heating in addition to the microwave. |
| Dry → "Microwave" on page 19 | Use after every microwave operation. |
| Self-cleaning → "Cleaning function" on page 23 | The self-cleaning function cleans your oven automatically. |
| Settings → "Basic settings" on page 18 | You can adapt your appliance's basic settings to suit your needs. |
| HomeConnect → "Home Connect" on page 24 | This function allows you to connect your oven with a mobile device. |
| | |

When cooking at very high temperatures, the appliance lowers the temperature slightly after an extended period.

| Types of | heating | Temperature | Use |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------|------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ® | 4D hot air | 30-275 °C | For baking and roasting on one or more levels. The fan distributes the heat from the ring heating element in the back panel evenly around the cooking compartment. |
| | Top/bottom heating | 30-300 °C | For traditional baking and roasting on one level. Especially suitable for cakes with moist toppings. Heat is emitted evenly from above and below. |
| (A)e | Hot air eco | 30-275 °C | For gentle cooking of selected dishes on one level without preheating. The fan distributes the heat from the ring heating element in the back panel around the cooking compartment. |
| e | Top/bottom heating eco | 30-300 °C | For gentle cooking of selected dishes on one level. The heat is emitted from above and below. |
| Image: Control of the | Hot air grilling | 30-300 °C | For roasting poultry, whole fish and larger pieces of meat. The grill heating element and the fan switch on and off alternately. The fan circulates the hot air around the food. |
| "" | Grill, large area | Grill settings: 1 = low 2 = medium 3 = high | For grilling flat items such as steaks, sausages or bread, and for browning food. The whole area of the grill heating element becomes hot. |
| ~ | Grill, small area | Grill settings: 1 = low 2 = medium 3 = high | For grilling small quantities of food such as steaks, sausages or bread, and for browning food. The centre part under the grill heating element becomes hot. |

| Pizza setting 30-275 °C For preparing pizza and dishes which require a lot of heat from underneath. The bottom heating element and the ring heating element in the back panel heat up. Intensive heat 30-300 °C For dishes with a crispy base. The heat is emitted from above and more intensively from below. Slow cooking 70-120 °C For gentle and slow cooking of seared, tender pieces of meat in ovenware without a lid. The heat is emitted evenly from the top and bottom at low temperatures. Bottom heating 30-250 °C For cooking in a bain marie and for the final baking stage. The heat is emitted from below. Drying 30-150 °C For drying herbs fruit and vegetables. For keeping cooked food warm. For keeping cooked food warm. CoolStart function 30-275 °C For the quick preparation of frozen products on level 1. The temperature depends on the manufacturer's instructions. Use the highest temperature specified on the packaging. The cooking time is as specified or shorter. Preheating is not required. | | | | |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------|---------------------|-----------|----------------------------------------------------------------------------------|
| The heat is emitted from above and more intensively from below. Slow cooking 70-120 °C For gentle and slow cooking of seared, tender pieces of meat in ovenware without a lid. The heat is emitted evenly from the top and bottom at low temperatures. Bottom heating 30-250 °C For cooking in a bain marie and for the final baking stage. The heat is emitted from below. Drying 30-150 °C For drying herbs fruit and vegetables. Keeping warm 60-100 °C For keeping cooked food warm. Preheating ovenware 30-70 °C For preheating ovenware. For the quick preparation of frozen products on level 1. The temperature depends on the manufacturer's instructions. Use the highest temperature specified on the | <u>®</u> | Pizza setting | 30-275°C | The bottom heating element and the ring heating element in the back panel heat |
| a lid. The heat is emitted evenly from the top and bottom at low temperatures. Bottom heating 30-250 °C For cooking in a bain marie and for the final baking stage. The heat is emitted from below. Drying 30-150 °C For drying herbs fruit and vegetables. Keeping warm 60-100 °C For keeping cooked food warm. Preheating ovenware 30-70 °C For preheating ovenware. CoolStart function 30-275 °C For the quick preparation of frozen products on level 1. The temperature depends on the manufacturer's instructions. Use the highest temperature specified on the | | Intensive heat | 30-300 °C | |
| The heat is emitted from below. Drying 30-150 °C For drying herbs fruit and vegetables. Keeping warm 60-100 °C For keeping cooked food warm. Preheating ovenware 30-70 °C For preheating ovenware. CoolStart function 30-275 °C For the quick preparation of frozen products on level 1. The temperature depends on the manufacturer's instructions. Use the highest temperature specified on the | | Slow cooking | 70-120 °C | a lid. |
| Keeping warm 60-100 °C For keeping cooked food warm. Preheating ovenware 30-70 °C For preheating ovenware. CoolStart function 30-275 °C For the quick preparation of frozen products on level 1. The temperature depends on the manufacturer's instructions. Use the highest temperature specified on the | | Bottom heating | 30-250 °C | |
| Preheating ovenware 30-70 °C For preheating ovenware. CoolStart function 30-275 °C For the quick preparation of frozen products on level 1. The temperature depends on the manufacturer's instructions. Use the highest temperature specified on the | ® | Drying | 30-150 °C | For drying herbs fruit and vegetables. |
| CoolStart function 30-275 °C For the quick preparation of frozen products on level 1. The temperature depends on the manufacturer's instructions. Use the highest temperature specified on the | SSS | Keeping warm | 60-100 °C | For keeping cooked food warm. |
| on the manufacturer's instructions. Use the highest temperature specified on the | SS | Preheating ovenware | 30-70 °C | For preheating ovenware. |
| | » * δ | CoolStart function | 30-275 °C | on the manufacturer's instructions. Use the highest temperature specified on the |

Default values

For each type of heating, the appliance specifies a default temperature or level. You can accept this value or change it in the appropriate area.

Further information

In most cases, the appliance provides notes and further information on the action just carried out. To do this, press the i button. The note is shown for a few seconds.

Some notes are displayed automatically, for example as confirmation, or to provide an instruction or warning.

Cooking compartment functions

Some functions make your appliance easier to use. This, for example, enables the cooking compartment to be well lit and a cooling fan to prevent the appliance from overheating.

Opening the appliance door

If you open the appliance door during an operation, the operation is paused. The operation resumes when you close the door.

Note: When using the Microwave operating mode, you must touch the start/stop button once the door has been closed to resume the operation. You can change the basic setting for this.

Interior lighting

When you open the appliance door, the interior lighting switches on. If the door remains open for longer than 15 minutes, the lighting switches off again.

For most operating modes, the interior lighting switches on as soon as the operation is started. When the operation has finished, the lighting switches off. **Note:** You can set the interior lighting not to come on during the operation in the basic settings.

Cooling fan

The cooling fan switches on and off as required. The hot air escapes above the door.

Caution!

Do not cover the ventilation slots. Otherwise the oven will overheat.

So that the cooking compartment cools down more quickly after operation, the cooling fan continues to run for a certain period afterwards.


Note: You can change how long the cooling fan continues to run for in the basic settings. → "Basic settings" on page 18

Accessories

Your appliance is accompanied by a range of accessories. Here, you can find an overview of the accessories included and information on how to use them correctly.

Accessories included

Your appliance is equipped with the following accessories:



Only use original accessories. They are specially adapted for your appliance.

You can buy accessories from the after-sales service, from specialist retailers or online.

Note: The accessories may deform when they become hot. This does not affect their function. Once they have cooled down again, they regain their original shape.


Microwave

Only the wire rack provided is suitable when using the microwave only. If you use the universal pan or the baking tray, this may create sparks, which may damage the cooking compartment.

When using the appliance in combination with the microwave or "Dishes" mode, you can use the universal pan, baking tray or any other accessories that have been included with the appliance.

Inserting accessories

The cooking compartment has three shelf positions. The shelf positions are counted from the bottom up.




When using positions 2 and 3, always insert the accessory between the two guide rods for a shelf position.

The accessories can be pulled out approximately halfway without tipping. With the pull-out rails at level 1, you can pull the accessories out further.

Ensure that the accessory is placed behind the catch tappet **a** on the pull-out rail.

Example in the picture: Universal pan




Notes

- Ensure that you always insert the accessories into the cooking compartment the right way round.
- Always insert the accessories fully into the cooking compartment so that they do not touch the appliance door.

Locking function


The accessories can be pulled out approximately halfway until they lock in place. The locking function prevents the accessories from tilting when they are pulled out. The accessories must be inserted into the cooking compartment correctly for the tilt protection to work properly.

When inserting the wire rack, ensure that the catch tappet **a** is at the rear and is facing downwards. The lettering "microwave" must be at the front and the outer rail must face downwards —.



When inserting baking trays, ensure that the catch tappet **a** is at the rear and is facing downwards. The sloping edge of the accessory **b** must be facing forwards towards the appliance door.

Example in the picture: Universal pan



Optional accessories

You can buy optional accessories from the after-sales service, from specialist retailers or online. *You will find a comprehensive range of products for your appliance in our brochures and online.

Both availability and whether it is possible to order online differ between countries. Please see your sales brochures for more details.

Note: Not all optional accessories are suitable for every appliance. When purchasing, please always quote the exact identification number (E-no.) of your appliance.

→ "Customer service" on page 33

Special accessories

Wire rack

For ovenware, cake tins and ovenproof dishes, and for roasts and grilled food.

Universal pan, Self-cleaning

For moist cakes, pastries, frozen meals and large roasts. It can be used to catch dripping fat when you are grilling directly on the wire rack.

Baking tray, Self-cleaning

For tray bakes and small baked products.

Wire insert

For meat, poultry and fish.

For inserting into the universal pan to catch dripping fat and meat juices.

Profi pan

For preparing large quantities.

Lid for the Profi pan

The lid turns the Profi pan into a Profi roasting dish.

Pizza tray

For pizzas and large round cakes.

Grill tray, Self-cleaning

Use for grilling in place of the wire rack or as a splatter guard. Only use in the universal pan.

Bread-baking stone, Self-cleaning

For home-made bread, bread rolls and pizzas that require a crispy base.

The baking stone must be preheated to the recommended temperature.

Glass roasting dish

For stews and bakes.

Particularly suitable for the "Meals" operating mode.

Glass tray

For large roasts, moist cakes and bakes.

Glass tray

For bakes, vegetable dishes and baked goods.

Decorative trims

For concealing the lower shelf of the unit and the base of the appliance.

Before using for the first time

Before you can use your new appliance, you must make some settings. You must also clean the cooking compartment and accessories.

Initial use

After connecting the appliance to the power or following a power cut, the settings for initial use are shown in the display.

Note: You can change these settings at any time in the basic settings. → "Basic settings" on page 18

Setting the language

German is the preset language.

- 1. Use the rotary selector to select the required language.
- 2. Touch the V arrow.
 The next setting appears.

Setting the clock

The time starts at 12:00.

- 1. Use the rotary selector to set the current time.
- 2. Touch the \bigvee arrow

Setting the date

The default date is 1.1.2014.

- Always touch the V arrow to move to the next setting.
- 2. Use the rotary selector to set the current day, month and year.

With HomeConnect

- 1. Touch "Set using the assistant".
- Further instructions can be found in section
 → "Home Connect" on page 24

Cleaning the cooking compartment and accessories

Before using the appliance to prepare food for the first time, you must clean the cooking compartment and accessories.

Cleaning the cooking compartment

To remove the new-appliance smell, heat up the cooking compartment when empty and with the oven door closed.

Make sure that there is no leftover packaging, such as polystyrene pellets, in the cooking compartment and remove the adhesive tape that is in or on the appliance. Before heating the appliance, wipe the smooth surfaces in the cooking compartment with a soft, wet cloth. Keep the kitchen ventilated while the appliance is heating.

Apply the settings indicated.

| Settings | |
|-----------------|----------------------|
| Type of heating | Top/bottom heating 🔲 |
| Temperature | 240 °C |
| Cooking time | 1 hour |

You can find out how to set the type of heating and the temperature in the next section.

Switch off the appliance after the cooking time indicated using the On/Off button.

After the cooking compartment has cooled down, clean the smooth surfaces with soapy water and a dish cloth.

Cleaning the accessories

Clean the accessories thoroughly using soapy water and a dish cloth or soft brush.

Operating the appliance

You have already learnt about the controls and how they work. Now we will explain how to set your appliance. You will learn about what happens when you switch the appliance on and off, and how to select the operating mode.

Switching the appliance on and off

Before you are able to set the appliance, you must switch it on.

Exception: The childproof lock and the timer can be set when the appliance is switched off.

Displays or information, e.g the residual heat indicator in the cooking compartment, remain visible in the display after the appliance has been switched off.

Switch off your appliance when you do not need to use it. If no settings are applied for a long time, the appliance switches itself off automatically.

Switching the appliance on

Use the On/Off button to switch the appliance on. The on/off symbol above the button is illuminated in blue.

The Siemens logo appears in the display, and then a type of heating and a temperature.

Note: You can specify which operating modes should appear after the appliance is switched on in the basic settings.

Switching off the appliance

Use the On/Off button to switch off the appliance. The lighting above the button goes out.

A set function is cancelled.

The time appears in the display.

Note: You can set whether or not the time should be displayed when the appliance is switched off in the basic settings.

Starting or interrupting operation

To start operation or to interrupt an operation which has started running, press the Start/Stop button. The cooling fan may continue to run after an operation is interrupted.

Press the On/Off button to delete all settings.

If you open the cooking compartment door during operation, operation is interrupted. Close the cooking compartment door to resume operation.

Tip: You can change this setting in the basic settings. → "Basic settings" on page 18

Selecting an operating mode

When you select an operating mode, the appliance must be switched on.

- Press the menu button.
 The operating modes menu opens.
- Touch the required operating mode. Depending on the operating mode, different options are available.
- **3.** Use the rotary selector to change the selection. Depending on the selection, change further settings.
- 4. Use the start/stop button to start. The elapsed time appears in the display. The settings and progress line can be seen.

Setting the type of heating and temperature

After the appliance is switched on, the set default type of heating appears with the temperature. You can start this setting immediately with the Start/Stop button. If you want to set another type of heating, proceed as follows.


For other settings, you can change the values as follows:

Example in the picture: Top/bottom heating at 180 °C.

1. Use the rotary selector to change the type of heating.



- 2. Touch the default temperature.
- 3. Use the rotary selector to change the temperature.



4. Press the Start/Stop button to start.




The set type of heating and the temperature are shown on the display.

Rapid heat up

You can use the **»** \$\mathbb{M}\$ button to heat up the cooking compartment particularly quickly.

The rapid heat up function is not possible for all types of heating.

Suitable types of heating:



To ensure an even cooking result, do not place your food and the accessory in the cooking compartment until rapid heating is complete.

Applying settings

Ensure you have selected a suitable type of heating. The temperature must be set to above 100 °C, otherwise the rapid heating function cannot be started.

- 1. Set the type of heating and temperature.
- 2. Press the » 555 button.



The » \$\mathbb{S}\$ symbol appears on the left next to the temperature. The temperature indicator starts to fill in.

When rapid heating is complete, an audible signal sounds. The »\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\square\squares\square\square\square\square\square\square\square\square\square\

Notes

- If a cooking time has been set, this runs independently of rapid heating and counts down immediately when the operation is started.
- You can use the i button to check the current cooking compartment temperature during rapid heating.

Cancelling

Press the »\squares button. The »\squares symbol disappears from the display.

Time-setting options

Your appliance has different time-setting options.

| Time | setting option | Use |
|---------------|----------------|------------------------------------------------------------------------------------------------------------------------------|
| \triangle | Timer | The timer functions like an egg timer. An audible signal sounds once the set time has elapsed. |
| → | Cooking time | A signal sounds once a set cooking time has elapsed. The appliance switches off automatically. |
| \rightarrow | End time | Set a cooking time and an end time. The appliance switches off automatically so that the operation ends at the desired time. |

Notes

- A cooking time of up to one hour can be set exactly to the minute.
 - A cooking time over one hour can be set in fiveminute increments.
- Depending on which direction you turn the rotary selector, the cooking time starts at a default value: Anti-clockwise, 10 minutes, Clockwise, 30 minutes.
- After a time-setting option has elapsed, a signal sounds and "Finished" appears in the status bar.
- Using the i button, you can request information during the operation, which then appears briefly in the display.

Timer

You can set the timer at any time, even if the appliance is switched off. It runs parallel to the other time settings and has a separate audible signal. In this way, you can tell whether it is the timer or a cooking time which has elapsed.

The maximum setting you can apply is 24 hours.

- 1. Press the 🕒 button.
 The field for the timer opens.
- 2. Use the rotary selector to set the timer duration. The timer starts after a few seconds.

The \bigcirc symbol for the timer and the time counting down are displayed on the left in the status bar.

When the time has elapsed

An audible signal sounds. "Timer elapsed" appears in the display. Use the \bigcirc button to cancel the audible signal early.

Cancelling the timer duration

Press the 🕒 button to open the time-setting options menu and turn the time back. Press the 🖰 button to close the menu.

Changing the timer duration

Use the \bigcirc button to open the time-setting options menu and change the timer time in the next few seconds using the rotary selector. Start the timer with the \bigcirc button.

Cooking time

If you set the cooking time for your meal, the operation stops automatically once this time has elapsed. The oven stops heating.

The maximum setting you can apply is 23 hours and 59 minutes.


Prerequisite: A type of heating and a temperature have been set

For example: Setting for 4D hot air, 180 $^{\circ}$ C, cooking time 45 minutes.

1. Press the 🕒 button.
The time-setting options menu opens.



2. Set the cooking time using the rotary selector.



3. Press the Start/Stop button to start.

You can see the I→I cooking time counting down in the status bar.

The cooking time has elapsed

A signal sounds. The oven stops heating. "Finished" appears in the status bar. You can cancel the audible signal early using the \bigcirc button.

Cancelling the cooking time

Press the button to open the time-setting options menu. Turn the time back. The type of heating and temperature set are shown in the display.

Changing the cooking time

Press the button to open the time-setting options menu. Change the cooking time using the rotary selector.

End time

If you change the end time, please remember that easily spoiled foods must not be allowed to remain in the cooking compartment for too long.


Prerequisite: The selected operation has not already begun. A cooking time has been set. The time-setting options menu \bigcirc is open.

Example in the picture: You put the dish in the cooking compartment at 9:30. It takes 45 minutes to cook and will be ready at 10:15, but you would like it to be ready at 12:45 instead.

1. Touch the "End →I" field.
The end time is displayed.



2. Using the rotary selector, set a later end time.



3. Confirm with the Start/Stop button.



The oven is on standby. The operation starts at the appropriate time. You can see the cooking time counting down in the status bar.

The cooking time has elapsed

A signal sounds. The oven stops heating. "Finished" appears in the status bar. You can cancel the audible signal early using the \bigcirc button.

Correcting the end time

This is possible if the oven is in standby. Use the button to open the time-setting options menu, touch "End >1" and use the rotary selector to correct the end time. Press the button to close the menu.

Cancelling the end time

This is possible if the oven is on standby. To do so, open the time-setting options menu using the \bigcirc button. Touch "End \rightarrow I" and reset the End time using the rotary selector. The cooking time immediately starts to count down.

Childproof lock

Your appliance is equipped with a childproof lock so that children cannot switch it on accidentally or change any settings.

Activating and deactivating

You can activate and deactivate the childproof lock when the appliance is switched on or off.

In each case, press the seconds. A confirmation note appears in the display and the symbol appears in the status bar.

The appliance door is locked

In the basic settings, you can change the settings so that the appliance door is also locked in addition to the control panel.

The appliance door locks if the temperature in the cooking compartment reaches approx. 50 °C. The symbol is displayed in the status bar. When the oven is switched off, the appliance door locks immediately if the childproof lock has been activated.

Basic settings

There are various settings available to you in order to help use your appliance effectively and simply. You can change these settings as required.

Changing settings

- Press the menu button.
 The operating modes menu opens.
- 2. Select the "Settings" operating mode. The first basic setting appears.
- 3. Use the rotary selector to change the values.
- Touch the
 √ arrow to switch to the next basic settings.
- 5. Press the menu button to save.
 "Save" or "Discard" appears on the display.

List of settings

This list tells you all the basic settings and how to change them. Depending on the model of the appliance you own, the display will show only those settings that apply to your appliance.

You can change the following settings:

| Setting | Options |
|-----------------|-------------------------------|
| Select language | Additional languages possible |
| Time of day | Sets the current time |
| Date | Sets the current date |

| Audible signal duration | Short (30 s) |
|---------------------------|-----------------------------------------------------------------------------------------|
| | Medium (1 m) |
| | Long (5 m) |
| Volume | Can be adjusted to one of five different levels |
| Button tone | Switched off (button tone still sounds when switching on/off using the "On/off" button) |
| | Switched on |
| Display brightness | Can be adjusted to one of five different levels |
| Clock display | Digital with date |
| | Analogue |
| | Off |
| Lighting | On during operation |
| | Off during operation |
| Continue automatically | When closing the door |
| | Do not continue automatically (press the Stop/Start button) |
| Childproof lock | Door lock + button lock |
| | Button lock only |
| Operation after switching | Main menu |
| on | Types of heating |
| | Microwave |
| | Microwave combination |
| | Dishes* |
| Warning: Baking tray in | Display |
| MW | Do not display |
| Night-time dimming | Switched off |
| | Switched on (display dimmed between 10 p.m. and 5.59 a.m.) |
| Brand name logo | Display |
| | Do not display |
| Dry microwave | On |
| | Off |
| Fan run-on time | Recommended |
| | Minimum |
| Sabbath mode | Switched on |
| | Switched off |
| Home Connect | Switches Wi-Fi on or off \longrightarrow "Home Connect" on page 24 |
| Factory settings | Restore |
| | Do not restore |
| *) Included, depending on | appliance model |
| | |

Note: Changes to the language, button tone and display brightness settings take effect immediately. All other changes take effect after the settings have been saved.

Changing the time

You can change the time in the basic settings.

For example: Changing from summer to winter time.

- Press the menu button.
 The operating modes menu opens.
- 2. Touch "Settings".
- 3. Touch the arrow \bigvee to move to "Clock".
- 4. Use the rotary selector to change the time.
- **5.** Press the menu button. "Save" or "Discard" appears on the display.

Power cut

Following a long power cut, the settings for initial use are shown in the display.

Reset the language, time and date.

Microwave

You can use the microwave to cook, heat up or defrost food quickly. The microwave can be used on its own, or in combination with a type of heating.

To ensure optimum use of the microwave, please observe the notes on cookware and familiarise yourself with the data in the application tables at the end of the instruction manual.

Cookware

Not all cookware is suitable for microwaves. To ensure that your food is heated and the appliance is not damaged, only use cookware that is suitable for microwaves.

Heat-resistant cookware made of glass, glass ceramic, porcelain or heat-resistant plastic is suitable. These materials allow microwaves to pass through. You can also use ceramic if it has been fully glazed and has no cracks.

You can also use serving dishes. This saves you having to transfer food from one dish to another. You should only use cookware with decorative gold or silver trim if the manufacturer guarantees that they are suitable for use in microwaves.

To bake in combined operation, you can use ordinary metal baking tins. This means that the cake is also browned from below.

Metal dishes are not suitable for other applications. Metal does not allow microwaves to pass through. Food in covered metal containers will remain cold.

Caution!

Creation of sparks: Metal (e.g. a spoon in a glass) must be kept at least 2 cm from the cooking compartment walls and the inside of the door. Sparks may irreparably damage the glass on the inside of the door.

Cookware test

Never switch on the microwave unless there is food inside. The short cookware test is the only exception to this rule.

Perform the following test if you are unsure whether your cookware is suitable for use in the microwave.

- Heat the empty cookware at maximum power for ½
 to 1 minute.
- Check the temperature of the cookware during this time.

The cookware should remain cold or warm to the touch.

The cookware is unsuitable if it becomes hot or sparks are generated.

In this case, stop the test.

⚠ Warning – Risk of burns!

The accessible parts become very hot when in operation. Never touch hot parts. Keep children at a safe distance.

Accessories included

Only the wire rack provided is suitable when using the microwave only. If you use the universal pan or the baking tray, this may create sparks, which may damage the cooking compartment.

When using the appliance in combination with the microwave or "Dishes" mode, you can use the universal pan, baking tray or any other accessories that have been included with the appliance.

When using the microwave, it is best to insert accessories at level 1, unless otherwise specified.

Microwave power settings

A variety of microwave power settings that are suitable for different types of food and food preparation are available.

A cooking time must always be set to operate the microwave. You can either apply the default cooking time or adjust it in the relevant menu.

| Setting | Food | Maximum cook- ing time |
|---------|-------------------------------------------------|---------------------------|
| 90 W | For defrosting delicate foods | 1 hr 30 mins |
| 180 W | For defrosting and continued cooking | 1 hr 30 mins |
| 360 W | For cooking meat and for heating delicate foods | 1 hr 30 mins |
| 600 W | For heating and cooking food | 1 hr 30 mins |
| Max. | For heating liquids | 30 mins |

The maximum setting is for heating liquids. After a certain period, the microwave's power output is reduced to below maximum to protect the appliance. After a cooling period, the microwave's full power will be available once more.

Setting the microwave combined with a type of heating

You can set output settings from 90 W to 360 W. Not all types of heating are suitable for combining with the microwave.

Suitable types of heating:

| (8) | 4D hot air |
|-----|--------------------|
| | Top/bottom heating |
| T) | Hot air grilling |
| | Grill, large area |
| ["] | Grill, small area |

- 1. Press the menu button.
 - The operating modes menu opens.
- Select the "Microwave combination" operating mode. A type of heating, temperature, microwave output setting and cooking time are suggested.
- 3. Touch the appropriate field and use the rotary selector to set the required values.
- Press the Start/Stop button to start.
 The cooking time starts counting down.

You can change the values. Pause the oven by pressing the Start/Stop button. Touch the appropriate microwave field and use the rotary selector to change the cooking time. Press the Start/Stop button to restart.

The cooking time has elapsed

An audible signal sounds. The cooking compartment stops heating. \rightarrow 0 min 00 s appears on the display and "Finished" appears in the status bar. You can cancel the audible signal before it has finished by pressing the \bigcirc button.

Pausing the operation

Press the start/stop button: The oven is paused. Press the start/stop button again; the operation continues.

Open the appliance door: The operation is interrupted. After closing the door: The operation continues.

Cancelling the operation

Press the On/Off button.

Setting the microwave

To achieve optimum results with the microwave, always insert the wire rack at shelf position 1.

- 1. Press the menu button.
- The operating modes menu opens.

 2. Select the "Microwave" operating mode.
- Select the "Microwave" operating mode.
 Microwave output settings and a cooking time are suggested.
- Touch the required microwave output setting to select it.
- 4. Touch the "Cooking time" field and set the cooking time using the rotary selector.
- **5.** Start the microwave using the Start/Stop button. The cooking time starts counting down.

You can change the microwave output setting. Pause the oven by pressing the Start/Stop button. Touch the appropriate microwave field. Press the Start/Stop button to restart.

You can change the cooking time at any time while the operation is running.

The cooking time has elapsed

A signal sounds. The microwave operation has finished. I→I 0 min 00 s appears in the display end "Finished" appears in the status bar. You can cancel the audible signal before it has finished by pressing the (2) button. If you want to set a microwave output setting again, touch the appropriate field and enter a cooking time. The operation starts again.

Pausing the operation

Press the start/stop button: The oven is paused. Press the start/stop button again; the operation continues.

Open the appliance door: The operation is interrupted. After closing the door, press the start/stop button. The operation continues.

Note: If you have altered the basic setting, make sure that the microwave does not resume operation without food inside. → Page 18

⚠ Warning – Risk of burns!

The accessible parts become very hot when in operation. Never touch hot parts. Keep children at a safe distance.

Cancelling the operation

Press the On/Off button.

Dry

With the "Dry" operating mode, the cooking compartment is heated up and the moisture in the cooking compartment evaporates. Use the drying function after every microwave operation.

- 1. Press the menu button. The operating modes menu opens.
- 2. Select the "Dry" operating mode.
- 3. Press the Start/Stop button to start. The drying function starts and ends automatically after 10 minutes.

Open the appliance door for 1 to 2 minutes so that the moisture can escape.

Drying function

To prevent condensation from forming when the appliance is in microwave mode only, the appliance will automatically switch on an additional heating element when it is set to 600 W or "Max.".

You can switch off this function in the basic settings.

Meat thermometer

The meat thermometer Plus makes precise cooking possible. It measures the temperature inside the food. Once the set temperature has been reached, the appliance automatically switches itself off.

Types of heating

Once you have placed the meat thermometer in the cooking compartment, the following heating modes are available for you to select.

For some types of heating, you can combine the type of heating with the microwave. Switch to the "Microwave combination" operating mode.

| (A) | 4D hot air | Microwave |
|------------|------------------------|-----------|
| ⊗ e | Hot air eco | |
| | Top/bottom heating | Microwave |
| e | Top/bottom heating eco | |
| <u>®</u> | Pizza setting | |
| Z | Hot air grilling | Microwave |
| | Intensive heat | |

Notes

- The meat thermometer measures the temperature on the inside of the food between 30 °C and 99 °C.
- Use only the meat thermometer supplied. You can purchase it as a spare part from the after-sales service.
- After use, always remove the meat thermometer from the cooking compartment. Never store it inside the cooking compartment.

Cooking compartment temperature

To prevent damage to the meat thermometer, do not set temperatures higher than 250 °C.

The interior temperature set in the cooking compartment must be at least 10 °C higher than the core temperature that has been set.

Inserting the meat probe into the food


Before placing your food into the cooking compartment, insert the meat probe into the food.

The meat probe has three measuring points. Ensure that the middle measuring point is inserted in the food.


Caution!


When you turn the microwave on, the tip of the meat probe must be inserted in the food.

Meat: For large pieces of meat, insert the meat probe at an angle from above as far as it will go into the meat. For relatively thin pieces of meat, insert the meat probe from the side at the thickest point.



Poultry: Insert the meat probe as far as it will go into the thickest point in the breast. Insert the meat probe into the poultry crossways or lengthways depending on its structure. Then turn the poultry and place it on the wire rack breast-side down.





Turning the food: If you wish to turn the food, do not remove the meat probe. Once you have turned the food, check that the meat probe is correctly positioned in the food.

If you remove the meat probe while the food is cooking, all settings will be reset and you will have to apply them again.

Caution!

Ensure that the meat probe's cable does not become trapped.

To prevent the meat probe from being damaged by excessive heat, there must be a gap of a few centimetres between the grill element and the meat probe. The meat may expand during the cooking process.

Setting the core temperature

- 1. Insert the meat thermometer in the socket on the left-hand side of the cooking compartment.
- 2. Use the rotary selector to select the type of heating or the "Dishes" operating mode.
- **3.** Touch the default temperature and set the temperature using the rotary selector.
- 4. Touch the "Core temperature" field and set the core temperature using the rotary selector. You can switch on the microwave or steam function as required.
- 5. Press the Start/Stop button to start.

 The progress line shows the core temperature as it rises.

Once the set core temperature in the food has been reached

An audible signal sounds. The oven stops heating. You can unplug the meat thermometer from the socket. The

** symbol goes out.

Changing the core temperature

You can change the core temperature at any time.

Cancelling

Unplug the meat thermometer from the socket.

⚠ Warning – Risk of burns!

The cooking interior and the core temperature probe become very hot. Use oven mitts to plug and unplug the core temperature probe.

⚠ Warning – Risk of electric shock!

The insulation of an incompatible meat probe may be damaged. Only use the meat probe which is recommended for this appliance.

Core temperatures of different foods

Do not use frozen food. The figures in the table are given as a guide. They depend on the quality and composition of the food.

You can find comprehensive information on the heating mode and temperature at the end of the instruction manual. → "Tested for you in our cooking studio" on page 35

| Food | Core temperature in °C |
|-------------------------------|------------------------|
| Poultry | 75 |
| Pork | 75 |
| Beef, rare | 50 |
| Beef, medium | 60 |
| Beef, well done | 70 |
| Lamb | 70 |
| Other: Heating/reheating food | 65-75 |

II Sabbath mode

With the Sabbath mode, a cooking time of up to 74 hours can be set. You can keep the food in the cooking compartment warm without having to switch the oven on or off.

Starting Sabbath mode

Prerequisite: "Sabbath mode activated" is activated in the basic settings. → "Basic settings" on page 18

The cooking compartment heats up with top/bottom heating and a temperature between 85 °C and 140 °C.

- Press the On/Off button.
 A type of heating and a temperature are suggested in the display.
- 2. Turn the rotary selector anti-clockwise and select the "Sabbath mode" type of heating.
- Touch the suggested temperature and set the temperature using the rotary selector.
- 4. Press the 🖰 button to open the time-setting options menu and touch the "Cooking time" field. 25:00 hours are suggested.
- Use the rotary selector to set the required cooking time
- Press the Start/Stop button to start. You can see the cooking time counting down in the status bar.

The cooking time has elapsed

A signal sounds. The oven stops heating. "Finished" appears in the status bar.

Setting a later end time

It is not possible to set a later end time.

Cancelling Sabbath mode

Press the On/Off button. All settings are deleted. You can apply new settings.

Cleaning function

You can use the "Self-cleaning" operating mode to clean the cooking compartment effortlessly. The cooking compartment is heated up to a very high temperature. Residues from roasting, grilling and baking will burn.

You can choose from three cleaning settings.

| Setting | Cleaning level | Duration |
|---------|----------------|----------------------------|
| 1 | Light | Approx. 1 hour, 15 minutes |
| 2 | Medium | Approx. 1 hour, 30 minutes |
| 3 | Intensive | Approx. 2 hours |

The dirtier the cooking compartment and the longer the dirt has been there, the higher the cleaning setting should be. A cleaning cycle requires only approx. 2.5 – 4.7 kilowatt hours.

Note: For your safety, the cooking compartment door locks automatically. It cannot be opened again until the
symbol for the locking mechanism goes out in the status bar. The interior lighting remains off during cleaning.

⚠ Warning Risk of burns!

- The cooking compartment becomes extremely hot during the cleaning function. Never open the appliance door. Allow the appliance to cool down. Keep children away from the appliance.
- ⚠ The appliance will become very hot on the outside during the cleaning function. Never touch the appliance door. Allow the appliance to cool down. Keep children away from the appliance.

Prior to initiating the cleaning function

While cleaning is in progress, you can clean an accessory at the same time, e.g. the universal pan or the baking tray. Before cleaning is started, remove the worst dirt. Slide the accessory in at level 2.

Clean the inside of the appliance door and along the surface edges of the cooking compartment in the area around the seal. Do not scrub the seal and do not remove!

Notes

- You can clean the enamelled accessory supplied at the same time as carrying out the cleaning function. You cannot clean any of the wire racks at the same time. The wire racks are not suitable for cleaning using the cleaning function; this will discolour them. Further accessories suitable for cleaning using the cleaning function are listed in the table for special accessories. → "Accessories" on page 13
- If the cooking compartment is very dirty, it is best to clean it without any accessories inside. This will achieve an optimum result.
 If you would like to clean accessories at the same time, start the cleaning function again.

⚠ Warning Risk of fire!

- Loose food residues, grease and meat juices may catch fire during the cleaning function. Before starting the cleaning function, remove coarse dirt from the cooking compartment and from the accessories.
- The appliance will become very hot on the outside during the cleaning function. Never hang combustible objects, e.g. tea towels, on the door handle. Do not place anything against the front of the appliance. Keep children away from the appliance.

Marning – Risk of serious damage to health!

The appliance will become very hot during the cleaning function. The non-stick coating on baking trays and tins is destroyed and noxious gases are released. Never clean non-stick baking trays and baking tins using the cleaning function. Only clean enamelled accessories using the cleaning function.

Setting the self-cleaning function

- 1. Press the menu button.
 The operating modes menu opens.
- Select the "Self-cleaning" operating mode.
 Cleaning setting 3 is suggested. You can start the cleaning process immediately using the "Start/stop" button or
- select a different cleaning setting using the rotary selector.
- 4. Press the "Start/stop" button to start the cleaning operation.

Ventilate the kitchen when the cleaning function is running.

The cooking compartment door locks shortly after operation starts. The figure symbol for the locking mechanism appears on the right-hand side of the status bar next to the elapsing duration.

The cooking compartment door cannot be opened until the figure symbol goes out in the status bar.

Once the cleaning has finished

An audible signal sounds. The oven stops heating. "Finished" appears in the status bar. Use the 🕒 button to switch off the audible signal.

Cancelling the cleaning operation

Use the "On/off" button to switch off the oven. The cooking compartment door cannot be opened until the symbol goes out in the status bar.

Adjusting the cleaning setting

Once cleaning starts, the cleaning setting can no longer be changed.

You can set the cleaning to run overnight

In the section "Time settings", you can find out how to delay the end time. This allows you to use the oven at any time throughout the day. \rightarrow "Time-setting options" on page 17

Once the cleaning function has ended

Once the cooking compartment has cooled down, use a damp cloth to wipe off the ash that has been left behind in the cooking compartment, in the accessories, on the shelves and around the appliance door.

Wipe the pull-out rails with a damp cloth. Then slide the pull-out rails in and out several times. After cleaning, some discolouration may remain on the pull-out rails. This has no effect on performance.

Notes

- During cleaning, the frame on the inside of the appliance door may discolour. This is normal and does not affect performance. The discolouration can only be removed using a stainless-steel cleaning agent.
- Very bad soiling may cause white deposits to remain on the enamel surfaces. This is residue from the food and is harmless. It does not affect performance. You can remove these residues using lemon juice if required.

Home Connect

This appliance is WiFi-capable and can be remotely controlled using a mobile device.

If the appliance is not connected to the home network, the appliance functions in the same way as an oven with no network connection and can still be operated via the display.

Notes

- Ensure that you follow the safety instructions in this instruction manual and that these are complied with even when operating the appliance via the Home Connect app and when you are away from home. Follow the instructions in the Home Connect app. → "Important safety information" on page 5
- Operation on the appliance always has priority.
 During this time, it is not possible to operate the appliance using the Home Connect app.

Setting up

To implement settings via Home Connect, you must have installed and set up the Home Connect app on your mobile device.

Observe the Home Connect documents supplied for this.

Follow the steps specified by the app to make the settings.

The app must be open in order to perform the setup process.

Automatic registration in the home network

Notes

- You require a router that has WPS functions.
- You can start the Home Connect Assistant during initial start-up or using the menu.
- 1. Press the Menu button.
- 2. Touch "Home Connect Assistant".


 The appliance is ready to connect to the network automatically.



3. Press the WPS button on the router.
Wait until "Network connection successful" is shown in the display.



4. Touch "Connect to the app".



The appliance is ready to connect to the app.

5. Start the app on the mobile device and follow the instructions for automatic network registration.

The process for registering is completed once "Successfully connected to the app" is shown in the display.



Manual registration in the home network

Note: You can start the Home Connect Assistant during initial start-up or using the menu.

- 1. Press the menu button.
- 2. Touch "Home Connect Assistant".
- 3. Touch "Connect manually".



The appliance is ready to connect to the network manually.

The SSID and the key for the oven network are shown in the display.




4. Use the SSID "HomeConnect" and the key "HomeConnect" to register the mobile device on the oven network.



Wait until "Network connection successful" is shown in the display.



5. Touch "Connect to the app".



The appliance is ready to connect to the app.

Start the app on the mobile device and follow

6. Start the app on the mobile device and follow the instructions for manual network registration.

The process for registering is completed once "Successfully connected to the app" is shown in the display.



Remote Start

If you want to start an oven operation using your mobile device, you must activate remote start.

Notes

- "Remote start" is only visible if the Home Connect Assistant has been successfully completed.
- Note that some operating modes can only be started on the oven itself.
- 1. Press the menu button.
- 2. Touch "Remote Start".
- appears in the display

Remote start is automatically deactivated in the following situations:

- The oven door is opened 15 minutes after remote start is activated.
- The oven door is opened 15 minutes after the oven operation ends.
- 24 hours after remote start is activated.

When you start the oven operation on the appliance, remote start is automatically activated. You can therefore make changes on your mobile device or start a new programme.

Home Connect settings

You can adjust Home Connect to suit your requirements at any time.

Note: In the Home Connect settings, press the i button to display network and device information.

WiFi

If WiFi is activated, you can use the Home Connect functions.

Note: In the networked standby mode, your appliance requires a maximum of 3 W.

- 1. Press the menu button
- 2. Touch "Settings".
- 3. Touch "Home Connect".
- 4. Touch "WiFi" to switch the wireless module on or off.

| 09:30 Home Connect settings | | ? |
|-----------------------------|----------------------------|-----------------------|
| WiFi on | Disconnect from network | Connect to the app |
| Back to settings | | Remote op. on |

Disconnecting from the network

You can disconnect your oven from the network at any time.

Note: If your oven is disconnected from the network, it is not possible to operate the oven using Home Connect.

- 1. Press the Menu button.
- 2. Touch "Settings".

- 3. Touch "Home Connect".
- 4. Touch "Disconnect from the network".

| 09:30 Home | Connect settings | |
|---------------------|----------------------------|-----------------------|
| WiFi on | Disconnect from network | Connect to the app |
| Back to settings | | Remote op. on |

Connecting to the network

- 1. Press the menu button.
- 2. Touch "Settings".
- 3. Touch "Home Connect".
- 4. Touch "Connect to network".
- 5. Touch "Connect manually" or "Connect automatically".
- 6. Follow the notes in the section
 "Manual registration in the home network" or
 "Automatic registration in the home network".

Connect to the app

If the Home Connect app is installed on your mobile device, you can connect it to your oven.

Note: The appliance must be connected to the network.

- 1. Press the Menu button.
- 2. Touch "Settings".
- 3. Touch "Home Connect".
- 4. Touch "Connect to the app".

| 09:30 Home | Connect settings | |
|---------------------|----------------------------|-----------------------|
| WiFi on | Disconnect from network | Connect to the app |
| Back to settings | | Remote op. on |

Remote control

You can use the Home Connect app to easily access the functions of your oven.

Notes

- Operation on the appliance always has priority.
 During this time, it is not possible to operate the appliance using the Home Connect app.
- The remote control is activated when the appliance is first delivered.
- If the remote control has been deactivated, only the oven's operating statuses are displayed in the Home Connect app.
- The remote control is automatically activated when the remote start is activated.
- 1. Press the menu button.
- 2. Touch "Settings".
- 3. Touch "Home Connect".

4. Touch "Remote operation" to switch operation via the Home Connect app on or off.

| 09:30 Home | Connect settings | ·) |
|---------------------|----------------------------|-----------------------|
| WiFi on | Disconnect from network | Connect to the app |
| Back to settings | | Remote op. on |

About data protection

When your appliance is connected for the first time to a WLAN network, which is connected to the Internet, your appliance transmits the following categories of data to the Home Connect server (initial registration):

- Unique appliance identification (consisting of appliance codes as well as the MAC address of the installed WiFi communication module).
- Security certificate of the WiFi communication module (to ensure a secure IT connection).
- The current software and hardware version of your domestic appliance.
- Status of any previous resetting to factory settings.

This initial registration prepares the Home Connect functions for use and is only required when you want to use these Home Connect functions for the first time.

Note: Ensure that the Home Connect functions can be used only in conjunction with the Home Connect app. Information on data protection can be accessed in the Home Connect app.

Declaration of Conformity

BSH Hausgeräte GmbH hereby declares that the appliance which features Home Connect is in accordance with the basic requirements and the other relevant provisions of the directive 2014/53/EU.

A detailed RED Declaration of Conformity can be found online at www.siemens-home.bsh-group.com on the product page of your appliance with the additional documents.



Cleaning agent

With good care and cleaning, your appliance will retain its appearance and remain fully functioning for a long time to come. We will explain here how you should correctly care for and clean your appliance.

Suitable cleaning agents

To ensure that the different surfaces are not damaged by using the wrong cleaning agent, observe the information in the table. Depending on the appliance model, not all of the areas listed may be on/in your appliance.

Caution!

Risk of surface damage

Do not use:

- Harsh or abrasive cleaning agents,
- Cleaning agents with a high alcohol content,
- Hard scouring pads or cleaning sponges,
- High-pressure cleaners or steam cleaners,
- Special cleaners for cleaning the appliance while it is hot.

Wash new sponge cloths thoroughly before use.

Tip: Highly recommended cleaning and care products can be purchased through the after-sales service. Observe the respective manufacturer's instructions.

⚠ Warning – Risk of burns!

The appliance becomes very hot. Never touch the interior surfaces of the cooking compartment or the heating elements. Always allow the appliance to cool down. Keep children at a safe distance.

| Area | Cleaning |
|-----------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Appliance exteri | or |
| Stainless steel front | Hot soapy water: Clean with a dish cloth and then dry with a soft cloth. Remove flecks of limescale, grease, starch and albumin (e.g. egg white) immediately. Corrosion can form under such flecks. Special stainless steel cleaning products suitable for hot surfaces are available from our after-sales service or from specialist retailers. Apply a very thin layer of the cleaning product with a soft cloth. |
| Plastic | Hot soapy water: Clean with a dish cloth and then dry with a soft cloth. Do not use glass cleaner or a glass scraper. |
| Painted surfaces | Hot soapy water: Clean with a dish cloth and then dry with a soft cloth. |
| Control panel | Hot soapy water: Clean with a dish cloth and then dry with a soft cloth. Do not use glass cleaner or a glass scraper. |

| Door panels | Hot soapy water: Clean with a dish cloth and then dry with a soft cloth. Do not use a glass scraper or a stainless steel scouring pad. |
|-----------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Door handle | Hot soapy water: Clean with a dish cloth and then dry with a soft cloth. If descaler comes into contact with the door han- dle, wipe it off immediately. Otherwise, any stains will not be able to be removed. |
| Appliance interio | r |
| Enamelled sur- faces | Hot soapy water or a vinegar solution: Clean with a dish cloth and then dry with a soft cloth. Soften baked-on food residues with a damp cloth and soapy water. Use stainless steel wire wool or oven cleaner to remove stubborn dirt. Leave the cooking compartment open to dry after cleaning. |
| | Using the cleaning function gives the best results. → "Cleaning function" on page 23 |
| | Note: Food residues can cause white deposits to form. These are harmless and do not affect how the appliance works. Remove using lemon juice if required. |
| Glass cover for the interior light- ing | Hot soapy water: Clean with a dish cloth and then dry with a soft cloth. If the cooking compartment is heavily soiled, use oven cleaner. |
| Door cover | made from stainless steel: Use stainless steel cleaner. Follow the manufacturers' instructions. Do not use stainless steel care products. made from plastic: Clean using hot soapy water and a dish cloth. Dry with a soft cloth. Do not use glass cleaner or a glass scraper. Remove the door cover for cleaning. |
| Stainless steel interior door frame | Stainless steel cleaner: Observe the manufacturer's instructions. This can be used to remove discolouration. Do not use stainless steel care products. |
| Rails | Hot soapy water: Soak and clean with a dish cloth or brush. |
| Pull-out system | Hot soapy water: Clean with a dish cloth or a brush. Do not remove the lubricant while the pull-out rails are pulled out – it is best to clean them when they are pushed in. Do not clean in the dishwasher. |
| Accessories | Hot soapy water: Soak and clean with a dish cloth or brush. If there are heavy deposits of dirt, use a stainless steel scouring pad. |
| Meat thermome- ter | Hot soapy water: Clean with a dish cloth or a brush. |

Do not clean in the dishwasher.

Notes

- Slight differences in colour on the front of the appliance are caused by the use of different materials, such as glass, plastic and metal.
- Shadows on the door panels, which look like streaks, are caused by reflections made by the interior lighting.
- Enamel is baked on at very high temperatures. This can cause some slight colour variation. This is normal and does not affect operation. The edges of thin trays cannot be completely enamelled. As a result, these edges can be rough. This does not impair the anti-corrosion protection.

Keeping the appliance clean

Always keep the appliance clean and remove dirt immediately so that stubborn deposits of dirt do not build up.

⚠ Warning – Risk of fire!

Loose food remnants, fat and meat juices may catch fire. Before using the appliance, remove the worst of the food remnants from the cooking compartment, heating elements and accessories.

Tips

- Clean the cooking compartment after each use. This will ensure that dirt cannot be baked on.
- Always remove flecks of limescale, grease, starch and albumin (e.g. egg white) immediately.
- Use the universal pan for baking very moist cakes.
- Use suitable ovenware for roasting, e.g. a roasting dish.

Rails

With good care and cleaning, your appliance will retain its appearance and remain fully functional for a long time to come. This will tell you how to remove the shelves and clean them.


Detaching and refitting the rails


⚠ Warning – Risk of burns!

The rails become very hot. Never touch the hot rails. Always allow the appliance to cool down. Keep children away from the appliance.


Detaching the rails

- 1. Pull out the pull-out forwards.
- 2. Push the front rail forwards and up (fig. 11) and detach it (fig. 2).





3. Then swing the entire rail outwards a and detach it at the rear **b** (fig. 3).





Clean the rails with cleaning agent and a sponge. For stubborn deposits of dirt, use a brush.

Inserting the holders


If the holders fall out when you remove the rails, these must be re-inserted.

- 1. The holders at the front differ from those at the rear (fig. 11).
- 2. Use the hook to mount the front holder at the top into the round hole a, set it at a slight incline, attach it at the bottom, and straighten it **b** (fig. **2**).






3. Use the hook to attach the rear holder into the upper hole **a** and push it into the lower hole **b** (fig. **3**).




Attaching the rails


When hanging the rails, ensure that the pull-out is at the bottom.




The rails only fit on the right or the left side. The pull-out rails must pull out forwards.


- 1. Hold the rear of the frame at an angle and mount it at the top and bottom a (fig. 11).
- 2. Pull the rail forwards (fig. 2).





- 3. Then fold it forwards and insert it (fig. 3).
- 4. And push it downwards (fig. 4).





5. Completely reinsert the pull-outs.


Appliance door


With good care and cleaning, your appliance will retain its appearance and remain fully functional for a long time to come. This will tell you how to clean the appliance door.

Removing the door cover

The stainless-steel inlay in the door cover may become discoloured. To carry out thorough cleaning, you can remove the cover.


- 1. Open the appliance door slightly.
- 2. Press on the right and left side of the cover (fig. 11).
- Remove the cover (fig. 2).Close the appliance door carefully





Note: Clean the stainless-steel inlay in the cover with a stainless-steel cleaning agent. Clean the rest of the door cover with soapy water and a soft cloth.

4. Open the appliance door again slightly. Put the cover back in place and press on it until it clicks audibly into place (fig. 3).




5. Close the appliance door.


Removing and fitting the door panels

To facilitate cleaning, you can remove the glass panels from the appliance door.


Removing the door panels from the appliance


- 1. Open the appliance door slightly.
- 2. Press on the right and left side of the cover (fig. 11).
- 3. Remove the cover (fig. 2).






- Undo and remove the screws on the left and right of the appliance door (fig. 3).
- 5. Before closing the door again, trap a tea towel that has been folded several times in the door (fig. 4). Pull out the front panel upwards and lay it on a flat surface with the door handle facing downwards.





6. Push both retainers at the top of the intermediate panel upwards, but do not remove them (fig. 5). Hold the panel with one hand. Take out the panel.




Clean the panels with glass cleaner and a soft cloth.

⚠ Warning – Risk of serious damage to health!

If the screws are loosened, the safety of the appliance can no longer be guaranteed. Microwave energy may escape. Never loosen the screws.

Do not unscrew the four black screws (fig. 6).



Marning

Risk of injury!


- Scratched glass in the appliance door may develop into a crack. Do not use a glass scraper, sharp or abrasive cleaning aids or detergents.
- The hinges on the appliance door move when opening and closing the door, and you may be trapped. Keep your hands away from the hinges.

Fitting the door panels on the appliance


When fitting the intermediate panel, make sure that the arrow is in the top right of the panel and that it aligns with the arrow on the metal panel.


- 1. Insert the intermediate panel into the retainer at the bottom and push it in firmly from the top (fig. 1).
- 2. Push both retainers downwards (fig. 2).






- Insert the front panel downwards into the retainers (fig. 3).
- Close the front panel until both upper hooks are opposite the opening (fig. 4).





- **5.** Press the front panel down until it clicks audibly into place (fig. **5**).
- 6. Open the appliance door again slightly and remove the tea towel.
- 7. Screw both screws back in on the left and right.
- 8. Put the cover back in place and press on it until it clicks audibly into place (fig. 6).



9. Close the appliance door.

Caution!

Do not use the cooking compartment again until the panels have been correctly fitted.

Trouble shooting

If a fault occurs, there is often a simple explanation. Before calling the after-sales service, please refer to the fault table and attempt to correct the fault yourself.

Note: If a dish does not turn out as well as you had hoped, refer to the table section at the end of the instruction manual, where you will find plenty of tips and information. → "Tested for you in our cooking studio" on page 35

Marning – Risk of electric shock!

Incorrect repairs are dangerous. Repairs may only be carried out and damaged power cables replaced by one of our trained after-sales technicians. If the appliance is defective, unplug the appliance from the mains or switch off the circuit breaker in the fuse box. Contact the after-sales service.

Fault table

If an error message beginning with 'E' is shown, e.g. E0111, switch the appliance off and then on again. If this message appears again, contact the after-sales service.

| Fault | Possible cause | Information/remedial action |
|----------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------|
| The appliance does not work | The fuse is faulty | Check in the fuse box to make sure that the fuse for the appliance is in working order |
| | Power cut | Check whether other kitchen appliances are working |
| The appliance door will not open; the ☐ symbol is shown in the display | The appliance door is locked until the cooking compartment has cooled down. | Wait until the ⊕ symbol goes out |
| Although the appliance is switched on, it cannot be operated; the ⇔ symbol is shown in the display | The child lock is activated | Press and hold the ⇐⇒ button until the ⇐⇒ symbol goes out |
| The cooking compartment does not heat and "Demo mode on" is shown in the display | The appliance is in demo mode | Switch off the fuse in the fuse box and switch it back on again after approx. 10 seconds. Switch on the appliance and select "Demo mode off" in the settings. |
| The appliance will not start and "Cooking compartment too hot" appears on the display | The cooking compartment is too hot for the selected dish or type of heating | Allow the cooking compartment to cool down and start again |
| The interior lighting has failed | The LED bulb is defective | Call the after-sales service |
| Home Connect does not work correctly. | | Go to www.home-connect.com |

Maximum operating time exceeded

Your appliance automatically ends the operation if no duration has been set and the setting has not been changed for a long time.

The point at which this occurs depends on the temperature or grill setting that has been set.

A message appears on the display on the appliance to say that the operation is being ended automatically. The operation is then cancelled.

To use the appliance again, first switch it off. To switch the appliance back on again set the required operation.

Tip: Set a cooking time so that the appliance does not switch off when you do not want it to, e.g. with an extremely long preparation time. The appliance heats up until the set cooking time has elapsed.

Cooking compartment bulbs

To light the interior of your cooking compartment, your appliance has one or more long-life LED bulbs.

However, if ever an LED bulb or the bulb's glass cover is defective, call the after-sales service. The lamp cover must not be removed.


Customer service

Our after-sales service is there for you if your appliance needs to be repaired. We will always find an appropriate solution, also in order to avoid after-sales personnel having to make unnecessary visits.

E number and FD number

When calling us, please quote the full product number (E no.) and the production number (FD no.) so that we can provide you with the correct advice. The rating plate bearing these numbers can be found when you open the appliance door.

If your appliance operates with steam, you will find the rating plate on the right-hand side behind the panel.



To save time, you can make a note of the numbers for your appliance and the telephone number of the aftersales service in the space below in case you need them.



After-sales service 🕾

Please note that a visit from an after-sales service engineer is not free of charge in the event that the appliance has been misused, even during the warranty period.

Please find the contact data of all countries in the enclosed customer service list.

To book an engineer visit and product advice

GB 0344 892 8999

Calls charged at local or mobile rate.

IE 01450 2655

0.03 € per minute at peak. Off peak 0.0088 € per minute.

Rely on the professionalism of the manufacturer. You can therefore be sure that the repair is carried out by trained service technicians who carry original spare parts for your appliances.

Dishes

You can use the "Dishes" operating mode to prepare a wide variety of food. The appliance chooses the optimal setting for you.

To achieve good results, the cooking compartment must not be too hot for the type of food you have selected. If it is, a message will appear on the display. Allow the cooking compartment to cool down and start again.

Information on the settings

- The cooking result depends on the quality of the food and the size and type of cookware. For an optimal cooking result, use food that is in good condition and chilled meat only. For frozen food, use food straight out of the freezer only.
- For some food, a temperature, heating mode and cooking time is suggested. The temperature and the cooking time can be changed according to your requirements.
- For other dishes, you will be asked to enter the weight. Always enter the total weight unless the appliance asks for something different. The appliance will then apply the time and temperature settings for you.
 - It is not possible to set weights outside of the intended weight range.
- When roasting dishes for which the appliance will apply the temperature selection for you, temperatures of up to 300 °C can be saved. Therefore, make sure that you use cookware that is sufficiently heat resistant.
- Information is provided, e.g. on cookware, shelf position or the addition of liquid when cooking meat. Some food requires turning or stirring, etc., during cooking. This is shown in the display shortly after operation starts. An audible signal will remind you at the right time.
- Information on the right kind of cookware to use and tips and tricks for the preparation can be found at the end of the instruction manual. → "Tested for you in our cooking studio" on page 35

Microwave

For some food, the microwave is automatically activated. Using the microwave significantly reduces cooking time – cooking time is virtually cut in half. The appliance instructs you to use cookware that is suitable for the microwave. The "Microwave" section provides information on the type of cookware that is suitable.

→ "Microwave" on page 19

Meat thermometer

For some food, you can also use the meat thermometer. Once you have inserted the meat thermometer into the appliance, the food that is suitable for it will be displayed. You can change the interior temperature of the cooking compartment and the core temperature.

"Meat thermometer" on page 21

Selecting a dish

The dishes are arranged in a uniform structure:

- Category
- Food
- Dish

The following table lists the categories with the corresponding food. One or more dishes are listed beside each food.

| Categories | Food | | | | |
|----------------------|-------------------------------|--|--|--|--|
| | Cake | | | | |
| | Small baked items | | | | |
| Cakes, bread, pizza | Biscuits | | | | |
| | Bread, bread rolls | | | | |
| | Savoury cakes, pizza, quiches | | | | |
| | Lasagne, fresh | | | | |
| Dologo goufflóg | Soufflé in individual moulds | | | | |
| Bakes, soufflés | Fruit crumble | | | | |
| | Yorkshire pudding | | | | |
| | Pizza | | | | |
| | Bread rolls | | | | |
| Frozen products | Bakes | | | | |
| | Potato products | | | | |
| | Poultry, fish | | | | |
| | Chicken | | | | |
| Poultry | Duck, goose | | | | |
| | Turkey | | | | |
| | Pork | | | | |
| Meat | Beef | | | | |
| Weat | Lamb | | | | |
| | Meat dishes | | | | |
| Fish | Fish | | | | |
| LISH | Fish fillets | | | | |
| | Vegetables | | | | |
| Side dishes, vegeta- | Potatoes | | | | |
| bles | Rice | | | | |
| | Cereals | | | | |
| | Bread, bread rolls | | | | |
| Defrecting food | Cake | | | | |
| Defrosting food | Meat, poultry | | | | |
| | Fish | | | | |
| | | | | | |

Baking sensor

Your appliance is equipped with a baking sensor. This sensor is automatically activated when you select a baked item from any of the following categories in the selection list. If the baking sensor has been activated, the symbol appears on the display.

| Category | Food | Dishes | | |
|--------------------|---------------------------------|-----------------------|--|--|
| Cake, bread, pizza | Cake | Cakes in deep tins | | |
| | | Cakes in shallow tins | | |
| | | Cakes on a tray | | |
| | Small baked items | Puff pastry | | |
| | | Scones | | |
| | | Muffins | | |
| | | Leavened cake | | |
| | Bread/bread rolls | Bread rolls | | |
| | | Bread | | |
| | | Flatbread | | |
| | Savoury cakes, pizza, quiche | Savoury cakes, quiche | | |
| | | Pizza | | |

The appliance now takes over. The appliance then regulates the baking process completely automatically – you do not need to implement any further settings. Once the food is cooked, the appliance will switch itself off automatically. An audible signal will then sound. The cooking time is roughly the same as that listed in the recipe for your baked item and is not displayed. The oven sensor can only be started from the oven when it is cool.

No other baked goods categories are monitored by the baking sensor. In this case, you will be offered a tried and tested setting with customisation options.

Dark-coloured metal baking tins are suitable. Do not use any silicone bakeware or accessories that contain silicone. Otherwise, the baking sensor will be damaged.

The baking sensor is active while "Do not open door" is shown on the display. Do not open the appliance door; otherwise, the settings will be cancelled. The appliance will continue to heat and you can adjust the suggested time. You must monitor the process yourself.

Applying settings for dishes

You will be guided through the entire setting process for your chosen food. Always touch the "Next" field.

- 1. Press the menu button.
 The operating modes menu will open.
- Select "Dishes" mode. The first category will appear on the display.
- 3. Use the rotary selector to select the category you require.
- 4. Touch the "Next" field.
- **5.** Use the rotary selector to select the food.
- 6. Touch the "Next" field.
- 7. Use the rotary selector to select the dish.
- 8. Touch the "Next" field.
- Turn the rotary selector to set the weight.
 Note: Touch the "Tip" field for information on the best shelf position, cookware, etc. to use.
- **10.** Press the Start/Stop button to start.

The setting has ended

A signal sounds. "Finished" appears in the status bar. The oven stops heating. You can cancel the audible signal early using the \bigcirc button.

If you are not satisfied with the cooking result, you can increase the cooking time again. Touch the "Extend cooking time" field. A cooking time is suggested. However, you can change this if you want.

If you are satisfied with the cooking result, touch "Finish". "Enjoy your meal" appears in the display.

Cancelling the setting

Press the On/Off button. All settings are deleted. You can implement new settings.

Setting a later end time

For some dishes, it is possible to set a later end time. You can find out how to set a later end time by looking in the time-setting options.

"Time-setting options" on page 17

Once you have set an end time, the display shows the waiting time. The status bar shows the time at which operation is to end. None of the settings can be changed. Please remember that easily spoiled foods must not be allowed to remain in the cooking compartment for too long.

Tested for you in our cooking studio

Here, you can find a selection of dishes and the ideal settings for them. We will show you which type of heating and temperature are best suited to your dish. You will get information on suitable cooking accessories and the height at which they should be placed in the oven. You will also get tips about cookware and preparation methods.

Note: A lot of steam can build up in the cooking compartment when cooking food.

Your appliance is very energy-efficient and radiates very little heat to its surroundings during operation. Due to the high difference in temperature between the appliance interior and the external parts of the appliance, condensation may build up on the door, control panel or adjacent kitchen cabinet panels. This is a normal physical phenomenon. Condensation can be reduced by preheating the oven or opening the door carefully.

Do not use silicone moulds

For optimal cooking results, we recommend using darkcoloured metal bakeware.

Caution!

Do not use silicone bakeware, accessories that contain silicone or film. Otherwise, the baking sensor may be damaged.

Even if the oven sensor is not being used, it may still be damaged.

Exception: If the appliance comes with a meat probe, this can be used.

Baking

Here, you can find recommended settings for many dishes.

Also refer to the notes in the section on allowing dough to rise.

Only use original accessories supplied with your appliance. These have been tailored to the cooking compartment and the operating modes of your appliance.

Baking in combination with a microwave

If you bake in combination with a microwave, you can reduce the cooking time considerably.

Always use heat-resistant cookware that is suitable for use in microwaves. Observe the notes on cookware suitable for microwaves.

"Microwave" on page 19

In combined operation, you can use conventional baking tins made from metal. If sparks form between the baking tin and the wire rack, check whether the baking tin is clean on the outside. Change the position of the baking tin on the wire rack. If this does not help, continue baking without the microwave. The baking time will be extended.

If you use baking tins/dishes made from plastic, ceramic or glass, the baking time indicated in the settings tables will be reduced. The cake will not brown as much underneath.

Baking in combination with a microwave is only possible on one level.

Shelf positions

Use the indicated shelf positions.

Baking on one level

When baking on one level, use the following shelf position:

Level 1

You can also prepare soufflés in a water bath in the universal pan. To do so, slide the universal pan in at level 1.

Baking on two levels

Use 4D hot air. Baked items that are placed into the oven on trays or in baking tins/dishes at the same time will not necessarily be ready at the same time.

- Universal pan: Level 3
 Baking tray: Level 1
- Baking tins/dishes on the wire rack First wire rack: Level 3 Second wire rack: Level 1

By preparing several dishes at the same time, you can make energy savings of up to 45 per cent. Position baking tins/dishes next to one another or offset and vertically stacked in the cooking compartment.

Accessories

Ensure that you always use suitable accessories and that they are placed in the oven the right way around.

Wire rack

Slide the wire rack in with the embossed "microwave" facing the appliance door, and the curved lip pointing

downwards. Always place ovenware, tins and dishes on the wire rack.

Universal pan or baking tray

Slide the universal pan or the baking tray in carefully as far as the limit stop with the bevelled edge facing the appliance door.

When baking moist cakes or pastries with many toppings, use the universal pan so that any excess liquid does not overflow and make the cooking compartment dirty.

Baking tins

Dark- coloured metal baking tins are most suitable.

Tinplate baking tins, ceramic dishes and glass dishes extend baking time and mean that the baked item will not brown evenly.

Greaseproof paper

Only use greaseproof paper that is suitable for the selected temperature. Always cut greaseproof paper to size.

Recommended setting values

The table lists the optimal heating type for various baked items. The temperature and baking time depend on the amount and consistency of the dough/mixture. For this reason, the table specifies setting ranges. Try using the lower values to start with. A lower temperature will result in more even browning. You can use a higher setting next time if necessary.

Note: Baking times cannot be reduced by using higher temperatures. Cakes or small baked items would only be cooked on the outside, and would not be fully baked in the middle.

The setting values apply to food that is placed into a cold cooking compartment; by doing this, you can make energy savings of up to 20 per cent. If you preheat the oven, you can reduce the indicated baking times by several minutes.

Preheating is necessary for selected food, and this is indicated in the table. Do not place your food or accessories into the cooking compartment until it has finished preheating.

If you wish to follow one of your own recipes when baking, you should use the setting values listed for similar baked items in the table as reference. Additional information can be found in the baking tips listed after the settings table.

Remove unused accessories from the cooking compartment. This will ensure that you achieve the best possible cooking results and energy savings of up to 20 per cent.

Types of heating used:

- □ Top/bottom heating
- Pizza setting

| Dish | Accessories/cookware | Shelf po- sition | Type of heating | Tempera- ture in °C | MW pow- er in watts | Cooking time in mins. |
|-------------------------------|---------------------------------|---------------------|-----------------|------------------------|---------------------------|-----------------------|
| One level baking | | | | | | |
| Victoria sponge cake | 2x Ø20 cm tins | 1 | | 160-170* | - | 20-30 |
| Light fruit cake | high Ø20cm tin | 1 | ® | 140-160 | - | 70-90 |
| Light fruit cake | high Ø20 cm tin | 1 | (A) | 140-150 | 90 | 50-60 |
| Rich Fruit Cake | high Ø23cm tin | 1 | | 130-150 | - | 150-180 |
| Rich Fruit Cake | high Ø23cm tin | 1 | (A) | 130-140 | 90 | 80-90 |
| Fruit crumble | flat glass dish | 2 | ® | 150-170* | - | 30-45 |
| Sponge Cake (fatless), 3 eggs | springform cake tin, Ø26 cm | 1 | (A) | 160-170* | - | 30-45 |
| Sponge flan, 6 eggs | springform cake tin, Ø28 cm | 1 | | 150-170* | - | 30-50 |
| Swiss Roll | swiss roll tin | 2 | | 180-190* | - | 10-18 |
| Fruit Pie | plate Ø20cm or pie tin | 1 | <u>®</u> | 180-190 | - | 45-50 |
| Quiche | quiche tin (dark coated) | 1 | <u>®</u> | 190-210 | - | 30-45 |
| (White) Bread | loaf tin (1x 900 g or 2x 450 g) | 1 | | 190-210* | - | 20-30 |
| Scones | baking tray | 1 | | 180-200* | - | 10-14 |
| Biscuits | baking tray | 2 | | 140-160* | - | 10-25 |
| Small cakes | 12-cup-tin | 1 | | 140-160* | - | 20-35 |
| Puff pastry slices | baking tray | 2 | (A) | 170-190* | - | 20-45 |
| Jam tarts | 12-cup-tin | 2 | (A) | 160-180* | - | 15-30 |
| Meringue | baking tray | 2 | (A) | 80-90* | - | 120-150 |
| Pavlova | baking tray | 2 | ® | 90-100* | - | 120-180 |
| Soufflé | 1,2 L-soufflé dish | 1 | ® | 160-170* | - | 40-50 |
| * Preheat | | | | | | |

| Dish | Accessories/cookware | Shelf po- sition | Type of heating | Tempera- ture in °C | MW pow- er in watts | Cooking time in mins. |
|------------------------------|-----------------------------|---------------------|-----------------|------------------------|---------------------------|-----------------------|
| Soufflé | individual moulds | 1 | | 170-190 | - | 65-75 |
| Choux pastry | baking tray | 1 | ® | 190-210* | - | 30-40 |
| Meat Pie | rectangular pie tin | 1 | ® | 180-190 | - | 40-50 |
| Yorkshire Pudding | 12-cup-tin | 1 | ® | 200-220* | - | 15-25 |
| Jacket potatoes | baking tray | 2 | (A) | 150-170 | - | 75-90 |
| Pizza, homemade | baking tray | 1 | <u>®</u> | 200-220 | - | 20-30 |
| Pizza, homemade | baking tray | 1 | | 220-230 | - | 25-30 |
| Pizza, homemade, thin base | pizza tray | 1 | <u>®</u> | 210-230 | - | 20-30 |
| Multishelf baking | | | | | | |
| Scones, 2 levels | 2 baking trays | 3+1 | (A) | 180-200* | - | 12-16 |
| Biscuits, 2 levels | 2 baking trays | 3+1 | (A) | 140-160* | - | 15-30 |
| Small cakes, 2 levels | 2x 12-cup-tins | 3+1 | (A) | 140-160* | - | 22-32 |
| Puff pastry slices, 2 levels | 2 baking trays | 3+1 | (A) | 170-190* | - | 20-45 |
| Jam tarts, 2 levels | 2x 12-cup-tins | 3+1 | (A) | 160-180* | - | 20-35 |
| Meringues, 2 levels | 2 baking trays | 3+1 | (A) | 80-90* | - | 120-150 |
| Jacket potatoes, 2 levels | universal pan + baking tray | 3+1 | (A) | 150-170* | - | 75-90 |
| Pizza, homemade, 2 levels | universal pan + baking tray | 3+1 | (A) | 180-200 | - | 35-45 |
| * Preheat | | | | | | |

Tips on baking

| 1 3 | |
|---------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| You want to find out whether the cake is completely cooked in the middle. | Push a cocktail stick into the highest point on the cake. If the cocktail stick comes out clean with no dough residue, the cake is ready. |
| The cake collapses. | Next time, use less liquid. Alternatively, set the temperature to be 10 °C lower and extend the baking time. Adhere to the specified ingredients and preparation instructions in the recipe. |
| The cake has risen in the middle but is lower around the edge. | Only grease the base of the springform cake tin. After baking, loosen the cake carefully with a knife. |
| The fruit juice overflows. | Next time, use the universal pan. |
| Small baked items stick to one another during baking. | There should be a gap of approx. 2 cm around each item. This gives enough space for the baked items to expand well and brown on all sides. |
| The cake is too dry. | Set the temperature 10 °C higher and shorten the baking time. |
| The cake is generally too light in colour. | If the shelf position and the cookware are correct, then you should increase the temperature if necessary or extend the baking time. |
| The cake is too light on top, and too dark underneath. | Bake the cake one level higher in the oven the next time. |
| The cake is too dark on top, and too light underneath. | Bake the cake one level lower in the oven the next time. Select a lower temperature and extend the baking time. |
| Cakes baked in a tray or tin are too brown at the back. | Place the baking tray in the middle of the accessories, not directly against the back wall. |
| The whole cake is too dark. | Select a lower temperature next time and extend the baking time if necessary. |
| The cake is unevenly browned. | Select a slightly lower temperature. |
| | Protruding greaseproof paper can affect the air circulation. Always cut greaseproof paper to size. Ensure that the baking tin does not stand directly in front of the openings in the cooking compartment back wall. When baking small items, you should use similar sizes and thicknesses wherever possible. |
| You were baking on several levels. The items on the top baking tray are darker than those on the lower baking tray. | Always select 4D hot air when baking on several levels. Baked items that are placed into the oven on trays or in baking tins/dishes at the same time will not necessarily be ready at the same time. |

The cake looks good, but is not cooked properly in the middle.

The cake cannot be turned out of the dish when it is turned upside down.

Use a lower temperature and bake slightly longer; if necessary, add slightly less liquid. For cakes with a moist topping, bake the base first. Sprinkle it with almonds or breadcrumbs and then place the topping on top.

Allow the cake to cool down for 5 to 10 minutes after baking. If it still sticks, carefully loosen the cake around the edges again using a knife. Turn the cake tin upside down again and cover it several times with a cold, wet cloth. Next time, grease the baking tin/dish and sprinkle with breadcrumbs.

Roasting and braising

Here, you can find information on roasting and braising poultry and meat. You can find the ideal settings for many dishes in the settings tables.

Poultry

For duck or goose, pierce the skin on the underside of the wings. This allows the fat to run out.

If using duck breast, score the skin. Do not turn duck breasts.

When you turn poultry, ensure that the breast side or the skin side is underneath at first.

Poultry will turn out particularly crispy and brown if you baste it towards the end of the roasting time with butter, salted water or orange juice.

Meat

Baste lean meat with fat as required or cover it with strips of bacon.

Score the rind crosswise. If you turn the joint when cooking, ensure that the rind is underneath at first.

When the joint is ready, turn off the oven and allow it to rest for another 10 minutes in the cooking compartment. This allows the meat juices to be better distributed. Wrap the joint in aluminium foil if necessary. The recommended resting time is not included in the cooking time indicated.

Roasting on the wire rack

On the wire rack, poultry and meat will become very crispy on all sides. Roasting on the wire rack is well suited for larger poultry or for multiple pieces at the same time.

Depending on the size and type of the meat, add up to ½ litres of water to the universal pan. Any dripping fat and meat juices will be caught. You can prepare a sauce using these meat juices. In addition, less smoke is generated, and the cooking compartment stays cleaner.

Slide the wire rack in at the indicated shelf position with the imprint "Microwave" facing the appliance door and the outer rail facing downwards. In addition, slide the universal pan in at the shelf position underneath with the slanted edge facing the appliance door.

Roasting and braising in cookware

It is more convenient to roast and braise meat in cookware. You can take the joint out of the cooking compartment more easily in the cookware, and prepare the sauce in the cookware itself.

Only use cookware which is suitable for use in an oven. Check whether the cookware fits in the cooking compartment.

Glass cookware is most suitable. Place hot glass cookware onto a dry mat after cooking. If the surface is damp or cold, the glass may crack.

Add in a little liquid for roasting if the meat is lean. A covering of approx. ½ cm depth should be applied to the base of any glass cookware.

The amount of liquid is dependent on the type of meat, the cookware material and also on whether or not a lid is used. If preparing meat in an enamelled or dark metal roasting dish, it will need a little more liquid than if cooked in glass cookware.

The steam evaporates in the cookware when roasting. Carefully pour in more liquid if required.

Shiny roasting dishes made from stainless steel or aluminium reflect heat like a mirror and are therefore not particularly suitable. The meat cooks more slowly and will not brown so much. Use a higher temperature and/or a longer cooking time.

Observe the manufacturer's instructions for your roasting cookware.

Roasting in uncovered cookware

It is best to use a deep roasting tin/dish for roasting poultry and meat. Place the tin/dish onto the wire rack. If you do not have any suitable cookware, use the universal pan.

Braising in covered cookware

When preparing food with covered cookware, the cooking compartment remains considerably cleaner. Ensure that the lid fits well and closes properly. Place the cookware onto the wire rack.

The distance between the meat and the lid must be at least 3 cm. The meat may rise.

Very hot steam may escape when opening the lid after cooking. Lift the lid at the rear, so that the hot steam can escape away from you.

If necessary, braise the meat first by searing it. Add water, wine, vinegar or a similar liquid to the braising liquid. A covering at least 2 cm deep should be applied to the base of the cookware.

The steam evaporates in the cookware when roasting. Carefully pour in more liquid if required.

Roasting in combination with a microwave

Certain foodstuffs can be prepared in combination with a microwave. The cooking time is considerably reduced by doing so.

As opposed to conventional operation, the cooking time is based on the total weight when roasting in combination with a microwave.

Tip: If you have quantities other than those indicated in the settings tables, the following basic rule applies: double the quantity equates to roughly double the cooking time.

Always use heat-resistant cookware that is suitable for use in microwaves. Roasting dishes made from metal or Römertopf dishes are only suitable for roasting without using the microwave. Observe the notes on cookware suitable for microwaves. → "Microwave" on page 19

Caution!

If you use an oven bag, do not seal it shut with metal clips. Use kitchen string. Do not use metal skewers for roulades. Sparks may form as a result.

Meat thermometer

You can cook accurately using a meat thermometer. Read important notes on using the meat thermometer in the corresponding chapter. There, you can find notes on inserting the meat thermometer, the possible heating types and additional information. \rightarrow "Meat thermometer" on page 21

Recommended setting values

In the table, you can find the ideal heating type for poultry and meat. Temperature and cooking time depend on the quantity, composition and temperature of the food. Different settings ranges are indicated for this reason. Try using the lower values at first. You can increase the temperature next time if necessary.

The setting values are based on the assumption that unstuffed, chilled, ready-to-roast poultry and meat are placed into a cold cooking compartment. By doing so, you can make energy savings of up to 20 per cent. If

you preheat the oven, the indicated cooking times will be reduced by several minutes.

In the table, you can find specifications for poultry and meat with default values for the weight. If you wish to prepare heavier poultry or meat, use the lower temperature in every case. If roasting several joints, use the weight of the heaviest piece as a basis for determining the cooking time. The individual pieces should be approximately equal in size.

A general rule: the larger the poultry or piece of meat is, the lower the cooking temperature and the longer the cooking time.

Turn the poultry and meat after approx. $\frac{1}{2}$ to $\frac{2}{3}$ of the indicated time.

Remove unused accessories from the cooking compartment. This will achieve the best possible cooking results and energy savings of up to 20 per cent.

Cooking time calculation (e. g. 20+35): Please calculate the cooking time with 20 minutes per 500 g meat + 35 minutes additional time. For 1,5 kg the calculated cooking time would be 95 minutes.

Cooking time range (e. g. 10-15): The food is done within the stated minutes.

- ☑ Circulated air grilling

| Dish | Accessories/cookware | Shelf posi- tion | Type of heating | Temperature in °C | MW power in watts | Time in min. |
|---------------------------------------|----------------------|---------------------|-----------------|-------------------|-------------------|--------------|
| Beef | | | | | | |
| Slow roasting joint | cookware, uncovered | 1 | 8 | 140-150 | - | 35+40 |
| Top side / Top rump | cookware, uncovered | 1 | ® | 160-170 | - | 30+25 |
| Lamb | | | | | | |
| Leg (bone-in) | cookware, uncovered | 1 | 8 | 160-170 | - | 25+25 |
| Shoulder (bone-in) | cookware, uncovered | 1 | ® | 160-170 | - | 25+20 |
| Shoulder (boned and rolled) | cookware, uncovered | 1 | 8 | 170-180 | - | 25+25 |
| Rack of lamb*** | cookware, uncovered | 1 | ® | 180-190* | - | 15+25 |
| Pork | | | | | | |
| Roasting joint | cookware, uncovered | 1 | ® | 180-190 | - | 30+35 |
| Loin joint | cookware, uncovered | 1 | | 180-190 | - | 35+35 |
| Belly | cookware, uncovered | 1 | | 170-180 | - | 30+25 |
| Gammon joint | cookware, uncovered | 1 | ® | 160-170 | - | 30+30 |
| Poultry | | | | | | |
| Chicken, whole | cookware, uncovered | 1 | ® | 170-180 | - | 25+15 |
| Chicken, portion, 200-250 g each** | cookware, uncovered | 1 | 8 | 190-200 | - | 35-45 |
| * Preheat | | | | | | |

- * Preheat
- ** skin side down
- *** without fat layer (best and neck), do not turn
- **** bone side down, do not turn
- **** turn after app. 1 hour

| Dish | Accessories/cookware | Shelf position | Type of heating | Temperature in °C | MW power in watts | Time in min. |
|-------------------------------------------|--------------------------------------------------|----------------|-----------------|-------------------------------------------|-------------------|-------------------------------------------------------------------------------|
| Duck | cookware, uncovered | 1 | ® | 180-190 | - | 25+20 |
| Turkey, crown**** | cookware, uncovered | 1 | 8 | 150-160 | - | 20+15 |
| Turkey, thighs | cookware, uncovered | 1 | ® | 170-180 | - | 25+30 |
| Turkey, whole, 4-8 kg**** | universal pan | 1 | ® | 150-160 | - | 12+12 |
| Meat dishes | | | | | | |
| Meat loaf | cookware, uncovered | 1 | ® | 170-180 | - | 20+35 |
| Meat loaf, 1 kg + 50 ml water | cookware, uncovered | 1 | X | 170-190 | 360 | 30-40 |
| Casserole | | | | | | |
| Diced meat (beef, pork, lamb), 500 g meat | cookware, covered | 1 | (A) | 140* | - | 100-120 |
| Braising steak | cookware, covered | 1 | ® | 140 | - | 65+60 |
| Chicken pieces (boned), 500 g meat | cookware, covered | 1 | (A) | 140* | - | 90-100 |
| Complete meal | | | | | | |
| With beef | wire rack + uncovered cook- ware on wire rack | 3+1 | 8 | 160, then 200 (Yorkshire Pud- ding) | | calculation for meat (see table above) + 15-25 for Yorkshire Pudding |
| With chicken | wire rack + uncovered cook- ware on wire rack | 3+1 | 8 | 180 | - | calculation for chicken (see table above) |

* Preheat

Tips on roasting and braising

| The cooking compartment becomes very dirty. | Prepare your food in an enclosed roaster with higher temperature or use the grill tray. You will achieve the best roasting results if you use the grill tray. The grill tray can be bought later as a special accessory. |
|-------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| The roast is too dark and the crackling is burned in places, and/or the roast is too dry. | Check the shelf position and temperature. Select a lower temperature the next time and reduce the roasting time if necessary. |
| The crackling is too thin. | Increase the temperature or switch on the grill briefly at the end of the roasting time. |
| The roast looks good but the juices are burnt. | Next time, use a smaller roasting dish and add more liquid if necessary. |
| The roast looks good but the juices are too clear and watery. | Next time, use a larger roasting dish and add less liquid if necessary. |
| The meat gets burned during braising. | The roasting dish and lid must fit together well and close properly. Reduce the temperature and add more liquid when braising if necessary. |
| The roast is not well-done enough. | Carve the roast. Prepare the sauce in the roasting dish and add the sliced roast meat to the sauce. Finish cooking the meat using the microwave only. |

^{**} skin side down

*** without fat layer (best and neck), do not turn

^{****} bone side down, do not turn

^{*****} turn after app. 1 hour

Grilling

Here, you can find information on grilling poultry, meat and fish, as well as toast. You can find the ideal settings for certain dishes in the settings tables.

Grilling with circulated air

Circulated air grilling is very well suited to the preparation of whole poultry, fish, and also meat, e.g. roast pork with crackling.

Poultry

For duck or goose, pierce the skin on the underside of the wings. This allows the fat to run out.

If using duck breast, score the skin. Do not turn duck breasts.

When you turn poultry, ensure that the breast side or the skin side is underneath at first.

Poultry will turn out particularly crispy and brown if you baste it towards the end of the roasting time with butter, salted water or orange juice.

Meat

Baste lean meat with fat as required or cover it with strips of bacon.

Score the rind crosswise. If you turn the joint when cooking, ensure that the rind is underneath at first.

When the joint is ready, turn off the oven and allow it to rest for another 10 minutes in the cooking compartment. This allows the meat juices to be better distributed. Wrap the joint in aluminium foil if necessary. The recommended resting time is not included in the cooking time indicated.

Fish

Fish cooked whole does not have to be turned. Place the whole fish into the cooking compartment in swimming position with the dorsal fin facing upwards. Placing half a potato or a small oven-proof container in the stomach cavity of the fish will provide stability.

You can tell when the fish is cooked because the dorsal fin can be removed easily.

Roasting on the wire rack

On the wire rack, poultry and meat will become very crispy on all sides. Roasting on the wire rack is well suited for larger poultry or for multiple pieces at the same time.

Depending on the size and type of the meat, add up to $\frac{1}{2}$ litres of water to the universal pan. Any dripping fat and meat juices will be caught. You can prepare a sauce using these meat juices. In addition, less smoke is generated, and the cooking compartment stays cleaner.

Slide the wire rack in at the indicated shelf position with the imprint "Microwave" facing the appliance door and the outer rail facing downwards. In addition, slide the universal pan in at the shelf position underneath with the slanted edge facing the appliance door.

Roasting in cookware

It is more convenient to roast and braise meat in cookware. You can take the joint out of the cooking compartment more easily in the cookware, and prepare the sauce in the cookware itself.

Only use cookware which is suitable for use in an oven. Check whether the cookware fits in the cooking compartment.

Glass cookware is most suitable. Place hot glass cookware onto a dry mat after cooking. If the surface is damp or cold, the glass may crack.

Add in a little liquid if the meat is lean. A covering of approx. ½ cm depth should be applied to the base of any glass cookware.

The quantity of liquid is dependent on the type of meat, the cookware material and also on whether or not a lid is used. If preparing poultry, meat or fish in an enamelled or dark metal roasting dish, it will need a little more liquid than if cooked in glass cookware.

The steam evaporates in the cookware when roasting. Carefully pour in more liquid if required.

Shiny roasting dishes made from stainless steel or aluminium reflect heat like a mirror and are therefore not particularly suitable. The meat cooks more slowly and will not brown so much. Use a higher temperature and/or a longer cooking time.

Observe the manufacturer's instructions for your roasting cookware.

Uncovered cookware

Use a deep roasting tin/dish for roasting meat. Place the tin/dish onto the wire rack. If you do not have any suitable cookware, use the universal pan.

Covered cookware

When cooking with covered cookware, the cooking compartment remains considerably cleaner. Ensure that the lid fits well and closes properly. Place the cookware onto the wire rack.

The distance between the meat and the lid must be at least 3 cm. The meat may rise.

Very hot steam may escape when opening the lid after cooking. Lift the lid at the rear, so that the hot steam can escape away from you.

If necessary, braise the meat first by searing it. Add water, wine, vinegar or a similar liquid to the braising liquid. A covering approx. 1-2 cm deep should be applied to the base of the cookware.

The steam evaporates in the cookware when roasting. Carefully pour in more liquid if required.

Meat can also become crispy in a covered roasting dish. To do so, use a roasting dish with a glass lid and set a higher temperature.

Roasting in combination with a microwave

Certain foodstuffs can be prepared in combination with a microwave. The cooking time is considerably reduced by doing so.

As opposed to conventional operation, the cooking time is based on the total weight when roasting in combination with a microwave.

Tip: If you have quantities other than those indicated in the settings tables, the following basic rule applies: double the quantity equates to roughly double the cooking time.

Always use heat-resistant cookware that is suitable for use in microwaves. Roasting dishes made from metal or Römertopf dishes are only suitable for roasting without using the microwave. Observe the notes on cookware suitable for microwaves.

"Microwave" on page 19

Caution!

If you use an oven bag, do not seal it shut with metal clips. Use kitchen string. Do not use metal skewers for roulades. Sparks may form as a result.

Grilling flat pieces

Flat pieces of poultry, meat and fish, such as steaks, drumsticks and burgers, can be prepared well using the "Grill" heating type. Excellent results are also achieved when grilling toast.

Grilling

Keep the appliance door closed when using the grill. Never grill with the appliance door open.

Slide the wire rack in at the indicated shelf position with the imprint "Microwave" facing the appliance door and the outer rail facing downwards. In addition, slide the universal pan in at least one shelf position lower, with the slanted edge facing the appliance door. Any dripping fat will be caught.

When grilling, try wherever possible to use pieces of food which are of a similar thickness and weight. This will allow them to brown evenly and remain succulent and juicy. Place the food to be grilled directly onto the wire rack.

Use tongs to turn the pieces of food you are grilling. If you pierce the meat with a fork, the juices will run out and it will become dry.

Do not add salt until after the meat has been grilled. Salt draws water from the meat.

Notes

- The grill element switches itself continuously on and off; this is normal. The grill setting determines how frequently this occurs.
- Smoke may be produced when grilling.

Meat thermometer

You can cook accurately using a meat thermometer. Read important notes on using the meat thermometer in the corresponding chapter. There, you can find notes on inserting the meat thermometer, the possible heating types and additional information. \longrightarrow "Meat thermometer" on page 21

Recommended setting values

In the table, you can find the ideal heating type for your poultry, meat and fish, in addition to toast. Temperature and cooking time depend on the quantity, composition and temperature of the food. Settings ranges are indicated for this reason. Try using the lower values at first. You can use a higher setting next time if necessary.

The setting values are based on the assumption that unstuffed, chilled, ready-to-roast poultry, meat and fish are placed into a cold cooking compartment.

In the table, you can find specifications for poultry, meat and fish with default values for the weight. If you wish to prepare heavier poultry, meat or fish, use the lower temperature in every case. If roasting several joints, use the weight of the heaviest piece as a basis for determining the cooking time. The individual pieces should be approximately equal in size.

A general rule: the larger the poultry, meat or fish is, the lower the cooking temperature and the longer the cooking time.

Turn the poultry, meat and fish after approx. $\frac{1}{2}$ to $\frac{2}{3}$ of the indicated time.

Remove unused accessories from the cooking compartment. This will achieve the best possible cooking results and energy savings of up to 20 per cent.

Cooking time calculation (e. g. 20+35):
Please calculate the cooking time with 20 minutes per 500 g meat + 35 minutes additional time. For 1,5 kg the calculated cooking time would be 95 minutes.

Cooking time range (e. g. 10-15): The food is done within the stated minutes.

- ဩ Circulated air grilling
- Grill, large area

| Dish | Accessories/cookware | Shelf po- sition | Type of heating | Temperature in C / Grill setting | MW power in watts | Time in min. |
|---------------------------------|----------------------|---------------------|-----------------|----------------------------------|-------------------|---------------|
| Beef | | | | | | |
| Steaks, height 2-3 cm wire rack | wire rack | 2 | "" | 3 | - | 1st side 8-10 |
| | | | | | | 2nd side 5-7 |
| Burger, height 1-2 cm | wire rack | 2 | | 3* - | | 1st side 6-8 |
| | | | | | | 2nd side 4-6 |
| Top side / Top rump | wire rack | 2 | X | 150-160 | - | 30+30 |

^{*} Preheat

^{**}Preheat 3 minutes

^{***} Preheat 5 minutes

^{****} Preheat 3 minutes, turn over several times

^{*****} Skin side down

| Dish | Accessories/cookware | Shelf po- sition | Type of heating | Temperature in C / Grill setting | MW power in watts | Time in min. |
|--------------------------------------------|----------------------|---------------------|-----------------|-------------------------------------|-------------------|----------------|
| Lamb | | | | | | |
| Steaks, height 2-3 cm | wire rack | 2 | | 3* | - | 1st side 8-10 |
| | | | | | | 2nd side 4-6 |
| Chops, height 2-3 cm | wire rack | 2 | | 3 | - | 1st side 6-8 |
| | | | | | | 2nd side 6-8 |
| Leg (bone-in) | cookware, uncovered | 1 | I | 170-180 | - | 25+30 |
| Shoulder (bone-in) | cookware, uncovered | 1 | X | 170-190 | - | 25+15 |
| Shoulder (boned and rolled) | cookware, uncovered | 1 | Z | 170-180 | - | 20+15 |
| Rack of lamb | cookware, uncovered | 1 | II. | 190-200 | - | 15+25 |
| Pork | | | | | | |
| Steaks, height 2 cm | wire rack | 3 | | 2 | - | 1st side 12-14 |
| | | | | | | 2nd side 6-8 |
| Chops, height 2-3 cm | wire rack | 2 | | 3* | - | 1st side 10-12 |
| | | | | | | 2nd side 9-10 |
| Burger, height 1-2 cm | wire rack | 2 | | 3* | - | 1st side 6-8 |
| | | | | | | 2nd side 4-6 |
| Bacon rashers | wire rack | 2 | | 3*** | - | 1st side 4-5 |
| | | | | | | 2nd side 3-4 |
| Sausages, thickness 2-4 cm | wire rack | 2 | | 3**** | - | 10-15 |
| Roasting joint | cookware, uncovered | 1 | II. | 180-200 | - | 30-40 |
| Loin joint | cookware, uncovered | 1 | I | 170-180 | - | 35+35 |
| Belly | cookware, uncovered | 1 | X | 200-220 | - | 30+25 |
| Gammon joint | cookware, uncovered | 2 | Z | 180-200 | - | 30+25 |
| Poultry | | | | | | |
| Chicken drumstick, 150 g each | wire rack | 2 | I | 210-230 | - | 20-30 |
| Chicken breast, boned, 150 g | wire rack | 2 | | 3** | - | 1st side 10-15 |
| each | | | | | | 2nd side 10-15 |
| Chicken breast, boned, 2 pieces 150 g each | cookware, uncovered | 1 | X | 190-210 | 180 | 25-30 |
| Chicken, whole | wire rack | 1 | I | 200-220 | - | 25+15 |
| Chicken, whole, 1 kg | cookware, covered | 1 | I | 230-250 | 360 | 25-35 |
| Chicken, portion, 200-250 g each**** | wire rack | 2 | I | 200-220 | - | 30-45 |
| Chicken, portion 4 pieces 250 g each***** | cookware, uncovered | 1 | II. | 190-210 | 360 | 20-30 |
| Duck, 2-3 kg | cookware, uncovered | 1 | Z | 190-200 | - | 20+20 |
| Duck, 2 kg | universal pan | 1 | Z | 170-190 | 180 | 60-80 |
| Turkey thighs | cookware, uncovered | 1 | z | 180-190 | - | 25+30 |
| Turkey, whole, 4-8 kg | universal pan | 1 | Z | 140-160 | - | 12+12 |
| * Prohoat | | | | | | |

^{*} Preheat

^{**}Preheat 3 minutes

^{***} Preheat 5 minutes

**** Preheat 3 minutes, turn over several times

^{*****} Skin side down

| Dish | Accessories/cookware | Shelf po- sition | Type of heating | Temperature in C / Grill setting | MW power in watts | Time in min. |
|--------------------------------|----------------------|---------------------|-----------------|----------------------------------|-------------------|---------------|
| Fish | | | | | | |
| Trout, whole, 300 g each | cookware, uncovered | 1 | II. | 170-190 | - | 20-30 |
| Trout, whole, 300 g each | wire rack | 2 | | 2 | 90 | 15-20 |
| Fillets, each 150 g | wire rack | 2 | | 1** | - | 1st side 5-10 |
| | | | | | | 2nd side 5-10 |
| Toast | | | | | | |
| Grilling white bread | wire rack | 3 | | 3 | - | 2-6 |
| * Preheat **Preheat 3 minutes | | | | | | |
| *** Preheat 5 minutes | | | | | | |

Convenience products

**** Skin side down

Here, you can find the ideal settings for preparing chilled and frozen food.

Preheat 3 minutes, turn over several times

Only use original accessories supplied with your appliance. These have been tailored to the cooking compartment and the operating modes of your appliance.

Tips

- The cooking result greatly depends on the quality of the food. Pre-browning and unevenness may already be present on the packaged product.
- Do not use frozen products that are heavily frosted.
 Remove any ice on the food.
- Distribute foods which are in pieces, such as bread rolls and potato products, so that they are spread flat and evenly on the accessories. Leave a little space between the individual pieces.
- Observe the instructions on the packaging.

Preparing food in combination with a microwave

If you prepare food in combination with a microwave, you can reduce the cooking time considerably.

Always use heat-resistant cookware that is suitable for use in microwaves. Observe the notes on cookware suitable for microwaves.

"Microwave" on page 19

In combined operation, you can use conventional baking tins made from metal. If sparks form between the baking tin and the wire rack, check whether the baking tin is clean on the outside. Change the position of the baking tin on the wire rack. If this does not help, continue preparing without the microwave. The cooking time will be extended.

If you use baking tins/dishes made from plastic, ceramic or glass, the cooking time indicated in the settings tables will be reduced.

Cooking in combination with a microwave is only possible on one level.

Take ready-to-eat meals out of the packaging. You can cook more quickly and evenly using cookware which is suitable for use in microwaves.

Shelf positions

Use the indicated shelf positions.

Baking on one level

When baking on one level, use the following shelf position:

Level 1

Baking on two levels

Use 4D hot air. Baked items that are placed into the oven on trays or in baking tins/dishes at the same time will not necessarily be ready at the same time.

Universal pan: Level 3
 Baking tray: Level 1

Accessories

Ensure that you always use suitable accessories and that they are placed in the oven the right way around.

Wire rack

Slide the wire rack in with the embossed "microwave" facing the appliance door, and the curved lip pointing downwards. Always place ovenware, tins and dishes on the wire rack.

Universal pan or baking tray

Slide the universal pan or the baking tray in carefully as far as the limit stop with the bevelled edge facing the appliance door.

Greaseproof paper

Only use greaseproof paper that is suitable for the selected temperature. Always cut greaseproof paper to size.

Recommended setting values

In the table, you can find the ideal heating type for various dishes. Temperature and cooking time depend on the quantity and composition of the product. Setting ranges are indicated for this reason. Try using the lower values at first. A lower temperature results in more even browning. You can use a higher setting next time if necessary.

Note: Cooking times cannot be reduced by using higher temperatures. The dish would only be cooked on the outside, but would not be fully cooked in the middle.

The setting values apply to dishes placed into a cold cooking compartment. By doing so, you can make energy savings of up to 20 per cent. If you preheat the oven, the indicated cooking times will be reduced by several minutes.

Preheating is necessary for selected dishes, and this is indicated in the table.

Remove unused accessories from the cooking compartment. This will achieve the best possible

cooking results and energy savings of up to 20 per cent.

- □ Top/bottom heating
- Pizza setting
- "* coolStart function

| Dish | Accessories/cookware | Shelf po- sition | Type of heating | Tempera- ture in °C | MW pow- er in watts | Cooking time in mins. |
|----------------------------------|---------------------------------|---------------------|------------------------------|------------------------|---------------------------|--------------------------|
| Pizza, chilled | | | | | | |
| Pizza, chilled | wire rack | 1 | <u>®</u> | 210-230 | - | 10-20 |
| Pizza, frozen | | | | | | |
| Pizza, thin base* | wire rack | 1 | » ξ | - | - | - |
| Pizza, thin base, 2 levels | 2 wire racks | 3+1 | | 200-220 | - | 15-25 |
| Pizza, thick base* | wire rack | 1 | » ξ | - | - | - |
| Pizza, thick base, 2 levels | 2 wire racks | 3+1 | | 160-180 | - | 25-35 |
| Pizza baguette | wire rack | 1 | | 200-220 | - | 20-30 |
| Pizza baguette, 2 pieces | universal pan | 1 | ® | 180-200 | 90 | 10-20 |
| Potatoe products, frozen | | | | | | |
| Oven chips* | baking tray | 1 | » [*] δ | - | - | - |
| Oven chips, 2 levels** | universal pan + baking tray | 3+1 | ® | 200-220 | - | 30-40 |
| Croquettes* | baking tray | 1 | » [*] δ | - | - | - |
| Hash browns* | universal pan | 2 | » [*] δ | - | - | - |
| Potatoe wedges* | baking tray | 1 | » ∛ | - | - | - |
| Baked goods, frozen, prebaked | d | | | | | |
| Rolls, baguettes* | universal pan | 2 | » [*] δ | - | - | - |
| Rolls, baguettes, 2 levels | grid + universal pan | 3+1 | | 160-180 | - | 15-25 |
| Fried food, frozen | | | | | | |
| Fish fingers* | baking tray | 1 | » ∛ | - | - | - |
| Chicken nuggets* | universal pan | 2 | » _δ | - | - | - |
| Food, chilled | | | | | | |
| Lasagna, 500 g | ovenproof dish on wire rack | 1 | | 180-200 | - | 30-40 |
| Lasagna, 1,5 kg | ovenproof dish on universal pan | 1 | ® | 180-200 | - | 35-45 |
| Food, frozen | | | | | | |
| Lasagna, 500 g* | ovenproof dish on universal pan | 1 | » ∖ | - | - | - |
| Lasagna, 500 g | ovenproof dish on wire rack | 1 | | 200-210 | 360 | 18-23 |
| Lasagna, 1,5 kg | ovenproof dish on wire rack | 1 | <u>®</u> | 160-180 | - | 60-80 |
| * Observe information on the pac | kaging | | | | | |
| ** Turn during cooking | | | | | | |

Microwave

Preparing food in a microwave is ideal if time is of the essence.

Place the cookware onto the wire rack. Always use heat-resistant cookware that is suitable for use in microwaves. Observe the notes on cookware suitable for microwaves.

"Microwave" on page 19

Slide the wire rack in at the indicated shelf position with the imprint "Microwave" facing the appliance door and the outer rail facing downwards.

Food which lies flat will cook more quickly than food which is piled high. Arrange the food as flat as possible in the cookware for this reason.

Cereal products foam a lot during cooking. For all cereal products, such as rice, use tall cookware with a lid.

This will help the food retain its flavour. This means that you can use salt and seasonings sparingly.

If you cannot find any indicated settings for your food quantity, you should extend or reduce the cooking time according to the following basic rule: double the quantity equates to roughly double the cooking time.

Stir or turn the food two to three times during this time. After heating up the food, leave it to rest for two to three minutes to compensate for the temperature difference.

The food transfers heat to the cookware. It can become very hot when only using the microwave for preparation.

Shelf position

Slide the wire rack in at level 1 with the cookware on it.

Steaming fish in the microwave

You can also steam fish in the microwave.

To do so, use enclosed cookware that is suitable for microwave use or use a plate or microwave film to cover the dish. Observe the notes on cookware suitable for microwaves. → "Microwave" on page 19

This will help retain the flavour and means you can use salt and seasonings sparingly. If cooking fish whole, add one to three tablespoons of water or lemon juice.

After cooking, leave the fish to rest for another 2-3 minutes to compensate for the temperature difference.

Take ready-to-eat meals out of the packaging. You can cook more quickly and evenly using cookware which is suitable for use in microwaves.

Custard made from custard powder

Mix custard powder with milk and sugar in a tall, microwave-suitable container according to the information on the packaging. Use the settings indicated in the table.

As soon as the milk starts to rise, stir thoroughly. Repeat this step two to three times.

Making rice pudding

- 1. Weigh the rice and add 4 times as much milk.
- 2. Pour the rice and milk into a tall container which is suitable for microwave use.
- 3. Use the settings indicated in the table.
- As soon as the milk starts to rise, stir thoroughly and reduce the microwave power as indicated in the table.

Stir several times whilst it continues to cook.

Compote

Weigh the fruit in a microwave-suitable container and add a tablespoon of water for every 100 g. Add sugar and spices according to taste. Cover the container and use the settings indicated in the table.

Stir two to three times during the cooking time.

Microwave popcorn

Use flat, heat-resistant glass cookware, e.g. the lid of an ovenproof dish. Do not use porcelain or heavily curved plates.

Place the popcorn bag onto the cookware with the labelled side facing downwards. Use the settings indicated in the table. The time may need to be adjusted, depending on the product and quantity in question.

Remove the popcorn bag after 1½ minutes and shake it to ensure that the popcorn doesn't burn. Wipe the cooking compartment clean after preparation.

Marning – Risk of burns!

Airtight packaging may burst when food is heated. Always observe the instructions on the packaging. Always use oven gloves to remove dishes from the cooking compartment.

Recommended setting values

Tip: You can find additional applications which only use the microwave in sections "Defrosting" and "Heating food"

Type of heating used:

■ Microwave

| Dish | Accessories/cookware | Shelf po- sition | Type of heating | MW power in watts | Cooking time in mins. |
|-----------------------------------------|----------------------|---------------------|-----------------|-------------------|-----------------------|
| Fish | | | | | |
| Fish fillet, plain, braised, 400 g | cookware, covered | 1 | | 600 | 4 |
| | | | | 360 | 3-8 |
| * Turn 1-2 times during cooking | | | | | |
| ** Lay unopened package on the cookware | | | | | |

| Dish | Accessories/cookware | Shelf po- sition | Type of heating | MW power in watts | Cooking time in mins. |
|--------------------------------------------------------------------------|----------------------|---------------------|-----------------|-------------------|-----------------------|
| Vegetables, fresh | | | | | |
| Vegetable, fresh, 250 g* | cookware, covered | 1 | | 600 | 8-12 |
| Vegetable, fresh, 500 g* | cookware, covered | 1 | | 600 | 12-17 |
| Vegetables, frozen | | | | | |
| Spinach, 450 g* | cookware, covered | 1 | | 600 | 13-18 |
| Mixed vegetables, 250 g + 25 ml water* | cookware, covered | 1 | | 600 | 10-14 |
| Mixed vegetables, 500 g + 25 ml water* | cookware, covered | 1 | | 600 | 15-20 |
| Rice | | | | | |
| Long-grain rice, 250 g + 500 ml water | cookware, covered | 1 | | 600 | 7-9 |
| Long-grain rice, 250 g + 500 ml water | cookware, covered | 1 | | 180 | 13-16 |
| Brown rice, 250 g + 650 ml water | cookware, covered | 1 | | 600 | 11-13 |
| Brown rice, 250 g + 650 ml water | cookware, covered | 1 | | 180 | 25-30 |
| Risotto, 250 g + 900 ml water | cookware, covered | 1 | | 600 | 12-14 |
| Risotto, 250 g + 900 ml water | cookware, covered | 1 | | 180 | 22-27 |
| Cereals | | | | | |
| Couscous, 250 g + 500 ml water | cookware, covered | 1 | | 600 | 6-8 |
| Dessert | | | | | |
| Custard out of custard powder* | cookware, covered | 1 | | 600 | 5-8 |
| Rice pudding, 125 g + 500 ml milk* | cookware, covered | 1 | | 600 | 10 |
| Rice pudding, 125 g + 500 ml milk * | cookware, covered | 1 | | 180 | 20-25 |
| Fruit compote, 500 g | cookware, covered | 1 | | 600 | 9-12 |
| Microwavepopcorn, 1 package á 100 g** | cookware, uncovered | 1 | | 600 | 4-6 |
| * Turn 1-2 times during cooking ** Lay unopened package on the cookware | | | | | |

Yogurt

You can make your own yogurt using your appliance.

Preparing yogurt

Remove accessories and shelves from the cooking compartment. The cooking compartment must be empty.

1. Heat 1 litre of milk (3.5 % fat) to 90 °C on the hob and then cool down to 40 °C.

It is sufficient to heat UHT milk to 40 °C.

- 2. Stir in 150 g (chilled) yogurt.
- 3. Pour into cups or small jars and cover with cling film.
- 4. Place the cups or jars onto the cooking compartment floor and use the settings indicated in the table.
- **5.** After preparation, leave the yogurt to cool in the refrigerator.

Type of heating used:

■ ☐ Top/bottom heating

| Dish | Cookware | Shelf position | Tempera- ture in °C | Cooking time in hours |
|---------|-------------------|---------------------------|------------------------|-----------------------|
| Yoghurt | individual moulds | cooking compartment floor | 40-45 | 8-9 |

Eco types of heating

Hot air eco and Top/bottom heating eco are intelligent heating types for the gentle preparation of meat, fish and pastries. The appliance optimally controls the supply of energy to the cooking compartment. The food is prepared in phases using residual heat. This means that it remains more succulent and browns less. Energy can be saved, depending on the preparation and food.

Place the food into the empty cooking compartment before it has heated up. Always keep the appliance door closed when cooking.

Remove unused accessories from the cooking compartment. This will allow you to achieve optimum cooking results and save energy.

Only use original accessories supplied with your appliance. These have been tailored to the cooking compartment and the operating modes of your appliance.

Accessories

Ensure that you always use suitable accessories and that they are placed in the oven the right way around.

Wire rack

Slide the wire rack in with the embossed "microwave" facing the appliance door, and the curved lip pointing downwards. Always place ovenware, tins and dishes on the wire rack.

Universal pan or baking tray

Slide the universal pan or the baking tray in carefully as far as the limit stop with the bevelled edge facing the appliance door.

Baking tins and cookware

Dark- coloured metal baking tins are most suitable. These allow you to make energy savings of up to 35 per cent.

Cookware made from stainless steel or aluminium reflects heat like a mirror. Non-reflective cookware made from enamel, heat-resistant glass or coated, diecast aluminium is more suitable.

Tinplate baking tins, ceramic dishes or glass dishes prolong baking time, and the cake will not brown so evenly.

Greaseproof paper

Only use greaseproof paper that is suitable for the selected temperature. Always cut greaseproof paper to size.

Recommended setting values

Here, you can find specifications for various dishes. The temperature and baking time are dependent on the quantity and composition of the dough. Different settings ranges are indicated for this reason. Try using the lower values at first. A lower temperature results in more even browning. If necessary, use a higher setting the next time.

Note: Baking times can not be reduced by using higher temperatures. Cakes or baked items would only be cooked on the outside, but would not be cooked completely in the middle.

- Medical Eco
- I Top/bottom heating Eco

| Dish | Accessories/cookware | Shelf po- sition | Type of heating | Tempera- ture in °C | Cooking time in mins. |
|-------------------------------|---------------------------------|---------------------|-----------------|------------------------|-----------------------|
| Baking | | | | | |
| Victoria sponge cake | 2x Ø20 cm tins | 1 | ⊕e | 170-180 | 25-35 |
| Light fruit cake | high Ø20 cm tin | 1 | ⊗ e | 150-170 | 70-90 |
| Rich Fruit Cake | high Ø23 cm tin | 1 | ⊕e | 140-160 | 120-180 |
| Fruit crumble | flat glass dish | 1 | ⊕e | 160-180 | 40-60 |
| Sponge cake (fatless), 3 eggs | springform cake tin, Ø26 cm | 1 | ⊕e | 160-170 | 25-35 |
| Swiss Roll | swiss roll tin | 1 | ⊕e | 180-200 | 10-20 |
| Fruit Pie | plate Ø20 cm or pie tin | 1 | ⊕e | 170-190 | 60-75 |
| Quiche | quiche tin (dark coated) | 1 | ⊕e | 190-210 | 35-45 |
| (White) Bread | loaf tin (1x 900 g or 2x 450 g) | 1 | ⊕e | 190-200 | 45-55 |
| Scones | baking tray | 1 | ⊕e | 190-210 | 15-20 |
| Biscuits | baking tray | 2 | ⊕e | 140-160 | 15-30 |
| Jam tarts | 12-cup-tin | 1 | ⊕e | 170-190 | 15-30 |
| Soufflé | 1,2 L-soufflé dish | 1 | ⊕e | 160-170 | 40-50 |
| Meat Pie | rectangular pie tin | 1 | ⊕e | 190-210 | 40-55 |
| Jacket potatoes | baking tray | 2 | ⊕e | 150-170 | 60-90 |
| Meat | | | | | |
| Beef, slow roast joint | wire rack | 1 | ⊕e | 140+150 | 35+40 |

| Dish | Accessories/cookware | Shelf po- sition | Type of heating | Tempera- ture in °C | Cooking time in mins. |
|-------------------------------------------|----------------------|---------------------|--------------------|------------------------|-----------------------|
| Casserole | | | | | |
| Diced meat (beef, pork, lamb), 500 g meat | cookware, covered | 1 | ⊗ e | 140 | 100-120 |
| Braising steak | cookware, covered | 1 | ⊗ e | 140 | 65+60 |
| Fish | | | | | |
| Fish, braised, whole 300 g, e.g. trout | cookware, covered | 1 | e | 190-210 | 25-35 |
| Fish, braised, whole 1,5 kg, e.g. salmon | cookware, covered | 1 | e | 190-210 | 45-55 |
| Fish fillet, plain, braised, 100 g | cookware, covered | 1 | e | 190-210 | 15-35 |

Acrylamide in foodstuffs

Acrylamide is mainly produced in grain and potato products prepared at high temperatures, such as potato

crisps, chips, sliced bread, bread rolls, bread or fine baked goods (biscuits, gingerbread, spiced biscuit).

| Tips for keeping acrylar | nide to a minimum |
|--------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| General | Keep cooking times as short as possible. Cook food until it is golden brown, but not too dark. Large, thick pieces of food contain less acrylamide. |
| Baking | With top/bottom heating at max. 200 °C. With hot air at max. 180 °C. |
| Biscuits | With top/bottom heating at max. 190 °C. With hot air at max. 170 °C. Egg or egg yolk reduces the production of acrylamide. |
| Oven chips | Spread out a single layer evenly on the baking tray. Cook at least 400 g at once on a baking tray so that the chips do not dry out. |

Slow cook

Slow cooking is a technique for cooking food over a long period at low temperatures. For this reason, it is also called "low-temperature cooking".

Slow cooking is ideal for all prime cuts (e.g. tender portions of beef, veal, pork, lamb or poultry) which are to be cooked "à point". The meat will remain succulent and tender.

The benefit of this cooking method is that it allows lots of scope for menu planning because slow-cooked meat is easy to keep warm. You do not have to turn the meat when cooking. Keep the appliance door closed in order to maintain an even cooking climate.

Only use fresh, clean and hygienic meat without bones. Carefully remove sinews and fat from around the edge. Fat develops a strong, distinct flavour during slow cooking. You can also use seasoned or marinated meat. Do not use defrosted meat.

Meat can be carved immediately following slow cooking. No standing time is required. Due to the special cooking method, the meat looks pink, but is not raw or undercooked.

Note: Delayed-start operation with an end time is not possible for the slow cooking heating type.

Cookware

Use flat cookware, e.g. a glass/porcelain serving dish. Place the cookware into the cooking compartment to preheat it.

Always place the uncovered cookware onto the wire rack at level 1.

You can find additional information in the tips on slow cooking attached to the settings table.

Your appliance features the heating type "Slow cook". Only start operation when the cooking compartment has fully cooled down. Allow the cooking compartment to warm up for around 10 minutes with the cookware inside.

Sear the meat on the hotplate at a very high heat and for a sufficiently long time on all sides, even on the ends. Place into the preheated cookware right away. Place the cookware containing the meat into the cooking compartment once again and cook slowly.

Recommended setting values

The slow cooking temperature and cooking time are dependent on the size, thickness and quality of the meat. Different settings ranges are indicated for this reason.

en

Type of heating used:

Slow cooking

| Dish | Cookware | Shelf posi- tion | Heating function | Searing time in mins | Tempera- ture in °C | Cooking time in mins |
|----------------------------------------------|---------------------|---------------------|------------------|----------------------|------------------------|----------------------------|
| Poultry | | | | | | |
| Duck breast, medium rare, 300 g each | Cookware, uncovered | 1 | | 6-8 | 95* | 45-60 |
| Chicken breast fillet, 200 g each, well done | Cookware, uncovered | 1 | | 4 | 120* | 45-60 |
| Turkey breast, boned, 1 kg, well done | Cookware, uncovered | 1 | | 6-8 | 120* | 100-130 |
| Pork | | | | | | |
| Pork tenderloin steak, 5-6 cm thick, 1.5 kg | Cookware, uncovered | 1 | | 6-8 | 85* | 130-180 |
| Fillet of pork, whole | Cookware, uncovered | 1 | | 4-6 | 85* | 45-70 |
| Beef | | | | | | |
| Joint of beef (rump), 6-7 cm thick, 1.5 kg | Cookware, uncovered | 1 | | 6-8 | 100* | 150-190 |
| Fillet of beef, 1 kg | Cookware, uncovered | 1 | | 4-6 | 85* | 90-120 |
| Sirloin, 5-6 cm thick | Cookware, uncovered | 1 | | 6-8 | 85* | 120-180 |
| Beef medallions/rump steak, 4 cm thick | Cookware, uncovered | 1 | | 4 | 85* | 40-60 |
| Veal | | | | | | |
| Joint of veal, 4-5 cm thick, 1.5 kg | Cookware, uncovered | 1 | | 6-8 | 85* | 100-130 |
| Joint of veal, 7-10 cm thick, 1.5 kg | Cookware, uncovered | 1 | | 6-8 | 85* | 150-210 |
| Fillet of veal, whole, 800 g | Cookware, uncovered | 1 | | 4-6 | 85* | 70-120 |
| Veal medallions, 4 cm thick | Cookware, uncovered | 1 | | 4 | 80* | 40-60 |
| Lamb | | | | | | |
| Saddle of lamb, boneless, 200 g each | Cookware, uncovered | 1 | | 4 | 85* | 30-45 |
| Leg of lamb, boned, medium, 1 kg, tied | Cookware, uncovered | 1 | | 6-8 | 95* | 120-180 |
| * Preheat | | | | | | |

Tips for slow cooking

| Slow-cooking duck breast. | Place the cold duck breast into a pan and fry the skin side first. After slow cooking, grill for 3 to 5 minutes until crispy. |
|--------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------|
| The slow-cooked meat is not as hot as conventionally roasted meat. | So that the roasted meat does not cool so quickly, warm the plates and serve the sauces very hot. |

Drying

Your appliance features the heating type "Drying", using which you can dry fruit, vegetables and herbs with outstanding results. With this type of preserving, flavourings are concentrated by the dehydration.

Only use unblemished fruit, vegetables and herbs and wash them thoroughly. Line the wire rack with greaseproof paper or parchment paper. Drain the excess water from the fruit and dry it.

If necessary, cut it into equal chunks or thin slices. Place unpeeled fruit onto the dish with the sliced surfaces facing upwards. Ensure that neither fruit nor mushrooms overlap on the wire rack.

Grate vegetables and then blanch them. Allow the blanched vegetables to drain off and distribute them evenly on the wire rack.

Dry herbs on the stem. Position the herbs evenly and slightly heaped on the wire rack.

Use the following shelf positions for drying:

- 1 wire rack: Level 2
- 2 wire racks: Level 3+1

Turn very juicy fruit and vegetables several times. After drying, remove the dried products from the paper immediately.

Recommended setting values

In the table, you can find settings for drying various foodstuffs. The temperature and cooking time are dependent on the type, moisture, ripeness and thickness of the food to be dried. The longer you leave the food to be dried, the better it will be preserved. The thinner the slices are, the quicker the drying process

will be and the more aromatic the dried food will remain. Setting ranges are indicated for this reason.

If you wish to dry additional foodstuffs, you should use similar foodstuffs in the table as a reference.

Type of heating used:

B Drying

| Dish | Accessories | Shelf posi- tion | Type of heating | Tempera- ture in °C | Cooking time in hours |
|------------------------------------------------------|----------------|---------------------|-----------------|------------------------|-----------------------------|
| Pomes (apple rings, 3 mm thick, 200 g per wire rack) | 1-2 wire racks | - | @ _ | 80 | 4-7 |
| Stone fruit (plums) | 1-2 wire racks | - | ® | 80 | 8-10 |
| Root vegetables (carrots), grated, blanched | 1-2 wire racks | - | <u></u> | 80 | 4-7 |
| Sliced mushrooms | 1-2 wire racks | - | ® 0 | 60 | 6-9 |
| Herbs, washed | 1-2 wire racks | - | ® 0 | 60 | 2-4 |

Preserving

You can preserve fruit and vegetables using your appliance.

⚠ Warning – Risk of injury!

If the food is preserved incorrectly, the preserving jars may burst. Follow the instructions for preserving.

Jars

Use only clean and undamaged preserving jars. Only use heat-resistant, clean and undamaged rubber rings. Check clips and clamps in advance.

For each preserving process, only use preserving jars that are the same size and contain the same food. In the cooking compartment, you can preserve the contents of a maximum of six ½, 1 or 1½-litre preserving jars at the same time. Do not use jars that are larger or taller than this. The lids could rupture.

Preserving jars must not touch one another in the cooking compartment during the preserving process.

Preparing fruit and vegetables

Only use fruit and vegetables that are in good condition. Wash them thoroughly.

Peel, core and chop fruit and vegetables appropriate to their type and fill the preserving jars with them up to approx. 2 cm below the rim.

Fruit

Fill the preserving jars with the fruit along with a hot, skimmed sugar solution (approx. 400 ml for a 1-litre jar). For one litre of water:

- Approx. 250 g sugar for sweet fruit
- Approx. 500 g sugar for sour fruit

Vegetables

Fill the jars with the vegetables along with hot, boiled water

Wipe the rims of the jars, as they must be clean. Place a damp rubber ring and a lid on each jar. Seal the jars with clamps. Place the jars into the universal pan so that they do not touch each other. Pour 500 ml hot water (approx. 80 °C) into the universal pan. Use the settings indicated in the table.

Ending the preserving process

Fruit

After a short while, small bubbles will form at short intervals. Switch off the appliance once all preserving jars are bubbling. Remove the jars from the cooking compartment after the indicated cooling time.

Vegetables

After a short while, small bubbles will form at short intervals. As soon as all preserving jars are bubbling, reduce the temperature to 120 °C and allow the jars to continue to bubble in the closed cooking compartment as indicated in the table. After this time has elapsed, switch off the appliance and make use of the residual heat for several minutes as indicated in the table.

After preserving, remove the jars from the cooking compartment and place them onto a clean cloth. Do not place these hot jars onto a cold or damp surface, as they may crack. Cover the preserving jars to protect them from draughts. Only remove the clamps once the jars are cold.

Recommended setting values

The indicated times in the settings table are average values for preserving fruit and vegetables. They may be influenced by room temperature, the number of jars, quantity, heat and quality of the jar contents. The specifications are based on 1-litre round jars. Before you switch off the appliance or change the cooking mode, check whether the contents of the jars are bubbling as they should. The bubbling process starts after approx. 30-60 minutes.

Type of heating used:

| Dish | Cookware | Shelf posi- tion | Type of heating | Tempera- ture in °C | Cooking time in mins. |
|-------------------------------------|------------------------------------------------------|-----------------------------------------------|-----------------|----------------------------------|----------------------------------|
| Preserving | | | | | |
| Vegetables, e.g. carrots | Vegetables, e.g. carrots 1-litre preserving jars 1 💽 | 1 🛞 | 160-170 | Before it starts bubbling: 30-40 | |
| | | | 120 | When it starts to bubble: 30-40 | |
| | | | | - | Residual heat: 30 |
| Vegetables, e.g. cucumbers | cumbers 1-litre preserving jars 1 🚇 | s, e.g. cucumbers 1-litre preserving jars 1 🚇 | ® | 160-170 | Before it starts bubbling: 30-40 |
| | | | | - | Residual heat: 30 |
| Stone fruit, e.g. cherries, damsons | 1-litre preserving jars | 1 | ® | 160-170 | Before it starts bubbling: 30-40 |
| | | | | - | Residual heat: 35 |
| Pomes, e.g. apples, strawberries | 1-litre preserving jars | 1 | ® | 160-170 | Before it starts bubbling: 30-40 |
| | | | | - | Residual heat: 25 |

Prove dough

You can prove yeast dough in your appliance more quickly than at room temperature. Use the top/bottom heating type. Only start operation when the cooking compartment has fully cooled down.

Always allow yeast dough to prove twice. Observe the specifications in the settings tables for the 1st and 2nd proving processes (dough fermentation and final fermentation).

Dough fermentation

Use the settings indicated in the table and heat up the appliance. Position the dough bowl on the wire rack.

Do not open the appliance door during the proving process, as moisture will escape. Cover the dough with a damp cloth.

Final fermentation

Place your baked item into the oven at the shelf position indicated in the table.

If you want to preheat the oven, the final fermentation takes place outside the appliance in a warm place.

Recommended setting values

The temperature and proving time are dependent on the type and quantity of the ingredients. The values in the table are therefore only meant to be average values.

Type of heating used:

■ □ Top/bottom heating

| Dish | Accessories/cookware | Shelf posi- tion | Type of heating | Tempera- ture in °C | Cooking time in mins. |
|-----------------------------|----------------------|---------------------|-----------------|------------------------|-----------------------------|
| Yeast dough, light | Bowl | 1 | | 35-40 | 25-30 |
| | Baking tray | 1 | | 35-40 | 10-20 |
| Yeast dough, heavy and rich | Bowl | 1 | | 35-40 | 20-40 |
| | Baking tray | 1 | | 35-40 | 15-25 |

Defrosting

Use the "Microwave" operation mode to defrost frozen fruit, vegetables, poultry, meat, fish and baked items.

Remove the frozen food from its packaging and place it onto the wire rack in cookware suitable for microwave use. Observe the notes on cookware suitable for microwaves. — "Microwave" on page 19

Slide the wire rack in with the imprint "Microwave" facing the appliance door and the outer rail facing downwards.

Remove unused accessories from the cooking compartment. This will allow you to achieve optimum cooking results and save energy.

Recommended setting values

The times in the table are average values. They are dependent on the quality, freezing temperature (-18 °C) and composition of the food. Time ranges are indicated. Set the shortest time first and then extend the time if necessary. You can often achieve better results when defrosting in several steps. These are indicated one below the other in the table.

Tip: Items which were frozen flat or portioned defrost faster than those frozen in a block.

Stir the food or turn it once or twice in between. Large pieces of food should be turned several times. Occasionally split the food or remove items which have already defrosted from the cooking compartment.

Leave the defrosted food to rest for another 10 to 30 minutes in the appliance whilst it is switched off, so that the temperature balances out.

Tip: If you have quantities other than those indicated in the settings table, this basic rule will help: double the quantity equates to roughly double the cooking time.

Type of heating used:
■ Microwave

| Dish | Accessories/cookware | Shelf posi- tion | Type of heating | Tempera- ture in °C | MW power in watts | Cooking time in mins. |
|----------------------------------------------|----------------------|---------------------|-----------------|------------------------|-------------------|-----------------------------|
| Bread, bread rolls | | | | | | |
| Bread, 500 g | Cookware, uncovered | 1 | | - | 180 | 3 |
| | | | | - | 90 | 10-15 |
| Bread rolls | Wire rack | 1 | (A) | 140-160 | 90 | 2-4 |
| Cake | | | | | | |
| Cake, moist, 500 g | Cookware, uncovered | 1 | | - | 180 | 2 |
| | | | | - | 90 | 10-15 |
| Cake, dry, 750 g | Cookware, uncovered | 1 | | - | 90 | 10-15 |
| Meat and poultry | | | | | | |
| Chicken, whole, 1.2 kg* | Cookware, uncovered | 1 | | - | 180 | 10 |
| | | | | - | 90 | 10-15 |
| Poultry portions, 250 g* | Cookware, uncovered | 1 | | - | 180 | 10 |
| | | | | - | 90 | 10-15 |
| Duck, 2 kg* | Cookware, uncovered | 1 | | - | 180 | 10 |
| | | | | - | 90 | 40-50 |
| Whole pieces of meat, e.g. joint (raw meat), | Cookware, uncovered | 1 | | - | 180 | 15 |
| 800 g | | | | - | 90 | 10-15 |
| Whole pieces of meat, e.g. joint (raw meat), | Cookware, uncovered | 1 | | - | 180 | 15 |
| 1 kg* | | | | - | 90 | 20-30 |
| Whole pieces of meat, e.g. joint (raw meat), | Cookware, uncovered | 1 | | - | 180 | 15 |
| 1.5 kg* | | | | - | 90 | 25-35 |
| Meat, in pieces or slices, e.g. goulash (raw | Cookware, uncovered | 1 | | - | 180 | 8 |
| meat), 500 g* | | | | - | 90 | 5-10 |
| Minced meat, mixed, 200 g* | Cookware, uncovered | 1 | | - | 90 | 8-15 |
| Minced meat, mixed, 500 g* | Cookware, uncovered | 1 | | - | 180 | 5 |
| | | | | - | 90 | 10-15 |
| Minced meat, mixed, 1000 g* | Cookware, uncovered | 1 | | - | 180 | 10 |
| | | | | - | 90 | 20-30 |
| Fish | | | | | | |
| Fish, whole, 300 g* | Cookware, uncovered | 1 | | - | 180 | 3 |
| | | | | - | 90 | 10-15 |
| Fish fillet, 400 g* | Cookware, uncovered | 1 | | - | 180 | 5 |
| | | | | - | 90 | 10-15 |
| Fruit, vegetables | | | | | | |
| Berries, 300 g | Cookware, uncovered | 1 | | - | 180 | 5-10 |
| Vegetables, 600 g | Cookware, uncovered | 1 | | - | 180 | 10 |
| | , | | | | 90 | 8-13 |

| Dish | Accessories/cookware | Shelf posi- tion | Type of heating | Tempera- ture in °C | MW power in watts | Cooking time in mins. |
|-------------------------------------|----------------------|---------------------|-----------------|------------------------|-------------------|-----------------------------|
| Miscellaneous | | | | | | |
| Defrosting butter, 125 g | Cookware, uncovered | 1 | | - | 90 | 7-9 |
| * Turn halfway through cooking time | | | | | | |

Heating food in a microwave

Using the microwave, you can heat food, or defrost and heat it in a single step.

Take ready-to-eat meals out of the packaging. The food will heat up more quickly and evenly in cookware that is suitable for microwaves. The various components of a dish may require different times to heat up.

Food which lies flat will cook more quickly than food which is piled high. Arrange the food as flat as possible in the cookware for this reason. Food should not be vertically stacked.

Cover the food. This will ensure better cooking results. If you do not have a lid that fits your cookware, use a plate or microwave film for this purpose.

Stir food two to three times during cooking and turn it if necessary. After heating food up, leave it to rest for 1 to 2 minutes to compensate for the temperature difference.


If you are heating up baby food, place the bottle onto the wire rack without the teat or the lid. After heating up, shake well or stir and be sure to check the temperature.

The food transfers heat to the cookware. It can become very hot when only using the microwave for preparation.

Tip: If you have quantities other than those indicated in the settings table, this basic rule will help: double the quantity equates to roughly double the cooking time.

Marning – Risk of scalding!

There is a possibility of delayed boiling when a liquid is heated. This means that the liquid reaches boiling temperature without the usual steam bubbles rising to the surface. Even if the container only vibrates a little, the hot liquid may suddenly boil over and spatter. When heating, always place a spoon in the container. This will prevent delayed boiling.



Caution!

Creation of sparks: Metal – e.g. a spoon in a glass – must be kept at least 2 cm from the cooking compartment walls and the inside of the door. Sparks can irreparably damage the glass on the inside of the door.

Recommended setting values

In the table, you can find the setting values for heating various drinks and foodstuffs up in the microwave. The times specified are only average values. These depend on the cookware used, the quality, temperature and composition of the food in question. Time ranges are indicated. Set the shortest time first and then extend the time if necessary.

The values in the table apply to food placed into a cold cooking compartment.

If no values are indicated for your food, use similar foods in the table as orientation.

Remove any accessories from the cooking compartment which are not being used. This will ensure optimum cooking results and will also save energy.

Wipe the cooking compartment clean after cooking.

Type of heating used:

■ Microwave

| Dish | Cookware | Shelf posi- tion | Type of heating | Temperature in °C | MW power in watts | Cooking time in mins. |
|----------------------------------|---------------------|---------------------|-----------------|-------------------|-------------------|-----------------------|
| Heating drinks | | | | | | |
| 200 ml (stir well) | Cookware, uncovered | 1 | | - | max | 1-3 |
| 400 ml (stir well) | Cookware, uncovered | 1 | | - | max | 2-6 |
| Heating baby food | | | | | | |
| Baby bottles, 150 ml (stir well) | Cookware, uncovered | 1 | | - | 360 | 1-3 |
| Vegetables, chilled | | | | | | |
| 250 g | Cookware, covered | 1 | | - | 600 | 3-8 |

| Dish | Cookware | Shelf posi- tion | Type of heating | Temperature in °C | MW power in watts | Cooking time in mins. |
|-----------------------------------------------------------|---------------------|---------------------|-----------------|-------------------|-------------------|-----------------------|
| Vegetables, frozen | | | | | | |
| loose, 250 g | Cookware, covered | 1 | | - | 600 | 8-12 |
| Creamed spinach, frozen block, 450 g | Cookware, covered | 1 | | - | 600 | 11-16 |
| Dishes, chilled | | | | | | |
| Plated meal, 1 portion | Cookware, covered | 1 | | - | 600 | 4-8 |
| Soup, stew, 400 ml | Cookware, covered | 1 | | - | 600 | 5-7 |
| Side dishes, e.g. pasta, dumplings, potatoes, rice | Cookware, covered | 1 | | - | 600 | 5-10 |
| Bakes, 400 g, e.g. lasagne, potato gratin | Cookware, uncovered | 1 | | - | 600 | 5-10 |
| Dishes, frozen | | | | | | |
| Plated meal, 1 portion | Cookware, covered | 1 | | - | 600 | 11-15 |
| Soup, stew, 200 ml (stir well) | Cookware, covered | 1 | | - | 600 | 4-6 |
| Side dishes, 500 g, e.g. pasta, dumplings, potatoes, rice | Cookware, covered | 1 | | - | 600 | 7-10 |
| Bakes, 400 g, e.g. lasagne, potato gratin | Cookware, uncovered | 1 | I | 180-200 | 180 | 20-25 |

Keeping warm

You can keep cooked dishes warm using the "Keeping warm" heating type. This will avoid condensation developing, and means you will not have to wipe out the cooking compartment.

Do not keep cooked dishes warm for longer than two hours. Be aware that some dishes may continue cooking whilst being kept warm. Cover the dishes if necessary.

Test dishes

These tables have been produced for test institutes to facilitate the inspection of the appliance.

As per EN 60350-1:2013 and IEC 60350-1:2011 and as per standard EN 60705:2012, IEC 60705:2010.

Baking

Baked items that are placed into the oven on trays or in baking tins/dishes at the same time will not necessarily be ready at the same time.

Shelf positions for baking on two levels:

 Universal pan: Level 3 Baking tray: Level 1

Apple pie

Apple pie on one level: place dark-coloured springform cake tins diagonally next to each other.

Cakes in tinplate springform cake tins: bake on one level with top/bottom heating. Place the springform cake tin onto the universal pan instead of onto the wire rack.

Fatless sponge cake

Fatless sponge cake on two levels: vertically stack springform cake tins in an offset manner on the wire racks.

Notes

- The setting values apply to dishes placed into a cold cooking compartment.
- Please note the information in the tables about preheating. The setting values are valid without rapid heating-up.
- For baking, use the lower of the indicated temperatures first.

- □ Top/bottom heating
- Pizza setting
- Intensive heat

| Dish | Accessories/cookware | Shelf position | Type of heating | Tempera- ture in °C | Cooking time in mins. | |
|------------------------------------------------------|----------------------|----------------|-----------------|------------------------|-----------------------------|--|
| Baking | | | | | | |
| Shortbread | Baking tray | 1 | | 150-160* | 20-30 | |
| Shortbread | Baking tray | 1 | (A) | 140-150* | 25-35 | |
| * Preheat for 5 mins, do not use quick heat function | | | | | | |
| ** Preheat, do not use quick heat function | | | | | | |

| Dish | Accessories/cookware | Shelf posi- tion | Type of heating | Tempera- ture in °C | Cooking time in mins. | |
|------------------------------------------------------|--------------------------------------|---------------------|-----------------|------------------------|-----------------------------|--|
| Small cakes | Baking tray | 1 | | 160* | 25-35 | |
| Small cakes | Baking tray | 1 | ® | 150* | 20-30 | |
| Small cakes, 2 levels | Universal pan + baking tray | 3+1 | ® | 140* | 30-40 | |
| Fatless sponge cake | Springform cake tin, diameter 26 cm | 1 | | 160-170** | 25-35 | |
| Fatless sponge cake | Springform cake tin, diameter 26 cm | 1 | ® | 160-170** | 30-45 | |
| Apple pie | 2 x black plate tins, diameter 20 cm | 1 | | 170-180 | 65-90 | |
| Apple pie | 2 x black plate tins, diameter 20 cm | 1 | <u>®</u> | 170-180 | 60-80 | |
| * Preheat for 5 mins, do not use quick heat function | | | | | | |

^{**} Preheat, do not use quick heat function

Grilling

Also slide in the universal pan. The liquid will be caught and the cooking compartment stays cleaner.

Type of heating used:

Grill, large area

| Dish | Accessories | Shelf posi- tion | Type of heating | Grill setting | Cooking time in mins. |
|------------------------------------|-------------|---------------------|-----------------|------------------|-----------------------|
| Grilling | | | | | |
| Browning toast | Wire rack | 3 | "" | 3 | 2-6 |
| Beefburgers, x 12* | Wire rack | 2 | | 3 | 20-30 |
| * Turn after 2/3 of the total time | | | | | |

Preparing food with a microwave

When preparing food in a microwave, always use cookware which is heat-resistant and suitable for microwave use. Observe the notes on cookware suitable for microwaves.

"Microwave" on page 19


If you place your cookware onto the wire rack, slide the wire rack in with the imprint "Microwave" facing the appliance door and the outer rail facing downwards.

- Microwave

| Dish | Accessories/cookware | Shelf posi- tion | Type of heating | Tempera- ture in °C | MW power in watts | Cooking time in mins. |
|------------------------------------|----------------------|---------------------|-----------------|------------------------|-------------------|-----------------------|
| Microwave defrosting | | | | | | |
| Meat | Cookware, uncovered | 1 | | - | 180 | 5 |
| | | | | | 90 | 10-15 |
| Microwave cooking | | | | | | |
| Egg wash | Cookware, uncovered | 1 | | - | 360 | 20 |
| | | | | | 180 | 20-25 |
| Sponge flan | Cookware, uncovered | 1 | | - | 600 | 7-9 |
| Meat loaf | Cookware, uncovered | 1 | | - | 600 | 22-27 |
| Combined microwave cooking | | | | | | |
| Potato gratin | Cookware, uncovered | 1 | z | 150-170 | 360 | 25-30 |
| Cake | Cookware, uncovered | 1 | | 190-210 | 180 | 12-18 |
| Chicken* | Cookware, uncovered | 1 | II. | 180-200 | 360 | 25-35 |
| * Turn after 2/3 of the total time | | | | | | |







BSH Hausgeräte GmbH Carl-Wery-Str. 34, 81739 München GERMANY

siemens-home.bsh-group.com

Manufactured by BSH Hausgeräte GmbH under Trademark License of Siemens AG