



MICRODRAWER® OVEN

Sensor Cooking, Defrost, and More Modes

Sensor Cooking

- Sensor cooking controls humidity and automatically adjusts the cooking level and time
- View the menu label for Sensor Cook Options and select the number that corresponds with the desired food
- Do not open the door during the sensing process or the process will be canceled
- Each food has a cooking hint. To access this press the timer / settings button and it will provide specific hints

SENSOR COOK

- | | |
|-------------------|-----------------------------|
| 1. Baked Potatoes | 6. Fresh Vegetables: Quick |
| 2. Sweet Potatoes | 7. Fresh Vegetables: Longer |
| 3. Fish/Seafood | 8. Frozen Vegetables |
| 4. Brown Rice | 9. Ground Meat |
| 5. White Rice | 10. Frozen Entrees |

Defrost

- Touch Defrost Key, refer to label to select the number correlating to your need
- Enter the weight and touch start (+30 secs)
- After each audible signal, turn the food over and touch the start (30+) again

DEFROST

- | | |
|---------------------|----------------------|
| 1. Ground Meat | 4. Bone-in Poultry |
| 2. Steaks/Chops | 5. Roast |
| 3. Boneless Poultry | 6. Casserole or Soup |

More Modes

- Addition modes can be accessed by selecting the more modes key
- View menu label and enter the number key that corresponds with your desired mode
- Follow the instructions on screen, enter the quantity, then touch start key to begin

MORE MODES

- | | |
|-------------------------|---------------------------------|
| 1. Melt Butter | 7. Beverage Reheat |
| 2. Melt Chocolate | 8. Hot Water |
| 3. Soften Ice Cream | 9. Hot Cereal |
| 4. Soften Cream Cheese | 10. Reheat Fresh Rolls/Muffins |
| 5. Warm Syrup | 11. Reheat Frozen Rolls/Muffins |
| 6. Warm Dessert Topping | 12. Keep Warm |