




PKC8..T..
Hob

 **BOSCH**

[en] Instruction manual



en Table of contents

Safety precautions	2	Automatic childproof lock	7
Causes of damage	3	Timer	8
Environmental protection	4	Automatic hotplate switch-off	8
Environmental protection	4	Automatic timer	8
Tips for saving energy	4	Kitchen timer	8
Getting to know your appliance	4	Automatic time limit	8
The control panel	4	Basic settings	9
The hotplates	4	Changing the basic settings	9
Residual heat indicator	5	Cleaning and care	10
Setting the hob	5	Ceramic	10
Switching the hob on and off	5	Hob surround	10
Setting a hotplate	5	Rectifying faults	10
Table of cooking times	5	After-sales service	11
Electronic boil start control	6		
Setting the electronic boil start control	6		
Table of cooking times for electronic boil start control	7		
Tips for the electronic boil start control	7		
Childproof lock	7		
Switching the childproof lock on and off	7		

Additional information on products, accessories, replacement parts and services can be found at www.bosch-home.com and in the online shop www.bosch-eshop.com

⚠ Safety precautions

Please read this manual carefully. Please keep the instruction and installation manual as well as the appliance certificate in a safe place for later use or for subsequent owners.

Check the appliance for damage after unpacking it. Do not connect the appliance if it has been damaged in transport.

This appliance is intended for domestic use and the household environment only. This appliance must only be used for food

preparation. Do not leave the appliance unattended during operation.

This appliance may be used by children 8 years old and older and by persons with reduced physical, sensory or mental capacity or a lack of experience or knowledge if they are supervised or they have been instructed about the safe use of the appliance and have understood the associated dangers.

Never let children play with the appliance. Cleaning and user

maintenance must not be carried out by unsupervised children.

Risk of fire!

- Hot oil and fat can ignite very quickly. Never leave hot fat or oil unattended. Never use water to put out burning oil or fat. Switch off the hotplate. Extinguish flames carefully using a lid, fire blanket or something similar.
- The hotplates become very hot. Never place combustible items on the hob. Never place objects on the hob.
- The appliance gets hot. Do not keep combustible objects or aerosol cans in drawers directly underneath the hob.
- The hob switches off automatically and can no longer be operated. It may switch on unintentionally at a later point. Switch off the circuit breaker in the fuse box. Contact the after-sales service.

Risk of burns!

- The hotplates and surrounding area become very hot. Never touch the

Causes of damage

Caution!

- Rough pot and pan bases scratch the ceramic.
- Avoid boiling pots dry. This may cause damage.
- Never place hot pots or pans on the control panel, the display area or the surround. This may cause damage.

Overview

The following table provides an overview of the most frequent kinds of damage:

Damage	Cause	Action
Stains	Food spills	Remove spills immediately with a glass scraper.
	Unsuitable cleaning agents	Only use cleaning agents which are suitable for ceramic
Scratches	Salt, sugar and sand	Do not use the hob as a work surface or storage space.
	Rough pot and pan bases scratch the ceramic.	Check your cookware.
Discolouration	Unsuitable cleaning agents	Only use cleaning agents which are suitable for ceramic
	Pan abrasion (e.g. aluminium)	Lift the pots and pans when moving them.
Blisters	Sugar, food with a high sugar content	Remove spills immediately with a glass scraper.

hot surfaces. Children under 8 years old must be kept at a safe distance from the appliance.

- The hotplate heats up but the display does not work. Switch off the circuit breaker in the fuse box. Contact the after-sales service.

Risk of electric shock!

- Cracks or fractures in the glass ceramic may cause electric shocks. Switch off the circuit breaker in the fuse box. Contact the after-sales service.
- Cleaning the appliance with steam may cause electric shocks. Do not use steam cleaners.
- Incorrect repairs are dangerous. Repairs must only be carried out by a trained after-sales engineer. If the appliance is defective, switch off the circuit breaker in the fuse box.

Risk of injury!

Saucepans may suddenly jump due to liquid between the pan base and the hotplate. Always keep the hotplate and saucepan bases dry.

- Damage can occur if hard or pointed objects fall on the hob.
- Aluminium foil and plastic containers melt on hot hotplates. Oven protective foil is not suitable for your hob.

Environmental protection

Unpack the appliance and dispose of the packaging in an environmentally-responsible manner.

Environmental protection



This appliance is labelled in accordance with the European Directive 2002/96/EU concerning used electrical and electronic appliances (WEEE – waste electrical and electronic equipment). The guideline determines the framework for the return and recycling of used appliances as applicable.

Tips for saving energy


■ Always use the right lid for the pan in question. Cooking without the lid requires four times as much energy.

- Use pots and pans with even bases. Using cookware with uneven bases increases energy consumption.
- The diameter of the base of your pot or pan should match the size of the hotplate. In particular, if pots that are too small are placed on the hotplate, energy is wasted. Please note: Cookware manufacturers often specify the diameter of the top of the pan. This is usually bigger than the diameter of the base of the pan.
- Use a small pan for small quantities of food. A larger, less full saucepan requires more energy.
- Use only a little water when cooking. This saves energy. It also preserves vitamins and minerals in vegetables.
- Switch to a lower heat setting as soon as possible.
- Use the residual heat of the hob. For longer cooking times, you can switch the hotplate off 5 - 10 minutes before the end of the cooking time.

Getting to know your appliance

An overview of the models with their dimensions is given on page 2.

The control panel



Controls

When you touch a symbol, the respective function is activated.

Notes

- The settings will remain unchanged if you touch several symbols at once. This allows you to wipe up spills on the control panel.
- Always keep the controls dry. Moisture reduces their effectiveness.

The hotplates

Hotplate	Activating and deactivating
○ Single-circuit hotplate	
◎ Dual-circuit hotplate	Touch the ◎ symbol
⊖ Dual-circuit hotplate, hotplate with extended cooking zone	Touch the ⊖ symbol; the 2nd filament circuit is activated. Touch the ⊖ symbol; the extended cooking zone is activated.

When the hotplate is activated: the corresponding display lights up.

When the hotplate is switched on: the last selected size is automatically selected again

Residual heat indicator

The hob has a two-stage residual heat indicator for each hotplate.

If **H** appears in the display the hob is still hot. It may be used, for example, to keep a small meal warm or to melt cooking chocolate. As the hotplate cools down further, the display changes to **h**. The display remains lit until the hotplate has cooled sufficiently.

Setting the hob

This section informs you how to set the hotplates. The table shows heat settings and cooking times for various meals.

Switching the hob on and off

The main switch is used to switch the hob on and off.

To switch on: touch the **①** symbol. A signal sounds. The indicator above the main switch lights up. The hob is ready for use.

To switch off: touch the **①** symbol until the display above the main switch goes out. All hotplates are switched off. The residual heat indicator remains on until the hotplates have cooled down sufficiently.

Note: The hob switches off automatically if all hotplates have been switched off for more than 20 seconds.

Setting a hotplate

Use the **+** and **-** symbols to set the desired heat setting.

Heat setting 1 = lowest setting

Heat setting 9 = highest setting

There is an intermediate setting between each heat setting. This is identified by a dot.

Set the heat setting:

The hob must be switched on.


1. Touch the **+** or **-** symbol.

D lights up in the display.

2. Touch the **+** or **-** symbol within the next 10 seconds. The basic setting appears.

+ symbol: heat setting 9

- symbol: heat setting 4



3. Changing the heat setting: touch the **+** or **-** symbol until the desired heat setting appears.

Note: Hotplate temperature is regulated by the heat switching on and off. The heat may also switch on and off at the highest setting.

Switching off the hotplate

Touch the **+** or **-** symbol until **D** appears. After about 10 seconds, the residual heat indicator appears.

When heating thick liquids, stir regularly.

For bringing liquids to the boil, use heat setting 9.

Table of cooking times

The following table provides some examples.

Cooking times and heat settings may vary depending on the type of food, its weight and quality. Deviations are therefore possible.

	Ongoing cooking setting	Ongoing cooking time in minutes
Melting		
Chocolate, cooking chocolate, butter, honey	1-2	-
Gelatine	1-2	-
Heating and keeping warm		
Stew (e.g. lentil stew)	1-2	-
Milk**	1-2.	-
Heating sausages in water**	3-4	-
Defrosting and heating		
Frozen spinach	2.-3.	20-30 mins
Frozen goulash	2.-3.	10-15 mins
Poaching, simmering		
Dumplings	4.-5.	20-30 mins
Fish	4-5*	10-15 mins
White sauces, e.g. béchamel sauce	1-2	3-6 mins
Emulsified sauces, e.g. béarnaise sauce, hollandaise sauce	3-4	8-12 mins

* Continue cooking without a lid

** Without lid

	Ongoing cooking setting	Ongoing cooking time in minutes
Boiling, steaming, stewing		
Rice (with double the quantity of water)	2-3	15-30 mins
Rice pudding	1.-2.	25-35 mins
Unpeeled boiled potatoes	4-5	25-30 mins
Boiled potatoes	4-5	15-25 mins
Pasta, noodles	6-7*	6-10 mins
Stew, soups	3.-4.	15-60 mins
Vegetables	2.-3.	10-20 mins
Vegetables, frozen	3.-4.	10-20 mins
Cooking in a pressure cooker	4-5	-
Braising		
Roulades	4-5	50-60 mins
Pot roasts	4-5	60-100 mins
Goulash	2.-3.	50-60 mins
Frying**		
Escalope, plain or breaded	6-7	6-10 mins
Escalope, frozen	6-7	8-12 mins
Cutlet, plain or breaded	6-7	8-12 mins
Steak (3 cm thick)	7-8	8-12 mins
Poultry breast (2 cm thick)	5-6	10-20 mins
Chicken breast, frozen	5-6	10-30 mins
Fish and fish fillet, plain	5-6	8-20 mins
Fish and fish fillet, breaded	6-7	8-20 mins
Fish and fish fillet, breaded and frozen, e.g. fish fingers	6-7	8-12 mins
Scampi and prawns	7-8	4-10 mins
Stir fry, frozen	6-7	6-10 mins
Pancakes	6-7	continuous
Omelette	3.-4.	continuous
Fried eggs	5-6	3-6 mins
Deep-fat frying (fry 150-200g per portion continuously in 1-2 litres oil**)		
Frozen products, e.g. chips, chicken nuggets	8-9	-
Croquettes	7-8	-
Meat balls	7-8	-
Meat, e.g. chicken portions	6-7	-
Fish, breaded or battered	5-6	-
Vegetables, mushrooms, breaded or battered	5-6	-
Small items, e.g. doughnuts, fruit in batter	4-5	-

* Continue cooking without a lid

** Without lid

Electronic boil start control

The electronic boil start control heats the hotplate using the highest heat setting and then switches down to the simmer setting you have selected.

The time taken for the hotplate to heat up depends on the simmer setting selected.

Setting the electronic boil start control

The electronic boil start control can only be activated in the first 30 seconds after you have switched on the hotplate:

1. Set the desired simmer setting for the hotplate.
2. Touch the  symbol.

The electronic boil start control is activated.  and the ongoing cooking setting flash alternately.

After the food has been brought to the boil, only the simmer setting remains lit in the display.

Table of cooking times for electronic boil start control

The table below shows which dishes electronic boil start control can be used for.

The smaller quantities specified are for the smaller hotplates and the larger quantities are for the larger hotplates. The values given are guidelines.

Dish with electronic boil start control	Quantity	Heat setting	Total cooking time in minutes
Heating			
Stock	500 ml-1 litre	A 7-8	4-7 mins
Thick soups	500 ml-1 litre	A 2-3	3-6 mins
Milk**	200-400 ml	A 1-2	4-7 mins
Heating and keeping warm			
Stew (e.g. lentil stew)	400-800 g	A 1-2	-
Defrosting and heating			
Frozen spinach	300-600 g	A 2-3.	10-20 mins
Frozen goulash	500g-1 kg	A 2-3.	20-30 mins
Poaching			
Fish	300-600 g	A 4-5*	20-25 mins
Boiling			
Rice (with double the quantity of water)	125-250 g	A 2-3	20-25 mins
Unpeeled boiled potatoes with 1-3 cups of water	750 g-1.5 kg	A 4-5	30-40 mins
Boiled potatoes with 1-3 cups of water	750 g-1.5 kg	A 4-5	20-30 mins
Vegetables with 1-3 cups of water	500g-1 kg	A 2-3.	15-20 mins
Frozen vegetables with 1-3 cups of water	500g-1 kg	A 4-.5.	15-20 mins
Braising			
Roulades	4 pieces	A 4-5	50-60 mins
Pot roasts	1 kg	A 4-5	80-100 mins
Frying**			
Escalope, plain or breaded	1-2	A 6-7	8-12 mins
Cutlet, plain or breaded	1-2	A 6-7	8-12 mins
Steak (3 cm thick)	1-2	A 7-8	8-12 mins
Fish and fish fillet, breaded	1-2	A 6-7	8-12 mins
Fish and fish fillet, breaded and frozen, e.g. fish fingers	200-300 g	A 6-7	8-12 mins
Pancakes		A 6-7	continuous frying

* Continue cooking without a lid

** Without lid

Tips for the electronic boil start control

Electronic boil start control is designed to conserve food's nutritional value while using little water for cooking.

- Add only approximately 3 cups of water to the food for large hotplates and approximately 2 cups of water for small hotplates.
- Place a lid on the saucepan.
- Electronic boil start control is not suitable for food that is cooked in a large volume of water (e.g. pasta).

Childproof lock

You can use the childproof lock to prevent children from switching on the hotplates.

Switching the childproof lock on and off

The hob must be switched off.

To switch on: touch the  symbol for approx. 4 seconds. The  symbol lights up for 10 seconds. The hob is locked.

To switch off: touch the  symbol for approx. 4 seconds. The hob is unlocked.

Automatic childproof lock

This function automatically activates the childproof lock every time you switch the hob off.

Switching on and off

You can find out how to switch the automatic childproof lock on and off in the Basic settings section.

Timer

The timer can be used in two different ways:


- To switch a hotplate off automatically
- As a kitchen timer

Automatic hotplate switch-off

Enter a cooking time for the relevant hotplate. When the cooking time has elapsed, the hotplate switches off automatically.

Setting the cooking time:

1. Set the heat setting.
2. Touch the \odot symbol. The \rightarrow indicator for the desired hotplate lights up. 00 lights up on the timer display. To select a different hotplate, touch the \odot symbol repeatedly until the \rightarrow indicator for the desired hotplate lights up.
3. Touch the + or - symbol. The default value appears.
 - + symbol: 30 minutes
 - symbol: 10 minutes



4. Touch the + or - symbol until the desired cooking time appears on the timer display.

The cooking time counts down. If you have set a cooking time for several hotplates, you can display each cooking time. To do this, touch the \odot symbol repeatedly until the \rightarrow indicator lights up brightly for the desired hotplate.

When the cooking time has elapsed

When the cooking time has elapsed, the hotplate switches off. D lights up in the hotplate display. The \rightarrow indicator for the hotplate lights up brightly. A signal sounds. 00 lights up on the

timer display for 10 seconds. Touch the \odot symbol. The displays go out and the audible signal ceases.

Changing or cancelling the cooking time

Touch the \odot symbol repeatedly until the desired \rightarrow indicator lights up brightly. Use the + or - symbol to change the cooking time or to set to 00 .

Note: You can set a cooking time of up to 99 minutes.

Automatic timer

You can use this function to preselect a cooking time for all hotplates. Each time a hotplate is switched on, the preselected cooking then counts down. When the cooking time has elapsed, the hotplate switches off automatically.

You can find out how to switch on the automatic timer in the Basic settings section.

Note: You can change the cooking time for a hotplate or switch off the automatic timer for the hotplates.

Touch the \odot symbol repeatedly until the desired \rightarrow indicator lights up brightly. Use the + or - symbol to change the cooking time or to set to 00 .

Kitchen timer

You can use the kitchen timer to set a time of up to 99 minutes. It runs independently of all the other settings.

Setting procedure

1. Touch the \odot symbol repeatedly until the Δ indicator for the kitchen timer lights up. 00 lights up on the timer display.
2. Touch the + or - symbol. The default value appears. + symbol: 10 minutes - symbol: 05 minutes.
3. Use the + or - symbol to set the time.

The timer starts counting down after a few seconds.

When the time has elapsed

A signal sounds once the time has elapsed. 00 lights up on the timer display. The Δ indicator for the kitchen timer lights up brightly. After 10 seconds, the indicator switches off.

Changing the time

Touch the \odot symbol repeatedly until the Δ indicator for the kitchen timer lights up. Use the + or - symbol to set the time.

Automatic time limit

If a hotplate is in use for a long time without the setting being changed, the automatic time limit is activated.

The hotplate stops heating. F and B flash alternately in the hotplate indicator.

The display goes out when you touch any control. You can make new settings.

When the time limit is activated depends on the heat setting selected (1 to 10 hours).

Basic settings

Your appliance has various basic settings. You can adapt these settings to your needs.


Indicator	Function
c 1	Automatic childproof lock <input checked="" type="checkbox"/> Switched off.* <input type="checkbox"/> Switched on.
c 2	Audible signal <input checked="" type="checkbox"/> Confirmation signal and operation error signal switched off. <input type="checkbox"/> Only operation error signal switched on. <input type="checkbox"/> Confirmation signal and operation error signal switched on.*
c 5	Automatic timer <input checked="" type="checkbox"/> Switched off. 1-99 Duration after which the hotplates switch off
c 6	Duration of the timer end signal <input type="checkbox"/> 10 seconds.* <input type="checkbox"/> 30 seconds <input type="checkbox"/> 1 minute.
c 7	Activation of the filament circuits <input checked="" type="checkbox"/> Switched off. <input type="checkbox"/> Switched on. <input type="checkbox"/> Last setting before the hotplate was switched off.*
c 0	Reset to basic setting <input checked="" type="checkbox"/> Switched off. <input type="checkbox"/> Switched on.

*Basic setting

Changing the basic settings

The hob must be switched off.


1. Switch on the hob.
2. Within the next 10 seconds, touch the  symbol for 4 seconds



 and  flash alternately in the left-hand display;  lights up in the right-hand display.

3. Touch the  symbol repeatedly until the desired indicator appears in the left-hand display.

4. Touch the  symbol repeatedly until the desired setting appears in the display.



5. Touch the  symbol for 4 seconds.
The setting is activated.

Switching off

To exit the basic setting, switch off the hob with the main switch and make new settings.

Cleaning and care

The information in this section provides help on how best to care for your hob.

Suitable maintenance and cleaning products can be purchased from the after-sales service or in our e-Shop.

Ceramic

Clean the hob after each use. This will prevent spills from burning onto the ceramic.

Only clean the hob when it has cooled down sufficiently.

Use only cleaning agents which are suitable for ceramic. Follow the cleaning instructions on the packaging.

Never use:

- Undiluted washing-up liquid
- Detergent intended for dishwashers
- Scouring agents

- Harsh cleaning agents such as oven spray or stain remover
- Abrasive sponges
- High-pressure cleaners or steam jet cleaners

Ground-in dirt can be best removed with a glass scraper, available from retailers. Please note the manufacturer's instructions.

You can also obtain a suitable glass scraper from our after-sales service or from the e-Shop.

Hob surround

To prevent damage to the hob surround, please observe the following instructions:

- Use only warm, soapy water.
- Do not use harsh or abrasive agents.
- Do not use the glass scraper.

Rectifying faults

Malfunctions often have simple explanations. Please read the following notes before calling the after-sales service.

Indicator	Fault	Action
Blank	There is no power supply.	Check the household fuse for the appliance. Check whether there is a power cut by trying other electronic appliances.
E is flashing	The controls are damp or an object is resting on them.	Dry the controls or remove the object.
Er + number	Electronic fault.	Switch the appliance off and back on again after about 30 seconds using either the household fuse or the circuit breaker in the fuse box. Contact the after-sales service if this appears in the display again.
F2	The electronics have overheated and have switched off the corresponding hotplate.	Wait until the electronics have cooled down sufficiently. Then touch a control for the hotplate.*
F4	The electronics have overheated and have switched off all hotplates.	Wait until the electronics have cooled down sufficiently. Then touch any control.*
F8	The hotplate was in operation for too long and has switched itself off.	You can switch the hotplate back on again immediately.

* Do not place hot pans close to or on the control panel

After-sales service

Our after-sales service is there for you if your appliance should need to be repaired. We are committed to find the best solution also in order to avoid an unnecessary call-out.

E number and FD number:

Please quote the E number (product number) and the FD number (production number) of your appliance when contacting the after-sales service. The rating plate bearing these numbers can be found on the appliance certificate.

Please note that a visit from an after-sales service engineer is not free of charge, even during the warranty period.

Please find the contact data of all countries in the enclosed customer service list.

To book an engineer visit and product advice

GB 0844 8928979

Calls from a BT landline will be charged at up to 3 pence per minute. A call set-up fee of up to 6 pence may apply.

IE 01450 2655

Trust the expertise of the manufacturer, and rest assured that the repair will be carried out by trained service technicians using original spare parts for your domestic appliance.

Robert Bosch Hausgeräte GmbH
Carl-Wery-Straße 34
81739 München
Germany
www.bosch-home.com



9000625121

910203