



SIEMENS

Built-in oven

HB33CB550

siemens-home.com/welcome

en Instruction manual

Register
your
product
online

Table of contents

| | | | |
|--|-----------|---|-----------|
| Important safety information..... | 4 | After-sales service | 15 |
| Causes of damage | 5 | E number and FD number | 15 |
| Your new oven | 6 | Energy and environment tips | 16 |
| Control panel | 6 | Saving energy..... | 16 |
| Buttons and display..... | 6 | Environmentally-friendly disposal..... | 16 |
| Function selector..... | 6 | Tested for you in our cooking studio | 16 |
| Temperature selector..... | 7 | Cakes and pastries | 16 |
| Cooking compartment | 7 | Baking tips | 18 |
| Your accessories | 7 | Meat, poultry, fish..... | 19 |
| Inserting accessories | 7 | Tips for roasting and grilling | 21 |
| Optional accessories | 8 | Slow cooking | 21 |
| After-sales service products | 8 | Tips for slow cooking | 22 |
| Before using the oven for the first time..... | 9 | Bakes, gratins, toast..... | 22 |
| Setting the clock | 9 | Convenience products..... | 22 |
| Heating up the oven | 9 | Acrylamide in foodstuffs | 24 |
| Cleaning the accessories..... | 9 | Test dishes | 24 |
| Setting the oven..... | 9 | Baking | 24 |
| Type of heating and temperature | 9 | Grilling | 25 |
| Rapid heating | 9 | | |
| Setting the time-setting options..... | 10 | | |
| Timer | 10 | | |
| Cooking time | 10 | | |
| End time..... | 11 | | |
| Clock | 11 | | |
| Childproof lock | 11 | | |
| Changing the basic settings | 12 | | |
| Care and cleaning | 12 | | |
| Cleaning agents | 12 | | |
| Cleaning the hook-in racks | 13 | | |
| Folding down the grill element..... | 13 | | |
| Removing and fitting the appliance door..... | 13 | | |
| Cleaning the door panels..... | 14 | | |
| Troubleshooting | 15 | | |
| Malfunction table..... | 15 | | |
| Replacing the oven light bulb..... | 15 | | |
| Glass cover | 15 | | |

Additional information on products, accessories, replacement parts and services can be found at **www.siemens-home.com** and in the online shop **www.siemens-eshop.com**

Important safety information

Read these instructions carefully. Only then will you be able to operate your appliance safely and correctly. Retain the instruction manual and installation instructions for future use or for subsequent owners.

This appliance is only intended to be fully fitted in a kitchen. Observe the special installation instructions.

Check the appliance for damage after unpacking it. Do not connect the appliance if it has been damaged in transport.

Only a licensed professional may connect appliances without plugs. Damage caused by incorrect connection is not covered under warranty.

This appliance is intended for domestic use only. The appliance must only be used for the preparation of food and drink. The appliance must be supervised during operation. Only use this appliance indoors.

This appliance is intended for use up to a maximum height of 2000 metres above sea level.

This appliance may be used by children over the age of 8 years old and by persons with reduced physical, sensory or mental capabilities or by persons with a lack of experience or knowledge if they are supervised or are instructed by a person responsible for their safety how to use the appliance safely and have understood the associated hazards.

Children must not play with, on, or around the appliance. Children must not clean the appliance or carry out general maintenance unless they are at least 8 years old and are being supervised.

Keep children below the age of 8 years old at a safe distance from the appliance and power cable.

Always slide accessories into the cooking compartment correctly. See "*Description of accessories*" in the instruction manual.

Risk of fire!

- Combustible items stored in the cooking compartment may catch fire. Never store combustible items in the cooking compartment. Never open the appliance door if there is smoke inside. Switch off the appliance and unplug it from the mains or switch off the circuit breaker in the fuse box.
- A draught is created when the appliance door is opened. Greaseproof paper may come into contact with the heating element and catch fire. Do not place greaseproof paper loosely over accessories during preheating. Always weight down the greaseproof paper with a dish or a baking tin. Only cover the surface required with greaseproof paper. Greaseproof paper must not protrude over the accessories.

Risk of burns!

- The appliance becomes very hot. Never touch the interior surfaces of the cooking compartment or the heating elements. Always allow the appliance to cool down. Keep children at a safe distance.
- Accessories and ovenware become very hot. Always use oven gloves to remove accessories or ovenware from the cooking compartment.
- Alcoholic vapours may catch fire in the hot cooking compartment. Never prepare food containing large quantities of drinks with a high alcohol content. Only use small quantities of drinks with a high alcohol content. Open the appliance door with care.

Risk of scalding!

- The accessible parts become hot during operation. Never touch the hot parts. Keep children at a safe distance.
- When you open the appliance door, hot steam may escape. Open the appliance door with care. Keep children at a safe distance.
- Water in a hot cooking compartment may create hot steam. Never pour water into the hot cooking compartment.

Risk of injury!

Scratched glass in the appliance door may develop into a crack. Do not use a glass scraper, sharp or abrasive cleaning aids or detergents.

Risk of electric shock!

- Incorrect repairs are dangerous. Repairs may only be carried out by one of our trained after-sales engineers. If the appliance is faulty, unplug the mains plug or switch off the fuse in the fuse box. Contact the after-sales service.
- The cable insulation on electrical appliances may melt when touching hot parts of the appliance. Never bring electrical appliance cables into contact with hot parts of the appliance.
- Do not use any high-pressure cleaners or steam cleaners, which can result in an electric shock.
- When replacing the cooking compartment bulb, the bulb socket contacts are live. Before replacing the bulb, unplug the appliance from the mains or switch off the circuit breaker in the fuse box.
- A defective appliance may cause electric shock. Never switch on a defective appliance. Unplug the appliance from the mains or switch off the circuit breaker in the fuse box. Contact the after-sales service.

Causes of damage

Caution!


- Accessories, foil, greaseproof paper or ovenware on the cooking compartment floor: do not place accessories on the cooking compartment floor. Do not cover the cooking compartment floor with any sort of foil or greaseproof paper. Do not place ovenware on the cooking compartment floor if a temperature of over 50 °C has been set. This will cause heat to accumulate. The baking and roasting times will no longer be correct and the enamel will be damaged.
- Water in a hot cooking compartment: do not pour water into the cooking compartment when it is hot. This will cause steam. The temperature change can cause damage to the enamel.
- Moist food: do not store moist food in the cooking compartment when it is closed for prolonged periods. This will damage the enamel.
- Fruit juice: when baking particularly juicy fruit pies, do not pack the baking tray too generously. Fruit juice dripping from the baking tray leaves stains that cannot be removed. If possible, use the deeper universal pan.
- Cooling with the appliance door open: only allow the cooking compartment to cool when it is closed. Even if the appliance door is only open a little, front panels of adjacent units could be damaged over time.
- Very dirty door seal: If the door seal is very dirty, the appliance door will no longer close properly when the appliance is in use. The fronts of adjacent units could be damaged. Always keep the door seal clean.
- Appliance door as a seat, shelf or worktop: Do not sit on the appliance door, or place or hang anything on it. Do not place any cookware or accessories on the appliance door.
- Inserting accessories: depending on the appliance model, accessories can scratch the door panel when closing the appliance door. Always insert the accessories into the cooking compartment as far as they will go.
- Carrying the appliance: do not carry or hold the appliance by the door handle. The door handle cannot support the weight of the appliance and could break.

Your new oven

Here you will learn about your new oven. The control panel and the individual operating controls are explained. You will find information on the cooking compartment and the accessories.

Control panel

Here is an overview of the control panel. The display never shows all of the symbols at the same time. Details may vary, depending on the appliance model.



Control knobs

The control knobs are retractable. To lock it in or out, press the control knob in the off position.

Buttons and display

You can use the buttons to set various additional functions. On the display, you can read the values that you have set.

| Button | Use |
|----------------------|--|
| Time-setting options | Selects the timer , cooking time , end time and clock . |
| Minus | Decreases the set values. |
| Plus | Increases the set values. |
| Rapid heating | Heats up the oven particularly quickly. |
| Childproof lock | Locks and unlocks oven functions. |

The time-setting option that is currently selected in the display is indicated by the ► arrow next to the corresponding symbol. Exception: For the clock, the symbol only lights up if the time is being changed.

Function selector

Use the function selector to set the type of heating.



| Setting | Use |
|--------------------|---|
| Off position | The oven switches off. |
| 3D hot air* | For cakes and pastries on one to three levels. The fan distributes the heat from the heating ring in the back panel evenly around the cooking compartment. |
| Top/bottom heating | For cakes, bakes and lean joints of meat (e.g. beef or game) on one level. Heat is emitted evenly from the top and bottom. |
| Pizza setting | For the quick preparation of frozen products without preheating, e.g. pizza, chips or strudel. The bottom heating element and the ring heating element in the back panel heat up. |
| Hot air grilling | For roasting meat, poultry and whole fish. The grill element and the fan switch on and off alternately. The fan causes the hot air to circulate around the dish. |
| Grill, large area | For grilling steaks, sausages, bread and pieces of fish. The whole area below the grill heating element becomes hot. |
| Grill, small area | For grilling small amounts of steaks, sausages, bread and pieces of fish. The centre part of the grill element becomes hot. |
| Bottom heating | For preserving, browning and final baking stage. The heat is emitted from below. |
| Defrost | For defrosting, e.g. meat, poultry, bread and cakes. The fan causes the warm air to circulate around the dish. |
| Oven light | Switches on the oven light. |


* Type of heating used to determine the energy efficiency class in accordance with EN50304.

When you make settings, the indicator lamp above the function selector lights up. The oven light in the cooking compartment switches on.

Temperature selector

The temperature selector is used to set the temperature or grill setting.

| Setting | | Meaning |
|------------|-------------------|--|
| ● | Off position | The oven does not heat up. |
| 50-270 | Temperature range | The temperature in the cooking compartment in °C. |
| ●, ●●, ●●● | Grill settings | The grill settings for the small  and large  area grills. ● = setting 1, low ●● = setting 2, medium ●●● = setting 3, high |

When the oven is heating, the indicator lamp above the temperature selector lights up. It goes out during heating pauses. The lamp does not light up for the  Defrost type of heating.

Your accessories


The accessories supplied with your appliance are suitable for making many meals. Ensure that you always insert the accessories into the cooking compartment the right way round. There is also a selection of optional accessories, with which you can improve on some of your favourite dishes, or simply to make working with your oven more convenient.


Inserting accessories

You can insert the accessories into the cooking compartment at 3 different levels. Always insert them as far as they will go so that the accessories do not touch the door panel.



The accessories can be pulled out approximately halfway until they lock in place. This allows meals to be removed easily. When sliding the accessories into the cooking compartment, ensure that the kink in the side rail is at the back. Only then will they lock in place.




When working with  3D hot air, do not use shelf position 2, as this will adversely affect air circulation.

Cooking compartment

The oven light is located in the cooking compartment. A cooling fan protects the oven from overheating.


Oven light


During operation, the oven light in the cooking compartment is on. The  setting on the function selector can be used to switch on the light without heating the oven.


Cooling fan

The cooling fan switches on and off as required. The hot air escapes above the door. Caution: do not cover the ventilation slots. Otherwise the oven will overheat. So that the cooking compartment cools down more quickly after operation, the cooling fan continues to run for a certain period afterwards.


Note: The accessories may become deformed when they become hot. Once they cool down again, they regain their original shape. This does not affect their function. You can buy accessories from the after-sales service, from specialist retailers or online. Please specify the HZ number.



Wire rack
For ovenware, cake tins, joints, grilled items and frozen meals.
Insert the wire rack with the open side facing the oven door and the curvature pointing downwards .



Enamel baking tray
For cakes and biscuits.
Slide in the baking tray with the sloping edge facing the oven door.



Universal pan
For moist cakes, pastries, frozen meals and large roasts. It can also be used to catch dripping fat when you are grilling directly on the wire rack.
Slide in the universal pan with the sloping edge facing the oven door.

Optional accessories

You can purchase optional accessories from the after-sales service or specialist retailers. You will find a comprehensive range of products for your oven in our brochures and online. The availability of optional accessories and the options for ordering these vary from region to region. Please check the sales brochures.

Not every optional accessory fits every appliance. When purchasing, please always quote the exact identification number (E no.) for your appliance.

| Optional accessories | HZ number | Application |
|---|-----------|--|
| Wire rack | HZ334000 | For cookware, cake tins, roasts, grilling and frozen meals. |
| Enamel baking tray | HZ331003 | For cakes and biscuits. Slide the baking tray into the oven with the sloping edge facing towards the oven door. |
| Universal pan | HZ332003 | For moist cakes, pastries, frozen meals and large roasts. It can also be used to catch dripping fat when you are grilling directly on the wire rack. Slide the universal pan into the oven with the sloping edge facing towards the oven door. |
| Wire insert | HZ324000 | For roasting. Always place the wire rack in the universal pan. This ensures that dripping fat and meat juices are collected. |
| Grill tray | HZ325000 | Use for grilling instead of the wire rack or as a splatter guard, so that the oven does not become very dirty. Only use the grill tray in the universal pan. Grilling on the grill tray: Use only on shelf positions 1 and 2. Grill tray as splash guard: Slide the universal pan with the grill tray under the wire rack. |
| Pizza tray | HZ317000 | Ideal for pizza, frozen products or large, round cakes. You can use the pizza tray instead of the universal pan. Place the tray on the wire rack and refer to the specifications in the tables. |
| Baking stone | HZ327000 | If you want your bread, bread rolls or pizza to have a crispy base, the baking stone is ideal. The baking stone must always be preheated to the recommended temperature. |
| Enamel baking tray with non-stick coating | HZ331011 | Cakes and biscuits can be removed from the baking tray more easily. Slide the baking tray into the oven with the sloping edge facing towards the oven door. |
| Universal pan with non-stick coating | HZ332011 | Moist cakes, pastries, frozen meals and large roasts can be removed more easily from the universal pan. Slide the universal pan into the oven with the sloping edge facing towards the oven door. |

After-sales service products

You can obtain suitable care and cleaning agents and other accessories for your domestic appliances from the after-sales service, specialist retailers or (in some countries) online via the e-Shop. Please specify the relevant product number.

| | | |
|--|--------------------|--|
| Cleaning cloths for stainless-steel surfaces | Product no. 311134 | Reduces the build-up of dirt. Impregnated with a special oil for perfect maintenance of your appliance's stainless-steel surfaces. |
| Oven and grill cleaning gel | Product no. 463582 | For cleaning the cooking compartment. The gel is odourless. |
| Microfibre cloth with honeycomb structure | Product no. 460770 | Especially suitable for cleaning delicate surfaces, such as glass, glass ceramic, stainless steel or aluminium. The microfibre cloth removes liquid and grease deposits in one go. |
| Door lock | Product no. 612594 | To prevent children from opening the oven door. The locks on different types of appliance door are screwed in differently. See the information sheet supplied with the door lock. |

Before using the oven for the first time

In this section, you can find out what you must do before using your oven to prepare food for the first time. First read the section on *Safety information*.

Setting the clock

After the appliance has been connected, the ⏰ symbol and three zeros flash in the display. Set the clock.


1. Press the ⏰ button.

The clock in the display shows 12:00. The time symbols light up and the ► arrow is next to ⏰.


2. Use the + or - button to set the clock.

After a few seconds, the time that has been set is adopted.

Heating up the oven

To remove the new cooker smell, heat up the oven when it is empty and closed. An hour of Top/bottom heating  at 240 °C is ideal for this purpose. Ensure that no packaging remnants have been left in the cooking compartment.

Keep the kitchen ventilated the whole time the oven is on.

1. Use the function selector to set Top/bottom heating .
2. Set the temperature selector to 240 °C.

After an hour, switch off the oven. To do so, turn the function selector to the off position.

Cleaning the accessories

Before you use the accessories for the first time, clean them thoroughly with hot soapy water and a soft dish cloth.


Setting the oven

There are various ways in which you can set your oven. Here we will explain how you can select the desired type of heating and temperature or grill setting. You can select the oven cooking time and end time for your dish. Please refer to the section on *Setting the time-setting options*.


Type of heating and temperature

Example in the picture: Top/bottom heating at 190 °C.

1. Use the function selector to set the type of heating.



2. Set the temperature or grill setting using the temperature selector.



The oven begins to heat up.

Switching off the oven

Turn the function selector to the off position.




Changing the settings

The type of heating and temperature or grill setting can be changed at any time using their respective selectors.


Rapid heating


With rapid heating, your oven reaches the temperature selected particularly quickly.

Use rapid heating when temperatures above 100 °C are selected. The following types of heating are suitable:


-  3D hot air
-  Top/bottom heating
-  Pizza setting

To ensure an even cooking result, do not place your dish in the cooking compartment until rapid heating is complete.



1. Set the type of heating and temperature.
2. Press the  button briefly.

The  symbol lights up in the display. The oven begins to heat up.

The rapid heating process is complete

A signal sounds. The  symbol in the display goes out. Put your dish in the oven.

Cancelling rapid heating

Press the  button briefly. The  symbol in the display goes out.

Setting the time-setting options

Your oven has various time-setting options. You can use the ⌚ button to call up the menu and switch between the individual functions. All the time symbols are lit when you can make settings. The ► arrow shows you the time-setting option that is active. A time-setting option that has already been set can be changed direction with the + or – button when the ► arrow is next to the relevant time symbol.

Timer

You can use the timer as a kitchen timer. It runs independently of the oven. The timer has its own signal. In this way, you can tell whether it is the timer or a cooking time which has elapsed.

1. Press the ⌚ button once.

The time symbols light up in the display and the ► arrow is next to ⌚.

2. Use the + or – button to set the timer duration.

Default value for +button = 10 minutes

Default value for –button = 5 minutes

After a few seconds, the time setting is adopted. The timer starts. The ►⌚ symbol lights up in the display and the timer duration counts down. The other time symbols go out.

The timer duration has elapsed

A signal sounds. 0:00 is shown in the display. Use the ⌚ button to switch off the timer.

Changing the timer duration

Use the + or – button to change the timer duration. After a few seconds, the change is adopted.

Cancelling the timer duration

Use the – button to reset the timer duration to 0:00. The change will be adopted after a few seconds. The timer is switched off.

Checking the time settings

If several time-setting options are set, the relevant symbols are illuminated on the display. The time-setting options symbol is in the foreground and preceded by the ► arrow.

To call up the ⌚ timer, I→I cooking time, →I end time or ⌚ clock, press the ⌚ button repeatedly until the ► arrow is next to the relevant symbol. The display shows the value for a few seconds.

Cooking time


The cooking time for your dish can be set on the oven. When the cooking time has elapsed, the oven switches itself off automatically. This means that you do not have to interrupt other work to switch off the oven. The cooking time cannot be accidentally exceeded.

Example in the picture: cooking time 45 minutes.

1. Use the function selector to set the type of heating.
2. Set the temperature or grill setting using the temperature selector.

3. Press the ⌚ button twice.


0:00 is shown in the display. The time symbols light up and the ► arrow is next to I→I.



4. Use the + or – button to set the cooking time.

Default value for + button = 30 minutes

Default value for – button = 10 minutes



The oven will start up after a few seconds. The cooking time counts down in the display and the ►I→I symbol lights up. The other time symbols go out.

The cooking time has elapsed

A signal sounds. The oven stops heating. 0:00 is shown in the display. Press the ⌚ button. You can set a new cooking time using the + or – button. Or press the ⌚ button twice and turn the function selector to the off position. The oven switches off.

Changing the cooking time

Use the + or – button to change the cooking time. After a few seconds, the change is adopted. If the timer has been set, press the ⌚ button beforehand.

Cancelling the cooking time

Use the – button to reset the cooking time to 0:00. After a few seconds, the change is adopted. The cooking time is cancelled. If the timer has been set, press the ⌚ button beforehand.

Checking the time settings

If several time-setting options are set, the relevant symbols are illuminated on the display. The time-setting options symbol is in the foreground and preceded by the ► arrow.



To call up the ⌚ timer, I→I cooking time, →I end time or ⌚ clock, press the ⌚ button repeatedly until the ► arrow is next to the relevant symbol. The display shows the value for a few seconds.



End time


You can change the time at which you wish your dish to be ready. The oven starts automatically and finishes at the desired time. You can, for example, put your dish in the cooking compartment in the morning and set the cooking time so that it is ready at lunch time.

Ensure that food is not left in the cooking compartment for too long as it may spoil.


Example in the picture: it is 10:30 am, the cooking time is 45 minutes and the oven is required to finish cooking at 12:30 pm.








1. Adjust the function selector.
2. Set the temperature selector.
3. Press the  button twice.
4. Use the **+** or **-** button to set the cooking time.
5. Press the  button.

The  arrow is next to . The time when the dish will be ready is displayed.



6. Use the **+** or **-** button to set a later end time.



After a few seconds, the oven adopts the settings and switches to standby position. The display shows the time at which the dish will be ready and the  arrow is next to the  symbol. The  and  symbols go out. When the oven starts, the cooking time counts down in the display and the  arrow is next to the  symbol. The  symbol goes out.

Childproof lock



The oven has a childproof lock to prevent children from switching it on by accident.

The oven will not respond to any settings. You can still set the clock and the timer when the childproof lock is activated.


If the type of heating and temperature or grill setting are set, the childproof lock interrupts the heater element.

Note: If a hob is connected, it will not be affected by the childproof lock on the oven.


The cooking time has elapsed

A signal sounds. The oven stops heating. 0:00 is shown in the display. Press the  button. You can set a new cooking time using the **+** or **-** button. Or press the  button twice and turn the function selector to the off position. The oven switches off.


Changing the end time







Use the **+** or **-** button to change the end time. After a few seconds, the change is adopted. If the timer has been set, first press the  button twice. Do not change the end time if the cooking time has already started to elapse. The cooking result would no longer be correct.

Cancelling the end time


Use the **-** button to reset the end time to the current time. After a few seconds, the change is adopted. The oven starts. If the timer has been set, first press the  button twice.

Checking the time settings



If several time-setting options are set, the relevant symbols are illuminated on the display. The time-setting options symbol is in the foreground and preceded by the  arrow.

To call up the  timer,  cooking time,  end time or  clock, press the  button repeatedly until the  arrow is next to the relevant symbol. The display shows the value for a few seconds.

Clock

After connecting the appliance to the mains or after a power cut, the  symbol and three zeros flash in the display. Set the clock.

1. Press the  button.

The clock in the display shows 12:00. The time symbols light up and the  arrow is next to .



2. Use the **+** or **-** button to set the clock.

After a few seconds, the time that has been set is adopted.

Changing the clock

No other time-setting option should have been set.

1. Press the  button four times.

The time symbols light up in the display and the  arrow is next to .

2. Use the **+** or **-** button to change the clock.

After a few seconds, the time that has been set is adopted.


Hiding the clock

You can hide the clock. For more information, please refer to the section *Changing the basic settings*.


Activating the childproof lock


No cooking time or end time should be set.

Press and hold the  button for approx. four seconds.

The  symbol appears in the display. The childproof lock is activated.


Deactivating the childproof lock

Press and hold the  button for approx. four seconds.

The  symbol goes out in the display. The childproof lock is deactivated.

Changing the basic settings

Your oven has various basic settings. These settings can be customised to suit your requirements.

| Basic setting | Selection 1 | Selection 2 | Selection 3 |
|---|--------------------|--|--------------------|
| c1 Clock display | always* | only with the  button | - |
| c2 Signal duration upon completion of a cooking time or timer period | approx. 10 seconds | approx. 2 minutes* | approx. 5 minutes |
| c3 Waiting time until a setting is applied | approx. 2 seconds | approx. 5 seconds* | approx. 10 seconds |

* Factory setting


No other time-setting option should have been set.

1. Press and hold the  button for approx. 4 seconds.

The current basic setting for the clock display is shown in the display, e.g. c1 1 for selection 1.

2. Use the **+** or **-** button to change the basic setting.

3. Confirm by pressing the  button.

The next basic setting appears in the display. You can scroll through all levels with the  button and change the setting with the **+** or **-** button.

4. To finish, press and hold the  button for approx. 4 seconds.

All basic settings are applied.

You may change the basic settings at any time.

Care and cleaning

With good care and cleaning, your oven will remain clean and fully-functioning for a long time to come. Here we will explain how to maintain and clean your oven correctly.

Notes

- Slight differences in the colours on the front of the oven are caused by the use of different materials, such as glass, plastic and metal.
- Shadows on the door panel which look like streaks, are caused by reflections made by the oven light.
- Enamel is baked on at very high temperatures. This can cause some slight colour variations. This is normal and does not affect their function. The edges of thin trays cannot be completely enamelled. As a result, these edges can be rough. This will not impair the anti-corrosion protection.

Cleaning agents

To ensure that the different surfaces are not damaged by using the wrong type of cleaning agent, observe the information in the table. Do not use

- harsh or abrasive cleaning agents,
- cleaning agents with a high concentration of alcohol,
- hard scouring pads or sponges,
- high-pressure cleaners or steam cleaners.

Wash new sponge cloths thoroughly before use.


| Area | Cleaning agents |
|-----------------|--|
| Control panel | Hot soapy water: Clean with a dish cloth and dry with a soft cloth. Do not use glass cleaners or glass scrapers. |
| Stainless steel | Hot soapy water: Clean with a dish cloth and dry with a soft cloth. Remove traces of limescale, grease, starch and albumin (e.g. egg white) immediately. Corrosion can form under such residues. Special stainless steel cleaning products suitable for hot surfaces are available from our after-sales service or from specialist retailers. Apply a very thin layer of the cleaning product with a soft cloth. |

| Area | Cleaning agents |
|--------------------------------|---|
| Door panels | Glass cleaner: Clean with a soft cloth. Do not use a glass scraper. |
| Glass cover for the oven light | Hot soapy water: Clean with a dish cloth. |
| Seal Do not remove. | Hot soapy water: Clean with a dish cloth. Do not scour. |
| Rails | Hot soapy water: Soak and clean with a dish cloth or brush. |
| Telescopic shelves | Hot soapy water: Clean with a dish cloth or a brush. Do not remove the lubricant while the pull-out rails are pulled out – it is best to clean them when they are inserted. Do not soak or clean in the dishwasher. |
| Accessories | Hot soapy water: Soak and clean with a dish cloth or brush. |

Cleaning the self-cleaning surfaces in the cooking compartment

The back wall in the cooking compartment is coated with a highly porous ceramic layer. This coating absorbs and disintegrates splashes from baking and roasting while the oven is in operation. The higher the temperature and the longer the oven is in operation, the better the result will be.

If splashes are still visible even after repeated use, proceed as follows:

1. Clean the floor, ceiling and side panels of the cooking compartment thoroughly.
2. Set  3D hot air.
3. With the door closed, heat up the empty oven for approximately 2 hours at maximum temperature.

The ceramic coating is regenerated. When the cooking compartment has cooled down, remove the brown or white residue with water and a soft sponge.

Light discolouration of the coating does not affect automatic self-cleaning.

Caution!

- Never use abrasive cleaning agents. You will scratch or destroy the highly porous coating.
- Never treat the ceramic coating with oven cleaner. If oven cleaner accidentally gets onto it, remove it immediately with a sponge and plenty of water.

Cleaning the cooking compartment floor, ceiling and side walls

Use a dish cloth and hot soapy water or a vinegar solution.

If there are heavy deposits of dirt, use a stainless steel scouring pad or oven cleaner. Only use when the cooking compartment is cold. Never treat the self-cleaning surfaces with a scouring pad or oven cleaner.


Cleaning the hook-in racks

You can remove the hook-in racks for easier cleaning.


⚠ Risk of burning due to hot components in the cooking compartment!

Wait until the cooking compartment has cooled down.

1. Push the hook-in rack upwards at the front and unhook to the side.
2. Pull the hook-in rack forwards at the rear and unhook to the side.



3. Clean the hook-in rack with washing-up liquid and a sponge or brush.
4. Align the hook-in rack with the kink (a) facing upwards, so that the shelf positions match.
5. Insert the hook-in rack at the rear as far as it will go.
6. Push the hook-in rack towards the rear.
7. Insert the hook-in rack at the front as far as it will go.
8. Push the hook-in rack downwards.



Folding down the grill element


You can fold down the grill element to clean the ceiling.

⚠ Risk of burns!

The oven must be cold.

1. Hold the grill element and pull the handle forwards until it clicks audibly in place (figure A).

2. Fold the grill element downwards (figure B).



3. After cleaning, fold the grill element back up and hold it.

4. Pull the handle downwards until it clicks audibly into place.

Removing and fitting the appliance door

You can remove the appliance door to clean it more thoroughly.

⚠ Risk of injury!


The hinges of the appliance door may snap shut with great force. Always open the hinge locking lever fully when removing the appliance door and close it fully after refitting. Do not reach into the hinge.

⚠ Risk of injury!

If the appliance door has only been unhinged on one side, do not reach into the hinge. The hinge can snap back with great force. Call the after-sales service.


Removing the appliance door

1. Open the appliance door fully.
2. Open the locking levers on the left and right-hand side fully.





The hinges are secured and cannot snap closed.

3. Close the appliance door until resistance becomes noticeable (figure A).
4. With both hands, grip the door on the left and right-hand side, close the door a little more and pull it out (figure B).



Fitting the appliance door

1. Insert the hinges in the left and right-hand holders (figure C). The notch on both hinges must engage.
2. Open the appliance door fully.
3. Close the locking levers on the left and right-hand side fully (figure D).



The appliance door is secured and can no longer be removed.

4. Close the appliance door.

Cleaning the door panels

To facilitate cleaning, you can remove the inner door panels from the appliance door.

Risk of injury!

The components inside the appliance door may have sharp edges. Take care not to cut yourself. Wear protective gloves.



Risk of injury!

The appliance must not be used again until the door panels and appliance door have been correctly fitted.

Removing the door panel


Note: Before removing, make a note of which way round the door panel is fitted, so that it is not refitted the wrong way round.

1. Unhook the appliance door and lay it on a soft, clean surface with the front side facing downwards (see section: Removing and installing the appliance door).
2. Pull off the cover at the top of the appliance door. Press in the tabs on the left and right using your fingers (figure A).
3. Lift the door panel slightly and pull it out (figure B).



Removing the intermediate panel

Lift the intermediate panel slightly and pull it out towards you.



Cleaning

Clean the door panel with glass cleaner and a soft cloth.


Risk of injury!

Scratched glass in the appliance door may develop into a crack. Do not use a glass scraper, sharp or abrasive cleaning aids or detergents.

Fitting the intermediate panel


Note: During installation, make sure that the lettering "top right" is upside down at the bottom left.

Insert the intermediate panel towards the back as far as it will go.



Fitting the door panel

1. Insert the door panel at an angle towards the back into both brackets as far as it will go. The smooth surface must face outwards.



2. Put the cover back in place and press on it until it clicks in place.
3. Refit the appliance door.

Troubleshooting

Malfunctions often have simple explanations. Refer to the table before calling the after-sales service as you may be able to remedy the fault yourself.

Malfunction table

If a dish does not turn out as well as you had hoped, refer to the section *Tested for you in our cooking studio*, where you will find plenty of cooking tips and notes.

| Problem | Possible cause | Remedy/information |
|-----------------------------------|-----------------------------------|--|
| The oven does not work. | The circuit breaker is defective. | Look in the fuse box and check that the circuit breaker is in working order. |
| | Power cut | Check whether the kitchen light or other kitchen appliances are working. |
| ⌚ and zeros flash in the display. | Power cut | Reset the clock. |
| The oven does not heat up. | There is dust on the contacts. | Turn the control knobs back and forth several times. |

Error messages

If an error message with **E** appears, press the ⌚ button. The message disappears. A time function that has been set is cleared. If the error message does not disappear, please contact the after-sales service.

You can take remedial action yourself if the following error message is displayed.

| Error message | Possible cause | Remedy/information |
|---------------|---|---|
| E011 | A button was depressed for too long or is covered up. | Press all buttons individually. Check whether any buttons are jammed, covered up or soiled. |

⚠ Risk of electric shock!

Incorrect repairs are dangerous. Repairs may only be carried out by one of our trained after-sales engineers.

After-sales service

Our after-sales service is there for you if your appliance needs to be repaired. We will always find the right solution in order to avoid unnecessary visits from a service technician.

E number and FD number

When calling us, please give the product number (E no.) and the production number (FD no.) so that we can provide you with the correct advice. The rating plate containing these numbers can be found on the right-hand side of the oven door. You can make a note of the numbers of your appliance and the telephone number of the after-sales service in the space below to save time should it be required.

| E no. | FD no. |
|-----------------------|--------|
| | |
| After-sales service ☎ | |

Replacing the oven light bulb


Replace faulty oven light bulbs.

You can obtain replacement light bulbs from customer service or specialist retailers: E14, 220 - 240 V, 40 W, heat resistant to 300 °C. Only use these oven light bulbs.

⚠ Risk of electric shock !

Disconnect the appliance from the power supply. Switch off the circuit breaker or remove the fuse from the household fuse box.

1. Place a tea towel in the cold cooking compartment to prevent damage.
2. Turn the glass cover anticlockwise and remove it.



3. Replace the oven light bulb with a bulb of the same type.
4. Screw on the glass cover again.
5. Remove the tea towel and switch on the circuit breaker.

Note: If the glass cover cannot be unscrewed: use rubber gloves to turn it. You can order a special removal tool through the after-sales service (order no. 613634)

Glass cover

You must replace a damaged glass cover. Suitable glass covers may be obtained from the after-sales service. Please specify the E number and FD number of your appliance.

Please note that there will be a fee for a visit by a service technician in the event of a malfunction, even during the warranty period.

Please find the contact data of all countries in the enclosed customer service list.

To book an engineer visit and product advice

| | |
|-----------|--|
| GB | 0344 892 8999 Calls charged at local or mobile rate. |
| IE | 01450 2655 0.03 € per minute at peak. Off peak 0.0088 € per minute. |

Rely on the professionalism of the manufacturer. You can therefore be sure that the repair is carried out by trained service technicians who carry original spare parts for your appliances.

Energy and environment tips

Here you can find tips on how to save energy when baking and roasting and how to dispose of your appliance properly.

Saving energy

- Only preheat the oven if this is specified in the recipe or in the operating instruction tables.
- Use dark, black lacquered or enamelled baking tins. They absorb the heat particularly well.
- Open the oven door as infrequently as possible while you are cooking, baking or roasting.
- It is best to bake several cakes one after the other. The oven is still warm. This reduces the baking time for the second cake. You can also place two loaf tins next to each other.
- For longer cooking times, you can switch the oven off 10 minutes before the end of the cooking time and use the residual heat to finish cooking.

Environmentally-friendly disposal

Dispose of packaging in an environmentally-friendly manner.



This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE). The guideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.

Tested for you in our cooking studio



Here you will find a selection of dishes and the ideal settings for them. We will show you which type of heating and which temperature are best suited for your dish. You can find information about suitable accessories and the height at which they should be inserted. There are also tips about cookware and preparation methods.

Notes


- The values in the table always apply to dishes placed into the cooking compartment when it is cold and empty.
Only preheat the appliance if the table specifies that you should do so. Do not line the accessories with greaseproof paper until after they have been preheated.
- The times specified in the tables are guidelines only. They will depend on the quality and composition of the food.
- Use the accessories supplied. Additional accessories may be obtained as special accessories from specialist retailers or from the after-sales service.
Before using the oven, remove any unnecessary accessories and ovenware from the cooking compartment.
- Always use oven gloves when taking hot accessories or ovenware out of the cooking compartment.

Cakes and pastries

Baking on one level

When baking cakes, the best results can be achieved using  Top/bottom heating. When baking with  3D hot air, note the following: Bake cakes in tins and on a tray at shelf height 1.

Baking on two or more levels

Use  3D hot air.

Baking on 2 levels:

- Baking tray in shelf position 3
- Universal pan in shelf position 1

Baking trays that are placed in the oven at the same time will not necessarily be ready at the same time.

The tables show numerous suggestions for well-known dishes.

Baking tins

It is best to use dark-coloured metal baking tins. Baking times are increased when light-coloured baking tins made of thin metal or glass dishes are used, and cakes do not brown so evenly.






If you wish to use silicone baking tins, use the information and recipes provided by the manufacturer as a guide. Silicone baking tins are often smaller than normal tins. The amount of mixture and recipe instructions may differ.

Tables








The tables show the ideal type of heating for the various cakes and pastries. The temperature and baking time depend on the amount and consistency of the mixture. This is why temperature ranges are given in the tables. You should try the lower temperature first, since a lower temperature allows more even browning. You can increase the temperature next time if necessary.

Preheating the oven shortens the baking time by 5 to 10 minutes.


















More information can be found in the "Baking tips" section which follows the tables.













| Cakes in tins | Cookware | Level | Type of heating | Temperature in °C | Baking time in minutes |
|--|--------------------------|-------|---|-------------------|------------------------|
| Sponge cake, simple | Ring/loaf tin | 1 |  | 150-160 | 60-75 |
| Sponge cake, delicate (e.g. sand cake) | Ring/loaf tin | 1 |  | 150-160 | 60-70 |
| Sponge flan base | Flan-base cake tin | 1 |  | 160-170 | 20-35 |
| Delicate fruit flan, sponge | Springform/ring cake tin | 1 |  | 160-170 | 60-70 |
| Sponge base, 2 eggs (preheat) | Flan-base cake tin | 1 |  | 160-170 | 20-35 |

* Turn off the oven and allow the cake to cool for approximately 20 minutes with the oven door closed.

| Cakes in tins | Cookware | Level | Type of heating | Temperature in °C | Baking time in minutes |
|---|--------------------------|-------|--|-------------------|------------------------|
| Fatless sponge cake, 6 eggs (preheat) | Dark springform cake tin | 1 |  | 160-170 | 30-45 |
| Pastry base with crust | Dark springform cake tin | 1 |  | 180-190 | 20-30 |
| Fruit tart or cheesecake on pastry base* | Dark springform cake tin | 1 |  | 160-170 | 60-75 |
| Swiss flan | Round pizza tray | 1 |  | 190-210 | 35-45 |
| Ring cake | Ring cake tin | 1 |  | 170-180 | 40-50 |
| Pizza, thin base, light topping (preheat) | Round pizza tray | 1 |  | 200-220 | 15-25 |
| Savoury cakes* | Dark springform cake tin | 1 |  | 170-190 | 45-60 |

* Turn off the oven and allow the cake to cool for approximately 20 minutes with the oven door closed.







| Cakes on trays | Accessories | Level | Type of heating | Temperature in °C | Cooking time in minutes |
|--|-----------------------------|-------|--|-------------------|-------------------------|
| Sponge with dry topping | Baking tray | 2 |  | 160-170 | 25-35 |
| | Baking tray + universal pan | 3+1 |  | 150-160 | 35-45 |
| Sponge with moist topping (fruit) | Universal pan | 2 |  | 160-170 | 30-45 |
| | Baking tray + universal pan | 3+1 |  | 160-170 | 40-50 |
| Yeast dough with dry topping | Baking tray | 2 |  | 170-180 | 45-55 |
| | Baking tray + universal pan | 3+1 |  | 160-170 | 60-75 |
| Yeast dough with moist topping (fruit) | Universal pan | 2 |  | 160-170 | 70-90 |
| Shortcrust pastry with dry topping | Baking tray | 2 |  | 170-180 | 55-70 |
| Shortcrust pastry with moist topping (fruit) | Universal pan | 2 |  | 170-180 | 70-85 |
| Swiss flan | Universal pan | 1 |  | 190-210 | 35-45 |
| Swiss roll (preheat) | Baking tray | 2 |  | 190-200 | 10-15 |
| Plaited loaf with 500 g flour | Baking tray | 2 |  | 170-180 | 35-50 |
| Stollen with 500 g flour | Baking tray | 1 |  | 160-170 | 70-80 |
| Strudel, sweet | Universal pan | 1 |  | 190-210 | 35-45 |
| Pizza | Baking tray | 1 |  | 180-200 | 20-30 |
| | Baking tray + universal pan | 3+1 |  | 170-190 | 35-45 |
| Tarte flambée (preheat) | Universal pan | 1 |  | 190-210 | 20-25 |

| Small baked products | Accessories | Level | Type of heating | Temperature in °C | Cooking time in minutes |
|------------------------|--------------------------------|-------|--|-------------------|-------------------------|
| Cookies | Baking tray | 1 |  | 130-140 | 15-25 |
| | Baking tray + universal pan | 3+1 |  | 130-140 | 20-30 |
| Macaroons | Baking tray | 1 |  | 120-130 | 25-35 |
| | Baking tray + universal pan | 3+1 |  | 110-120 | 30-40 |
| Meringue | Baking tray | 1 |  | 80 | 130-160 |
| Muffins | Wire rack with muffin tray | 2 |  | 150-160 | 25-35 |
| | 2 wire racks with muffin trays | 3+1 |  | 150-160 | 30-40 |
| Choux pastry (preheat) | Baking tray | 2 |  | 200-210 | 25-35 |
| Puff pastry (preheat) | Baking tray | 1 |  | 190-200 | 20-35 |
| | Baking tray + universal pan | 3+1 |  | 190-200 | 25-40 |
| Leavened cake | Baking tray | 2 |  | 190-200 | 20-30 |
| | Baking tray + universal pan | 3+1 |  | 170-180 | 25-35 |



Bread and bread rolls

Never pour water into the oven while it is hot.

When baking bread, preheat the oven unless directed otherwise.

| Bread and bread rolls | Accessories | Level | Type of heating | Temperature in °C | Cooking time in minutes |
|-----------------------------------|-----------------------------|-------|---|-------------------|-------------------------|
| Yeast bread with 1.2 kg flour | Universal pan | 1 |  | 240 200 | 10-15 40-45 |
| Sourdough bread with 1.2 kg flour | Universal pan | 1 |  | 240 200 | 10-15 45-55 |
| Flatbread | Universal pan | 1 |  | 240 | 20-25 |
| Bread rolls (do not preheat) | Baking tray | 2 |  | 220-230 | 20-30 |
| Rolls made with sweet yeast dough | Baking tray | 2 |  | 210-220 | 10-20 |
| | Baking tray + universal pan | 3+1 |  | 190-200 | 15-25 |

Baking tips

| | |
|---|--|
| You wish to bake according to your own recipe. | Use similar items in the baking tables as a guide. |
| How to establish whether sponge cake is baked through. | Approximately 10 minutes before the end of the baking time specified in the recipe, stick a cocktail stick into the cake at the highest point. If the cocktail stick comes out clean, the cake is ready. |
| The cake collapses. | Use less fluid next time or set the oven temperature 10 degrees lower. Observe the specified mixing times in the recipe. |
| The cake has risen in the middle but is lower around the edge. | Do not grease the sides of the springform cake tin. After baking, loosen the cake carefully with a knife. |
| The cake goes too dark on top. | Place it lower in the oven, select a lower temperature and bake the cake for a little longer. |
| The cake is too dry. | When it is done, make small holes in the cake using a cocktail stick. Then drizzle fruit juice or an alcoholic beverage over it. Next time, select a temperature 10 degrees higher and reduce the baking time. |
| The bread or cake (e.g. cheesecake) looks good, but is soggy on the inside (sticky, streaked with water). | Use slightly less fluid next time and bake for slightly longer at a lower temperature. For cakes with a moist topping, bake the base first. Sprinkle it with almonds or bread crumbs and then place the topping on top. Please follow the recipe and baking times. |
| The cake is unevenly browned. | Select a slightly lower temperature to ensure that the cake is baked more evenly. Bake delicate pastries on one level using  Top/bottom heating. Protruding greaseproof paper can affect the air circulation. For this reason, always cut greaseproof paper to fit the baking tray. |
| The bottom of a fruit cake is too light. | Place the cake one level lower the next time. |
| The fruit juice overflows. | Next time, use the deeper universal pan, if you have one. |
| Small baked items made out of yeast dough stick to one another when baking. | There should be a gap of approx. 2 cm around each item. This gives enough space for the baked items to expand well and turn brown on all sides. |
| You were baking on several levels. The items on the top baking tray are darker than that on the bottom baking tray. | Always use  3D hot air to bake on more than one level. Baking trays that are placed in the oven at the same time will not necessarily be ready at the same time. |
| Condensation forms when you bake moist cakes. | Baking may result in the formation of water vapour, which escapes above the door. The steam may settle and form water droplets on the control panel or on the fronts of adjacent units. This is a natural process. |

Meat, poultry, fish

Ovenware

You may use any heat-resistant ovenware. The universal pan is suitable for large roasts.

Glass ovenware is the most suitable. Ensure that the lid of the roasting dish fits well and closes properly.

Add a little more liquid when using enamelled roasting dishes.

With roasting dishes made of stainless steel, browning is not so intense and the meat may be somewhat less well cooked. Increase the cooking times.

Information in the tables:

Ovenware without a lid = open

Ovenware with a lid = closed

Always place the ovenware in the centre of the wire rack.

Place hot glass ovenware on a dry mat after cooking. The glass could crack if placed on a cold or wet surface.

Roasting

Add in a little liquid if the meat is lean. Cover the base of the ovenware with approx. ½ cm of liquid.

Add liquid generously for pot roasts. Cover the base of the ovenware with approx. 1 - 2 cm of liquid.

The amount of liquid depends on the type of meat and the material the ovenware is made of. If preparing meat in an enamelled roasting dish, it will need a little more liquid than if cooked in glass ovenware.

Roasting dishes made from stainless steel are not ideal. The meat cooks more slowly and browns less fully. Use a higher temperature and/or a longer cooking time.

Grilling

When grilling, preheat the oven for approx. 3 minutes, before placing the food into the cooking compartment.

Always grill with the oven door closed.

As far as possible, the pieces of food you are grilling should be of equal thickness. This will allow them to brown evenly and remain succulent and juicy.

Turn the food you are grilling after ⅔ of the time.

Do not add salt to steaks until they have been grilled.

Place the food to be grilled directly on the wire rack. If you are grilling a single piece, the best results are achieved by placing it in the centre of the wire rack.

The universal pan should also be inserted at level 1. The meat juices are collected in the pan and the oven is kept cleaner.

When grilling, do not insert the baking tray or universal pan at level 4 or 5. The high heat distorts it and the cooking compartment can be damaged when removing it.

The grill element switches on and off continually. This is normal. The grill setting determines how frequently this will happen.



















Meat







Turn pieces of meat halfway through the cooking time.

When the roast is ready, turn off the oven and allow it to rest for an additional 10 minutes. This allows better distribution of the meat juices.



After cooking, wrap sirloin in aluminium foil and leave it to rest for 10 minutes in the oven.

For roast pork with a rind, score the rind in a crossways pattern, then lay the roast in the dish with the rind at the bottom.


| Meat | Weight | Accessories and cookware | Level | Type of heating | Temperature in °C, grill setting | Cooking time in minutes |
|---------------------------------|--------|---------------------------|-------|---|----------------------------------|-------------------------|
| Beef | | | | | | |
| Pot-roasted beef | 1.0 kg | Covered | 1 |  | 200-220 | 100-120 |
| | 1.5 kg | | 1 |  | 190-210 | 120-140 |
| | 2.0 kg | | 1 |  | 180-200 | 140-160 |
| Fillet of beef, medium | 1.0 kg | Uncovered | 1 |  | 210-230 | 50-70 |
| | 1.5 kg | | 1 |  | 200-220 | 60-80 |
| Sirloin, medium | 1.0 kg | Uncovered | 1 |  | 210-230 | 50-60 |
| Steaks, 3 cm thick, medium | | Wire rack + universal pan | 3+1 |  | 3 | 20-25 |
| Veal | | | | | | |
| Joint of veal | 1.0 kg | Uncovered | 1 |  | 190-210 | 80-100 |
| | 1.5 kg | | 1 |  | 180-200 | 90-120 |
| | 2.0 kg | | 1 |  | 180-200 | 100-140 |
| Knuckle of veal | 1.5 kg | Uncovered | 1 |  | 200-220 | 120-130 |
| Pork | | | | | | |
| Joint without rind (e.g. neck) | 1.0 kg | Uncovered | 1 |  | 190-210 | 100-120 |
| | 1.5 kg | | 1 |  | 180-200 | 110-130 |
| | 2.0 kg | | 1 |  | 170-190 | 120-140 |
| Joint with rind (e.g. shoulder) | 1.0 kg | Uncovered | 1 |  | 190-210 | 120-140 |
| | 1.5 kg | | 1 |  | 180-200 | 130-150 |
| | 2.0 kg | | 1 |  | 170-190 | 140-160 |
| Fillet of pork | 500 g | Wire rack + universal pan | 2+1 |  | 230-240 | 30-40 |

| Meat | Weight | Accessories and cookware | Level | Type of heating | Temperature in °C, grill setting | Cooking time in minutes |
|-----------------------------|--------|---------------------------|-------|---|----------------------------------|-------------------------|
| Pork joint, lean | 1.0 kg | Uncovered | 1 |  | 200-220 | 80-100 |
| | 1.5 kg | | 1 |  | 190-210 | 90-120 |
| | 2.0 kg | | 1 |  | 180-200 | 100-130 |
| Smoked pork on the bone | 1.0 kg | Covered | 1 |  | 200-220 | 50-60 |
| Steaks, 2 cm thick | | Wire rack + universal pan | 3+1 |  | 3 | 15-20 |
| Pork medallions, 3 cm thick | | Wire rack + universal pan | 3+1 |  | 3 | 12-18 |


Lamb

| | | | | | | |
|----------------------------|--------|-----------|---|---|---------|---------|
| Saddle of lamb on the bone | 1.5 kg | Uncovered | 1 |  | 200-220 | 40-50 |
| Leg of lamb, boned, medium | 1.5 kg | Uncovered | 1 |  | 190-210 | 120-150 |


Game

| | | | | | | |
|-------------------------------|--------|-----------|---|---|---------|---------|
| Saddle of venison on the bone | 1.5 kg | Uncovered | 1 |  | 190-210 | 70-90 |
| Boned leg of roe venison | 1.5 kg | Covered | 1 |  | 190-210 | 90-120 |
| Wild boar joint | 1.5 kg | Covered | 1 |  | 190-210 | 120-140 |
| Joint of venison | 1.5 kg | Covered | 1 |  | 190-210 | 100-120 |
| Rabbit | 2.0 kg | Covered | 1 |  | 200-220 | 60-70 |

Minced meat

| | | | | | | |
|-----------|----------------------|-----------|---|---|---------|-------|
| Meat loaf | Made from 500 g meat | Uncovered | 1 |  | 180-200 | 60-70 |
|-----------|----------------------|-----------|---|---|---------|-------|

Sausages

| | | | | | | |
|----------|--|---------------------------|-----|---|---|-------|
| Sausages | | Wire rack + universal pan | 3+1 |  | 3 | 10-15 |
|----------|--|---------------------------|-----|---|---|-------|

Poultry








The weights indicated in the table refer to oven-ready poultry (without stuffing).

Place whole poultry on the lower wire rack breast-side down. Turn after $\frac{2}{3}$ of the specified time.

Turn roasts, such as rolled turkey joint or turkey breast, halfway through the cooking time. Turn poultry portions after $\frac{2}{3}$ of the time.

For duck or goose, pierce the skin on the underside of the wings. This allows the fat to run out.

Poultry will turn out particularly crispy and brown if you baste it towards the end of the roasting time with butter, salted water or orange juice.

| Poultry | Weight | Accessories and cookware | Level | Type of heating | Temperature in °C, grill setting | Cooking time in minutes |
|------------------|------------|--------------------------|-------|---|----------------------------------|-------------------------|
| Chicken, whole | 1.2 kg | Wire rack | 1 |  | 200-220 | 60-70 |
| Chicken, halved | 500 g each | Wire rack | 1 |  | 210-230 | 40-50 |
| Chicken portions | 150 g each | Wire rack | 2 |  | 210-230 | 30-40 |
| Chicken portions | 300 g each | Wire rack | 2 |  | 210-230 | 35-45 |
| Duck, whole | 2.0 kg | Wire rack | 1 |  | 170-190 | 100-120 |
| Duck breast | 300 g each | Wire rack | 2 |  | 230-250 | 25-35 |
| Goose legs | 400 g each | Wire rack | 2 |  | 210-230 | 40-50 |






Fish

If you are grilling directly on the wire rack, the universal pan should also be inserted at level 1. The liquid will be caught and the oven remains cleaner.

Turn the pieces of fish after $\frac{2}{3}$ of the grilling time.

There is no need to turn a whole fish. Place the whole fish in the oven in its swimming position with its dorsal fin facing upwards. Placing a scored potato or a small oven-proof container in the stomach cavity of the fish will provide stability.

For fish fillets, add a few tablespoons of liquid to braise.

| Fish | Weight | Accessories and cookware | Level | Type of heating | Temperature in °C, grill setting | Cooking time in minutes |
|------------------------|--------------------|--------------------------|-------|---|----------------------------------|-------------------------|
| Fish, whole | approx. 300 g each | Wire rack | 2 |  | 2 | 20-25 |
| | 1.0 kg | Wire rack | 1 |  | 200-220 | 45-55 |
| | 1.5 kg | Wire rack | 1 |  | 180-200 | 60-70 |
| Fish steak, 3 cm thick | | Wire rack | 2 |  | 2 | 20-25 |
| Fish fillet | | Covered | 1 |  | 210-230 | 25-30 |

Tips for roasting and grilling

| | |
|---|---|
| The table does not contain information for the weight of the joint. | Select the next lowest weight from the instructions and extend the time. |
| How to tell when the roast is ready. | Use a meat thermometer (available from specialist shops) or carry out a "spoon test". Press down on the roast with a spoon. If it feels firm, it is ready. If the spoon can be pressed in, it needs to be cooked for a little longer. |
| The roast is too dark and the crackling is partly burnt. | Check the shelf height and temperature. |
| The roast looks good but the juices are burnt. | Next time, use a smaller roasting dish or add more liquid. |
| The roast looks good but the juices are too clear and watery. | Next time, use a larger roasting dish and use less liquid. |
| Steam rises from the roast when basted. | This is normal and due to the laws of physics. The majority of the steam escapes through the steam outlet. It may settle and form condensation on the cooler switch panel or on the fronts of adjacent units. |

Slow cooking


Slow cooking, also known as low-temperature cooking, is the ideal method for cooking tender pieces of meat medium rare or medium. The meat remains very juicy and turns out as soft as butter. The benefit of this cooking method is that it allows lots of scope for menu planning because slow-cooked meat is easy to keep warm.

Suitable cookware

Use a flat dish, e.g. a porcelain serving plate or a glass roasting dish without a lid.

Always place the open dish on the wire rack at level 1.

Method







1. Select  Top/bottom heating and set a temperature between 70-90 °C. Preheat the oven and warm up the dish at the same time.
2. Place a little fat in a pan on a high heat. Sear the meat on all sides, including the ends, and then place immediately into the preheated dish.
3. Place the dish with the meat in it back into the oven and slow cook. A slow-cook temperature of 80 °C is ideal for most pieces of meat.

Notes






- Only use fresh, good-quality meat Carefully remove sinews and fat. Fat develops a strong, distinct taste of its own during slow cooking.
- Sear the meat over a very high heat and for a sufficiently long time on all sides, including the ends.
- Larger pieces of meat do not need to be turned.
- Meat can be carved immediately following slow cooking. No standing time is required.
- Due to the special cooking method, the meat looks pink, i.e. medium rare. This does not mean, however, that it is raw or not well done enough.
- If you would like gravy with your meat, cook using ovenware with a lid. Please take note that the cooking times will be reduced.
- In order to check whether the meat is cooked, use a meat thermometer. A core temperature of 60 °C must be maintained for at least 30 minutes.

Table

Any tender cut of poultry, beef, veal, pork and lamb is suited to slow cooking. The slow cooking times depend on the thickness and the inside temperature of the meat.

| Meal | Weight | Level | Type of heating | Temperature in °C | Searing time in minutes | Low-temperature time in hours |
|--|----------------|-------|---|-------------------|-------------------------|-------------------------------|
| Poultry | | | | | | |
| Turkey breast | 1000 g | 1 |  | 80 | 6-7 | 4-5 |
| Duck breast* | 300-400 g | 1 |  | 80 | 3-5 | 2-2,5 |
| Beef | | | | | | |
| Joint of beef (e.g. rump) 6-7 cm thick | approx. 1.5 kg | 1 |  | 80 | 6-7 | 4,5-5,5 |
| Fillet of beef, whole | 1.5 kg | 1 |  | 80 | 6-7 | 5-6 |
| Sirloin, 5-6 cm thick | 1.5 kg | 1 |  | 80 | 6-7 | 4-5 |
| Beef steaks, 3 cm thick | | 1 |  | 80 | 5-7 | 80-110 min. |

* For crispy skin, briefly fry the duck breast in a frying pan after slow cooking.

| Meal | Weight | Level | Type of heating | Temperature in °C | Searing time in minutes | Low-temperature time in hours |
|---|----------------|-------|---|-------------------|-------------------------|-------------------------------|
| Veal | | | | | | |
| Joint of veal 6-7 cm thick (e.g. topside) | approx. 1.5 kg | 1 |  | 80 | 6-7 | 5-6 |
| Fillet of veal | approx. 800 g | 1 |  | 80 | 6-7 | 3-3,5 |
| Pork | | | | | | |
| Lean joint of pork (e.g. loin) 5-6 cm thick | approx. 1.5 kg | 1 |  | 80 | 6-7 | 5-6 |
| Pork fillet, whole | approx. 500 g | 1 |  | 80 | 6-7 | 2,5-3 |
| Lamb | | | | | | |
| Lamb saddle fillet, whole | approx. 200 g | 1 |  | 80 | 5-6 | 1,5-2 |

* For crispy skin, briefly fry the duck breast in a frying pan after slow cooking.

Tips for slow cooking

Slow-cooked meat is not as hot as conventionally roasted meat.

If you wish to keep slow-cooked meat warm.

So that the roast meat does not cool too quickly, warm the plates and serve the gravy very hot.








After slow cooking, turn the temperature down to 70 °C. Small pieces of meat can be kept warm for up to 45 minutes, larger pieces for up to 2 hours.

Bakes, gratins, toast

If you are grilling directly on the wire rack, the universal pan should also be inserted at level 1. The oven is kept cleaner.

Always place the ovenware on the wire rack.

The cooking information for a bake depends on the size of the cookware and the height of the bake. The figures in the table are only reference values.









| Bakes | Accessories and cookware | Level | Type of heating | Temperature in °C | Baking time in minutes |
|--|--------------------------|-------|---|-------------------|------------------------|
| Bake, sweet | Ovenproof dish | 1 |  | 180-200 | 45-55 |
| Soufflé | Ovenproof dish | 1 |  | 180-200 | 35-45 |
| | Ramekins | 1 |  | 200-220 | 20-30 |
| Pasta bake | Ovenproof dish | 1 |  | 190-210 | 35-50 |
| Lasagne | Ovenproof dish | 1 |  | 180-200 | 40-50 |
| Potato gratin, raw ingredients, max. 4 cm deep | Ovenproof dish | 1 |  | 170-190 | 50-60 |
| Toast with topping | Wire rack | 2 |  | 2 | 8-12 |






Convenience products

Observe the instructions on the packaging.

If you line the accessories with greaseproof paper, please make sure that the paper is suitable for these temperatures. Make sure the paper is a suitable size for the ovenware.

The cooking result is heavily dependent on the quality of the food. Browning and unevenness can sometimes be seen on the raw product.

| Meal | Accessories | Level | Type of heating | Temperature in °C, grill setting | Cooking time in minutes |
|--------------------------------|---------------|-------|---|----------------------------------|-------------------------|
| Pizza, frozen | | | | | |
| Pizza with thin base | Universal pan | 1 |  | 200-220 | 10-20 |
| Deep-pan pizza | Universal pan | 1 |  | 180-200 | 20-30 |
| Pizza baguette | Universal pan | 1 |  | 180-200 | 20-30 |
| Mini pizza | Universal pan | 1 |  | 200-220 | 5-15 |
| Pizza, chilled | Universal pan | 1 |  | 180-200 | 10-20 |
| Potato products, frozen | | | | | |
| Chips | Universal pan | 1 |  | 200-220 | 15-25 |
| Croquettes | Universal pan | 1 |  | 190-210 | 20-30 |
| Rösti, stuffed potato pockets | Universal pan | 1 |  | 190-210 | 20-30 |

| Meal | Accessories | Level | Type of heating | Temperature in °C, grill setting | Cooking time in minutes |
|---|---------------|-------|--|----------------------------------|-------------------------|
| Baked items, frozen | | | | | |
| Bread rolls, baguette | Universal pan | 1 |  | 180-200 | 10-20 |
| Pretzels (dough) | Universal pan | 1 |  | 180-200 | 15-25 |
| Baked items, prebaked | | | | | |
| Part-cooked rolls or part-cooked baguette | Universal pan | 1 |  | 170-190 | 5-15 |
| Processed portions, frozen | | | | | |
| Fish fingers | Universal pan | 1 |  | 210-230 | 15-25 |
| Strudel, frozen | Universal pan | 1 |  | 180-200 | 35-45 |

Special dishes

Your appliance can be set to temperatures between 50 and 275 °C. This is equally useful for producing creamy yoghurt as it is for making light yeast dough.




Yoghurt

Bring the milk (3.5 % fat) to the boil, cool down to 45 °C. Stir in 150 g of yoghurt. Pour into cups or small screw-lid jars, cover, then place on the wire rack. Preheat for 5 minutes to 50 °C, then prepare as indicated.

Proving dough

Prepare the yeast dough as per usual. Place it in a heat-resistant ceramic dish and cover. Preheat the cooking compartment for 5-10 minutes. Switch off the appliance and leave the dough to prove in the cooking compartment.

Preparation

| Dishes | Accessories | Level | Type of heating | Temperature in °C | Cooking time in minutes |
|---------------|---|--|---|--|-------------------------|
| Yoghurt | Place the cups or screw-lid jars on the wire rack | 1 |  | Preheat to 50°C, switch on the  oven light | 6-8 hrs |
| Proving dough | Heat-resistant dish | Place on the cooking compartment floor |  | Preheat to 50 °C, switch off the appliance | 5-10 mins |
| | | | | Place the yeast dough in the cooking compartment | 20-30 mins |



Defrosting

Remove the frozen food from the packaging and place in a suitable dish on the wire rack.

Please observe the manufacturer's instructions on the packaging.

The defrosting time depends on the amount and type of food.

Place poultry on a plate breast-side down.

| Dishes | Accessories | Level | Type of heating | Temperature in °C |
|--|-------------|-------|---|------------------------------|
| Delicate frozen foods e.g. cream gateaux, buttercream cakes, gateaux with chocolate or sugar-based icing, fruit, etc. | Wire rack | 1 |  | 0 °C, do not set temperature |
| Other frozen products Chicken, sausage and meat, bread and bread rolls, cake and other baked goods | Wire rack | 1 |  | 50 °C |





Desiccation

Use unblemished fruit and vegetables only and wash it thoroughly.

Drain off the excess water, then wipe it dry.

Insert the universal pan at shelf height 1, insert wire rack at shelf height 3. Line the universal pan and the wire rack with greaseproof or parchment paper.

Turn very juicy fruit or vegetables several times. Remove fruit and vegetables from the paper as soon as they have dried.

| Dishes | Level | Type of heating | Temperature in °C | Cooking time in hours |
|-------------------------|-------|---|-------------------|-----------------------|
| 600 g apple rings | 1+3 |  | 80 | approx. 5 |
| 800 g pear slices | 1+3 |  | 80 | approx. 8 |
| 1.5 kg damsons or plums | 1+3 |  | 80 | approx. 8-10 |
| 200 g herbs, washed | 1+3 |  | 80 | approx. 1½ |

Acrylamide in foodstuffs

Acrylamide is mainly produced in grain and potato products prepared at high temperatures, such as potato crisps, chips,

toast, bread rolls, bread or fine baked goods (biscuits, gingerbread, cookies).

Tips for keeping acrylamide to a minimum when preparing food

General

- Keep cooking times to a minimum.
- Cook meals until they are golden brown, but not too dark.
- Large, thick pieces of food contain less acrylamide.

Baking

With top/bottom heating max. 200 °C.

With 3D hot air or hot air max. 180 °C.

Biscuits

With top/bottom heating max. 190 °C.

With 3D hot air or hot air max. 170 °C.

Egg or egg yolk reduces the production of acrylamide.

Oven chips

Spread evenly over the baking tray, in a single layer. Bake at least 400 g per baking tray so that the chips do not dry out

Test dishes

These tables have been produced for test institutes to facilitate the inspection and testing of the various appliances.

In accordance with EN/IEC 60350.


Baking

When baking on two levels, always insert the baking tray above the universal pan.

Piped cookies: Food on baking trays that are placed in the oven at the same time will not necessarily all be ready at the same time.

German apple pie on 1 level: Place dark springform cake tins diagonally next to each other.



Note: For baking, use the lower of the temperatures indicated first.




| Dish | Accessories and ovenware | Level | Type of heating | Temperature in °C | Cooking time in minutes |
|----------------------------------|---|-------|-----------------|-------------------|-------------------------|
| Piped cookies | Baking tray | 2 | □ | 150-160 | 20-30 |
| | Baking tray | 1 | ⊗ | 140-150 | 20-30 |
| | Baking tray + universal pan | 3+1 | ⊗ | 140-150 | 25-40 |
| Small cakes (preheat) | Baking tray | 2 | □ | 160-170 | 20-30 |
| | Baking tray | 1 | ⊗ | 150-160 | 20-30 |
| | Baking tray + universal pan | 3+1 | ⊗ | 150-160 | 25-35 |
| Hot water sponge cake (pre-heat) | Springform cake tin on the wire rack | 1 | □ | 160-170 | 25-35 |
| | Springform cake tin on the wire rack | 1 | ⊗ | 160-170 | 25-35 |
| Double crust apple pie | Wire rack+ 2 springform cake tins, dia. 20 cm | 1 | ⊗ | 170-180 | 70-80 |


Grilling

If you are grilling food directly on the wire rack, the universal pan should also be inserted at level 1. The liquid will be caught and the oven remains cleaner.

| Meal | Accessories and cookware | Level | Type of heating | Temperature in °C | Cooking time in minutes |
|--|---------------------------|-------|--|-------------------|-------------------------|
| Making toast, preheat for 10 minutes | Wire rack + universal pan | 3+1 |  | 3 | 1-2 |
| Beefburgers, x 12* (do not preheat) | Wire rack + universal pan | 3+1 |  | 3 | 25-30 |

* turn over after 2/3 of the cooking time.





BSH Hausgeräte GmbH
Carl-Wery-Straße 34, 81739 München, GERMANY

siemens-home.com



9000722747 950218