

# Tumble dryer

### siemens-home.bsh-group.com/welcome

en Installation and operating instructions

Register your product online

#### Your new tumble dryer

You have opted for a tumble dryer manufactured by Siemens.

Please take a few minutes to read and become familiar with the advantages of your tumble dryer.

To meet the high quality demands required by Siemens, every tumble dryer that leaves our factory is carefully checked to ensure that it functions correctly and is in perfect condition.

For more information on our products, accessories, replacement parts and services, see our website www.siemenshome.bsh-group.com or contact our Customer Service centres.

If the operating and installation instructions describe different models, any differences will be pointed out at the relevant points in the text.



Read these operating and installation instructions before operating the tumble dryer.

#### **Display rules**

#### ▲ Warning!

This combination of symbol and signal word indicates a possibly dangerous situation. Not heeding the warning can cause death or injuries.

#### Caution!

This signal word indicates a possibly dangerous situation. Not heeding the caution can cause property and/or environmental damage.

#### Note/tip

Information about the optimum use of the appliance/any other useful information.

#### 1. 2. 3. / a) b) c)

The steps are represented by numbers or letters.

#### / -

Lists are represented by a small box or a dash.

## **Table of contents**

8

<sup>9</sup> Intended use4
Safety instructions5Children/people/pets5Installation6Operation9Cleaning/Maintenance12
Energy-saving tips13
Installing and connecting the appliance
Appliance settings.18Childproof lock18Activating setting mode18Exiting setting mode19
Quick reference guide
Familiarising yourself with your appliance
<sup>C</sup> P Overview of programmes24
P+ Programme settings26
Laundry.28Preparing the laundry.28Sorting laundry.29

## Operating the appliance ...... 30

Loading laundry and switching on
the appliance
Setting a programme
Starting a programme
Programme progress
Changing the programme
or adding more laundry
Cancelling the programme
Programme end
Removing laundry and switching off
the appliance
Emptying the condensation
container
Removing the fluff
Home Connect
Calling up the Home Connect
menu

menu
Connecting to the home network
and the Home Connect app
Activating/deactivating Wi-Fi
Resetting your network settings39
Updating the software
Information on data protection40
Declaration of Conformity40

<b>∱</b> ↓ ∟∆	Draining the condensation water4	1
	Cleaning and maintenance4	4
Clea	aning the appliance	4

Cleaning the moisture sensor	 44
Cleaning the filter in	
the condensation container	 45

#### en Intended use

	nformation on the display 46
?	lelp with the appliance 47
	Fransporting the appliance 49
	Consumption values 50
	Imption values table
for co	tton laundry
ך ?	Cechnical specifications 51
କ୍ଷିଥି ।	Disposal51
	After-sales service

### <sup>§</sup> Note: Note: Section 1 and the section 1

- This appliance is intended for private domestic use only.
- Do not install or operate this appliance anywhere that is liable to experience frost and/or outdoor conditions. There is a risk that the appliance will be damaged if residual water in it freezes. If hoses freeze up, they may crack/burst.
- This appliance must only be used for drying and freshening up domestic laundry, consisting of items that have been washed with water and are suitable for tumble drying (see label on item). Using the appliance for any other purpose is outside of the scope of its intended application and is forbidden.
- This appliance is intended for use up to a maximum height of 4000 metres above sea level.

#### Before you switch on the appliance:

Check that there is no visible damage to the appliance. Do not operate the appliance if it is damaged. Should you have any problems, please contact your specialist dealer or our customer service.

Read and follow the operating and installation instructions and all other information provided with this appliance.

Retain the documents for subsequent use or for subsequent owners.

## A Safety instructions

The following safety information and warnings are provided to protect you from injury and to prevent material damage to your surroundings.

It is nevertheless important to take the necessary precautions and to proceed with care when installing, maintaining, cleaning and operating the appliance.

### Children/people/pets

### ▲ Warning Risk of death!

Children and other people who are unable to assess the risks involved when using the appliance may injure themselves or may find themselves in life-threatening situations. Therefore please note:

- The appliance may be used by children over the age of 8 years and by persons with reduced physical, sensory or mental capacity or by persons with a lack of experience or knowledge as long as they are supervised or have received instruction on how to use the appliance safely and they have understood the potential risks of using the appliance.
- Children must not play with this appliance.

- Do not allow children to clean or maintain this appliance unsupervised.
- Keep children under 3 years and pets away from this appliance.
- Do not leave the appliance unattended when children or other people who are unable to assess the risks are in the vicinity.

### ▲ Warning Risk of death!

Children may lock themselves inside appliances and find themselves in a life-threatening situation.

- Do not position the appliance behind a door, as this may obstruct the appliance door or prevent it from opening completely.
- Once an appliance has reached the end of its life, pull the mains plug from the socket **before** severing the mains cable, and then destroy the lock on the appliance door.

## Marning Risk of suffocation!

If allowed to play with the packaging/plastic film or packing components, children may become caught in these or pull them over their heads and suffocate.

Keep packaging, plastic film and packing components away from children.

### ▲ Warning Risk of poisoning!

Detergents and care products may result in poisoning if consumed.

If accidentally swallowed, seek medical advice. Keep detergents and care products out of the reach of children.

## Marning Eye/skin irritation!

Contact with detergents or care products may cause eye/skin irritation.

Rinse eyes/skin thoroughly if they/it come(s) into contact with detergents or care products. Keep detergents and care products out of the reach of children.

## Installation

#### Warning Risk of electric shock/fire/ material damage/damage to the appliance!

If the appliance is not installed properly, this may lead to a dangerous situation. Ensure the following:

- The mains voltage on your power socket must match the rated voltage specified on the appliance (identification plate). The connected loads and the required fuse protection are specified on the identification plate.
- The appliance must not be supplied through an external switching device, such as a timer, or connected to a circuit that is regularly switched on and off by a utility.
- The mains plug and the protective contact socket must match and the earthing system must be correctly installed.
- The installation must have an adequate cross section.

- The mains plug must be freely accessible at all times. If this is not possible, in order to comply with the relevant safety regulations, a switch (all pole disconnection) must be built into the permanent installation in accordance with electrical installation regulations.
- If using a residual current circuit breaker, only use one that bears the following mark: A line presence of this mark is the only way to be sure that it fulfils all the applicable regulations.

#### **Marning**

#### Risk of electric shock/fire/ material damage/damage to the appliance!

If the appliance's mains cable is altered or damaged, this may result in electric shock, short circuiting or fire due to overheating.

The mains cable must not be kinked, crushed or altered, and must not come into contact with any heat sources.

### \land Warning

#### Risk of fire/material damage/ damage to the appliance!

The use of extension cords or power strips may result in fire due to overheating or short circuiting.

Connect the appliance directly to an earthed socket that has been correctly installed. Do not use extension cords, power strips or multi-way couplers.

#### Warning Risk of injury/material damage/damage to the appliance!

- The appliance may vibrate or move when in operation, potentially resulting in injury or material damage.
   Place the appliance on a clean, even, solid surface and, using a spirit level to guide you, level it with the screw-in feet.
- Incorrectly placing (stacking) this appliance on top of a washing machine may result in injury, material damage and/or damage to the appliance.

If this appliance is to be placed on top of a washing machine, the washing machine must be of at least the same depth and width as the appliance, and it must be secured in place with the appropriate connection set if available.  $\rightarrow Page \ 18$ The appliance MUST be secured with this connection set. Stacking the appliance in any other way is forbidden.  If you take hold of any of the appliance's protruding parts (e.g. the appliance door) in order to lift or move it, these parts may break off and cause injury.

Do not take hold of any of the appliance's protruding parts in order to move the appliance.

### ⚠ Warning Risk of injury!

- The appliance is very heavy. Lifting it may result in injury. Do not lift the appliance on your own.
- The appliance has sharp edges on which you could cut your hands.
   Do not take hold of the appliance by its sharp edges. Wear protective gloves to lift it.
- If the hoses and mains cables are not correctly routed, they may constitute a tripping hazard, which may result in injury.
   Route hoses and cables such that they do not constitute a tripping hazard.

### Operation

#### ▲ Warning Risk of explosions/fire!

Laundry that has come into contact with solvents, oil, wax, wax remover, paint, grease or stain remover may ignite when dried in the machine, or even cause the appliance to explode. Therefore please note:

- Rinse the laundry thoroughly with warm water and detergent before drying it in the machine.
- Do not place laundry in this appliance to be dried if the laundry has not been washed first.
- Do not use the appliance if industrial chemicals have been used to clean the laundry.

#### Marning Risk of explosions/fire!

- If there is any residual material left in the fluff filter, this may ignite when drying is in progress, or even cause the appliance to catch fire or explode.
  - Clean the fluff filter regularly.
- Certain objects may ignite when drying is in progress, or even cause the appliance to catch fire or explode. Remove any lighters or matches from pockets on items of clothing.
- If there is coal dust or flour in the air around the appliance, this may cause an explosion. Make sure that the area around the appliance is kept clean when it is in operation.

### \Lambda Warning

#### Risk of fire/material damage/ damage to the appliance!

The appliance contains R290, a refrigerant that is environmentally friendly but flammable. Keep open fire and ignition sources away from the appliance.



### \Lambda Warning

#### Risk of fire/material damage/ damage to the appliance!

If a program is terminated before the drying cycle has finished, this prevents the laundry from cooling down sufficiently and may cause the laundry to ignite, or may result in material damage or damage to the appliance.

- During the last part of the drying cycle, the laundry in the drum is not heated (cooling cycle). This is to ensure that it remains at a temperature at which it will not be damaged.
- Do not switch off the appliance before the drying cycle has finished unless you remove all items of laundry from the drum immediately and spread them out (to dissipate the heat).

#### Warning Risk of poisoning/material damage!

Condensation water is not suitable for drinking and may be contaminated with lint. Contaminated condensation water may be hazardous to health and may cause material damage.

Do not drink or reuse.

### ▲ Warning Risk of poisoning!

Poisonous fumes may be given off by cleaning agents that contain solvents, e.g. cleaning solvent.

Do not use cleaning agents that contain solvents.

### ▲ Warning Risk of injury!

 If you support your weight/sit on the appliance door when it is open, the appliance may tip over, which may result in injury.

Do not support your weight on the appliance door when it is open.

 If you climb onto the appliance, the worktop may break, which may result in injury.

Do not climb onto the appliance.

 If you reach into the drum while it is still rotating, you risk injuring your hands. Wait until the drum has stopped rotating.

#### Caution! Material damage/damage to the appliance

 If the amount of laundry in the appliance exceeds its maximum load capacity, it may not be able to operate properly, or this may result in material damage or damage to the appliance.

Do not exceed the maximum load capacity of dry laundry. Make sure you comply with the maximum load capacities specified for each of the programs.  $\rightarrow$  Page 24

- If you operate the appliance without a fluff catcher (e.g. fluff filter, fluff depot, depending on appliance specifications), or if the fluff catcher is incomplete or defective, this may result in damage to the appliance. Do not operate the appliance without a fluff catcher, or with a fluff catcher that is incomplete or defective.
- Light objects such as hair and lint may be sucked into the air inlet when the appliance is in operation. Keep these away from the appliance.
- Foam and foam rubber may deform or melt if dried in the appliance.

Do not dry laundry items that contain foam or foam rubber in the appliance.

- If you pour the wrong quantity of detergent or cleaning agent into the appliance, this may result in material damage or damage to the appliance. Use detergents/care products/cleaning agents and softeners in accordance with the manufacturers' instructions.
- If the appliance overheats, it may not be able to operate properly, or this may result in material damage or damage to the appliance. Make sure that the appliance's air inlet is never obstructed when the appliance is in operation, and that the area around the appliance is adequately ventilated.

### **Cleaning/Maintenance**

### ▲ Warning Risk of death!

The appliance is powered by electricity. There is a risk of electric shock if you come into contact with live components. Therefore please note:

- Switch off the appliance. Disconnect the appliance from the power supply (pull out the plug).
- Never take hold of the mains plug with wet hands.
- When removing the mains plug from the socket, always take hold of the plug itself and never the mains cable, otherwise this may damage the mains cable.
- Do not make any technical modifications to the appliance or its features.
- Repairs and any other work on the appliance must only be conducted by our customer service or by an electrician. The same applies for replacing the mains cable (when necessary).
- Spare mains cables can be ordered from our customer service.

### ▲ Warning Risk of poisoning!

Poisonous fumes may be given off by cleaning agents that contain solvents, e.g. cleaning solvent.

Do not use cleaning agents that contain solvents.

#### A Warning Risk of electric shock/material damage/damage to the appliance!

If moisture penetrates the appliance, this may cause it to short circuit.

Do not use a pressure washer, steam cleaner, hose or spray gun to clean your appliance.

#### Warning Risk of injury/material damage/damage to the appliance!

The use of spare parts and accessories supplied by other brands is dangerous and may result in injury, material damage or damage to the appliance. For safety reasons, use genuine spare parts and accessories only.

#### **Caution!**

## Material damage/damage to the appliance

Cleaning agents and agents for pretreating laundry (e.g. stain removers, prewash sprays, etc.) may cause damage if they come into contact with the surfaces of the appliance. Therefore please note:

- Do not allow these agents to come into contact with the surfaces of the appliance.
- Clean the appliance with nothing but water and a soft, damp cloth.
- Remove any detergent, spray or other residues immediately.

## Energy-saving tips

- Spin the laundry before drying. The drier the laundry, the shorter the programme will be, in turn reducing energy consumption.
- Load the appliance with the maximum loads permitted for the programmes.


**Note:** If the maximum load is exceeded, this extends the programme duration and increases energy consumption.

- Operate the appliance in a ventilated room and make sure that the air inlet on the appliance is unobstructed so that air exchange can take place unhindered.
- Regularly remove the fluff from the appliance. If there is fluff in the appliance, this extends the programme duration and increases energy consumption.
- If you do not perform any actions on the appliance for an extended period before the programme starts or once the programme has ended, the appliance will automatically switch to Energy saving mode. The display and indicator lights will go out after a few minutes and **Start/Pause** ►II will flash.To end Energy saving mode, all you need to do is perform an action on the appliance, such as opening and closing the door.
- If you do not perform any actions on the appliance for an extended period when it is in Energy saving mode, the appliance will automatically switch itself off.

**Note:** If Wi-Fi is activated, the appliance will not switch itself off automatically.

### Installing and connecting the appliance

#### Included with the appliance:



- Accompanying documents (e.g. installation and operating instructions)
- 2 Fastening parts
- 3 U-piece for fixing the drain hose in place
- 4 Drain hose
- 5 Connection adapter
- 1. Remove any packaging and protective covers completely from the appliance.
- 2. Open the door.
- 3. Remove all the accessories from the drum.

You can now install and connect the appliance.

#### Caution!

## Risk of material damage/damage to the appliance

Objects remaining in the drum that are not designed for operation with the appliance may result in material damage and damage to the appliance. Remove these objects, along with all accessories, from the drum.

### Installing the appliance

## Warning Risk of death!

Children may lock themselves inside appliances and find themselves in a lifethreatening situation.

- Do not position the appliance behind a door, as this may obstruct the appliance door or prevent it from opening completely.
- Once an appliance has reached the end of its life, pull the mains plug from the socket **before** severing the mains cable, and then destroy the lock on the appliance door.

#### Marning Risk of explosions/fire!

If there is coal dust or flour in the air around the appliance, this may cause an explosion.

Make sure that the area around the appliance is kept clean when it is in operation.

#### **Marning**

## Risk of fire/material damage/damage to the appliance!

The appliance contains R290, a refrigerant that is environmentally friendly but flammable.

Keep open fire and ignition sources away from the appliance.



#### Warning Risk of injury/material damage/ damage to the appliance!

 The appliance may vibrate or move when in operation, potentially resulting in injury or material damage.

Place the appliance on a clean, even, solid surface and, using a spirit level to guide you, level it with the screw-in feet.

 Incorrectly placing (stacking) this appliance on top of a washing machine may result in injury, material damage and/or damage to the appliance.

If this appliance is to be placed on top of a washing machine, the washing machine must be of at least the same depth and width as the appliance, and it must be secured in place with the appropriate connection set if available.

 $\rightarrow$  Page 18

The appliance MUST be secured with this connection set. Stacking the appliance in any other way is forbidden.

If you take hold of any of the appliance's protruding parts (e.g. the appliance door) in order to lift or move it, these parts may break off and cause injury.

Do not take hold of any of the appliance's protruding parts in order to move the appliance.

#### Warning Risk of injury!

- The appliance is very heavy. Lifting it may result in injury.
   Do not lift the appliance on your own.
- The appliance has sharp edges on which you could cut your hands.
   Do not take hold of the appliance by its sharp edges. Wear protective gloves to lift it.

#### Caution!


## Material damage/damage to the appliance

If the appliance overheats, it may not be able to operate properly, or this may result in material damage or damage to the appliance.

Make sure that the appliance's air inlet is never obstructed when the appliance is in operation, and that the area around the appliance is adequately ventilated.

#### Install the appliance as follows:

- 1. Place the appliance on a clean, even, solid surface.
- 2. Check that the appliance is level using a spirit level.



**3.** If necessary, turn the appliance feet to make sure it is level.

You can now connect the appliance.

#### Notes

- All appliance feet must stand firmly on the ground.
- If appliances are not installed correctly, this may result in noises, vibrations, uneven drum operation and/or to residual water leaking out of the appliance.

### **Connecting the appliance**

#### \land Warning

## Risk of electric shock/fire/material damage/damage to the appliance!

If the appliance is not installed properly, this may lead to a dangerous situation. Ensure the following:

- The mains voltage on your power socket must match the rated voltage specified on the appliance (identification plate). The connected loads and the required fuse protection are specified on the identification plate.
- The appliance must not be supplied through an external switching device, such as a timer, or connected to a circuit that is regularly switched on and off by a utility.
- The mains plug and the protective contact socket must match and the earthing system must be correctly installed.
- The installation must have an adequate cross section.
- The mains plug must be freely accessible at all times. If this is not possible, in order to comply with the relevant safety regulations, a switch (all pole disconnection) must be built into the permanent installation in accordance with electrical installation regulations.
- If using a residual current circuit breaker, only use one that bears the following mark: A The presence of this mark is the only way to be sure that it fulfils all the applicable regulations.

### **Marning**

## Risk of electric shock/fire/material damage/damage to the appliance!

If the appliance's mains cable is altered or damaged, this may result in electric shock, short circuiting or fire due to overheating.

The mains cable must not be kinked, crushed or altered, and must not come into contact with any heat sources.

#### Warning Risk of fire/material damage/damage to the appliance!

The use of extension cords or power strips may result in fire due to overheating or short circuiting. Connect the appliance directly to an earthed socket that has been correctly installed. Do not use extension cords, power strips or multi-way couplers.


## Warning Risk of injury!

If the hoses and mains cables are not correctly routed, they may constitute a tripping hazard, which may result in injury.

Route hoses and cables such that they do not constitute a tripping hazard.

#### Connect the appliance as follows:

1. Connecting the drain hose.  $\rightarrow$  Page 41



- 2. Plug the appliance's mains plug into the designated socket.
- 3. Check that the mains plug is in securely.

Your appliance is now ready to use.

#### Caution!

## Risk of material damage/damage to the appliance

The appliance contains refrigerant and may be damaged if it is operated immediately after transportation. Allow the appliance to rest for two hours before initial use.

**Note:** If in doubt, have your appliance connected by a qualified professional.

## Before using the appliance for the first time

#### Before you switch on the appliance:

Check that there is no visible damage to the appliance. Do not operate the appliance if it is damaged. Should you have any problems, please contact your specialist dealer or our customer service.

**Note:** Once the appliance has been properly installed and connected, it is ready to use. No further steps are necessary.

### **Optional accessories**

Order optional accessories\* from the after-sales service:

**Basket for woollens:** Dry or air individual woollen items, sports shoes and soft toys in the basket for woollens.

Order number: WZ20600.

Platform:

.

For easier loading and unloading, raise your dryer with a platform. You can transport laundry with the laundry basket integrated into the platform drawer.

- Order number: WZ20500.

 Washer-dryer stack connection kit: To save space, the dryer can be placed on top of a suitable washing machine of the same width and depth.

Only this connection kit may be used to secure the dryer to the washing machine.

- Order number with pull-out worktop: WZ20400
- Order number without pull-out worktop: **WZ11410**.

## b Appliance settings

### Childproof lock

Activating the childproof lock prevents the settings from being accidentally changed on the control panel.


## Activating/deactivating the childproof lock:

Press and hold (Childproof lock)
 Sec. for 3 seconds.

**Note:** The childproof lock will remain active, even once the appliance has been switched off. If you wish to change settings on the control panel when you turn on the appliance, you will need to deactivate the childproof lock.

### Activating setting mode


In order to apply the settings described below, you will first need to activate setting mode. The options on the programme selector that will allow you to do this are as follows:



- 1 Activate setting mode
- 2 Activate **setting mode** and adjust **audible notification signal** volume
- 3 Adjust the **audible button signal** volume
- 4 Automatic switch-off function

\* Depending on the appliance features

1. Switch on the appliance.



- 2. Turn the programme selector to position 1.
- 3. Press Adjust ≚ and, at the same time, turn the programme selector to position 2.
- 4. Release Adjust 🖄.

Setting mode is now activated.

#### Changing the audible signal volume

You can adjust the volume of audible notification signals (that indicate that a programme has ended, for example) and audible button signals by turning the rotary selector to the following positions:

- 2: Audible notification signal volume
- 3: Audible button signal volume
- 1. Activate setting mode.
- 2. Turn the programme selector to the required position.
- Use the (Finish in) (b) + or button to set the volume you require (0 = off; 4 = very loud).

## Switching the automatic switch-off function on/off

If the appliance is not used for an extended period, it may automatically switch itself off until a programme starts or when a programme has ended in order to save energy. It can be switched back on again at any time by pressing ①.

You can switch the appliance's automatic switch-off function on or off as follows:

- 1. Activate setting mode.
- 2. Turn the programme selector to position 4.
- 3. Use the (Finish in) (b) + or button to switch the appliance's automatic switch-off function on or off.

**Note:** If Wi-Fi is activated, the appliance will not switch itself off automatically.


#### **Exiting setting mode**

Once you have applied all the settings, press ① to switch off the appliance.

The settings you have selected will be saved and will take effect the next time the washing machine is switched on.

## 🖗 Quick reference guide


Note: The appliance must be correctly installed and connected.  $\rightarrow$  Page 14



Remove the fluff.

## Familiarising yourself with your appliance

#### **Appliance overview**



- **1** Condensation container
- 2 Control panel

**Drum interior lighting** (depending on the model)

- 4 Air inlet
- 5 Door
- 6 Fluff filter

### Panel

22

<ol> <li>Programmes → Page 24</li> <li>Programme selector         <ul> <li>Press to switch the appliance on/off</li> <li>Turn to set a programme</li> </ul> </li> <li>Childproof lock         <ul> <li>Prevents the functions you have set from being changed accidentally. To activate/deactivate it:→ Page 18</li> <li>Anti-Crease 60 min</li> <li>Anti-Crease 120 min</li> <li>Low-Heat Drying</li> <li>Display             <ul> <li>Display settings and information</li> <li>▶ II for:</li> <li>If the set of the</li></ul></li></ul></li></ol>
<ul> <li>Starting a programme</li> <li>Pausing a programme, e.g. to add items of laundry</li> <li>Cancelling a programme</li> <li>9 Ready in</li> <li>10 Degree of dryness</li> <li>11 Dryness level</li> <li>12 Audible signal</li> <li>13 Remote start and Home Connect settings→ Page 35</li> </ul>

## Display

	⊞⁺ ≜` 💩 – – □
(ș 🗋	
≗ i i i i i i i i i i i i i i i i i i i	Empty the condensation container → Page 32 Remove the fluff → Page 33 The heat exchanger is being cleaned automatically Programme progress for: Drying Iron Dry Cupboard Dry Anti-Crease Pause
, - 0 -	Programme end
Ŷ E ☆ * C (	Dryness levels for: Iron Dry Cupboard Dry Cupboard Dry Plus Degree of dryness selected Remote start selected Off: Wi-Fi is switched off and the appliance is not connected to your home network Flashing: The appliance is trying to connect to your home network Lit: Wi-Fi is switched on and the appliance is connected to your home network
© 1:27 3h	Timed programme selected Expected programme duration in hours and minutes Programme delay in hours when "Ready in" time is selected

## **Overview of programmes**

Programme	Maximum load
<b>Programme name</b> Brief explanation of the programme and the items for which it is suitable.	Maximum load based on the dry weight of the items
Cottons Hard-wearing items and heat-resistant items made of cotton or linen.	9 kg
Easy-Care	3.5 kg
Items made of synthetic or blended fabrics.	3.5 KY
Mix	3 kg
Mixed load consisting of items made from cotton and synthetic fabrics.	e ng
<b>Lingerie</b> Delicate, washable underwear, e.g. made from lace, Lycra, satin or blended fabrics.	1 kg
<ul> <li>Wool Finish</li> <li>Machine-washable items made of wool or containing wool.</li> <li>Notes</li> <li>Laundry becomes fluffier but not dry.</li> <li>Remove laundry once the programme has ended and allow to dry.</li> </ul>	0.5 kg
Cold (L)	3 kg
Timed programme for all types of fabric except for wool and silk.	
For freshening up or airing clothing that has hardly been worn.	
Note: You can adjust the programme duration. → "Programme settings" on page 26	
Warm 🕒	3 kg
Timed programme for all types of fabric except silk. Suitable for pre-dried or slightly damp laundry and for drying off multi-layered, thick laundry.	Max. load for wool- lens/soft toys in the basket: 1 basket load
<ul> <li>Notes</li> <li>Dry woollens, sports shoes and soft toys only with the basket for woollens.</li> <li>In the timed programme, the laundry's remaining moisture is not automatically detected. If the laundry is still too damp when the drying programme has ended, repeat the programme and, if required, extend the programme duration.</li> <li>→ "Programme settings" on page 26</li> </ul>	Max. load for shoes in the basket: 1 pair
Shirts/Business	1.5 kg
Shirts/blouses made of cotton, linen, or synthetic or blended fabrics.	
<b>Note:</b> Once the laundry is dry, iron it or hang it up. This will allow the residual mois- ture to be distributed evenly.	

ture to be distributed evenly.

Duvet Clothing, pillows, quilts or bedspreads filled with synthetic fibres. Note: Dry large items individually. Follow the instructions on the care label.	2.5 kg
Pillow Pillows stuffed with down or synthetic fibres. Note: Once the programme has ended, shake down-stuffed pillows to distribute the stuffing and eliminate any pockets of moisture. Restart the programme if neces- sary.	1 pillow
<b>Outdoor</b> Weatherproof and outdoor clothing with a membrane coating and water-repellent fabrics.	1 item
<b>Towels</b> Hard-wearing towels and dressing gowns made of cotton.	6 kg
Super 40' Mixed load of synthetic fabrics and light cottons.	2 kg
Hygiene Hard-wearing items. Note: The programme reaches high temperatures. Particularly suitable for strict hygiene requirements.	4 kg

## P+ Programme settings

Buttons	Displays	Explanations and information
Note: Not all buttons a	nd their functions	can be selected in all programmes.
Remote Start ⊡ੈ		Pressing <b>Remote Start</b> <sup>(1)</sup> enables the appliance to be started remotely via the Home Connect app and takes you to the Home Connect settings.
		<ul> <li>Pressing this button briefly enables the appliance to be started remotely via the Home Connect app. Remote start remains enabled for 24 hours after it has been activated. It is automatically deactivated if you do not start the programme via the Home Connect app during this time. If you carry out any operations on the appliance itself, such as opening the door or selecting a different programme, the remote start button will be deactivated for safety reasons.</li> <li>Notes</li> <li>Remote start can only be activated if the appliance door is closed.</li> </ul>
		Remote start cannot be activated if the childproof lock is on. Press and hold this button for at least 3 seconds to go to the Home Connect settings $\rightarrow Page 35$ .
C Level 🖄 :		Select the dryness level depending on the required degree of dryness.
		If you have selected a dryness level, this will be stored for the selected programme even after the appliance has been switched off. Exception: The settings will not be saved for Cottons.
cupboard extra plus	<b>⊡</b> *	Multi-layered, thick laundry that does not dry readily.
cupboard dry	Ŧ	Normal, single-layered laundry.
iron dry	Þ	Normal, single-layered laundry that still needs to be damp after drying and is suitable for ironing or hanging up.
Adjust <u>≭</u>	* * * * * *	If you think the laundry is still too damp when the drying pro- gramme has ended, you can adjust the degree of dryness to achieve a particular dryness level. To increase the dryness level, set the degree of dryness to between $*$ and $* * *$ . This will extend the programme duration but the temperature will remain the same. Once you have adjusted the degree of dryness for a pro- gramme, this setting will be retained for the programme even after the appliance has been switched off.

(Finish in) 🕒	1-24	<b>Before starting the programme</b> , you can preselect the pro- gramme end time ("Ready in" time) in hourly increments (h = hour), up to a maximum of 24 hours:
		<ol> <li>Select a programme. The programme duration will be displayed for the selected programme, e.g. <i>1</i>:45 (hours:minutes).</li> <li>Press (Finish in) ③ repeatedly until the required number of hours is displayed. Note: Use the (Finish in) ④ + button to increase the setting values, and the (Finish in) ④ - button to reduce them.</li> <li>Press Start/Pause ►II. This activates the time delay. Before the programme starts, the selected number of hours (e.g. B) is shown on the display and counts down until the drying programme starts. The duration of the programme will then be displayed.</li> <li>Note: The programme duration is included in the "Ready in"</li> </ol>
		time.
	E.g. 🕒 🕻 : ۲С	The drying time for <b>timed programmes</b> can be extended to up to 3 hours 30 minutes in 10-minute increments.
(Anticrease 60) 2 60' (Anticrease 120) 2 120'		The drum moves the laundry at regular intervals after drying to prevent creasing. You can extend the automatic Anti-Crease function by 60 minutes (by pressing (Anticrease 60) 27 60') or 120 minutes (by pressing (Anticrease 120) 27 120') after any programme has finished.
(Low heat) *//		Reduced temperature for delicate fabrics, e.g. polyacrylic or elastane; may increase the drying time.
(Signal) ♀		Use the (Signal) $\bigtriangleup$ button to activate or deactivate the audible signal that sounds to indicate that the programme has ended. If the setting has been selected, the button's indicator light will be lit and the signal tone is activated.

## 🕰 Laundry

#### Preparing the laundry

#### Warning Risk of explosions/fire!

Certain objects may ignite when drying is in progress, or even cause the appliance to catch fire or explode. Remove any lighters or matches from pockets on items of clothing.

#### **Caution!**

## Risk of damage to the drum and laundry

Leaving objects in the pockets of your clothing can cause damage to the drum and laundry when the appliance is in operation. Remove all objects (e.g. metal items) from clothing pockets.

Prepare the laundry as follows:

- Tie cloth belts, apron strings, etc. together or use a laundry bag.
- Close zips, hooks, eyelets and buttons. Button up large items of laundry, such as covers.
- Always dry very small items of laundry, e.g. babies' socks, together with large items such as towels.
- Use timed programmes for single items.
- Knitted items, such as T-shirts and jerseys, often shrink slightly the first time they are tumble-dried. Use a gentle programme.
- Do not overdry easy-care laundry. This leads to increased creasing of your laundry.

Some detergents and care products, e.g. starch or softeners, contain particles that may accumulate on the moisture sensor. This may impair the sensor's performance and, in turn, the drying result.

#### Notes

- When washing laundry to be tumble-dried, use the correct amount of detergent and care products as specified in the manufacturer's instructions.
- Clean the moisture sensor regularly  $\rightarrow$  Page 44.

#### Sorting laundry

**Note:** Load the laundry item by item into the appliance. For more effective drying, do not stuff an entire bundle of laundry into the dryer at once.

#### Caution!

## Risk of material damage to the dryer or laundry

Laundry that is unsuitable for tumbledrying may damage the appliance and the laundry when it is dried. Before you dry it, sort the laundry according to the information given on the care label:

- Suitable for tumble drying
- Dry at normal temperature
- Dry at low temperature
- Do not tumble-dry

When sorting the laundry to be dried, take the following points into account:

- To achieve an even drying result, only dry laundry of the same type of fabric and texture together.
   If you dry thin, thick and multilayered fabrics together, they will dry to differing degrees.
- Use the fabric descriptions given for the individual drying programmes to help you choose the most appropriate programme.
   → "Overview of programmes" on page 24

**Note:** You can select a timed programme to add extra drying time for laundry that is still damp.

#### Caution!

## Risk of material damage to the appliance and laundry

Do **not** tumble-dry the following items or fabrics in the appliance:


- Laundry contaminated with solvents, wax or grease.
- Unwashed items.
- Items made from non-breathable fabrics (e.g. rubber-coated).
- Items made from delicate fabrics, such as silk and curtains made of synthetic material.

### Operating the appliance


## Loading laundry and switching on the appliance

**Note:** The appliance must be correctly installed and connected.  $\rightarrow$  Page 14

- **1.** Prepare and sort the laundry.
- 2. Press ① to switch on the appliance.




3. Open the door. Check that the drum has been completely emptied. Empty it if necessary.



4. Load the laundry unfolded into the drum.



5. Close the appliance door.



#### Caution!

## Risk of material damage to the appliance or laundry.

Make sure that laundry is not trapped in the door.




**Note:** The appliance's drum is lit up after the door is opened and closed and once the programme has started. The drum's interior light goes out on its own.

#### Setting a programme

**Note:** If you have activated the childproof lock, you must deactivate it before you can set a programme.  $\rightarrow$  Page 18

1. Set the programme you require.



The programme settings will appear on the display.

2. Adjust the programme settings, if required.

→ "Programme settings" on page 26

### Starting a programme

#### Press Start/Pause ►II.

**Note:** If you want to prevent the programme from being adjusted inadvertently, you can activate the childproof lock.  $\rightarrow$  Page 18

#### **Programme progress**

The programme status will be indicated on the display.

**Note:** When a programme is selected, the expected drying time for the maximum permitted load is displayed. The moisture sensor measures the residual moisture in the laundry as it is being dried. The programme duration and the remaining time indicated on the display are automatically adjusted as the programme progresses, depending on how damp the laundry is (exception: Timed programmes).

## Changing the programme or adding more laundry

You can remove or add laundry and change or adjust the programme at any time during drying.

- 1. Open the door or press Start/ Pause ►II to pause the programme.
- 2. Add or remove laundry.
- If required, select a different programme or a different programme setting.
   → "Overview of programmes" on page 24
   → "Programme settings" on page 26
- 4. Close the door.
- 5. Press Start/Pause ►II.

**Note:** The programme duration is updated on the display, depending on the load and on the residual moisture in the laundry. The values displayed may change when the programme or load is changed.

#### **Cancelling the programme**

The programme can be cancelled at any time by opening the door or pressing **Start/Pause** ►II.

#### **Caution!**

#### Risk of fire. Laundry may catch fire.


If you cancel the programme, remove all items of laundry from the dryer and spread them out to allow the heat to dissipate.

#### **Programme end**


-  $\square$  - will appear on the display.

## Removing laundry and switching off the appliance

1. Remove the laundry.



2. Press ① to switch off the appliance.




## Emptying the condensation container


Condensation will form in the appliance as it dries the laundry.

If there is no drain hose connected to the appliance, the condensation water from the appliance will run into the condensation container. In this case, you will need to empty the condensation container each time the dryer finishes drying the laundry, and also if it becomes full before drying is complete.

1. Pull out the condensation container horizontally.




2. Pour out the condensation water.



#### **Caution!**

## Risk of harm to health and material damage

Condensation water is not suitable for drinking and may be contaminated with fluff. Contaminated condensation water may be harmful to your health and cause material damage. Do not drink the condensation water or reuse it. 3. Push the condensation container back into the appliance until you feel it lock into place.




**Note:** The filter in the condensation container filters the condensation water, which is used during the appliance's automatic cleaning cycle. The filter is cleaned by emptying out the condensation water. You should still check the filter regularly for any build-up, and remove this if necessary.  $\rightarrow$  "Cleaning the filter in the condensation container" on page 45

#### **Removing the fluff**


**Note:** During drying, fluff and hair from the laundry is trapped by the fluff filter. If the fluff filter is clogged or dirty, this reduces the flow of air, preventing the appliance from achieving optimal drying results. Dirty fluff filters increase the power consumption and increase the required drying time.

## Clean the fluff filter after each drying cycle:


- 1. Open the door and remove all fluff from it.
- 2. Pull out the two-part fluff filter.




**3.** Remove the fluff from the fluff filter recess. Ensure that no fluff falls into the open shaft.




4. Pull the two-part fluff filter apart.




5. Open the two parts of the filter.




6. Remove all fluff from both parts of the filter.



7. Rinse off fluff under warm, running water.



8. Dry the two parts of the fluff filter, snap them shut and reinsert the filter.



#### Caution! Material damage/damage to the appliance

If you operate the appliance without a fluff catcher (e.g. fluff filter, fluff depot, depending on appliance specifications), or if the fluff catcher is incomplete or defective, this may result in damage to the appliance.

Do not operate the appliance without a fluff catcher, or with a fluff catcher that is incomplete or defective.

## Home Connect

This appliance is Wi-Fi-capable and can be remotely controlled using a mobile device.

You can use the Home Connect app to do the following on your appliance from your mobile device:

- Set up programs and launch them.
- Adjust, activate and deactivate program settings.
- Query the status of programs.
- Adjust, activate and deactivate appliance settings.
- Switch off the appliance.

Before you can use the Home Connect functions, you will need to carry out the following steps:

- 1. Install the Home Connect app on your mobile device.
- 2. Register in the Home Connect app.
- Connect your appliance to your home network automatically or manually (you only need to do this the first time).
- 4. Connect your appliance to the Home Connect app.

You can find information about the app on our Home Connect website www.home-connect.com

Home Connect services are not available in every country. The availability of the Home Connect function depends on the availability of Home Connect services in your country. You can find information on this at: www.home-connect.com

#### Notes

- Please observe the safety precautions in this instruction manual and make sure that these are complied with even when operating the appliance via the Home Connect app while you are away from home. You must also follow the instructions in the Home Connect app.
- You cannot use the Home Connect app to make changes while the controls on the appliance are being operated. However, you can use the Home Connect app to see any adjustments made directly on the appliance itself.

## Calling up the Home Connect menu

In the Home Connect menu, you can create and view network connections, reset network settings, activate/ deactivate Wi-Fi and find other Home Connect functions.

- 1. Switch on the appliance.
- 2. Press and hold **Remote Start D** for at least 3 seconds.

*R*<sub>u</sub>*L* appears in the display. You are now in the Home Connect menu.

Note: Briefly press **Remote Start** □ to exit the Home Connect menu.

#### Connecting to the home network and the Home Connect app

Connect your appliance to the home network **automatically** or **manually** (you only need to do this the first time).

#### Notes

- If your home network router has a WPS function, you can connect the appliance to your home network automatically.
- If your home network router does not have a WPS function, you need to connect the appliance to your home network manually.

You must then connect to the Home Connect app.

**Note:** To connect your appliance to the home network, **Wi-Fi** must be activated on the appliance. **Wi-Fi** is deactivated on the appliance by default and is activated automatically when you connect your appliance to your home network.


## Connecting to your home network automatically

#### Step 2.1

Ensure that you are in the Home Connect menu.  $\rightarrow$  Page 35

#### 1. Press Start/Pause ►II.

The appliance now attempts to connect to your home network. The flashes in the display.



 Activate the WPS function on your home network router within the next 2 minutes.

If the appliance has connected to your home network successfully, *con* ✓ and *s* appear in the display and light up continuously.

**Note:** If you are not able to establish a connection, check whether your appliance is within range of your home network.Try connecting automatically again or connect your appliance manually.

# Connecting to your home network manually

### Step 2.2

Ensure that you are in the Home Connect menu.  $\rightarrow$  Page 35

Make sure that you have opened the Home Connect app and are logged in.

1. Set the programme to position 2.



**5***RP* (connect manually) appears in the display.

### 2. Press Start/Pause ►II.


The appliance now sets up its own Wi-Fi network with the name (SSID) **Home Connect**.



**3.** Call up the Wi-Fi setting on the mobile device.

 Connect the mobile device to the Home Connect Wi-Fi network and enter the password (key) HomeConnect.

Your mobile device now connects to the appliance. The connection process may take up to 60 seconds.



- Once you have connected successfully, open the Home Connect app on your mobile device and carry out the steps in the app.
- 6. In the Home Connect app, enter the network name (SSID) and password (key) for your home network.
- 7. Carry out the last steps in the Home Connect app to connect your appliance.

**Note:** If you are not able to establish a connection, check whether your appliance is within range of your home network. Try connecting manually again.

### Connecting to the Home Connect app

If your appliance is connected to your home network, you can connect it to the Home Connect app.

Ensure that you are in the Home Connect menu.  $\rightarrow$  Page 35

Make sure that you have opened the Home Connect app and are logged in.

1. Set the programme to position 3.



*RPP* (connect to app) appears in the display.

### 2. Press Start/Pause ►II.

The appliance now attempts to connect to the Home Connect app.

**3.** Once your appliance is displayed in the app, carry out the last steps in the Home Connect app.


**Note:** If you were not able to establish a connection, check whether your mobile end device is within range of your home network or is connected to this. Try connecting to the Home Connect app again.

### Activating/deactivating Wi-Fi

If your appliance is already connected to your home network, you can activate or deactivate **Wi-Fi** on your appliance.

Ensure that you are in the Home Connect menu.  $\rightarrow$  Page 35

**1.** Set the programme to position 4.



*Lan* (Wi-Fi function) appears in the display.

2. Press Start/Pause ►II.

If **on** appears in the display, Wi-Fi is activated on the appliance. If **oFF** appears in the display, Wi-Fi is deactivated on the appliance.

### Notes


- If you connect to your home network, Wi-Fi is activated automatically.
- If Wi-Fi is activated, the appliance will not switch itself off automatically.
- If Wi-Fi is switched off on the appliance, it is not possible to use the Home Connect app to start or control the appliance remotely.
- If Wi-Fi is switched off and your appliance was previously connected to your home network, this connection will be re-established automatically when Wi-Fi is switched back on.
- If you activate this function, the energy consumption increases in comparison to the values specified in the consumption value table.
  - $\rightarrow$  Page 50

# Resetting your network settings

You can reset all of the network settings.

Ensure that you are in the Home Connect menu.  $\rightarrow$  Page 35

1. Set the programme to position 5.



*rES* (reset network settings) appears in the display.

Press Start/Pause ►II.

*HES* appears in the display.

3. Press Start/Pause ►II.

**Note:** If you want to operate your appliance via the Home Connect app again, you will need to reconnect it to your home network and to the Home Connect app.


### Updating the software

You can update the Home Connect software on your appliance. As soon as a new software update is available, a note appears in the display: UPd

Install the update directly via the **message in the display** or **manually** as follows:

Ensure that you are in the Home Connect menu.  $\rightarrow$  Page 35

1. Set the programme to position 6.



**UP**<sup>*d*</sup> (update) appears in the display. Start/Pause▶ I flashes if a software update is available.

- 2. Press Start/Pause ►II.
- *YE5* appears in the display.
- 3. Press Start/Pause ►II.

**Note:** The software update may take several minutes. Do not switch the appliance off while updates are being installed.

### Information on data protection

When your appliance is connected for the first time to a Wi-Fi network, which is connected to the Internet, your appliance transmits the following categories of data to the Home Connect server (initial registration):

- Unique appliance identification (consisting of appliance codes as well as the MAC address of the installed Wi-Fi communication module).
- Security certificate of the Wi-Fi communication module (to ensure a secure data connection).
- The current software and hardware version of your household appliance.
- Status of any previous resetting to factory settings.

This initial registration prepares the Home Connect functions for use and is only required when you want to use these Home Connect functions for the first time.

**Note:** Ensure that the Home Connect functions can be used only in conjunction with the Home Connect app. Information on data protection can be accessed in the Home Connect app.

### **Declaration of Conformity**

BSH Hausgeräte GmbH hereby declares that the appliance with Home Connect functionality meets the basic requirements and other relevant provisions of the Directive 2014/53/EU.

A detailed RED Declaration of Conformity can be found online at www.siemens-home.bsh-group.com among the additional documents on the product page for your appliance.

# CE

2.4 GHz band: max. 100 mW

# Draining the condensation water


Condensation will form in the appliance as it dries the laundry.

You must ensure that the drain hose is connected when you operate the appliance.


If there is no drain hose connected to the appliance, the condensation water from the appliance will run into the condensation container. In this case, you will need to empty the condensation container each time the dryer finishes drying the laundry, and also if it becomes full before drying is complete.

### Connect the drain hose as follows:


1. Remove any accessories from the drum.



2. Remove all items from the bag.




3. Detach the condensation hose from the socket.




**Note:** The appliance comes delivered with the condensation hose already fitted to the socket.


4. Place the condensation hose in the "parked" position.




5. Take the drain hose from the accessories and attach it to the free socket, pushing it up to the stop.



 Secure the other side of the drain hose using the remaining accessories, depending on the connection situation.
 Washbasin:




### Siphon:



The connection point must be secured using a hose clamp (12-22 mm clamping range, available from specialist retailers). When connecting to a siphon, make sure that the drain hose is routed at a height of at least 80 cm, but no more than 100 cm.

### Floor drain:



### Caution!

## Risk of material damage due to leaks or draining water.


Secure the drain hose to prevent it from slipping out. Do not kink or bend the drain hose. The height difference between the surface on which the appliance is installed and the drain hose must be no more than 100 cm.

### Caution!


# Risk of accumulated water being drawn back into the appliance and causing material damage.

Check that the water drains away quickly. The drain must not be sealed or blocked.


7. Pull out the condensation container horizontally and empty it.




 Turn the condensation container 180° onto its underside and remove the stopper that is fitted.




 Turn the condensation container 180° again and insert the stopper into the recess in the top of the condensation container.




**10.** Pull the filter out of its snap-in lock.



**11.**Place the filter into the recess on the condensation container.



**12.** Slide in the condensation container until it clicks into place.



The condensation water is now discharged via the drain hose into the waste-water system or into a washbasin.

**Note:** If you want to drain the condensation water back into the condensation container, reverse these steps.

#### Caution!

## Risk of material damage/damage to the appliance

If you are draining condensation water into the condensation container, liquid may leak out of the socket and cause material damage. Before operating the appliance, make sure that the condensation hose is secured to the socket.

# Cleaning and maintenance

### **Cleaning the appliance**

### Warning Risk of death!

The appliance is powered by electricity. There is a risk of electric shock if you come into contact with live components. Therefore please note:

- Switch off the appliance. Disconnect the appliance from the power supply (pull out the plug).
- Never take hold of the mains plug with wet hands.
- When removing the mains plug from the socket, always take hold of the plug itself and never the mains cable, otherwise this may damage the mains cable.
- Do not make any technical modifications to the appliance or its features.
- Repairs and any other work on the appliance must only be conducted by our customer service or by an electrician. The same applies for replacing the mains cable (when necessary).
- Spare mains cables can be ordered from our customer service.

### Marning Risk of poisoning!

Poisonous fumes may be given off by cleaning agents that contain solvents, e.g. cleaning solvent.

Do not use cleaning agents that contain solvents.

### Warning

# Risk of electric shock/material damage/damage to the appliance!

If moisture penetrates the appliance, this may cause it to short circuit. Do not use a pressure washer, steam cleaner, hose or spray gun to clean your appliance.

#### Caution! Material damage/damage to the appliance


Cleaning agents and agents for pretreating laundry (e.g. stain removers, prewash sprays, etc.) may cause damage if they come into contact with the surfaces of the appliance. Therefore please note:

- Do not allow these agents to come into contact with the surfaces of the appliance.
- Clean the appliance with nothing but water and a soft, damp cloth.
- Remove any detergent, spray or other residues immediately.

### Cleaning the moisture sensor

**Note:** The moisture sensor measures the amount of moisture in the laundry. After long periods of usage, the moisture sensor may become covered by a fine layer of limescale or detergent and care product residue. These deposits must be removed regularly, otherwise the drying results may not be optimal.

1. Open the door.



2. Clean the moisture sensor with a rough sponge.



### Caution!


### Risk of damaging the moisture sensor.

The moisture sensor is made from stainless steel. Do not clean the sensor with abrasive cleaning products or wire wool.


# Cleaning the filter in the condensation container

**Note:** The filter in the condensation container cleans the condensation water, which is used during the appliance's automatic cleaning cycle.


1. Pull out the condensation container horizontally.



- 2. Pour out the condensation water.
- **3.** Remove the filter.



- 4. Clean the filter under warm, running water or in the dishwasher.
- 5. Push the filter in until you feel it lock into place.



#### Caution!

# If the filter is not inserted, fluff can find its way inside the appliance and damage it.

Only operate the appliance with the filter inserted.

6. Push the condensation container in until you feel it lock into place.

## Information on the display

Faults	Cause/remedy
台، on the display and drying has stopped.	<ul> <li>Empty the condensation container and reinsert it. → Page 32 Press Start/Pause ►II.</li> <li>Once you have installed the optional drain hose*, make sure that it: Is correctly connected → Page 41 Is free of kinks Is not blocked or clogged, e.g. with deposits</li> </ul>
歯 on the display.	Remove the fluff. $\rightarrow$ Page 33 Press Start/Pause $\triangleright$ II.
🛆 on the display.	Not a fault. The heat exchanger is being cleaned automatically. Do not pull out the condensation container while this is displayed.
I am unable to connect to my home network.	<ul> <li>Wi-Fi is switched off.To connect to your home network, switch on Wi-Fi. </li> <li>must appear on the display.</li> <li>Wi-Fi is switched on but a connection to your home network cannot be established.Check whether your home network is available or try to connect to your home network again.</li> </ul>
The display goes out and Start/Pause ►II flashes.	Not a fault. Energy saving mode is active .
* Depending on how the	appliance is equipped or the available accessory

**Note:** If you cannot rectify the fault yourself by turning the appliance off and then on again, please contact our after-sales service.  $\rightarrow$  Page 52

## **Provide a Series of Contract Se**

Faults	Cause/remedy
The appliance will not start.	Check the mains plug and the fuses.
Creasing.	<ul> <li>Load exceeded or incorrect programme selected for a type of fabric. All the required information can be found in the programme table. → Page 24</li> <li>Remove laundry from the drum as soon as the drying programme has finished. Creasing occurs when clothing is left in the drum.</li> </ul>
Water is leaking out.	The appliance may be positioned at an angle. Level the appliance. $\longrightarrow$ Page 14
Programme duration displayed changes as drying progresses.	Not a fault. The moisture sensor measures the residual moisture in the laundry and adjusts the programme duration (with the exception of timed programmes).
Laundry is not dried properly or is still too damp.	<ul> <li>After the programme has ended, warm laundry feels damper than it actually is. Spread out the laundry and let it cool down.</li> <li>Adjust the drying time or increase the degree of dryness. This will extend the drying time but the temperature will remain the same.</li> <li>Select a timed programme to add extra drying time for laundry that is still damp.</li> <li>Select a timed programme for a small load.</li> <li>Do not exceed the maximum load for a programme. → Page 24</li> <li>Clean the moisture sensor in the drum. The sensor may become covered in a fine layer of limescale or detergent and care product residue, which then impairs its performance. → Page 44</li> <li>Drying has been interrupted as a result of a power cut, because the condensation container is full or because the maximum drying time has been exceeded.</li> <li>Note: See also the laundry tips. → Page 28</li> </ul>
The programme will not start	Make sure that: ■ The door is closed. ■ (Childproof lock) ← 3 sec. has been deactivated ■ You have pressed Start/Pause ►II Note: If the programme has been delayed by setting (Finish in) (), the programme will start later.
Drying taking too long.	<ul> <li>The appliance may have fluff in it. This will increase the drying time. Remove the fluff. → Page 33</li> <li>If the air inlet on the appliance is blocked or not fully open, the drying time may increase. Make sure that the air inlet remains unobstructed.</li> <li>If the ambient temperature is lower than 15 °C or higher than 30 °C, this may increase the drying time.</li> <li>Inadequate air circulation in the room may increase the drying time. Make sure the room is adequately ventilated.</li> </ul>

Humidity in the room is increas- ing.	Make sure the room is sufficiently ventilated.
Drying programme is stopped.	If the drying programme is stopped due to a power failure, restart the programme or remove the laundry and spread it out.
Unusual noises when drying.	Automatic cleaning of the heat exchanger produces noises. This does not indicate that there is a malfunction on the appliance.
The appliance feels cold despite drying.	Not a fault. The appliance can dry effectively at low temperatures using a heat pump.
Home Connect is not working.	<ul> <li>You can find solutions to problems with Home Connect at www.home-connect.com.</li> <li>The availability of the Home Connect functionality depends on the availability of the Home Connect Services (e.g. provision of the app) in your country. Home Connect Services are not available in every country – for further information please check: www.home-connect.com.</li> </ul>
Residual water in the conden- sation container despite the appliance being connected to the drain hose*.	If the optional drain hose is installed, residual water remains in the con- densation container due to the appliance's self-cleaning function.
* Doponding on how the applian	ce is equipped or the available accessory

\* Depending on how the appliance is equipped or the available accessory

**Note:** If you cannot rectify the fault yourself by turning the appliance off and then on again, please contact our aftersales service.  $\rightarrow$  *Page 52* 

# Transporting the appliance

#### Warning Risk of injury/material damage/ damage to the appliance!


If you take hold of any of the appliance's protruding parts (e.g. the appliance door) in order to lift or move it, these parts may break off and cause injury. Do not take hold of any of the appliance's protruding parts in order to move the appliance.

### **Warning** Risk of injury!


- The appliance is very heavy. Lifting it may result in injury.
   Do not lift the appliance on your own.
- The appliance has sharp edges on which you could cut your hands. Do not take hold of the appliance by its sharp edges. Wear protective gloves to lift it.

# Prepare the appliance for transportation as follows:

1. Pull out the condensation container horizontally and empty it.



2. Push the condensation container back into the appliance until you feel it lock into place.



- 3. Switch on the appliance.
- 4. Set any programme.
- 5. Press Start/Pause ►II.
- 6. Wait for 5 minutes.
- The condensation water will be drained.
- 7. Empty the condensation container again.
- If installed, remove the drain hose from the washbasin, siphon or floor drain. → Page 41

Caution!

Secure the drain hose to the appliance to prevent it from slipping out. Do not kink the drain hose.

- 9. Switch off the appliance.
- **10.** Disconnect the appliance's mains plug from the power supply.

The appliance is now ready to be transported.

### Caution!

## Risk of material damage/damage to the appliance

Despite draining, there will always be some residual water in the appliance. Any residual water may leak out and cause material damage.

The appliance should therefore be transported upright.

### Consumption values

### **Consumption values table**

Programme	Spin speed used for spinning the laundry (in rpm)		tion** min)	Energy con (in k	
Cottons		9 kg	4.5 kg	9 kg	4.5 kg
cupboard dry ⊞*	1400	146	98	1.77	1.09
	1000	166	108	2.06	1.24
	800	186	118	2.35	1.39
iron dry 🔿*	1400	109	71	1.26	0.76
	1000	129	81	1.55	0.91
	800	149	91	1.84	1.06
Easy-Care		3.5 kg		3.5 kg	
cupboard dry ⊞*	800	57		0.55	
	600	65		0.65	

\* Programme setting in accordance with the applicable EN61121 standard when using the external drain hose.

\*\* The values may differ from those specified, depending on the type of fabric, composition of laundry to be dried, residual moisture in the laundry, the degree of dryness that has been set, the amount of laundry being loaded, the environmental conditions, and any additional functions that have been activated.

### Most efficient programme for cotton laundry

The "standard cottons programme" below (denoted by the  $\bigcirc$  symbol) is suitable for drying cotton laundry with a normal dampness level, and is the most efficient programme for drying damp cotton laundry in terms of combined energy consumption.

Standard programmes for cottons in accordance with current EU regulation 932/2012			
Programme + dryness level	Load (in kg)	Energy consumption (in kWh)	Programme duration (in min)
$\bigcirc$ Cottons + cupboard dry $\boxplus$	9/4.5	2.06/1.24	166/108
Programme setting for testing and energy labelling in accordance with Directive 2010/30/EU.			

### Technical specifications

### Dimensions:

85 x 60 x 60 mm (height x width x depth)

#### Weight:

57 kg (depending on the model)

#### Mains connection:

Mains voltage 220 - 240 V, 50 Hz

Nominal current 10 A

Nominal power max. 1000 W

### Maximum load:

9 kg

Power consumption when switched off: 0.10 W

Power consumption when left on:  $0.10\ \text{W}$ 

#### Drum interior light\*

#### Ambient temperature:

5 - 35 °C

## Power consumption when networked (Wi-Fi) in standby mode/duration:

1.8 W / 20 mins

### 🖏 Disposal

Dispose of packaging and the appliance in an environmentally responsible manner. This appliance is labelled in accordance with the European Directive 2012/19/EU, which governs waste electrical and electronic equipment (WEEE). The directive provides a framework for the collection and recycling of old appliances, which is valid across the EU.

### Caution!

# Risk of fire/risk of poisoning/risk of material damage and damage to the appliance

The appliance contains R290, a refrigerant that is environmentally friendly but flammable. If it is not disposed of correctly, this may result in fire or poisoning. Dispose of the appliance correctly and do not damage the pipes in the

refrigerant circuit.

Depending on the appliance features

### **After-sales service**

If you cannot rectify the fault yourself by turning the appliance off and then on again, please contact our after-sales service.  $\rightarrow$  Enclosed after-sales service directory or cover page

We will always find an appropriate solution in order to avoid unnecessary visits by engineers.

Please provide the after-sales service with the product number (E no.) and the production number (FD) of the appliance.

E-Nr	FD	

E no. Product number FD Production number

You can find this information, depending on the model\*:

On the inside of the door\*/open service flap\* and at the rear of the appliance.

# Trust in the expertise of the manufacturer.

Contact us for assistance. By doing so, you can be sure that the repairs are carried out by trained service engineers using genuine spare parts.

15	9
	Π
Y	/

15	9
	Π
Y	/

15	9
	Π
Y	/

### Repair order and advice in the event of faults

GB 0344 892 8999 (Calls charged at local or mobile rate.)

IE 01450 2655 (0.03 € per minute at peak. Off peak 0.0088 € per minute.)

You can find the contact information for all countries in the attached after-sales service directory.

BSH Hausgeräte GmbH Carl-Wery-Straße 34 81739 München GERMANY siemens-home.bsh-group.com

Manufactured by BSH Hausgeräte GmbH under Trademark License of Siemens AG

