

Table of contents

1 Safety	
1.2 Intended use	4 10.1 Starting an empty washing
 1.4 Safe installation	5 11 Laundry
3.1 Disposing of packaging	12.1 Detergent recommendation 351 12.2 Detergent dosage
3.3 Energy saving mode	2 13.1 Switching on the appliance 37 2 13.2 Setting a programme 37
 4.2 Contents of package	settings
5 Familiarising yourself with your appliance	 8 13.9 Soaking laundry
6 Display 2 7 Buttons 2	10.12 Headining the programme
8 Programmes	13.13 Unloading the laundry 39

14 C	hildproof lock	40
14.1	Activating the childproof lock	40
14.2	Deactivating the childproof lock	40
15 B	asic settings	41
15.1	Overview of the basic settings	
15.2	Changing the basic settings	
16 C	leaning and servicing	42
16.1	Tips on appliance care	42
	Cleaning the drum	42
16.3	Cleaning the detergent	4.0
16.4	drawer	4 đ 4 đ
	Cleaning the drain pump	
	Cleaning the water outlet	77
	hose at the siphon	
16.7	Clean the water inlet filters	46
17 T	roubleshooting	49
18 T	ransportation, storage and isposal	57
	Removing the appliance	
	Inserting the transit bolts	
	Using the appliance again	
18.4	Disposing of old appliance	58
19 C	ustomer Service	59
	Product number (E-Nr.) and	
	production number (FD)	59
20 C	onsumption values	60
21 T	echnical specifications	61



1 Safety

Observe the following safety instructions.

1.1 General information



- Read this instruction manual carefully.
- Keep the instruction manual and the product information safe for future reference or for the next owner.
- Do not connect the appliance if it has been damaged in transit.

1.2 Intended use

Only use this appliance:

- For washing machine-washable fabrics and hand-washable wool in accordance with the care label.
- With tap water and commercially available detergents and care products suitable for washing machines.
- In private households and in enclosed spaces in a domestic environment.
- Up to an altitude of max. 4000 m above sea level.

1.3 Restriction on user group

This appliance may be used by children aged 8 or over and by people who have reduced physical, sensory or mental abilities or inadequate experience and/or knowledge, provided that they are supervised or have been instructed on how to use the appliance safely and have understood the resulting dangers.

Children must not play with the appliance.

Cleaning and user maintenance must not be performed by children unless they are being supervised.

Keep children under the age of 3 years and pets away from the appliance.

1.4 Safe installation

Take note of the safety instructions when installing the appliance.

Improper installation is dangerous.

- ► Connect and operate the appliance only in accordance with the specifications on the rating plate.
- ► Connect the appliance to a power supply with alternating current only via a properly installed socket with earthing.
- ► The protective conductor system of the domestic electrical installation must be properly installed. The installation must have a sufficiently large cross section.
- ▶ When using a residual current circuit breaker, only use a type with the mark.
- ► Never equip the appliance with an external switching device, e.g. a timer or remote control.
- ▶ When the appliance is installed, the mains plug of the power cord must be freely accessible. If free access is not possible, an all-pole isolating switch must be installed in the permanent electrical installation according to the installation regulations.
- ▶ When installing the appliance, check that the power cable is not trapped or damaged.

If the insulation of the power cord is damaged, this is dangerous.

- ► Never let the power cord come into contact with hot appliance parts or heat sources.
- ► Never let the power cord come into contact with sharp points or edges.
- ▶ Never kink, crush or modify the power cord.

It is dangerous to use an extended power cord and non-approved adapters.

- ▶ Do not use extension cables or multiple socket strips.
- ▶ If the power cord is too short, contact Customer Service.
- ▶ Only use adapters approved by the manufacturer.

⚠ WARNING – Risk of injury!

The high weight of the appliance may result in injury when lifted.

▶ Do not lift the appliance on your own.

If this appliance is not correctly installed in a washer-dryer stack, the installed appliance may fall.

- ► Only stack the dryer on a washing machine using the connection kit from the dryer manufacturer. No other installation method is permitted.
- ➤ Do not install the appliance in a washer-dryer stack if the dryer manufacturer does not offer a suitable connection kit.
- ▶ Do not install appliances from different manufacturers and with varying depths and widths in a washer-dryer stack.
- ▶ Do not install a washer-dryer stack on a platform; the appliances may tip over.

△ WARNING – Risk of suffocation!

Children may put packaging material over their heads or wrap themselves up in it and suffocate.

- ► Keep packaging material away from children.
- ▶ Do not let children play with packaging material.

⚠ CAUTION – Risk of injury!

The appliance may vibrate or move when in use.

- ▶ Place the appliance on a clean, even, solid surface.
- ▶ Align the appliance using the appliance feet and a spirit level. If hoses and power cords have been laid incorrectly, this causes a tripping hazard.
- ► Lay hoses and power cords in such a way that there is no risk of tripping.

If the appliance is moved by holding onto protruding components, such as the appliance door, the parts may break off.

▶ Do not move the appliance by holding onto protruding parts.

△ CAUTION – Risk of cutting!

Touching sharp edges on the appliance may lead to cuts.

▶ Do not touch the sharp edges on the appliance.

► Wear protective gloves when installing and transporting the appliance.

1.5 Safe use

If the appliance or the power cord is damaged, this is dangerous.

- ▶ Never operate a damaged appliance.
- ▶ Never pull on the power cord to unplug the appliance. Always unplug the appliance at the mains.
- ▶ If the appliance or the power cord is damaged, immediately unplug the power cord or switch off the fuse in the fuse box and turn off the water tap.
- ► Call customer services. → Page 59

An ingress of moisture can cause an electric shock.

- ▶ Only use the appliance in enclosed spaces.
- ▶ Never expose the appliance to intense heat or humidity.
- ▶ Do not use steam- or high-pressure cleaners, hoses or sprays to clean the appliance.

⚠ WARNING – Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- ▶ Do not install the appliance behind a door as this may obstruct the appliance door or prevent it from opening.
- ▶ With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.

⚠ WARNING – Risk of suffocation!

Children may breathe in or swallow small parts, causing them to suffocate.

- ► Keep small parts away from children.
- ▶ Do not let children play with small parts.

△ WARNING – Risk of poisoning!

Detergents and care products may result in poisoning if consumed.

- ▶ If accidentally swallowed, seek medical advice.
- ► Keep detergents and care products out of the reach of children.

⚠ WARNING – Risk of explosion!

Laundry that has been pretreated with cleaning agents that contain solvents may cause an explosion in the appliance.

► Rinse pretreated laundry thoroughly with water before washing.

△ CAUTION – Risk of injury!

The covering plate may break if you stand on or climb onto the appliance.

▶ Do not stand on or climb onto the appliance.

The appliance may tip over if you sit on or lean against the open door.

- ▶ Do not sit on or lean against the appliance door.
- ▶ Do not place any objects on the appliance door.

Reaching into the drum while it is still turning may cause hand injuries.

▶ Wait for the drum to come to a complete stop before reaching inside.

⚠ CAUTION – Risk of burns!

When washing at high temperatures, the glass in the appliance door becomes hot.

- ▶ Do not touch the appliance door when it is hot.
- ► Keep children away from the appliance door when it is hot.

△ CAUTION – Risk of scalding!

When you wash at high temperatures, the detergent solution gets hot.

▶ Do not touch the hot detergent solution.

△ CAUTION – Risk of chemical burns!

If the detergent drawer is opened, detergent and care products may spray out from the appliance. Contact with eyes or skin may cause irritation.

- ► Rinse eyes and/or skin thoroughly with clean water if they come into contact with detergents or care products.
- ▶ If accidentally swallowed, seek medical advice.
- ► Keep detergents and care products out of the reach of children.

1.6 Safe cleaning and maintenance

Take note of the safety instructions when cleaning and performing maintenance work on the appliance.

Incorrect repairs are dangerous.

- ► Repairs to the appliance should only be carried out by trained specialist staff.
- ▶ Only use genuine spare parts when repairing the appliance.
- ▶ If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

An ingress of moisture can cause an electric shock.

▶ Do not use steam- or high-pressure cleaners, hoses or sprays to clean the appliance.

△ WARNING – Risk of injury!

The use of non-original spare parts and non-original accessories is dangerous.

► Only use the manufacturer's original spare parts and original accessories.

△ WARNING – Risk of poisoning!

Poisonous fumes may be given off if you use cleaning agents that contain solvents.

▶ Do not use cleaning agents that contain solvents.

2 Preventing material damage

Follow these instructions to avoid material damage and damage to the appliance.

ATTENTION!

The functionality of the appliance may be impaired if you use the wrong quantity of fabric softener, detergent, care product or cleaning agent.

► Follow the dosage recommendations from the manufacturer.

Exceeding the maximum load capacity impairs the function of the appliance.

- Observe the maximum load capacity for each programme and do not exceed it.
- → "Programmes", Page 24 The appliance is secured for transportation using transit bolts. Transit bolts which have not been removed may result in material damage and damage to the appliance.
- ▶ Before starting up the appliance, remove the transit bolts completely and keep them in a safe place.
- ▶ Before transport, fit the transit bolts fully in order to prevent damage in

Material damage may be caused if the water inlet hose is connected incorrectly.

- ► Tighten the screw connections on the water inlet until they are handtight.
- ► Ideally, connect the water inlet hose directly to the water tap, without any additional connecting elements such as adapters, extensions, valves or similar.
- ► Ensure that the inner diameter of the water tap is at least 17 mm.

Make sure that the length of the thread on the connection to the water tap is at least 10 mm.

If the water pressure is too high or too low, the appliance may not be able to operate properly.

- ► Ensure that the water pressure in the water supply system is at least 100 kPa (1 bar) and max. 1000 kPa (10 bar).
- ▶ If the water pressure exceeds the maximum value specified, a pressure-reducing valve must be installed between the drinking water connection and the hose set of the appliance.
- ▶ Do not connect the appliance to the mixer tap of an unpressurised hot-water boiler.

Modified or damaged water hoses may result in material damage and damage to the appliance.

- ► Never kink, crush, modify or cut through water hoses.
- Only use the water hoses supplied with the appliance or genuine spare hoses.
- Never re-use water hoses that have been used before.

Operating the appliance using water that is dirty or too hot may cause material damage.

 Only operate the appliance with cold mains water.

Unsuitable cleaning products may damage the surfaces of the appliance.

- ▶ Do not use harsh or abrasive detergents.
- ► Do not use cleaning products with a high alcohol content.
- Do not use hard scouring pads or cleaning sponges.
- Clean the appliance with nothing but water and a soft, damp cloth.

 Remove all detergent residue, spray residue or other residues immediately if they come into contact with the appliance.

3 Environmental protection and saving energy

3.1 Disposing of packaging

The packaging materials are environmentally compatible and can be recycled.

 Sort the individual components by type and dispose of them separately.

3.2 Save energy and conserve resources

If you follow these instructions, your appliance will use less electricity and less water.

Choose programmes with low temperatures and longer wash times and use maximum load capacity → Page 24.

 Energy consumption and water consumption is most efficient.

Add → Page 36 detergent based on the laundry's degree of soiling.

 For light to normal soiling, a smaller amount of detergent is sufficient. Observe the dosage recommendation from the detergent manufacturer.

Reduce the washing temperature for lightly and normally soiled laundry.

✓ At low temperatures, the appliance consumes less energy. For light to normal soiling, lower temperatures than indicated on the care label are also sufficient.

Set the maximum spin speed if you want to dry the laundry in a tumble dryer afterwards.

 ✓ The drier the laundry, the shorter the programme duration when drying which, in turn, reduces energy consumption. A higher spin speed reduces the residual moisture in the laundry and increases the volume of the spin noise.

Wash the laundry without prewash.

 Washing with prewash increases the programme duration and increases energy and water consumption.

The appliance has a continuous automatic load adjustment function.

✓ Depending on the type of fabric and load capacity, the continuous automatic load adjustment function optimally adjusts the water consumption and programme duration.

3.3 Energy saving mode

If you do not use the appliance for an extended period, it automatically switches to energy-saving mode. All displays go out and Έναρξη / Προσθήκη ρούχων flashes. Energy-saving mode ends when you use the appliance again, e.g. if you open or close the door.

4 Installation and connection

4.1 Unpacking the appliance

Note: Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.

ATTENTION!

Objects remaining in the drum that are not designed for operation with the appliance may cause material damage and damage to the appli-


► Remove these objects, along with all supplied accessories, from the drum before starting the appliance. 1. Remove any packaging and protective covers completely from the appliance.

For the environmentally friendly disposal of the packaging materials, observe the information on the topic of

- → "Disposing of packaging", Page 11.
- 2. Check the appliance for visible damage.
- 3. Open the door. → "Basic operation", Page 37
- 4. Remove the accessory from the drum.
- 5. Close the door.

4.2 Contents of package

After unpacking all parts, check for any damage in transit and completeness of the delivery.



- Washing machine
- Accompanying documents
- Water inlet hose
- Cover caps

4.3 Requirements for the installation location

Note: Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.

WARNING Risk of electric shock!

The appliance contains live parts. Touching live parts is dangerous.

▶ Do not operate the appliance without a cover cap.

WARNING Risk of injury!

When using the appliance on a base, the appliance may tip over.

► Always secure the feet of the appliance to a base using the manufacturer's fixing brackets → Page 32 before using the appliance for the first time.

ATTENTION!

If the appliance is installed in areas exposed to frost or outdoors, frozen residual water may damage the appliance and frozen hoses may crack or split.

▶ Do not install or operate this appliance anywhere that is liable to experience frost and/or outdoors.

The appliance underwent a function test before leaving the factory and may, therefore, contain residual water. This residual water may leak out if the appliance is tilted at an angle greater than 40°.

Tilt the appliance carefully.

Installation loca- Requirements tion

On a base




Secure the appliance with fixing brackets → Page 32.

On a wooden ioist floor



Place the appliance on a waterresistant wooden board which is screwed tightly to the floor. The wooden board should be at least 30 mm thick.


In a kitchen unit



- A niche width of 60 cm is reauired.
- Only install the appliance underneath a continuous worktop that is securely connected to adiacent cabinets.

Installation loca- Requirements tion

On a wall




Do not trap the hoses between the wall and the appliance.

4.4 Removing the transit bolts

The appliance is secured for transportation using transit bolts on the rear of the appliance.

Notes


- Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.
- Keep the transit bolts, screws and sleeves in a safe place for future transport → Page 57.
- 1. Pull the hoses out of the holders.




2. Unscrew ① and remove ② all four screws for the transit bolts with a WAF 13 wrench.



3. Pull the power cord out of the holder.




4. Remove the four sleeves.



5. Put on the four cover caps.




6. Press down on the four cover caps.




4.5 Connecting the appliance Connecting the water inlet hose Note

Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.

1. Connect the water inlet hose.



2. Connect the water inlet hose to a tap (26.4 mm = 3/4").



Open the water tap carefully and check that the connection points are tight.

Water outlet connection types

This information is intended to help you to connect this appliance to the water outlet.


Note: Please read the information in the Safety \rightarrow *Page 4* and Preventing material damage \rightarrow *Page 10* sections to ensure that you use the appliance safely.

ATTENTION!

When draining, the water outlet hose is subject to water pressure and may come loose from the installed connection point.


Secure the water outlet hose against unintentional loosening. **Note:** Observe the draining heights. The draining heights are: minimum: 60 cm, maximum: 100 cm.

Drainage into a siphon




Secure the connection point with a (24–40 mm) hose clamp.

Drainage into a washbasin



Fix and secure the water outlet using an elbow. → Page 32

Drainage into a plastic pipe with rubber sleeve.



Fix and secure the water outlet using an elbow.


→ Page 32

4.6 Aligning the appliance


In order to reduce noise and vibration and to prevent the appliance from moving, align the appliance correctly.

Note: Please read the information in the Safety → *Page 4* and Preventing material damage → *Page 10* sections to ensure that you use the appliance safely.

1. Loosen the lock nuts using a WAF 17 wrench by turning it in a clockwise direction.




2. To align the appliance, turn the appliance feet. Check that the appliance is level using a spirit level.



All appliance feet must stand firmly on the ground.

3. Screw the lock nuts tightly against the housing using a WAF 17 wrench



In doing so, hold the foot tight and do not adjust its height.

4.7 Connecting the appliance to the electricity supply


Note: Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.

- 1. Insert the mains plug of the appliance's power cable in a socket nearby.
 - The connection details of the appliance can be found under Technical data → Page 61.
- 2. Check the mains plug is inserted properly.

5 Familiarising yourself with your appliance

5.1 Appliance


You can find an overview of the parts of your appliance here.



On certain models, specific details such as the colour and shape may differ from those pictured.

1	Maintenance flap for the drain pump → Page 44
2	Door
3	Detergent drawer → Page 19
4	Controls → Page 19
5	Water outlet hose → Page 16
6	Power cord → Page 17
7	Transit bolts → Page 14






- Measuring aid for liquid deter-
 - → "Using a measuring aid for liquid detergent", Page 38
- Compartment II:
 - Detergent for main wash
 - Water softener
 - Bleach
 - Stain remover
- 3 Compartment \&:
 - Fabric softener
 - Liquid starch
 - Waterproofing agent
- 4 Compartment I:
 - Detergent for prewash
 - Hygiene detergent

5.3 Controls


You can use the control panel to configure all functions of your appliance and to obtain information about the operating status.



- Programmes → Page 24
- Programme selector → Page 37
- Display → Page 20
- **Buttons**

6 Display

The display shows the current settings, options or relevant information.



Display	Designation	Description
0:40 1	Programme duration/programme time remaining	Approximate expected programme duration or programme time remaining.
10h ¹	"Ready in" time	The programme end has been set and the remaining number of hours is displayed. → "Buttons", Page 22
7 kg ¹	Recommended load	The maximum load capacity for the selected programme in kg.
1200	Spin speed	Set spin speed in rpm. → "Buttons", Page 22 0= No final spin, only draining : Rinse Hold, no draining
※ − 90	Temperature	Set temperature in °C. → "Buttons", Page 22 (cold)
D00	Start/Pause	Start, cancel or pause Lights up: The programme is running and can be cancelled or paused. Flashes: The programme can be started or continued.
	Rinse Hold	Programme status
¹ Example		

Display	Designation	Description
End	End of programme	Programme status
~	Childproof lock	 ■ lights up: The childproof lock is activated. ■ flashes: The childproof lock is activated and the appliance has been operated. → "Deactivating the childproof lock", Page 40
✓	Prewash	Prewash is activated. → "Buttons", Page 22
√	Water Plus and Rinse Plus	Wash with more water and a rinse cycle is activated. → "Buttons", Page 23
=0	varioSpeed	Short wash activated. → "Buttons", Page 22
❖	Reminder to clean the drum	Flashes: Drum is dirty. Run the Καθαρισμός κάδου programme for cleaning and caring for the drum and the outer tub. → "Cleaning the drum", Page 42
C	Door	 Lights up: The door is locked and cannot be opened. Flashes: The door is not closed properly. Off: The door is unlocked and can be opened.
片	Тар	No water pressure.The water pressure is too low.
E:35 / -10 ¹	Error	Error code, error display, signal.
¹ Example		

7 Buttons

The selection of programme settings depends on the programme that is set. You can see the selection options for each programme in the overview for → "Programmes", Page 24.

Button	Selection	Description
Έναρξη / Προσθήκη ρούχων (Start / Pause / Reload)	StartCancelPause	Start, cancel or pause the programme.
vario Speed	ActivateDeactivate	Activate or deactivate a short washing programme. Note: Energy consumption increases. The washing result is not affected by this.
Λήξη σε 🤄 (Ready in)	1-24 hours	Set the programme end. The programme duration is already included in the set number of hours. Once the programme has started, the programme duration is displayed.
Θερμοκ. °C (Temp.)	※ − 90 °C	Adjust the temperature in °C.
Στύψιμο 🏵 (Spin)	1200	Adjust the spin speed or activate – – (Rinse Hold). If – – is selected, the water is not drained at the end of the washing cycle and the spin cycle is deactivated. The laundry remains in the water used for rinsing.
≂⊚ 3 бευт. (3 sec.)	ActivateDeactivate	Activate or deactivate the childproof lock. Disable the control panel to prevent unwanted or accidental operation. If the childproof lock is activated and the appliance has been switched off, the childproof lock remains activated. → "Childproof lock", Page 40
Πρόπλυση (Pre- wash)	ActivateDeactivate	Activate or deactivate prewash, e.g. for washing heavily soiled laundry.

Button	Selection	Description
↑ νερό +1 ξέβγαλ. (Water & Rinse Plus)	ActivateDeactivate	Activate or deactivate a washing programme with more water and an additional rinse cycle. Recommended for particularly sensitive skin or in regions with very soft water.

8 Programmes

Below is an overview of the programmes. You can find information on the load and on the adjustable programme options.

Tip: The laundry's care labels provide you with additional information on programme selection. → "Care symbols on the care labels", Page 34

Programme	Description	Ма		Pro	Programme settings	e settir	sbı	
		x. load (kg)	Max. temperature (°C)	Max. spin speed (rpm) 1	vario Speed	↑ νερό +1 ξέβγαλ.	Στύψιμο ⓒ – — (Rinse Hold)	Πρόπλυση
Βαμβακερά (Cotton)	Wash hard-wearing items made from cotton, linen or blended fabrics. Also suitable as a short programme for normally soiled laundry when you activate vario Speed. If vario Speed is activated, the maximum load capacity is reduced to 4 kg.	_	90	1200	•	•	•	•
Βαμβακερά εντατικό (Cotton Intensive)	Wash hard-wearing items made from cotton, linen or blended fabrics. Energy-saving programme.	7	90	1200	_	•	•	•
¹ Programme setting	Ďl.							

Programme	Description	Ma		Pro	Programme settings	e settil	sbu	
		x. load (kg)	Max. temperature (°C)	Max. spin speed (rpm) 1	vario Speed	↑ νερό +1 ξέβγαλ.	Στὑψιμο ⑤ – — (Rinse Hold)	Πρόπλυση
	Note: To save energy, the actual washing temperature may deviate from the set washing temperature. The washing performance meets legal requirements.							
Eco 40-60	Wash items made from cotton, linen or blended fabrics. Note: Textiles which can be washed from 40 °C var up to 60 °C var as per the care symbol can be washed together. The washing performance corresponds to the best possible washing performance class according to the legal requirements. For this programme, the washing temperature is automatically adjusted depending on the load size, in order to achieve the best possible energy		_	1200	_	•	•	•
¹ Programme setting	D							

ı	1	I		I	
	Πρόπλυση		•	•	•
ngs	Στὑψιμο ⑨ – — (Rinse Hold)		•	•	•
ne setti	↑ νερό +1 ξέβγαλ.		•	•	•
Programme settings	vario Speed		•	•	_
ď	Max. spin speed (rpm) 1		1200	1200	800
	Max. temperature (°C)		60	60	40
Ма	x. load (kg)		4	4	2
amme Description		efficiency with the best possible washing result. You cannot change the washing temperature.	Συνθετικά (Easy Wash items made from synthetic or Care)	Aνάμεικτα Wash items made from cotton, linen, (Quick / Mix) or synthetic or blended fabrics. Suitable for lightly soiled laundry.	Mεταξωτά (Delic- Wash delicate, washable items made ates / Silk) Use a detergent that is suitable for delicates or silk. Note: Wash especially delicate items or items with hooks, eyelets or clips in a mesh laundry bag.
Programme			Συνθετ Care)	Aváµsı (Quick	Μεταξι ates /

¹ Programme setting

Programme	Description	Ма		Pro	Programme settings	e settir	sbu	
		x. load (kg)	Max. temperature (°C)	Max. spin speed (rpm) ¹	vario Speed	↑ νερό +1 ξέβγαλ.	Στὑψιμο Ϭ – — (Rinse Hold)	Πρόπλυση
Μάλλινα (Wool)	Hand- or machine-washable items that are made from wool or contain wool. To prevent the laundry from shrinking, the drum moves the items very gently with long pauses. Use a detergent that is suitable for wool.	Q	40	800	_	_	•	_
Ξέβγαλμα (Rinse)	Rinses and then spins the laundry, and then drains the water.	I	_	1200	_	•	•	_
Στύψιμο / Άντληση (Spin / Drain)	Spins and drains the water. If you only want to drain the water, activate 0. The laundry is not spun.	ı	_	1200	_	_	_	_
Σκουρόχρωμα / Jeans (Dark Laundry / Jeans)	Wash dark-coloured and colour-intense items made from cotton or easy-care fabric, e.g. jeans. Turn laundry inside-out before washing.	4	40	1200	•	•	•	•
¹ Programme setting	٥							

Programme	Description	_		Proç	Programme settings	settin	sbi	
	in road (ng)	x. load (kg)	Max. temperature (°C)	Max. spin speed (rpm) 1	vario Speed	↑ νερό +1 ξέβγαλ.	Στύψιμο ⑨ – — (Rinse Hold)	Πρόπλυση
Εσώρουχα (Lingerie)	Particularly delicate, washable items made from synthetic fabrics, silk or Lycra, e.g. lacy negligees. Use a detergent that is suitable for delicates. Note: Wash especially delicate items or items with hooks, eyelets or clips in a mesh laundry bag.		40	800	_	•	•	•
Καθαρισμός κάδου (Drum Clean)	Cleaning and caring for the drum. Use this programme in the following cases: Before using the appliance for the first time If you regularly wash at temperatures of 40 °C or lower After a prolonged period of nonuse Use washing powder or a detergent containing bleach.	1	_	1200	_	_	_	_
¹ Programme setting	бı							

ttings	Πρόπλυση Στὑψιμο ⓒ – — (Rinse Hold)		-
Programme settings	↑ νερό +1 ξέβγαλ. vario Speed		_
	Max. spin speed (rpm) 1		800
Ма	Max. temperature (°C)	•	<u>40</u> ←
Programme Description			Outdoor + Wash all-weather and outdoor cloth-Aδιαβροχοποίηση ing with membrane technology and (Outdoor + Water- water-resistant equipment. Suitable for washing and then water-proofing. Use a detergent for outdoor fabrics. Use a waterproofing agent that is suitable for machine-washing.

Programme	Description	Ma		Pro	Programme settings	e settil	sbu	
		x. load (kg)	Max. temperature (°C)	Max. spin speed (rpm) 1	vario Speed	↑ νερό +1 ξέβγαλ.	Στύψιμο ⑤ – — (Rinse Hold)	Πρόπλυση
	Place the detergent for outdoor fabrics in compartment II in the detergent drawer and the waterproofing agent in the ℜ compartment. → "Detergent drawer", Page 19 After-treat the laundry in accordance with the manufacturer's instructions.							
Πουκάμισα / Ρούχα γραφείου(Shirts / Blouses)	Wash non-iron shirts and blouses made from cotton, linen, synthetic or blended fabrics. Note: Use the Μεταξωτά programme to wash shirts and blouses made from silk or delicate fabrics.	2	60	800	_	•	•	•
Грήγоро 15'/30' (Super 15'/30')	Wash items made from cotton, synthetic or blended fabrics. Short programme for small items of lightly soiled laundry. The programme duration is approx.	4	40	1200	•	•	•	_
1 Programme setting	91							

Programme settings	Πρόπλυση Στὑψιμο ⑤ – — (Rinse Hold) ↑ νερό +1 ξέβγαλ. vario Speed Max. spin speed (rpm) ¹ Max. temperature (°C)		
Programme Description W	x. load (kg)	If you wish to reduce the programme duration to 15 minutes, activate vario Speed. The maximum load is reduced to 2 kg.	¹ Programme setting

9 Accessories

Use original accessories. These have been made especially for your appliance.

	Use	Order number
Water inlet hose extension	Extend the water inlet hose for cold water or AquaStop (approx. 2.50 m).	WZ10131
Fixing brackets	Improves the stability of the appliance.	WX975600
Longer water inlet hose	Replace the standard water inlet hose with a longer hose (2.20 m).	00353925
Elbow	Secure the water outlet hose in place.	00655300
Liquid detergent insert	Measure liquid detergent.	00637516

10 Before using for the first time


Prepare the appliance for use.

10.1 Starting an empty washing cycle

Your appliance was inspected thoroughly before leaving the factory. To remove any residual water, run the first wash cycle without any laundry.


Note: Please read the information in the Safety \rightarrow *Page 4* and Preventing material damage \rightarrow *Page 10* sections to ensure that you use the appliance safely.

1. Turn the programme selector to Καθαρισμός κάδου.




2. Close the door.

3. Pull out the detergent drawer.




4. Pour washing powder into compartment II.



To prevent foaming, use only half of the amount of detergent recommended by the detergent manufacturer for light soiling. Do not use detergent suitable for woollens or delicates.

5. Push in the detergent drawer.



- 6. Press Έναρξη / Προσθήκη **ρούχων** (Start / Pause / Reload) to start the programme.
- ✓ The display shows the remaining. programme duration.
- → After the programme has ended, the display shows: "End".
- 7. Start the first wash cycle or set the programme selector to Off to switch off the appliance.
 - → "Basic operation", Page 37

11 Laundry

11.1 Preparing the laundry

Note: Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.

ATTENTION!

Objects remaining in the laundry may damage the laundry and the drum.

- ▶ Remove all items from any pockets in your laundry before using the appliance.
- ► To protect your appliance and the laundry, prepare the laundry beforehand.
 - Empty any pockets
 - Brush sand out of all collars and pockets
 - Close bed covers and cushion covers
 - Close all zips, Velcro fasteners, hooks and eyes
 - Tie cloth belts, apron strings, etc. together or use a laundry
 - Remove curtain hooks and lead strips or use a mesh laundry bag

en Laundry

- Use a mesh laundry bag for small items of laundry, such as children's socks
- Some stubborn or dried-in stains can be removed by washing several times
- Wash large and small items of laundry together
- Do not rub fresh stains but dab them with soapy water
- Separate items of laundry and shake them out

11.2 Sorting laundry

Note: Please read the information in the Safety \rightarrow *Page 4* and Preventing material damage \rightarrow *Page 10* sections to ensure that you use the appliance safely.

- ► To improve washing results and prevent discolouration, sort the laundry according to the following criteria before washing.
 - Type of fabric and fibre Wash laundry of the same type of fabric and fibre together.
 - Care symbols on the care labels
 → Page 34
 - Description of the programmes
 → Page 24
 - Whites
 - Colours

Wash new coloured items separately the first time you wash them.

11.3 Degrees of soiling

Degree of soiling	Soiling	Examples
Light	No dirt or stains are visibleLaundry has absorbed odours	Light summer clothing or sports clothing that has been worn for a just a few hours
Normal	Dirt or light stains are visible	 T-shirts, shirts or blouses are sweat-soaked or have been worn a few times Towels or bedding that has been used for up to one week
Heavy	Dirt or stains are clearly visible	Tea towels, baby items or work clothing

11.4 Care symbols on the care labels

Washing care symbols

Symbol	Washing process	Recommended programme
/# /# /# /# /# /# /# /# /# /# /# /# /# /	Normal	Cotton

Symbol	Washing process	Recommended programme
Viiiy Viiiy Viiiy	Gentle	Easy-Care
<u> </u>	Particularly gentle	Delicates/Silk for washing by hand
(E)	Hand wash	Wool
***	Not suitable for machine-washing	_

12 Detergents and care products

Note: Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.

The manufacturer's instructions for use and dosage can be found on the packaging.

Notes

- Only use liquid detergents that are self-flowing
- Do not mix different liquid detergents
- Do not mix detergent and fabric softener
- Do not use products that have expired or are highly congealed
- Do not use products containing solvents, caustic agents or volatile substances (e.g. bleach)
- Use dyes sparingly as salt may damage stainless steel
- Do not use bleaching agents in the appliance

12.1 Detergent recommendation

Detergent	Fabrics	Pro- gramme	Temperature
Standard detergent with optical brighteners	Heat-resistant white fabrics made from cotton or linen	Cotton	From cold up to 90 °C
Detergent for colours without bleach or optical brighteners	Coloured fabrics made from linen or cotton	Cotton	From cold up to 60 °C
Detergent for colours/delicates without optical brighteners	Coloured fabrics made from easy-care fabrics or synthetic materials	Easy-Care	From cold up to 60 °C
Detergent for delicates	Delicate fine textiles, silk or viscose	Delicates/ Silk	From cold up to 40 °C
Detergent for woollens	Wool	Wool	From cold up to 40 °C

en Detergents and care products

Tip: Visit www.cleanright.eu to find further information on detergents, care products and cleaning agents for domestic use.

12.2 Detergent dosage

The detergent dosage depends on:

- The amount of laundry
- Degree of soiling
- Water hardness

You can find out how hard your water is from your local water company or measure it yourself using a water hardness tester.

Water hardness

Hardness range	Total hardness in mmol/	German degrees in °dH
soft (I)	0-1.5	0-8.4
medium (II)	1.5- 2.5	8.4–14
hard (III)	over 2.5	over 14

Example of a manufacturer's instructions for detergent

These example values refer to a standard load of 4–5 kg.

Soiling	Light	Normal	Heavy
Water hardness: Soft/medium	40 ml	55 ml	80 ml
Water hardness: Hard/very hard	55 ml	80 ml	105 ml


The dosages can be found on the manufacturer's packaging.

 Adjust the dosage to the actual load.

13 Basic operation

13.1 Switching on the appliance


► Turn the programme selector to a programme.



13.2 Setting a programme

1. Set the programme selector to the required programme.

→ "Programmes", Page 24



2. If necessary, adjust the programme settings → Page 37.

13.3 Adjusting the programme settings

Requirement: A programme has been set.

→ "Setting a programme". Page 37

Adjust the programme settings. → "Programmes", Page 24

Note: The programme settings are not saved permanently for the programme.

13.4 Loading laundry


Notes

- Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.
- To prevent creasing, take note of the maximum load for the → "Programmes", Page 24.

Requirement: The laundry is prepared and sorted.

→ "Laundry". Page 33

1. Open the door.



Make sure that the drum is empty.


- 2. Load the laundry unfolded into the drum.
- 3. Close the door.

Ensure that there is no laundry trapped in the door.


13.5 Using a measuring aid for liquid detergent

If you order the measuring aid as an accessory, you must use the measuring aid.


1. Press down on the insert and remove the detergent drawer.



2. Insert the measuring aid.



3. Insert the detergent drawer.



13.6 Adding detergent and care product

Notes

- Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.
- Do not use the measuring aid for liquid detergent for gel detergents, washing powder, or if Prewash or "Ready in" time are activated.

Requirement: Find out the optimum dosage for detergent and care product. → *Page 35*

- 1. Pull out the detergent drawer.
- Pour in detergent.
 → "Detergent drawer", Page 19
- 3. If required, add the care product.
- 4. Push in the detergent drawer.

13.7 Starting the programme

Note: If you want to change the time until the programme ends, set the "Ready in" time first.

- Press Έναρξη / Προσθήκη ρούχων.
- The drum rotates and load detection takes place. This can take up to 2 minutes, after which water enters the drum.
- The display shows either the programme duration or the "Ready in" time.
- After the programme has ended, the display shows: "End".

13.8 Adjusting the "Ready in" time before the programme starts

You can readjust the selected "Ready in" time before the programme starts.

- 1. Press Έναρξη / Προσθήκη ρούχων.
- 2. Press Λήξη σε ⁽¹⁾ repeatedly until the display indicates the desired "Ready in" time.
- 3. Press Έναρξη / Προσθήκη ρούχων.

13.9 Soaking laundry

Note: No additional detergent is reguired. The washing solution is then used for washing.

- 1. Start the programme.
- 2. To pause the programme, after approx. 10 minutes, press Έναρξη / Προσθήκη ρούχων.
- 3. To resume the programme, after the desired soaking time, press Έναρξη / Προσθήκη ρούχων.

13.10 Adding laundry

Note: Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.

1. Press Έναρξη / Προσθήκη ρούχων.

The appliance is paused and checks whether it is possible to add or remove laundry. Take note of the programme status.

- 2. Add or remove laundry.
- **3.** Close the door.
- 4. Press Έναρξη / Προσθήκη ρούχων.

13.11 Cancelling the programme

Once the programme has started, you can cancel it at any time.

Note: Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.

- 1. Press Έναρξη / Προσθήκη ρούχων.
- 2. Open the door.

The appliance door remains locked for safety reasons if the temperature and water levels are hiah.

- If the temperature is high, start the Ξέβγαλμα programme.
- If the water level is high: Start the Στύψιμο or Άντληση programme.
- 3. Remove the laundry.

13.12 Resuming the programme when the programme status is Rinse Hold


- 1. Set the **Στύψιμο** or **Άντληση** programme.
- 2. Press Έναρξη / Προσθήκη ρούχων.

13.13 Unloading the laundry

Note: Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.


1. Open the door.

2. Remove the laundry.



13.14 Switching off the appliance

1. Turn the programme selector to **Off** .



- 2. Turn off the tap.
- **3.** Wipe the rubber gasket dry and remove any foreign objects.



 Leave the door and detergent drawer open so that residual water can evaporate.

14 Childproof lock

Secure your appliance against being operated unintentionally using the controls.

14.1 Activating the childproof lock

- Press and hold the two
 ³
 ^{δευτ.} buttons for approx.
 ³ seconds.
- The controls are locked.
- The childproof lock remains active even after the appliance has been switched off.

14.2 Deactivating the childproof lock

Requirement: To deactivate the childproof lock, the appliance must be switched on.

So that the programme currently running is not cancelled, the programme selector must be set to the initial programme.


✓ soes out in the display.

15 Basic settings

You can configure the appliance to meet your needs.

15.1 Overview of the basic settings


Below is an overview of the basic settings on your appliance.



Basic setting	Programme position	Value	Description
End signal	2	0 (off) 1 (quiet) 2 (me- dium) 3 (loud) 4 (very loud)	Set the volume of the signal at the end of the programme.
Button signal	3	0 (off) 1 (quiet) 2 (me- dium) 3 (loud) 4 (very loud)	The volume of the audible signal emitted when the buttons are pressed.
Drum cleaning reminder	5	ON OFF	Activate or deactivate the reminder to clean the drum.

15.2 Changing the basic settings

1. Set the programme selector to position 1.



- Press Έναρξη / Προσθήκη ρούχων and, at the same time, turn the programme selector to position 2.
- The display shows the current value.
- **3.** Set the programme selector to the required position.
- To change the value, press Λήξη σε
- **5.** To save the changes, switch off the appliance.

16 Cleaning and servicing

To keep your appliance working efficiently for a long time, it is important to clean and maintain it carefully.

16.1 Tips on appliance care

Follow the tips for appliance care to ensure your appliance works correctly in the long term.

Wipe down the housing and the control panel with nothing but water and a damp cloth.

Remove all de-

The appliance parts remain clean and hygienic.

tergent residue, spray residue or other residues immediately. Keep the appliance door and detergent drawer open after use. Fresh deposits are easier to remove without leaving any residue.

This allows the residual water to dry, reducing odours in the appliance.

16.2 Cleaning the drum

If you often wash at a washing temperature of 40 °C and lower or the appliance has not been used for a long period, clean the drum.

A CAUTION Risk of injury!

Permanently washing at low temperatures and a lack of ventilation for the appliance may damage the drum and cause injury.


 Regularly run a programme for cleaning the drum or wash at temperatures of at least 60 °C.

- ▶ Leave the appliance to dry after every operation with the door open, and leave the detergent drawer to dry.
- ► Run the Καθαρισμός κάδου programme without laundry. Add washing powder.


16.3 Cleaning the detergent drawer

Note: Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.


- 1. Pull out the detergent drawer.
- 2. Press down on the insert and remove the detergent drawer.




3. Press out the insert upwards from below.



4. Clean the detergent drawer and insert with water and a brush, and then dry them.



5. Fit the insert and lock it into place.



6. Cleaning the opening for the detergent drawer.



7. Push in the detergent drawer.

16.4 Descaling

If you add detergent correctly, you do not need to descale your appliance. If you still wish to use descaler, follow the manufacturer's instructions for use.

ATTENTION!

The use of unsuitable descaling agents, e.g. for coffee machines, may damage the appliance.

 For this appliance, only use descaling agents that are available from the manufacturer's website or our after-sales service.


16.5 Cleaning the drain pump

Clean the drain pump in the event of faults, e.g. blockages or rattling noises.


Emptying the drain pump

Note: Please read the information in the Safety \rightarrow *Page 4* and Preventing material damage \rightarrow *Page 10* sections to ensure that you use the appliance safely.


- 1. Turn off the water tap.
- 2. Switch off the appliance.
- **3.** Disconnect the appliance's mains plug from the power supply.
- 4. Open the maintenance flap.




5. Remove the maintenance flap.



6. Slide a sufficiently large receptacle under the opening.




7. Take the drain hose out of the holder.




- When you wash at high temperatures, the detergent solution gets hot.
- ► Do not touch the hot detergent solution.


To allow the detergent solution to flow out into the container, remove the sealing cap.



9. Firmly press on the sealing cap.



10. Insert the drain hose into the holder.




Cleaning the drain pump


Note: Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.

Requirement: The drain pump is empty. → Page 44

1. Since water may remain in the drain pump, remove the pump cap carefully.




- 2. Clean the interior, the thread on the pump cap and the pump housing.
- 3. Make sure that the impeller in the drain pump can be rotated.
- 4. Insert the pump cap and screw it on as far as it will go.



The handle on the pump cap must be in a vertical position.

en Cleaning and servicing

5. Insert the maintenance flap and lock it into place.




6. Close the maintenance flap.

16.6 Cleaning the water outlet hose at the siphon


If the water outlet hose at the siphon is dirty or the detergent solution is not being pumped out, you must clean these.

- 1. Switch off the appliance.
- 2. Disconnect the appliance's mains plug from the power supply.
- 3. Loosen the hose clamp and carefully remove the water outlet hose.




Residual water may leak out.

4. Clean the water outlet hose and siphon connecting piece.



Reattach the water outlet hose and secure the connection point using the hose clamp.



16.7 Clean the water inlet filters.

Emptying the water inlet hose


- 1. Turn off the tap.
- Set a programme, except for Ξέβγαλμα, Στύψιμο or Άντληση.
- **3.** Start the programme and leave it to run for approx. 40 seconds.
- 4. Switch off the appliance.
- 5. Disconnect the appliance's mains plug from the power supply.

Cleaning the filter on the tap


Note: Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safely.

Requirement: The water inlet hose is empty.


1. Remove the water inlet hose from the tap.



2. Clean the filter with a small brush.



3. Connect the water inlet hose and check for leaks.




Cleaning the filter on the appliance


Note: Please read the information in the Safety → Page 4 and Preventing material damage → Page 10 sections to ensure that you use the appliance safelv.

Requirement: The water inlet hose is


- → "Emptying the water inlet hose", Page 46
- 1. Disconnect the hose from the rear of the appliance.




- en Cleaning and servicing
- 2. Use pliers to remove the filter.



3. Clean the filter with a small brush.



- 4. Reinsert the filter.
- **5.** Connect the hose and check for leaks.



17 Troubleshooting

You can rectify minor faults on your appliance yourself. Read the troubleshooting information before contacting after-sales service. This will avoid unnecessary costs.



. WARNING

Risk of electric shock!

Incorrect repairs are dangerous.

- ► Repairs to the appliance should only be carried out by trained specialist staff.
- ▶ Only use genuine spare parts when repairing the appliance.
- ▶ If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

Fault	Cause and troubleshooting		
The display goes out and Έναρξη / Προσθήκη ρούχων flashes.	Energy-saving mode is active▶ Press any button.✓ The symbol lights up again.		
"E:36 / -10"	Drain pipe or water outlet hose is blocked. • Clean the drain pipe and the water outlet hose.		
	Drain pipe or water drain hose is caught or jammed.▶ Ensure that the drain pipe and water drain hose are not kinked or trapped.		
	Drain pump is blocked. ► → "Cleaning the drain pump", Page 44		
	The water outlet hose is connected too high. ► Install the water outlet hose at a maximum height of 1 metre.		
	Detergent dosage is too high. Immediate measure: Mix one tablespoon of fabric softener with 0.5 litres of water and pour the mixture into the left-hand compartment (not for outdoor clothing, sportswear or items stuffed with down). Reduce the amount of detergent for the next washing cycle with the same load.		
	Unapproved extension installed on the water drain hose. ► Remove any unapproved extensions from the water hose. Connecting the appliance		

en Troubleshooting

Fault	Cause and troubleshooting		
"E:36 / -25 / -26"	Drain pump is blocked. ► → "Cleaning the drain pump", Page 44		
声	The water pressure is low. No remedial action possible.		
	The filters in the water inflow are blocked. ► Clean the filters in the water inflow → Page 46.		
	The tap is turned off. ► Turn on the tap.		
	The water inlet hose is kinked or jammed. ► Ensure that the water inlet hose is not kinked or jammed.		
© lights up.	The temperature is too high. ► Wait until the temperature has dropped. ► → "Cancelling the programme", Page 39		
	Water level is too high. ► Start the ἀντληση programme.		
	 Laundry is caught in the door. Open the door again. Remove any trapped laundry. Close the door. Press Έναρξη / Προσθήκη ρούχων to start the programme. 		
C flashes.	 Door is not closed. 1. Close the door. 2. Press Έναρξη / Προσθήκη ρούχων to start the programme. 		
All other error codes.	Malfunction ► Call the after-sales service. → "Customer Service", Page 59		
The appliance is not working.	The mains plug of the power cord is not plugged in. Connect the appliance to the power supply.		
	The circuit breaker is faulty. ► Check the circuit breaker in the fuse box.		
	There has been a power cut. ► Check whether the lighting in your kitchen or other appliances are working.		
The programme does not start.	You have not pressed Έναρξη / Προσθήκη ρούχων. ► Press Έναρξη / Προσθήκη ρούχων.		
	Door is not closed.		

Fault	Cause and troubleshooting			
The programme does not start.	 Close the door. Press Ἐναρξη / Προσθήκη ρούχων to start the programme. 			
	Childproof lock is activated. ▶ → "Deactivating the childproof lock", Page 40			
	Λήξη σε ⁽¹⁾ is activated. ► Check whether Λήξη σε ⁽¹⁾ is activated. → "Buttons", Page 22			
	 Laundry is caught in the door. Open the door again. Remove any trapped laundry. Close the door. Press Έναρξη / Προσθήκη ρούχων to start the programme. 			
The door cannot be opened.	 is activated. Continue the programme by selecting Στὑψιμο or Άντληση and pressing Ἐναρξη / Προσθήκη ρούχων. → "Resuming the programme when the programme status is Rinse Hold", Page 39 			
	The temperature is too high. ► Wait until the temperature has dropped. ► → "Cancelling the programme", Page 39			
	Water level is too high. ► Start the Άντληση programme.			
	Power failure. ► Open the door using the emergency release. → "Emergency release", Page 57			
The water is not draining.	Drain pipe or water outlet hose is blocked. • Clean the drain pipe and the water outlet hose.			
	Drain pipe or water drain hose is caught or jammed. ► Ensure that the drain pipe and water drain hose are not kinked or trapped.			
	Drain pump is blocked. ► → "Cleaning the drain pump", Page 44			
	is activated.			

Fault	Cause and troubleshooting		
	Cause and troubleshooting		
The water is not draining.	 Continue the programme by selecting Στύψιμο or Άντληση and pressing Έναρξη / Προσθήκη ρούχων. "Resuming the programme when the programme status is Rinse Hold", Page 39 		
	The water outlet hose is connected too high. ► Install the water outlet hose at a maximum height of 1 metre.		
	 Detergent dosage is too high. Immediate measure: Mix one tablespoon of fabric softener with 0.5 litres of water and pour the mixture into the left-hand compartment (not for outdoor clothing, sportswear or items stuffed with down). Reduce the amount of detergent for the next washing cycle with the same load. 		
	Unapproved extension installed on the water drain hose. ▶ Remove any unapproved extensions from the water hose. Connecting the appliance		
Water is not flowing in. Detergent is not	You have not pressed Έναρξη / Προσθήκη ρούχων. ▶ Press Έναρξη / Προσθήκη ρούχων.		
being dispensed.	The filters in the water inflow are blocked. ► Clean the filters in the water inflow → Page 46.		
	The tap is turned off. ► Turn on the tap.		
	The water inlet hose is kinked or jammed. ► Ensure that the water inlet hose is not kinked or jammed.		
The spin cycle runs several times.	The unbalanced load detection system eliminates an imbalance by repeatedly redistributing the laundry. ▶ Not a fault – no action required.		
	Note: When loading, where possible, place large and small items of laundry together in the drum. Different sized items of laundry distribute themselves better during the spin cycle.		
The programme duration changes during the wash cycle.	The programme operation is optimised electronically. This may change the programme duration. ▶ Not a fault – no action required.		
	The unbalanced load detection system eliminates an imbalance by repeatedly redistributing the laundry. Not a fault – no action required.		

Fault	Cause and troubleshooting			
The programme duration changes during the wash cycle.	Note: When loading, where possible, place large and small items of laundry together in the drum. Different sized items of laundry distribute themselves better during the spin cycle.			
	Foam detection system switches on a rinse cycle if foam build-up is too high. ▶ Not a fault – no action required.			
No water is visible in the drum.	 Water is below the visible area. Not a fault – no action required. Do not add any extra water to the appliance while it is operating. 			
Drum jerks after the programme starts.	This is caused by an internal motor test. ▶ Not a fault – no action required.			
Residual water is present in the compartment &.	Insert in compartment % is blocked. ▶ → "Cleaning the detergent drawer", Page 43			
Vibrations and movement of the appliance	Appliance is not correctly aligned. • Aligning the appliance			
whilst spinning.	The appliance feet are not fixed. ▶ Secure the appliance feet. Aligning the appliance			
	Transit bolts have not been removed. ▶ Removing the transit bolts			
Drum does not turn, water does not flow in.	Load detection is active. ► Not a fault – no action required.			
	Note: The load detection can take up to two minutes.			
Heavy foam build-up	Detergent dosage is too high. ► Immediate measure: Mix one tablespoon of fabric softener with 0.5 litres of water and pour the mixture into the left-hand compartment (not for outdoor clothing, sportswear or items stuffed with down). ► Reduce the amount of detergent for the next washing cycle with the same load.			
High spin speed not reached.	A low spin speed is selected.▶ The next time you run a wash cycle, set a higher spin speed.			
	Unbalance load detection system is using a reduced spin speed to eliminate an unbalance. Redistribute the laundry in the drum.			

en Troubleshooting

Fault	Cause and troubleshooting
High spin speed not reached.	Note: Where possible, mix large and small items in the drum. Different sized items of laundry distribute themselves better during the spin cycle.
	Start the Στύψιμο programme.
The spin programme does not start.	Drain pipe or water outlet hose is blocked. • Clean the drain pipe and the water outlet hose.
	 Drain pipe or water drain hose is caught or jammed. Ensure that the drain pipe and water drain hose are not kinked or trapped.
	The unbalanced load detection system has interrupted the spin cycle because the laundry is unevenly distributed.
	► Redistribute the laundry in the drum.
	Note: Where possible, mix large and small items in the drum. Different sized items of laundry distribute themselves better during the spin cycle.
	Start the Στύψιμο programme.
Rushing, hissing noise.	Water is flushed under pressure into the detergent drawer. ► Not a fault – normal operating noise.
Loud noises during the spin cycle.	Appliance is not correctly aligned. ► Aligning the appliance
	The appliance feet are not fixed. • Secure the appliance feet. Aligning the appliance
	Transit bolts have not been removed. ► Removing the transit bolts
Banging noises, rattling in the drain pump.	Foreign bodies have got into the drain pump. ▶ → "Cleaning the drain pump", Page 44
Slurping, rhythmical suction noise.	The drain pump is active, the detergent solution is pumped out. Not a fault – normal operating noise.
Creasing.	The spin speed is too high. ► The next time you run a wash cycle, set a lower spin speed.
	The load is too large.▶ The next time you run a wash cycle, reduce the amount of laundry being loaded.

Fault	Cause and troubleshooting		
Creasing.	The wrong programme is selected for the type of fab-		
	ric. ► Select the programmes that are suitable for the type of fabric.		
	→ "Programmes", Page 24		
Detergent or fabric softener drips off the seal and collects on the door or in the seal fold.	Too much detergent/fabric softener in the detergent drawer. ► When dosing liquid detergent and fabric softener, observe the marking in the detergent drawer and do not dose above this.		
The spin result is not satisfactory. The laundry is too wet/too damp.	 A low spin speed is selected. The next time you run a wash cycle, set a higher spin speed. Start the Στύψιμο programme. 		
	Drain pipe or water outlet hose is blocked. Clean the drain pipe and the water outlet hose.		
	 Drain pipe or water drain hose is caught or jammed. ▶ Ensure that the drain pipe and water drain hose are not kinked or trapped. 		
	The unbalanced load detection system has interrupted the spin cycle because the laundry is unevenly distributed.		
	Redistribute the laundry in the drum.		
	Note: Where possible, mix large and small items in the drum. Different sized items of laundry distribute themselves better during the spin cycle.		
	Start the Στύψιμο programme.		
	Unbalance load detection system is using a reduced spin speed to eliminate an unbalance. ▶ Redistribute the laundry in the drum.		
	Note: Where possible, mix large and small items in the drum. Different sized items of laundry distribute themselves better during the spin cycle.		
	Start the Στύψιμο programme.		
Detergent residue on the damp washing.	Detergents may contain water-insoluble substances that deposit on the laundry. ► Start the Ξέβγαλμα programme.		
Detergent residue on the dry laundry.	Detergents may contain water-insoluble substances that deposit on the laundry. • Brush out the laundry after washing and drying.		

en Troubleshooting


Fault	Cause and troubleshooting		
Water is leaking out at the water inlet hose.	Water inlet hose is not correctly/securely connected.1. Connect the water supply hose correctly. Connecting the water inlet hose2. Tighten the screw connection.		
Water is leaking out at the water outlet hose.	The water outlet hose is damaged. • Replace the damaged water outlet hose.		
	Water outlet hose is not connected correctly. ► Connect the water outlet hose correctly. Water outlet connection types		
Odours have formed in the appliance.	Humidity and detergent residue may promote the formation of bacteria. ► → "Cleaning the drum", Page 42 ► If you are not using the appliance, leave the door and detergent drawer open so that residual water can evaporate.		

17.1 Emergency release

Releasing the door

Requirement: The drain pump is empty. → Page 44

- 1. **ATTENTION!** Escaping water may cause material damage.
- ▶ Do not open the door if you can see water through the glass. Pull the emergency release downwards with a tool and release.



- The door lock is released.
- 2. Insert the maintenance flap and lock it into place.
- 3. Close the maintenance flap.

18 Transportation, storage and disposal

You can find out here how to prepare your appliance for transportation and storage. You will also find out how to dispose of old appliances.

18.1 Removing the appliance


- 1. Turn off the tap.
- 2. → "Emptying the water inlet hose", Page 46.
- 3. Switch off the appliance.
- 4. Unplug the appliance's mains plug.

- 5. Drain the remaining detergent solution.
 - → "Cleaning the drain pump". Page 44
- 6. Detach the hoses.

18.2 Inserting the transit bolts


Secure the appliance for transportation using transit bolts in order to prevent damage.

- 1. Remove the four cover caps.
 - If necessary, use a screwdriver to remove the cover caps.




Keep the cover caps.


2. Insert the four sleeves.




3. Insert all screws into the four transit bolts and tighten slightly.



 Insert the power cord into the holder ① and tighten all four screws for the transit bolts with a WAF 13 wrench ②.



5. Insert the hose into holder.



18.3 Using the appliance again

Remove the transit bolts.

18.4 Disposing of old appliance

Valuable raw materials can be reused by recycling.

⚠ WARNING Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- Do not install the appliance behind a door as this may obstruct the appliance door or prevent it from opening.
- With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.
- **1.** Unplug the appliance from the mains.
- 2. Cut through the power cord.
- Dispose of the appliance in an environmentally friendly manner.
 Information about current disposal methods are available from your specialist dealer or local authority.



This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE). The guideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.

19 Customer Service

If you have any queries on use, are unable to rectify faults on the appliance yourself or if your appliance needs to be repaired, contact Customer Service.

You can solve many problems yourself by consulting the information on troubleshooting in these instructions or on our website. If this is not the case, contact our after-sales service. With any warranty claims, we will make sure that your appliance is repaired by trained after-sales technicians using genuine spare parts, including after the manufacturer's warranty has expired.

Function-relevant genuine spare parts according to the corresponding Ecodesign Order can be obtained from Customer Service for a period of at least 10 years from the date on which your appliance was placed on the market within the European Economic Area.

Note: Under the terms of the manufacturer's warranty the use of Customer Service is free of charge.

Detailed information on the warranty period and terms of warranty in your country is available from our aftersales service, your retailer or on our website.

If you contact Customer Service, you will require the product number (E-Nr.) and the production number (FD) of your appliance.

The contact details for Customer Service can be found in the enclosed Customer Service directory or on our website.

19.1 Product number (E-Nr.) and production number (FD)

You can find the product number (E-Nr.) and the production number (FD) on the appliance's rating plate. Depending on the model, the rating plate is located:

- On the inside of the door.
- On the inside of the maintenance
- On the rear of the appliance.

Make a note of your appliance's details and the Customer Service telephone number to find them again auickly.

20 Consumption values

The following information is provided in accordance with the EU Ecodesign Regulation. The values given for programs other than the **Eco 40-60** are indicative only and were determined in accordance with the applicable standard EN60456.

Programme	Load (kg)	Pro- gramm e dura- tion (hr:min	Energy con- sump- tion (kWh/ cycle) ¹	Water con- sump- tion (I/ cycle) ¹	Max- imum temper- ature (°C) 5 mins ¹	Spin speed (rpm) ¹	Residual moisture (%)1
Eco 40-60 ²	7,0	3:20	1,048	58,0	47	1200	50,00
Eco 40-60 ²	3,5	2:38	0,584	43,0	38	1200	52,00
Eco 40-60 ²	2,0	2:33	0,292	30,0	25	1200	58,00
Βαμβακερά 20 °C	7,0	2:59	0,290	80,0	23	1200	58,00
Βαμβακερά 40 °C	7,0	2:59	1,050	80,0	44	1200	58,00
Βαμβακερά 60 °C	7,0	2:59	1,300	80,0	56	1200	58,00
Βαμβακερά 40 °C + Πρόπλυση	7,0	3:29	1,070	80,0	44	1200	58,00
Συνθετικά 40 °C	4,0	2:29	0,770	63,0	43	1200	30,00
Ανάμεικτα 40 °C	4,0	1:00	0,620	44,0	41	1200	60,00
√ω Μάλλινα 30 ° C	2,0	0:41	0,220	40,0	22	800	25,00

Due to the influence of water pressure, hardness and inlet temperature, ambient temperature, type, amount and soiling of laundry, detergent used, fluctuations in the power supply and the selected additional functions, the actual values may deviate from the stated values.

² Test programme in accordance with the EU Ecodesign Directive and the EU Energy Labelling Regulation with cold water (15 °C).

21 Technical specifications

Facts and figures for your appliance can be found here.

Appliance height	85,0 cm
Appliance width	60,0 cm
Appliance depth	55,0 cm
Weight	65 - 70 kg ¹
Maximum load	7 kg
Mains voltage	220 - 240 V, 50 Hz
⇔ Minimum installation protection	10 A
Rated power	2300 W
Power consumption	Off mode: 0,12 WLeft-on mode: 0,50 W
Water pressure	Minimum: 100 kPa (1 bar)Maximum: 1000 kPa (10 bar)
Length of the water inlet hose	150 cm
Length of the water outlet hose	150 cm
Length of the	210 cm

More information about your model can be found online at https://energylabel.bsh-group.com¹. This web address is linked to the official EU EPREL product database. At the time

Depending on the appliance spe-

cifications

of printing its web address had not vet been published. Please then follow the instructions on searching for models. The model identifier is made up of the characters before the slash in the product number (E-Nr.) on the rating plate. Alternatively you can also find the model identifier in the first line of the EU energy label.

Only applies to countries in the European Economic Area





BSH Hausgeräte GmbH

Carl-Wery-Straße 34 81739 München GERMANY www.siemens-home.bsh-group.com

Valid within Great Britain: Imported to Great Britain by BSH Home Appliances Ltd. Grand Union House Old Wolverton Road Wolverton, Milton Keynes MK12 5PT United Kingdom

Manufactured by BSH Hausgeräte GmbH under the trademark licence of Siemens AG



en