SIEMENS



Double oven

MR557G5 0P

en User manual and installation instructions



Register your product on My Siemens and discover exclusive services and offers. siemens-home.bsh-group.com/welcome

The future moving in.

Table of contents

USER MANUAL

1	Safety 2
2	Preventing material damage 4
3	Environmental protection and saving energy 5
4	Familiarising yourself with your appliance 6
5	Accessories
6	Before using for the first time 11
7	Basic operation 12
8	Rapid heating 12
9	Time-setting options 12
10	Meat thermometer14
11	Programme
12	Childproof lock 17
13	Basic settings 17
14	Cleaning and servicing 18
15	Cleaning function
16	cleaning assistance humidClean21
17	Shelf supports22
18	Appliance door24
19	Troubleshooting
20	Disposal31
21	Customer Service
22	How it works31
23	INSTALLATION INSTRUCTIONS 35
23.1	General installation instructions 36

▲ 1 Safety

Observe the following safety instructions.

1.1 General information

- Read this instruction manual carefully.
- Keep the instruction manual and the product information safe for future reference or for the next owner.
- Do not connect the appliance if it has been damaged in transit.

1.2 Intended use

This appliance is designed only to be built into kitchen units. Read the special installation instructions.

Only a licensed professional may connect appliances without plugs. Damage caused by incorrect connection is not covered under the warranty.

Only use this appliance:

- To prepare meals and drinks.
- In private households and in enclosed spaces in a domestic environment.
- Up to an altitude of max. 4000 m above sea level.

1.3 Restriction on user group

This appliance may be used by children aged 8 or over and by people who have reduced physical, sensory or mental abilities or inadequate experience and/or knowledge, provided that they are supervised or have been instructed on how to use the appliance safely and have understood the resulting dangers.

Children must not play with the appliance. Children must not perform cleaning or user maintenance unless they are at least 15 years old and are being supervised.

Keep children under the age of 8 years away from the appliance and power cable.

1.4 Safe use

Always place accessories in the cooking compartment the right way round.

→ "Accessories", Page 10

⚠ WARNING – Risk of fire!

Combustible objects that are left in the cooking compartment may catch fire.

- ► Never store combustible objects in the cooking compartment.
- ▶ If smoke is emitted, the appliance must be switched off or the plug must be pulled out and the door must be held closed in order to stifle any flames.

Loose food remnants, fat and meat juices may catch fire.

▶ Before using the appliance, remove the worst of the food residues and remnants from the cooking compartment, heating elements and accessories.

Opening the appliance door creates a draught. Greaseproof paper may come into contact with the heating element and catch fire.

- Never place greaseproof paper loosely over accessories when preheating the appliance and while cooking.
- ► Always cut greaseproof paper to size and use a plate or baking tin to hold it down.

⚠ WARNING – Risk of burns!

The appliance and its parts that can be touched become hot during use.

- ► Caution should be exercised here in order to avoid touching heating elements.
- ► Young children under 8 years of age must be kept away from the appliance.

Accessories and cookware get very hot.

 Always use oven gloves to remove accessories or cookware from the cooking compartment.

When the cooking compartment is hot, any alcoholic vapours inside may catch fire.

- Only use small quantities of drinks with a high alcohol content in food.
- Open the appliance door carefully.

⚠ WARNING – Risk of scalding!

The accessible parts of the appliance become hot during operation.

- ► Never touch these hot parts.
- ► Keep children at a safe distance.

Hot steam may escape when you open the appliance door. Steam may not be visible, depending on the temperature.

- ► Open the appliance door carefully.
- ► Keep children at a safe distance.

If there is water in the cooking compartment when it is hot, this may create hot steam.

Never pour water into the cooking compartment when the cooking compartment is hot.

⚠ WARNING – Risk of injury!

Scratched glass in the appliance door may develop into a crack.

► Do not use any harsh or abrasive cleaners or sharp metal scrapers to clean the glass on the oven door, as they may scratch the surface.

The hinges on the appliance door move when the door is opened and closed, which could trap your fingers.

- ► Keep your hands away from the hinges. Components inside the appliance door may have sharp edges.
- ► Wear protective gloves.

MARNING – Risk of electric shock!

Incorrect repairs are dangerous.

- ► Repairs to the appliance should only be carried out by trained specialist staff.
- Only use genuine spare parts when repairing the appliance.
- ► If the power cord of this appliance is damaged, it must be replaced by trained specialist staff.

If the insulation of the power cord is damaged, this is dangerous.

- ► Never let the power cord come into contact with hot appliance parts or heat sources.
- ► Never let the power cord come into contact with sharp points or edges.
- Never kink, crush or modify the power cord.

An ingress of moisture can cause an electric shock.

► Do not use steam- or high-pressure cleaners to clean the appliance.

If the appliance or the power cord is damaged, this is dangerous.

- ► Never operate a damaged appliance.
- ► Never operate an appliance with a cracked or fractured surface.
- Never pull on the power cord to unplug the appliance. Always unplug the appliance at the mains.
- ► If the appliance or the power cord is damaged, immediately unplug the power cord or switch off the fuse in the fuse box.
- ► Call customer services. → Page 31

⚠ WARNING – Danger: Magnetism!

Permanent magnets are used in the control panel or in the controls. These may affect electronic implants, e.g. heart pacemakers or insulin pumps.

► Wearers of electronic implants must stay at least 10 cm away from the control panel.

⚠ WARNING – Risk of suffocation!

Children may put packaging material over their heads or wrap themselves up in it and suffocate.

Keep packaging material away from children.

► Do not let children play with packaging material.

Children may breathe in or swallow small parts, causing them to suffocate.

- Keep small parts away from children.
- ▶ Do not let children play with small parts.

1.5 Halogen bulb

MARNING – Risk of burns!

The bulbs in the cooking compartment get very hot. There is still a risk of burning for some time after they have been switched off.

- Do not touch the glass cover.
- Avoid contact with your skin when cleaning.

↑ WARNING – Risk of electric shock!

When changing the bulb, the bulb socket contacts are live.

▶ Before replacing the bulb, ensure that the appliance is switched off in order to prevent a potential electric shock.

Also unplug the appliance from the mains or switch off the circuit breaker in the fuse box.

1.6 Meat probe

⚠ WARNING – Risk of electric shock!

Using the wrong meat probe could damage the insulation.

Only use the meat probe for this specific appliance.

1.7 Cleaning function

⚠ WARNING – Risk of burns!

The outside of the appliance gets very hot when the cleaning function is in progress.

- ► Never touch the appliance door.
- ► Allow the appliance to cool down.
- ► Keep children at a safe distance.

2 Preventing material damage

2.1 General

ATTENTION!

Objects on the cooking compartment floor at over 50 °C will cause heat to build up. The baking and roasting times will no longer be correct and the enamel will be damaged.

- Do not place any accessories, greaseproof paper or foil of any kind on the cooking compartment floor.
- Only place cookware on the cooking compartment floor if a temperature above 50 °C has been set.

When the cooking compartment is hot, any water inside it will create steam. The change in temperature may cause damage.

- ► Never pour water into the cooking compartment when it is still hot.
- Never place cookware containing water on the cooking compartment floor.

The prolonged presence of moisture in the cooking compartment leads to corrosion.

- ► Allow the cooking compartment to dry after use.
- Do not keep moist food in the cooking compartment for a long time with the door closed.
- ► Do not store food in the cooking compartment. Leaving the appliance to cool down with the door open will damage the front of neighbouring kitchen units over time
- Always allow the cooking compartment to cool down with the door closed after cooking at high temperatures.
- Take care not to trap anything in the appliance door.

Only leave the cooking compartment to dry with the door open if a lot of moisture was produced during operation.

Fruit juice dripping from the baking tray leaves stains that cannot be removed.

- When baking very juicy fruit flans, do not pack too much on the baking tray.
- ► If possible, use the deeper universal pan.

Using oven cleaner in a hot cooking compartment damages the enamel.

- ► Never use oven cleaner in the cooking compartment when it is still warm.
- Remove all food remnants from the cooking compartment and the appliance door before you next heat up the appliance.

If the seal is very dirty, the appliance door will no longer close properly during operation. This may damage the front of adjacent kitchen units.

- ► Keep the seal clean at all times.
- Never operate the appliance if the seal is damaged or missing.

Sitting or placing objects on the appliance door may damage it.

- Do not place or hang objects on the appliance door.
- Do not place cookware or accessories on the appliance door.

With certain models, accessories may scratch the door pane when closing the appliance door.

Always push accessories fully into the cooking compartment.

Environmental protection and saving energy

Help protect the environment by using your appliance in a way that conserves resources and by disposing of reusable materials properly.

3.1 Disposing of packaging

The packaging materials are environmentally compatible and can be recycled.

Sort the individual components by type and dispose of them separately.

Information about current disposal methods are available from your specialist dealer or local authority.

3.2 Saving energy

If you follow these instructions, your appliance will use less power.

Only preheat the appliance if the recipe or the recommended settings tell you to do so.

■ Not preheating the appliance can reduce the energy used by up to 20%.

Use dark-coloured, black-coated or enamelled baking

These types of baking tin absorb the heat particularly well.

Open the appliance door as little as possible during operation.

■ This will maintain the temperature in the cooking compartment and eliminate the need for the appliance to reheat.

When baking multiple dishes, do so in succession or in parallel.

■ The cooking compartment is heated after baking the first dish. This reduces the baking time for the second cake.

If the cooking time is relatively long, you can switch the appliance off 10 minutes before the cooking time

 There will be enough residual heat to finish cooking the dish.

Remove any accessories that are not being used from the cooking compartment.

 Accessories that are not being used do not need to be heated.

Allow frozen food to defrost before cooking.


■ This will save the energy that would otherwise be required to defrost it.

4 Familiarising yourself with your appliance

4.1 Controls

You can use the control panel to configure all functions of your appliance and to obtain information about the operating status.

Note: On certain models, specific details such as colour and shape may differ from those pictured.



Buttons and display

The buttons are touch-sensitive surfaces. To select a function, simply press lightly on the relevant field.

The display shows symbols for active functions and the time-setting options.

→ "Buttons and display", Page 7

Main oven ∨

Controls for the main oven

3 Function selector ∨

Use the function selector to set the types of heating and other functions.

You can turn the function selector clockwise or anti-clockwise from the zero setting O. Depending on the appliance, the function selector can be pushed in. Press on the function selector to click it into or out of the zero setting O.

→ "Types of heating and functions", Page 7

$m{4}$ Heating-up control ee

→ "Heating-up control", Page 9

Temperature selector ∨

Use the temperature selector to set the temperature for the type of heating and select settings for other functions.

You can only turn the temperature selector clockwise from the zero setting ● until it offers resistance. You cannot turn it any further than this

Depending on the appliance, the temperature selector can be pushed in. Press on the temperature selector to click it into or out of the zero setting •.

→ "Temperature and setting levels", Page 8

6 Top oven ∧

Controls for the top oven

7 Function selector ∧

Use the function selector to set the types of heating and other functions.

You can turn the function selector clockwise or anti-clockwise from the zero setting O. Depending on the appliance, the function selector can be pushed in. Press on the function selector to click it into or out of the zero setting O.

→ "Types of heating and functions", Page 7

8 Heating-up control ∧

→ "Heating-up control", Page 9

Temperature selector ∧

Use the temperature selector to set the temperature for the type of heating and select settings for other functions.

You can only turn the temperature selector clockwise from the zero setting ● until it offers resistance. You cannot turn it any further than this.

Depending on the appliance, the temperature selector can be pushed in. Press on the temperature selector to click it into or out of the zero setting .

→ "Temperature and setting levels", Page 8

4.2 Buttons and display

You can use the buttons to set various functions for your appliance. The display shows the settings.

If a function is active, the corresponding symbol lights up in the display. The clock symbol © only lights up when you change the time.

Symbol	Function	Use	
To select the individual time-setting eral times. The arrows ≎ above and below a s		Select the time \odot , timer \bigtriangleup , cooking time \bowtie and the end time \Rightarrow . To select the individual time-setting options, press the \odot button several times. The arrows \diamondsuit above and below a symbol indicate the function to which the setting in the display corresponds.	
- +	Minus Plus	Decrease the setting values. Increase the setting values.	
kg	Weight	Select a weight for the programmes.	
~	Childproof lock	Activate or deactivate the childproof lock.	

4.3 Types of heating and functions

To ensure that you always use the right type of heating to cook your food, we have explained the differences and applications below.

Main oven ∨

Symbol	Type of heating	What it's used for/how it works	
(A)	3D hot air	Bake and roast on one or more levels. The fan distributes the heat from the ring-shaped heating element in the back wall evenly around the cooking compartment.	
	Hot air gentle	Cook selected dishes gently on one level without preheating. The fan distributes the heat from the ring-shaped heating element in the back wall evenly around the cooking compartment. The food is cooked in phases using residual heat. Select a temperature of between 120 °C and 230 °C. Always keep the appliance door closed when cooking. This type of heating is used to determine the energy consumption in air recirculation mode and the energy efficiency class.	
<u></u>	Pizza setting	Cook pizza or dishes that require a lot of heat from below. The bottom heating element and the ring-shaped heating element in the back wall heat the cooking compartment.	
	Bottom heating	Final baking or cooking food in a bain marie. Heat is emitted from below.	
""	Full-surface grill	Grill flat items such as steak and sausages, or make toast. Gratinate food. The entire area underneath the grill element becomes hot.	
\tilde{\	Hot air grilling	Roast poultry, whole fish and larger pieces of meat. The grill element and the fan switch on and off alternately. The fan circulates the hot air around the food.	

Symbol	Type of heating	What it's used for/how it works	
	Top/bottom heating	Traditionally bake or roast on one level. This type of heating is ideal for cakes with moist toppings. The heat is emitted evenly from above and below. This type of heating is used to measure the energy consumption in the conventional mode.	

Top oven \wedge

Symbol	Type of heating	What it's used for/how it works	
	Top/bottom heating	Bake on one level. The heat is emitted evenly from above and below. This type of heating is used to measure the energy consumption in the conventional mode.	
	Bottom heating	Final baking or cooking food in a bain marie. Heat is emitted from below.	
~	Grill, small area	Grill small quantities of steak, sausages or toast. Brown small quantities of food. The central area underneath the grill element becomes hot.	
~~	Full-surface grill	Grill flat items such as steak, sausages, or toast. Brown food. The entire area underneath the grill element becomes hot.	

Other functions

Here, you can find an overview of other functions of your appliance.

Main oven ∨

Symbol	Function	Use	
» 	Rapid heating	Rapidly preheat the cooking compartment without accessories. → "Rapid heating", Page 12	
点	Oven light	Illuminate the cooking compartment without heating. → "Lighting", Page 9	
Р	Programme	Use programmed setting values for various types of food. → "Programme", Page 15	
000	Cleaning function	Set the cleaning function, which regenerates the self-cleaning surfaces in the cooking compartment. → "Cleaning function", Page 20	

Top oven \wedge

Symbol	Function	Use
<u>-</u> Å-	Oven light	Illuminate the cooking compartment without heating. → "Lighting", Page 9
000	Cleaning function	Set the cleaning function, which regenerates the self-cleaning surfaces in the cooking compartment. \rightarrow "Cleaning function ", Page 20

4.4 Temperature and setting levels

There are different settings for the types of heating and functions.

Note: For temperature settings above 250 °C, the appliance reduces the temperature to approx. 240 °C after approx. 10 minutes. If your appliance has the top/bottom heating or bottom heating types, this temperature reduction does not take place.

Symbol	Function	Use	
•	Zero setting	The appliance is not heating up.	
50-275	Temperature range	Set the temperature in the cooking compartment in °C.	

Symbol	Function	Use
1, 2, 3 or I, II, III	Grill settings	Set the grill settings for Full-surface grill and Grill, small area (depending on the appliance model). 1 = low 2 = medium 3 = high
Р	Programme	Set the programme function.
000	Cleaning function	Set the cleaning function.

Heating-up control

The heating-up indicator for the oven remains lit while the appliance is heating.

Note: Due to thermal inertia, the temperature displayed may differ slightly from the actual temperature inside the cooking compartment.

Heating-up indicator ∨

When the main oven V heats up, the symbol I also lights up in the display. This symbol goes out when heating is paused.

4.5 Cooking compartment

The functions in the cooking compartment make your appliance easier to use.

Rails

The rails in the cooking compartment enable you to place accessories at different heights.


→ "Accessories", Page 10

The shelf positions are numbered from bottom to top. You can remove the rails, e. g. for cleaning.

→ "Shelf supports", Page 22


Main cooking compartment \vee

The cooking compartment has five shelf positions.



Top cooking compartment ∧

The cooking compartment has three shelf positions.



Self-cleaning surfaces

The self-cleaning surfaces in the cooking compartment are coated with a porous, matt ceramic layer and have a rough surface. When the appliance is in operation, the self-cleaning surfaces absorb splashes from roasting or grilling and break them down.

The following surfaces are self-cleaning:

Cooking compart- ment	Self-cleaning sur- faces	Cleaning
Main cooking compartment V	Back wallCeilingSide walls	Use the cleaning function regularly to help retain the cleaning ability of the self-cleaning surfaces and prevent damage. \rightarrow "Cleaning function ", Page 20
Top cooking compartment ∧	Back wallCeilingSide walls	Use the cleaning function regularly to help retain the cleaning ability of the self-cleaning surfaces and prevent damage. \rightarrow "Cleaning function ", Page 20

Lighting

The oven light lights up the cooking compartment.

With most types of heating and functions, the lighting lights up during operation. When the function selector is turned to bring operation to an end, the lighting goes out.

The **Oven light** setting on the function selector can be used to switch on the light without heating.

Cooling fan

The cooling fan switches on and off depending on the appliance's temperature. The hot air escapes above the door.

ATTENTION!

Do not cover the ventilation slot above the appliance door. The appliance overheats.

Ensure that the ventilation slots are unobstructed.

To ensure that the appliance cools down more quickly after operation, the cooling fan continues to run for a certain period afterwards.

Appliance door

If you open the appliance door during operation, the operation continues.

5 Accessories

Use original accessories. These have been made especially for your appliance.

Note: Accessories may become deformed if they get hot. Deformation has no effect on function. As the accessory cools down, it will regain its original shape.

The accessories supplied may differ depending on the appliance model.

Accessories	Use
Wire rack	 Cake tins Ovenproof dishes Cookware Meat, e.g. roasting joints or steak Frozen meals
Universal pan	 Moist cakes Baked items Bread Large roasts Frozen meals Catching dripping liquids, e.g. fat when grilling food on the wire rack.
Meat thermometer	High-precision roasting or cooking. → "Meat thermometer", Page 14

5.1 Locking function

The locking function prevents the accessories from tilting when they are pulled out.

You can pull out the accessories approximately halfway without them tipping. The accessories must be inserted into the cooking compartment correctly for the tilt protection to work properly.


5.2 Sliding accessories into the cooking compartment

Always slide accessories into the cooking compartment correctly. This is the only way to ensure that accessories can be pulled out approximately halfway without tipping.

- **1.** Turn the accessories so that the notch **a** is at the rear and is facing downwards.
- 2. Insert accessories between the two guide rods for the shelf position.


Wire rack

Insert the wire rack with the open side facing the appliance door and the curved lip — facing downwards.



Baking tray E.g. universal pan or baking tray


Slide the tray, e.g. the universal pan, in with the sloping edge b facing the appliance door.



3. Place the accessory at the shelf positions with the pull-out rails and pull out the pull-out rails.

Wire rack or baking tray

Position the accessory so that its edge is behind the lug a on the pullout rail.



Note: The pull-out rails lock in place when they are fully pulled out. Gently push the pull-out rails back into the cooking compartment.

4. Push the accessory all the way in, making sure that it does not touch the appliance door.


Note: Take any accessories that you will not be using out of the cooking compartment while the appliance is in operation.

Combining accessories

You can combine the wire rack with the universal pan to catch any liquid that drips down.

- 1. Place the wire rack on the universal pan so that both spacers a are on the rear edge of the univer-
- 2. Insert the universal pan between the two guide rods for a shelf position. In so doing, the wire rack is on top of the upper guide rod.

Wire rack on universal pan



5.3 Other accessories

You can purchase other accessories from our aftersales service, specialist retailers or online.

You will find a comprehensive range of products for your appliance in our brochures and online: www.siemens-home.bsh-group.com

Accessories vary from one appliance to another. When purchasing accessories, always quote the exact product number (E no.) of your appliance.

You can find out which accessories are available for your appliance in our online shop or from our aftersales service.

Before using for the first time

Configure the settings for initial start-up. Clean the appliance and accessories.

6.1 Initial use

You need to make settings for initial use before you can use your appliance.

Setting the time on the clock

Once the appliance has been connected to the mains or following a power failure, the time flashes on the display. The time starts at "12:00". Set the current time.

Requirement: The function selector must be set to the "Off" position o.

- **1.** Use the or + button to set the time.
- 2. Press the © button.
- ▼ The time that is set appears on the display.

Tip: You can go to the basic settings \rightarrow *Page 17* to specify whether or not the time should be shown on the display.

6.2 Cleaning the appliance before using it for the first time

Clean the cooking compartment and accessories before using the appliance to prepare food for the first time.

1. Remove any accessories and leftover packaging. such as polystyrene pellets, from the cooking compartment.

- 2. Before heating the appliance, wipe the smooth surfaces in the cooking compartment with a soft, damp cloth.
- 3. Keep the room ventilated while the appliance is heating.
- Set the type of heating and temperature. → "Basic operation", Page 12

	Main oven ∨	Top oven △
Type of heating	3D hot air ®	Top/bottom heating □
Temperat- ure	Maximum	240 °C
Cooking time	1 hour	1 hour

- **5.** Switch off the appliance after the specified cooking
- 6. Wait until the cooking compartment has cooled down
- 7. Clean the smooth surfaces with soapy water and a dish cloth.
- 8. Clean the accessories using soapy water and a dish cloth or soft brush.

Basic operation

7.1 Switching on the appliance

- Turn the function selector to any position other than the "Off" position o.
- The appliance is switched on.

7.2 Switching off the appliance

- Turn the function selector to the "Off" position o.
- The appliance is switched off.

7.3 Setting the type of heating and temperature

- **1.** Use the function selector to set the type of heating.
- 2. Use the temperature selector to set the temperature or grill setting.
- The appliance starts heating after a few seconds.

3. When your food is ready, switch off the appliance.

- The most suitable type of heating for your food can be found in the description of the type of heating.
- You can also set a cooking time and end time on the appliance.
 - → "Time-setting options", Page 12

Changing the type of heating

You can change the type of heating at any time.

▶ Use the function selector to set the required type of heating.

Changing the temperature

You can change the temperature at any time.

▶ Use the temperature selector to set the required temperature.

Rapid heating

To save time, you can use rapid heat-up to shorten the preheat time.

Only use rapid heat-up when a temperature of over 100 °C has been set.

After rapid heat-up, it is best to use the following types of heating:

■ 3D hot air ®

8.1 Setting rapid heating

To ensure an even cooking result, do not place the food in the cooking compartment until rapid heating has come to an end.

1. Use the function selector to select rapid heating ...

- 2. Use the temperature selector to set the required temperature.
- Rapid heating starts after a few seconds.
- When the rapid heating process ends, an audible signal sounds and the heating indicator goes out.
- 3. Use the function selector to set a suitable type of heating.
- **4.** Place the food in the cooking compartment.

Time-setting options

Your appliance has different time-setting options, with which you can control its operation.

9.1 Overview of the time-setting options

With the © button, select the different time-setting options.

Time-setting option	Use
Timer \triangle	The timer can be set independently of the appliance when it is in operation. It does not affect the appliance.
Cooking time	Main oven V: If you set a cooking time, operation of the appliance stops automatically once this time has elapsed.
End time →	Main oven V: For the cooking time, you can set the time at which operation ends. The appliance starts up automatically so that it finishes cooking at the required time.

Time-setting option	Use
Time ©	You can set the time.

9.2 Setting the timer

The timer runs independently of the appliance when it is in operation. The timer can be set when the appliance is switched on or off, up to 23 hours and 59 minutes. The timer has its own audible signal so that you can tell whether it is the timer or a cooking time which has elapsed.

- **1.** Press the \odot button repeatedly until \triangle is highlighted in the display.
- **2.** Use the or + button to set the timer duration.

Default value	
5 minutes	
10 minutes	

The timer duration can be set in 30-second increments up to 10 minutes. Above 10 minutes, the time increments become longer the higher the value.

- The timer starts and the timer duration begins to count down after a few seconds.
- An audible signal sounds and the timer duration is zero in the display when the timer duration has
- **3.** Once the timer duration has elapsed:
 - Press any button to switch off the timer.

Changing the timer

You can change the timer duration at any time.

Requirement: \triangle is highlighted on the display.

- Use the or + button to change the timer duration.
- The appliance applies the change after a few seconds.

Cancelling the timer

You can cancel the timer duration at any time.

Requirement: \triangle is highlighted on the display.

- ▶ Use the button to reset the timer duration to zero.
- ✓ After a few seconds, the appliance applies the change and \triangle goes out.

9.3 Setting the cooking time

You can set a cooking time for operation of up to 23 hours 59 minutes.

Requirement: A type of heating and a temperature or setting are set for the main oven V.

- 1. Press the ⊕ button repeatedly until → is highlighted in the display.
- **2.** Use the or + button to set the cooking time.

Button	Default value	
_	10 minutes	
+	30 minutes	

The cooking time can be set in 1-minute increments up to 1 hour, and then in 5-minute increments.

- The appliance starts heating and the cooking time counts down after a few seconds.
- ✓ If the cooking time has elapsed, an audible signal sounds and the display shows the cooking time as zero.
- **3.** When the cooking time has elapsed:
 - Press any button to end the audible signal before
 - To set a cooking time again, press the + button.
 - When your food is ready, switch off the appliance.

Changing the cooking time

You can change the cooking time at any time.

Requirement: \mapsto is highlighted on the display.

- Change the cooking time using the or + button.
- The appliance applies the change after a few seconds.

Cancelling the cooking time

You can cancel the cooking time at any time.

Requirement: \rightarrow is highlighted on the display.

- Reset the cooking time to zero using the button.
- After a few seconds, the appliance applies the change and continues to heat without a cooking time.

9.4 Setting the end time

You can delay the time at which cooking is due to finish by up to 23 hours and 59 minutes.

Notes

- The end time cannot be set for types of heating with arill function.
- In order to achieve a good cooking result, do not delay the end time once the appliance is already in operation.
- Food will spoil if you leave it in the cooking compartment too long.

Requirements

- A type of heating and a temperature or setting are set for the main oven V.
- A cooking time is set.
- 1. Press the ⓑ button repeatedly until → is highlighted in the display.
- **2.** Press the or + button.
- ▼ The display shows the calculated end time.
- 3. Use the or + button to delay the end time.
- After a few seconds, the appliance applies the setting and the display shows the set end time.
- Once the calculated start time has been reached, the appliance starts heating up and the cooking time starts counting down.
- Once the time has elapsed, an audible signal sounds and the display shows the cooking time as
- **4.** When the cooking time has elapsed:
 - Press any button to end the signal prematurely.
 - To set another cooking time, press the + button.
 - When your food is ready, switch off the appliance.

Changing the end time

In order to achieve a good cooking result, you can only change the set end time before operation starts and the cooking time starts counting down.

Requirement: → is highlighted on the display.

- Use the or + button to delay the end time.
- The appliance applies the change after a few seconds.

Cancelling the end time

You can delete the set end at any time.

Requirement: → is highlighted on the display.

- Reset the end time to the current time plus the set cooking time using the — button.
- After a few seconds, the appliance applies the change and starts heating up. The cooking time counts down.

9.5 Setting the time on the clock

Once the appliance has been connected to the mains or following a power failure, the time flashes on the display. The time starts at "12:00". Set the current time.

Requirement: The function selector must be set to the "Off" position o.

- **1.** Use the or + button to set the time.
- 2. Press the (9) button.
- ▼ The time that is set appears on the display.

Tip: You can go to the basic settings \rightarrow *Page 17* to specify whether or not the time should be shown on the display.

Changing the time on the clock

You can change the time on the clock at any time.

Requirement: The function selector must be set to the "Off" position o.

- 1. Press the © button repeatedly until © is highlighted in the display.
- 2. Use the or + button to change the time.
- The appliance applies the change after a few seconds.

10 Meat thermometer

Cook with precision by inserting the meat probe into the food and setting a core temperature on the appliance. Once the set core temperature has been reached in the food, the appliance stops automatically. The meat probe can be used in the main oven V.

10.1 Suitable types of heating with the meat thermometer

Only certain types of heating are suitable for use with the meat thermometer.

Suitable heating functions include:

- 3D hot air ®
- Hot air gentle &
- Pizza setting
- Hot air grilling 🖫
- Top/bottom heating □

Note: If the meat thermometer is being used and you select an unsuitable type of heating, a signal sounds.

10.2 Inserting the meat thermometer

Use the meat thermometer supplied or order a suitable meat thermometer from our after-sales service.

WARNING – Risk of electric shock!

Using the wrong meat probe could damage the insula-

Only use the meat probe for this specific appliance.

ATTENTION!

Otherwise the meat probe may be damaged.

- Do not trap the cable of the meat probe.
- To prevent the meat probe from being damaged by excessive heat, there must be a gap of a few centimetres between the grill element and the meat probe. The meat may expand during the cooking
- 1. Insert the meat thermometer at an angle into the thickest part of the meat.

Ensure that the tip of the meat thermometer is correctly positioned in the meat:

- The tip must be roughly in the middle of the food.
- The tip must not be inserted in the fat.
- The tip must not touch any cookware or bones.
- 2. Place the food with the meat thermometer into the cooking compartment.

It is best to place the food in cookware into the centre of the wire rack.

3. Plug the meat thermometer into the socket on the left-hand side of the cooking compartment.

Notes

- If you remove the meat thermometer while the food is cooking, all the settings will be reset.
- Do not remove the meat thermometer when turning the food. Once you have turned the food, check that the meat thermometer is correctly positioned in the

10.3 Setting the meat thermometer

The meat probe measures the temperature inside the food between 30 °C and 99 °C.

Requirements

- The food with the meat probe is in the cooking com-
- The meat probe is plugged in inside the cooking compartment.
- 1. Use the function selector to set a suitable type of heating.
- is marked in the display and the core temperature indicator appears.
- 2. Use the or + button to set the core temperature. The current core temperature of the food is shown on the left, while the set core temperature is shown on the right, e.g. 15 °C|75 °C.

Note: The current core temperature only appears once it reaches 10 °C.

- 3. Use the temperature selector to set the temperature of the cooking compartment.
 - Set the cooking compartment temperature at least 10 °C higher than the core temperature. Do not set the cooking compartment temperature to higher than 250 °C.
- The appliance starts heating after a few seconds.
- Once the food reaches the core temperature, an audible signal sounds and, in the display, the current core temperature is equal to the set core temperature, e.g. 75 °C|75 °C.

4. MARNING – Risk of burns!

The cooking compartment, accessories and meat probe become very hot.

Always use oven gloves to remove hot accessories and the meat probe from the cooking compartment.

When the core temperature is reached:

- Switch off the appliance.
- Pull the meat probe out of the socket in the cooking compartment.
- Pull the meat probe out of the food remove it from the cooking compartment.

11 **Programme**

The programmes help you to use your appliance to prepare different dishes by selecting the optimum settings automatically.

11.1 Cookware for programmes

You should therefore use heat-resistant cookware that is suitable for temperatures up to 300 °C. Glass or glass ceramic cookware is best. The joint should cover approx. two thirds of the cookware base. Cookware made from the following material is not suitable:

- Bright, shiny aluminium
- Unglazed clay
- Plastic or plastic handles

11.2 Programme table

The programme numbers are assigned to specific foods. The weight can be set to between 0.5 kg and 2.5 kg.

No.	Food	Cookware	Weight setting	Add liquid	Shelf positions	Information
01	Chicken, unstuffed Ready to cook, seasoned	Roasting dish with glass lid	Chicken weight	No	2	Place in the cook- ware with the breast facing up
02	Turkey breast Whole, seasoned	Roasting dish with glass lid	Turkey breast weight	Cover the bottom of the roasting dish and add up to 250 g vegetables if you wish	2	Do not sear the meat beforehand
03	Vegetable stew Vegetarian	Deep roasting dish with lid	Total weight	As per recipe	2	Cut vegetables that take longer to cook (e.g. carrots) into smaller pieces than vegetables that take less time to cook (e.g. tomatoes)
04	Goulash Diced beef or pork, with vegetables	Deep roasting dish with lid	Total weight	As per recipe	2	Place the meat at the bottom and cover with vegetables Do not sear the meat beforehand
05	Meat loaf, fresh Minced beef, pork or lamb	Roasting dish with lid	Roast weight	No	2	-

No.	Food	Cookware	Weight setting	Add liquid	Shelf posi- tions	Information
06	Pot-roasted beef E.g. prime rib, shoulder, rump or mar- inated beef roast	Roasting dish with lid	Weight of meat	Almost cover the meat with liquid	2	Do not sear the meat beforehand
07	Beef olives Stuffed with vegetables or meat	Roasting dish with lid	Total weight of all the stuffed beef olives	Add stock, water or an- other liquid to the dish until the beef olives are al- most covered	2	Do not sear the meat beforehand
08	Leg of lamb, well done Boned, seasoned	Roasting dish with lid	Weight of meat	Cover the bottom of the roasting dish and add up to 250 g vegetables if you wish	2	Do not sear the meat beforehand
09	Joint of veal, lean E.g. tenderloin or eye	Roasting dish with lid	Weight of meat	Cover the bottom of the roasting dish and add up to 250 g vegetables if you wish	2	Do not sear the meat beforehand
10	Pork neck joint Boned, seasoned	Roasting dish with glass lid	Weight of meat	Cover the bottom of the roasting dish and add up to 250 g vegetables if you wish	2	Do not sear the meat beforehand

11.3 Preparing food for the programme

Use fresh and, ideally, chilled food.

- 1. Weigh the food.
 - The weight of the food is required in order to correctly set the programme.
- 2. Add the food to the cookware.
- **3.** Place the cookware onto the wire rack. Always place the cookware into the cooking compartment while it is cold.

11.4 Setting a programme

The appliance selects the optimal type of heating, temperature and cooking time. All you need to do is set the weight.

Notes

- You can set the weight only in the intended area.
- After the programme starts, you can no longer change the programme and the weight.
- **1.** Use the function selector to set **Programme** \mathbb{P} .
- **2.** Use the temperature selector to set **Programme P**.
- Use the or + button to set the required programme.

- **4.** Press the kg button.
- 5. Use the or + button to set the weight of your food. Always set the next higher weight.
 - The display shows the calculated cooking time.
 The cooking time cannot be changed.
 - For some programmes, the © button can be used to delay the end.
 - → "Setting the end time", Page 13
 - To change the programme, press the kg button.
- After a few seconds, the programme starts and the cooking time counts down.
- If the programme has ended, an audible signal sounds and the display shows the cooking time as zero.
- 6. When the programme ends:
 - Press any button to end the audible signal prematurely.
 - To set a cooking time for further cooking, press the + button. The appliance continues to heat using the programme settings.
 - When your food is ready, switch off the appliance.

Childproof lock 12

Secure your appliance to prevent children from accidentally switching on the main oven V or changing the settings.

Notes

- You can go to the basic settings \rightarrow Page 17 to specify whether you want the option to set the childproof lock.
- After a power cut, the childproof lock is deactivated.

12.1 Activating and deactivating the childproof lock

Requirement: The function selector must be set to the "Off" position o.

- To activate the childproof lock, press and hold the → button until → appears in the display.
 - To deactivate the childproof lock, press and hold the ➡ button until ➡ goes out in the display.

13 Basic settings

You can configure the appliance to meet your needs.

13.1 Overview of the basic settings

Here you can find an overview of the basic settings and factory settings. The basic settings depend on the features of your appliance.

Display	Basic setting	Selection
<u> </u>	Time display	$ \Omega = \text{hide the time} $ $ I = \text{display the time}^1 $
c2	Signal duration upon completion of a cooking time or timer period	$I = 10 \text{ seconds}$ $Z = 30 \text{ seconds}^1$ $Z = 2 \text{ minutes}$
c 3	Button tone when pressing a button	$G = \text{off}$ $I = \text{on}^1$
сЧ	Cooling fan run-on time	 I = short Z = medium ∃ = long¹ Y = extra long
<i>c</i> 5	Waiting time until a setting is applied	$I = 3 \text{ seconds}^1$ Z = 6 seconds Z = 10 seconds
c	Childproof lock can be adjusted	$ G = \text{no} $ $ I = \text{yes}^1 $
ε 7	Water hardness ²	$ \Omega = \text{softened} $ $ I = \text{soft (up to 1.5 mmol/l)} $ $ Z = \text{medium (1.5-2.5 mmol/l)} $ $ Z = \text{hard (2.5-3.8 mmol/l)} $ $ Z = \text{very hard (above 3.8 mmol/l)} $

13.2 Changing basic settings

Requirement: The appliance is switched off.

- 1. Press and hold the © button for approximately four seconds.
- The first basic setting appears in the display, e.g. *c11*.
- **2.** Use the or + button to change the setting.
- 3. Use the (button to switch to the next basic setting.

4. To save the changes, press and hold the © button for approx. four seconds.

Note: Following a power failure, the factory basic settings are restored.

13.3 Discarding changes to the basic settings

- ► Turn the function selector.
- All changes are discarded and not saved.

² Only for appliance types with steam function

Cleaning and servicing

To keep your appliance working efficiently for a long time, it is important to clean and maintain it carefully.

14.1 Cleaning products

In order to avoid damaging the various oven surfaces on the appliance, do not use unsuitable cleaning products.

★ WARNING – Risk of electric shock!

An ingress of moisture can cause an electric shock.

Do not use steam- or high-pressure cleaners to clean the appliance.

ATTENTION!

Unsuitable cleaning products may damage the surfaces of the appliance.

- ► Do not use harsh or abrasive cleaning products.
- Do not use cleaning products with a high alcohol content.
- Do not use hard scouring pads or cleaning sponges.
- Do not use any special cleaners for cleaning the appliance while it is hot.

Using oven cleaner in a hot cooking compartment damages the enamel.

- Never use oven cleaner in the cooking compartment when it is still warm.
- Remove all food remnants from the cooking compartment and the appliance door before you next heat up the appliance.

New sponge cloths contain residues from production.

Wash new sponge cloths thoroughly before use.

Suitable cleaning agents

Only use cleaning agents that are suitable for the different surfaces on your appliance.

Follow the instructions on cleaning the appliance. → "Cleaning the appliance", Page 19

Appliance front

Surface	Suitable cleaning agents	Notes
Stainless steel	 Hot soapy water Special stainless steel cleaning products suitable for hot surfaces 	To prevent corrosion, remove any limescale, grease, starch or albumin (e.g. egg white) stains on stainless steel fronts immediately. Apply a thin layer of the stainless steel cleaning product with a soft cloth.
Plastic or painted surfaces E.g. control panel	■ Hot soapy water	Do not use glass cleaner or a glass scraper.

Appliance door

Area	Suitable cleaning agents	Notes
Door panels	■ Hot soapy water	Do not use a glass scraper or a stainless steel wool. Tip: Remove the door panels in order to clean them thoroughly. → "Appliance door", Page 24
Door cover	 Made of stainless steel: Stainless steel cleaner Made of plastic: Hot soapy water 	Do not use glass cleaner or a glass scraper. Tip: Remove the door cover for thorough cleaning. → "Appliance door", Page 24
Door handle	■ Hot soapy water	To avoid permanent stains, remove descaling agents from the door handle immediately.
Door seal	Hot soapy water	Do not remove or scrub.

Cooking compartment

Area	Suitable cleaning agents	Notes
Enamel surfaces	Hot soapy waterVinegar waterOven cleaner	 Soak any heavily soiled areas and use a brush or steel wool. Leave the appliance door open to dry the cooking compartment after cleaning it. Notes Enamel burns at very high temperatures, causing minor discolouration. The functionality of your appliance is not affected by this. The edges of thin trays cannot be completely enamelled and may be rough. This does not impair corrosion protection. Food residues will leave a white coating on the enamel surfaces. The coating does not pose a health risk. The functionality of your appliance is not affected by this. You can remove residues with lemon juice.
Self-cleaning surfaces	-	Follow the instructions for self-cleaning surfaces. → "Cleaning self-cleaning surfaces in the main cooking compartment", Page 19 → "Cleaning self-cleaning surfaces in the top cooking compart-
		ment", Page 20
Glass cover for the oven light	Hot soapy water	Use oven cleaner to remove very heavy soiling.
Rails	■ Hot soapy water	Soak any heavily soiled areas and use a brush or steel wool. Tip: Remove the shelf supports for cleaning. → "Shelf supports", Page 22
Pull-out system	■ Hot soapy water	Use a brush to remove very heavy soiling. Clean the pull-out rails while they are pushed in so that you do not remove the lubricant. Do not clean in the dishwasher. Tip: Detach the pull-out system for cleaning. → "Shelf supports", Page 22
Accessorles	Hot soapy waterOven cleaner	Soak any heavily soiled areas and use a brush or steel wool. Enamelled accessories are dishwasher-safe.
Meat probe	Hot soapy water	Use a brush to remove very heavy soiling. Do not clean in the dishwasher.

14.2 Cleaning the appliance

In order to avoid damaging the appliance, you must clean your appliance only as specified, and with suitable cleaning products.

★ WARNING – Risk of burns!

The appliance and its parts that can be touched become hot during use.

- Caution should be exercised here in order to avoid touching heating elements.
- Young children under 8 years of age must be kept away from the appliance.

⚠ WARNING – Risk of fire!

Loose food remnants, fat and meat juices may catch fire.

Before using the appliance, remove the worst of the food residues and remnants from the cooking compartment, heating elements and accessories.

Requirement: Read the information on cleaning products.

- → "Cleaning products", Page 18
- 1. Clean the appliance using hot soapy water and a dish cloth.

- For some surfaces, you can use alternative cleaning agents.
- → "Suitable cleaning agents", Page 18
- 2. Dry with a soft cloth.

14.3 Cleaning self-cleaning surfaces in the main cooking compartment

The back wall, ceiling and side walls of the main cooking compartment are self-cleaning and have a rough surface.

ATTENTION!

If you do not clean the self-cleaning surfaces regularly, they may become damaged.

- ► If dark stains are visible on the self-cleaning surfaces, use the cleaning function to clean the cooking compartment.
- If a prompt to clean appears in the display, use the cleaning function to clean the cooking compart-
- Do not use oven cleaner or abrasive cleaning aids. If oven cleaner accidentally comes into contact with the self-cleaning surfaces, dab it off immediately using water and a sponge cloth. Do not rub.

► Use the cleaning function. → "Cleaning function ", Page 20

14.4 Cleaning self-cleaning surfaces in the top cooking compartment

The back wall, ceiling and side walls of the top cooking compartment are self-cleaning and have a rough surface.

ATTENTION!

If you do not clean the self-cleaning surfaces regularly, they may become damaged.

- ► If dark stains are visible on the self-cleaning surfaces, use the cleaning function to clean the cooking compartment.
- If a prompt to clean appears in the display, use the cleaning function to clean the cooking compartment.
- ▶ Do not use oven cleaner or abrasive cleaning aids. If oven cleaner accidentally comes into contact with the self-cleaning surfaces, dab it off immediately using water and a sponge cloth. Do not rub.
- ► Use the cleaning function.
 - → "Cleaning function ", Page 20

15 Cleaning function

Use the cleaning function regularly to help retain the cleaning ability of the self-cleaning surfaces and prevent damage.

The self-cleaning surfaces in the cooking compartment are coated with a porous, matt ceramic layer and have a rough surface. When the appliance is in operation, the self-cleaning surfaces absorb splashes from roasting or grilling and break them down.

- The following surfaces are self-cleaning:
 Back wall
- Ceiling
- Side walls

ATTENTION!

If you do not clean the self-cleaning surfaces regularly, they may become damaged.

- ► If dark stains are visible on the self-cleaning surfaces, use the cleaning function to clean the cooking compartment.
- If a prompt to clean appears in the display, use the cleaning function to clean the cooking compartment
- ► Do not use oven cleaner or abrasive cleaning aids. If oven cleaner accidentally comes into contact with the self-cleaning surfaces, dab it off immediately using water and a sponge cloth. Do not rub.

15.1 Cleaning recommendation

The appliance detects the type and duration of the appliance operation and, if necessary, recommends using the cleaning function.

- ► If *EL* lights up in the display when the appliance is switched off, use the cleaning function as soon as possible.
 - To remove the information from the display, press any button except for the — button. However, the information will continue to be displayed until the cleaning function has been run in full.
 - To reset the cleaning recommendation, press and hold the — button for approx. four seconds.
 The information does not reappear until the appliance has been used again a certain number of times.

Notes

If the appliance is already dirty, e.g. because you have used it to cook fatty poultry or roasts, or if you notice dark patches on the self-cleaning surfaces,

- do not wait until this information appears in the display to run the cleaning function. The more often you use the cleaning function, the longer the selfcleaning surfaces will retain their cleaning ability.
- After a power failure, the cleaning recommendation is reset. It is therefore a good idea to run the cleaning function after a power failure has occurred.

15.2 Preparing the appliance for the cleaning function

In order to achieve a good cleaning result, prepare the appliance carefully.

ATTENTION!

Using oven cleaner on the self-cleaning surfaces damages the surfaces.

- ▶ Do not use oven cleaner on the self-cleaning surfaces. If oven cleaner does get onto these surfaces, dab it off immediately using water and a sponge cloth. Do not rub the surface and do not use abrasive cleaning aids.
- Remove accessories and cookware from the cooking compartment.
- **2.** Unhook the shelf supports and remove them from the cooking compartment.
 - → "Shelf supports", Page 22
- **3.** Use a detergent solution and a soft cloth to remove heavy soiling:
 - From the cooking compartment floor
 - From the inside of the appliance door
 - From the glass cover for the oven light
 This prevents stains that cannot be removed.
- **4.** Remove any objects from the cooking compartment. The cooking compartment must be empty.

15.3 Setting the cleaning function for the bottom oven \vee

Ventilate the kitchen while the cleaning function is running.

⚠ WARNING – Risk of burns!

The outside of the appliance gets very hot when the cleaning function is in progress.

- Never touch the appliance door.
- Allow the appliance to cool down.
- ► Keep children at a safe distance.

Requirement: Prepare the appliance for the cleaning function. → Page 20

- 1. Use the function selector to set Cleaning function
- The display shows the duration. The duration of one hour cannot be changed.
- 2. Use the temperature selector to set the cleaning setting 🕮.
- The cleaning function starts after a few seconds and the time counts down.
- Once the cleaning function ends, an audible signal sounds and the display shows the cooking time as
- **3.** Switch off the appliance.
- **4.** Wipe the appliance clean. \rightarrow Page 21

15.4 Setting the cleaning function for the top oven ∧

WARNING – Risk of burns!

The outside of the appliance gets very hot when the cleaning function is in progress.

- Never touch the appliance door.
- Allow the appliance to cool down.
- Keep children at a safe distance.

Requirement: Prepare the appliance for the cleaning function. → Page 20

- 1. Use the function selector to set Cleaning function 🛗.
- 2. Use the temperature selector to set the cleaning setting 🚟.
- **3.** Switch off the appliance after one hour.
 - You can also set the timer to remind you after one hour.
- **4.** Wipe the appliance clean. \rightarrow Page 21

15.5 Wiping the appliance clean following the cleaning function

- 1. Allow the appliance to cool down.
- 2. Wipe the cooking compartment clean with a damp cloth.

Note: Marks may appear on the self-cleaning surfaces. Residues of sugar and albumin in the food are not removed and remain on the surfaces. Reddish patches may be left over from salty food - the spots are not rust. These spots are not harmful. These marks do not impair the cleaning ability of the self-cleaning surfaces.

- **3.** Attach the shelf supports. → "Shelf supports", Page 22
- cleaning assistance humidClean

The cleaning assistance is a fast alternative for occasionally cleaning the cooking compartment. The cleaning assistance softens dirt by vaporising the soapy water. The dirt can then be removed more easily.

16.1 Setting the cleaning assistance

⚠ WARNING – Risk of scalding!

If there is water in the cooking compartment when it is hot, this may create hot steam.

Never pour water into the cooking compartment when the cooking compartment is hot.

Requirement: The cooking compartment has cooled down completely.

- 1. Remove the accessories from the cooking compart-
- 2. Mix 0.4 litres water with a drop of washing-up liquid and pour into the centre of the cooking compart-
 - Do not use distilled water.
- 3. Use the function selector to set the **Bottom heating** type of heating.
- **4.** Use the temperature selector to set 80 °C.
- 5. Press the ⊕ button repeatedly until → is highlighted in the display.
- **6.** Use the or + button to set the time to four minutes.
- After a few seconds, the appliance starts heating and the cooking time counts down.

- ✓ When the cooking time has elapsed, a signal sounds and the duration is at zero in the display.
- 7. Switch off the appliance and leave the cooking compartment to cool down for 20 minutes.

16.2 Recleaning the cooking compartment

ATTENTION!

The prolonged presence of moisture in the cooking compartment leads to corrosion.

After using the cleaning assistance, wipe the cooking compartment and allow it to dry completely.

Requirement: The cooking compartment has cooled down.

- 1. Open the appliance door and remove the remaining water with an absorbent sponge cloth.
- 2. Clean the smooth surfaces in the cooking compartment with a dish cloth or a soft brush. Remove stubborn food remnants using a stainless steel scouring
- **3.** Remove limescale with a cloth soaked in vinegar. Then wipe with clean water and rub dry with a soft cloth (including under the door seal).
- 4. Once the cooking compartment is cleaned sufficiently:
 - To allow the cooking compartment to dry, open the appliance door to the stop position (approx. 30°) and leave it open for approx. one hour.
 - To dry the cooking compartment quickly, heat up the appliance for approx. five minutes at **3D hot** air and 50 °C while the door is open.

Shelf supports


To clean the rails and the cooking compartment, or to replace the rails, you can remove these.

17.1 Detach the rails in the main cooking compartment \vee

WARNING - Risk of burns!

The shelf supports get very hot


- Never touch the shelf supports when hot.
- Always allow the appliance to cool down.
- Keep children at a safe distance.
- 1. Lift the rail forwards slightly ① and detach it ②.
- 2. Pull the whole rail to the front 3 and remove it.



17.2 Attaching the rails in the main cooking compartment V

Notes

- The rails only fit on the right or left.
- For both pull-out rails, ensure that you can pull them forwards and out.
- 1. First, push the rail into the middle of the rear socket ① until the rail rests against the cooking compartment wall, and then push this back 2.
- 2. Push the rail into the front socket 3 until the rail also rests against the cooking compartment wall, and then press this downwards 4.



17.3 Removing the pull-out rail

⚠ WARNING – Risk of burns!

The shelf supports get very hot

- Never touch the shelf supports when hot.
- Always allow the appliance to cool down.
- Keep children at a safe distance.


ATTENTION!

The self-cleaning surfaces in the cooking compartment may be damaged by detaching and attaching the pullout rails.


► Detach the rails before detaching or attaching the pull-out rails.

Note: If necessary, you can use pull-out rails on all levels.


1. Push on the tab marked **PUSH** behind the rail, and push the rail to the rear.




2. Keep the PUSH tab pushed back ① and swing the rail outwards 2.



3. Pull the rail out towards the front until the retainer at the back unhooks.



4. Remove the pull-out rail.




- 5. Clean the pull-out rail.
 - → "Cleaning products", Page 18


17.4 Attaching the pull-out rail

Note: The pull-out rails only fit on the right or left. Make sure when you fit them that you can pull them out towards the front.


1. Insert the pull-out rail between the two bars.




2. Push the retainer a in between the lower and the upper bar.



- 3. Keep the **PUSH** tab pushed in ① and swing the pullout rail inwards until the front retainer a is located between the two bars 2.
 - Release the **PUSH** tab.



- The retainer a clicks into place.
- Pull the pull-out rail out as far as it will go and slide it back in.




17.5 Detaching the rails in the top cooking compartment Λ

⚠ WARNING – Risk of burns!

The shelf supports get very hot


- Never touch the shelf supports when hot.
- Always allow the appliance to cool down.
- Keep children at a safe distance.
- **1.** Lift the rail forwards slightly ① and detach it ②.
- **2.** Pull the rail to the front 3 and remove it 4.



17.6 Attaching the rails in the top cooking compartment \wedge

The rails only fit on the right or left.

- For both shelf supports, ensure that the hooks that are attached at the rear are pointing upwards.
- 1. First, push the rail into the middle of the rear socket ① until the rail rests against the cooking compartment wall, and then push this back ②.
- 2. Push the rail into the front socket ③ until the rail also rests against the cooking compartment wall, and then press this downwards ④.





18 Appliance door

To ensure that your appliance retains its appearance and remains fully functioning for a long time, you can detach the appliance door and clean it.

18.1 Detaching the lower appliance door \vee

⚠ WARNING – Risk of injury!

Components inside the appliance door may have sharp edges.

▶ Wear protective gloves.

The hinges on the appliance door move when the door is opened and closed, which could trap your fingers.


- ► Keep your hands away from the hinges.
- 1. Open the appliance door fully.

When the hinges are not secured, they can snap shut with great force.

► Make sure that the locking levers are always either fully closed or (when detaching the oven door) fully open.

Open the locking levers on the left- and right-hand hinges.

Locking levers opened



The hinge is now secured and cannot snap shut.


Locking levers closed



The appliance door is secured and cannot be detached.

The locking levers are open. The hinges are now secured and cannot snap shut.

3. Close the appliance door fully ①. Grab hold of the appliance door with both hands (on the left and right) and pull it upwards and out 2.




4. Carefully place the appliance door on a level surface.

18.2 Attaching the lower appliance door \vee

⚠ WARNING – Risk of injury!

The hinges on the appliance door move when the door is opened and closed, which could trap your fingers.

- ► Keep your hands away from the hinges.
- When the hinges are not secured, they can snap shut with great force.
- Make sure that the locking levers are always either fully closed or (when detaching the oven door) fully
- 1. Slide the appliance door straight onto the two hinges ①. Slide the appliance door on as far as it will go.
- 2. Open the appliance door fully.
- 3. Close the locking levers on the left- and right-hand hinges 2.



- The locking levers are closed. The appliance door is secured and cannot be detached.
- **4.** Close the appliance door.


18.3 Removing the door panes from the lower the appliance door \vee

⚠ WARNING – Risk of injury!


The hinges on the appliance door move when the door is opened and closed, which could trap your fingers.

- Keep your hands away from the hinges.
- Components inside the appliance door may have sharp edges.
- Wear protective gloves.


- 1. Open the appliance door fully.
- Open the locking levers on the left- and right-hand hinges 1.
- The locking levers are open. The hinges are now secured and cannot snap shut.
- **3.** Close the appliance door fully ②.




- 4. Push on the left- and right-hand side of the door cover from the outside 1 until it is released.
- 5. Remove the door cover 2.



- 6. Lift out the inner pane 1 and set it down carefully on a flat surface.
- 7. Lift out the intermediate pane 2 and set it down carefully on a flat surface.



- **8.** If necessary, you can remove the condensate trough for cleaning.
 - Open the appliance door.
 - Tilt the condensate trough upwards and remove it.



Scratched glass in the appliance door may develop into a crack.

► Do not use any harsh or abrasive cleaners or sharp metal scrapers to clean the glass on the oven door, as they may scratch the surface.

Clean the removed door panes on both sides with glass cleaner and a soft cloth.

- **10.** Clean the condensate trough with a cloth and hot soapy water.
- 11. Clean the appliance door.
 - → "Suitable cleaning agents", Page 18
- 12. Dry the door panes and refit them.
 - \rightarrow "Installing the door panes for the lower the appliance door V", Page 26

18.4 Installing the door panes for the lower the appliance door \vee


⚠ WARNING – Risk of injury!

The hinges on the appliance door move when the door is opened and closed, which could trap your fingers.


► Keep your hands away from the hinges.

Components inside the appliance door may have sharp edges.


- Wear protective gloves.
- 1. Open the appliance door fully.
- **2.** Place the condensate trough vertically in the retainer a and turn it downwards.




 Slide the intermediate pane into the left- and righthand retainers a.




4. Push the intermediate pane upwards until it is in the left- and right-hand retainers a.



Slide the inner pane into the left- and right-hand retainers a.




6. Push the inner pane upwards until it is in the left-and right-hand retainers a.



- **7.** Put the door cover in position ① and push down on it until you hear it click into place.
- 8. Open the appliance door fully.

9. Close the locking levers on the left- and right-hand hinges 2.



- The locking levers are closed. The appliance door is secured and cannot be detached.
- 10. Close the appliance door.

Note: Do not use the cooking compartment again until the door panes have been correctly fitted.

18.5 Detaching the upper appliance door \wedge

⚠ WARNING – Risk of injury!

The hinges on the appliance door move when the door is opened and closed, which could trap your fingers.

- Keep your hands away from the hinges.
- Open the appliance door fully.


⚠ WARNING – Risk of injury!

When the hinges are not secured, they can snap shut with great force.

Make sure that the locking levers are always either fully closed or (when detaching the oven door) fully open.


Open the locking levers on the left- and right-hand hinges.

Locking levers opened



The hinge is now secured and cannot snap shut.


Locking levers closed



The appliance door is secured and cannot be detached.

The locking levers are open. The hinges are now secured and cannot snap shut.

3. Close the appliance door fully ①. Grab hold of the appliance door with both hands (on the left and right) and pull it upwards and out 2.



4. Carefully place the appliance door on a level surface.

18.6 Attaching the upper appliance door \wedge


⚠ WARNING – Risk of injury!

The hinges on the appliance door move when the door is opened and closed, which could trap your fingers.


► Keep your hands away from the hinges.

When the hinges are not secured, they can snap shut with great force.

- Make sure that the locking levers are always either fully closed or (when detaching the oven door) fully
- 1. Slide the appliance door straight onto the two hinges. Slide the appliance door on as far as it will go.



- 2. Open the appliance door fully.
- Close the locking levers on the left- and right-hand hinges.



The locking levers are closed. The appliance door is secured and cannot be detached.

4. Close the appliance door.

18.7 Removing the door panes from the upper the appliance door \wedge


⚠ WARNING – Risk of injury!

The hinges on the appliance door move when the door is opened and closed, which could trap your fingers.


Keep your hands away from the hinges.

Components inside the appliance door may have sharp edges.


- Wear protective gloves.
- 1. Open the appliance door fully.
- 2. Open the locking levers on the left- and right-hand hinges ①.
- The locking levers are open. The hinges are now secured and cannot snap shut.
- **3.** Close the appliance door fully ②. Grab hold of the appliance door with both hands (on the left and right) and pull it upwards and out ③.



- **4.** Carefully place the appliance door on a level surface.
- **5.** Push on the left- and right-hand side of the door cover from the outside ① until it is released.
- **6.** Remove the door cover ②.



Lift out the inner pane and set it down carefully on a flat surface.



8. WARNING – Risk of injury!

Scratched glass in the appliance door may develop into a crack.

► Do not use glass scrapers, sharp or abrasive cleaning aids, or harsh cleaning products.

Clean the removed door panes on both sides with glass cleaner and a soft cloth.

- **9.** Clean the appliance door.
 - → "Suitable cleaning agents", Page 18
- 10. Dry the door panes and refit them.
 - \rightarrow "Installing the door panes for the upper the appliance door \land ", Page 28

18.8 Installing the door panes for the upper the appliance door \wedge


⚠ WARNING – Risk of injury!

The hinges on the appliance door move when the door is opened and closed, which could trap your fingers.


► Keep your hands away from the hinges.

Components inside the appliance door may have sharp edges.


- Wear protective gloves.
- 1. Slide the inner pane in. In doing so, ensure that the inner pane is in the retainer a.




2. Push the inner pane upwards until it is in the leftand right-hand retainers a.




3. Put the door cover in position and push down on it until you hear it click into place.



4. Slide the appliance door straight onto the two hinges. Slide the appliance door on as far as it will go. When doing so, ensure that the hinges are inserted into the correct opening.



5. Close the locking levers on the left- and right-hand hinges.



- The locking levers are closed. The appliance door is secured and cannot be detached.
- Close the appliance door.

Note: Do not use the cooking compartment again until the door panes have been correctly fitted.

Troubleshooting

You can rectify minor faults on your appliance yourself. Read the troubleshooting information before contacting after-sales service. This will avoid unnecessary costs.

⚠ WARNING – Risk of injury!

Improper repairs are dangerous.

- Repairs to the appliance should only be carried out by trained specialist staff.
- If the appliance is defective, call Customer Service.

⚠ WARNING – Risk of electric shock!

Incorrect repairs are dangerous.

- Repairs to the appliance should only be carried out by trained specialist staff.
- Only use genuine spare parts when repairing the appliance.
- If the power cord of this appliance is damaged, it must be replaced by trained specialist staff.

19.1 Malfunctions

Fault	Cause and troubleshooting
The appliance is not working.	The circuit breaker is faulty.
	Check the circuit breaker in the fuse box.
	There has been a power cut.
	Check whether the lighting in your kitchen or other appliances are working.

Fault	Cause and troubleshooting	
The appliance does not switch off fully at the end of a cooking time.	At the end of a cooking time, the appliance stops heating up. The oven light and cooling fan do not switch off. For types of heating with recirculation, the fan continues to run in the back wall of the cooking compartment. Turn the function selector to the off position.	
	✓ The appliance is switched off.	
	 The appliance is switched off. The oven light and the fan in the back wall are switched off. 	
	 The cooling fan switches off automatically as soon as the appliance has cooled down. 	
The time flashes in the display.	There has been a power cut.	
	 Reset the time. → "Setting the time on the clock", Page 14 	
The time does not appear in the display when the appliance is switched off.	The basic setting has been changed. ► Change the basic setting for the time display. → "Basic settings", Page 17	
lights up in the display and no	Childproof lock is activated.	
settings can be made on the appliance.	 Use the ⇒ button to deactivate the childproof lock. → "Childproof lock", Page 17 	
Γ L appears in the display.	Cleaning recommendation	
	 Run the cleaning function in full. → "Cleaning function ", Page 20 	
	You can temporarily dismiss the information in the display by pressing any button.	
	→ "Cleaning recommendation", Page 20	
A message with <i>E</i> appears in the display, e.g. <i>E05-32</i> .	Electronics fault	
uispiay, e.g. Lui-iL.	1. Press the © button.	
	 If required, reset the time. If the fault was a one-off, the error message disappears. 	
	2. If the error message appears again, call the after-sales service. Quote the ex-	
	act error message and the E no. of your appliance. → "Customer Service", Page 31	

19.2 Replacing the oven light bulb

If the light in the cooking compartment fails, change the oven light bulb.

Note: Heat-resistant, 25-watt, 230 V halogen bulbs are available from the after-sales service or specialist retailers. Only use these bulbs. Hold the new halogen bulbs only with a clean, dry towel. This increases the service life of the bulb.

⚠ WARNING – Risk of burns!

The appliance gets very hot.

- Never touch the inside surfaces of the cooking compartment or the heating elements while they are hot.
- ► Always allow the appliance to cool down.
- ► Keep children at a safe distance.

⚠ WARNING – Risk of electric shock!

When changing the bulb, the bulb socket contacts are live.


Before replacing the bulb, unplug the appliance from the mains or switch off the circuit breaker in the fuse box.

Requirements

- The appliance is disconnected from the power supply.
- The cooking compartment has cooled down.
- You have a new halogen bulb to replace the old one.

- 1. Place a tea towel in the cooking compartment to prevent damage.
- **2.** Turn the glass cover anti-clockwise to remove it ①.
- **3.** Pull out the halogen bulb without turning it ②.





Insert the new halogen lamp and press it firmly into the socket.

Make sure the pins are positioned correctly.

- Depending on the appliance model, the glass cover may have a sealing ring. Put the sealing ring in position.
- **6.** Screw the glass cover on.
- **7.** Take the tea towel out of the cooking compartment.
- 8. Connect the appliance to the power supply.

20 Disposal

Find out here how to dispose of old appliances correctly.

20.1 Disposing of old appliance

Valuable raw materials can be reused by recycling.

- 1. Unplug the appliance from the mains.
- 2. Cut through the power cord.
- 3. Dispose of the appliance in an environmentally friendly manner.

Information about current disposal methods are available from your specialist dealer or local authority.



This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE).

The guideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.

Customer Service 21

If you have any queries on use, are unable to rectify faults on the appliance yourself or if your appliance needs to be repaired, contact Customer Service. Function-relevant genuine spare parts according to the corresponding Ecodesign Order can be obtained from Customer Service for a period of at least 10 years from the date on which your appliance was placed on the market within the European Economic Area.


Note: Under the terms of the manufacturer's warranty the use of Customer Service is free of charge.

Detailed information on the warranty period and terms of warranty in your country is available from our aftersales service, your retailer or on our website. If you contact Customer Service, you will require the product number (E-Nr.) and the production number (FD) of your appliance.

The contact details for Customer Service can be found in the enclosed Customer Service directory or on our website.

21.1 Product number (E-Nr.) and production number (FD)

You can find the product number (E-Nr.) and the production number (FD) on the appliance's rating plate. You will see the rating plate with these numbers if you open the appliance door.



Make a note of your appliance's details and the Customer Service telephone number to find them again quickly.

How it works 22

Here, you can find the ideal settings for various types of food as well as the best accessories and cookware. We have perfectly tailored these recommendations to your appliance.

22.1 Cooking tips

Observe this information when preparing food.

- The temperature and cooking time depend on the amount of food and the recipe. Settings ranges are specified for this reason. Try using the lower values to start with.
- The setting values apply to food placed in the cooking compartment while the cooking compartment is still cold. Do not slide the accessory into the cooking compartment until it has finished preheating.
- Remove any accessories that are not being used from the cooking compartment.

22.2 Notes on baking

When baking, use the shelf positions indicated.

Baking on one level	Height
Deep baked goods or tin on wire rack	2
Flat baked goods or goods in a baking tray	3

Baking on two levels	Height
Universal pan	3
Baking tray	<u> </u>
Baking tins/dishes on the wire rack:	Height
First wire rack	3
Second wire rack	1

Baking on three levels	Height
Baking tray	5
Universal pan	3
Baking tray	1

Notes

- When baking on several layers, always use hot air.
 Baked goods that are placed in the oven at the same time will not necessarily be ready at the same time
- Position baking tins/dishes either next to one another or offset on different shelves so that they are not directly one above the other in the cooking compartment.
- For best results, we recommend using dark-coloured metal bakeware.

22.3 Notes on roasting and grilling

The setting values are based on the assumption that unstuffed, chilled, ready-to-roast poultry, meat or fish is placed into a cold cooking compartment.

- The larger the poultry, meat or fish, the lower the cooking temperature and the longer the cooking time.
- Turn the poultry, meat or fish after approx. 1/2 to 2/3 of the time listed.
- Add a little liquid to the poultry in the cookware.
 Cover the bottom of the cookware with approx. 1–2 cm of liquid.
- When you turn poultry, ensure that the breast side or skin side is underneath to begin with.
- Cooking time calculation (e.g. 20 + 35): To calculate the cooking time, assume 20 minutes per 500 g of meat plus an extra 35 minutes. For 1.5 kg, the cooking time is then 95 minutes.
- Cooking time range (e.g. 10–15): Your food will be ready within the specified range of time.

Roasting and grilling on the wire rack

Roasting on the wire rack works particularly well for large poultry or for multiple pieces at the same time.

 Depending on the size and type of the food to be roasted, add up to 1/2 litre water to the universal pan.

You can make a sauce from the juices that are caught. This also means that less smoke is produced and the cooking compartment becomes less dirty.

- Keep the appliance door closed when using the grill.
 - Never grill with the appliance door open.
- Place the food to be grilled on the wire rack. In addition, slide the universal pan in at least one shelf position lower, with the slanted edge facing the appliance door. This means that any dripping fat is caught.

Roasting in cookware

When preparing food in cookware with a lid, the cooking compartment remains cleaner.

Follow the manufacturer's instructions for your roasting dishes. Glass cookware is best.

Cookware without lid

- Use a deep roasting dish.
- Place the cookware onto the wire rack.
- If you do not have any suitable cookware, use the universal pan.

Cookware with lid

- Place the cookware onto the wire rack.
- Meat, poultry and fish can also become crispy in a covered roasting dish. Use a roasting dish with a glass lid. Set a higher temperature.

⚠ WARNING – Risk of injury!

If hot glass cookware is placed on a wet or cold surface, the glass may shatter.

Place hot glass ovenware on a dry mat after cooking.

⚠ WARNING – Risk of scalding!

Very hot steam may escape when the lid is opened after cooking. Steam may not be visible, depending on the temperature.

- Lift the lid at the rear, so that the hot steam can escape away from you.
- Keep children at a safe distance.

22.4 Food selection

Selection for the main oven

Food	Accessories/cookware	Shelf pos- ition	Temperature in °C/grill setting	
Victoria sponge cake	2 pcs Ø 20 cm cake tin	2	150-170 ¹	15-25

- 1 Preheat the appliance. Do not use the rapid heating function.
- ² Preheat the appliance.
- ³ Preheat the appliance for five minutes. Do not use the rapid heating function.
- ⁴ Preheat the appliance to 150 °C using HotAir.
- ⁵ Preheat the appliance for 20 minutes.
- ⁶ Do not turn the food.
- ⁷ Slide the universal pan underneath the wire rack.
- 8 Add the food after approx. one hour.
- ⁹ Preheat the appliance for 5 minutes.
- ¹⁰ Preheat the appliance for three minutes.
- ¹¹ Turn the food occasionally.

¹ Preheat the appliance. Do not use the rapid heating function.

² Preheat the appliance.

³ Preheat the appliance for five minutes. Do not use the rapid heating function.

⁴ Preheat the appliance to 150 °C using HotAir.

⁵ Preheat the appliance for 20 minutes.

⁶ Do not turn the food.

⁷ Slide the universal pan underneath the wire rack.

⁸ Add the food after approx. one hour.

⁹ Preheat the appliance for 5 minutes.

¹⁰ Preheat the appliance for three minutes.

¹¹ Turn the food occasionally.

22.5 Food selection

Selection for the top oven

Food	Accessories/cook- ware	Shelf pos- ition	Type of heating	Temperature in °C	Cooking time in mins
Scones	Baking sheet	1		200-210 ¹	10-12
Small cakes	12-cup-tin	1		150-160 ¹	25-35
Lamb chops, height 2-3 cm	Wire rack	3		3 ¹	1. side 7-9 2. side 5-8
Pork sausages, thickness 2-4 cm	Wire rack	3		3	14-18

Preheat the appliance.

22.6 Yoghurt

You can use your appliance to make your own yoghurt.

Preparing yoghurt

- Remove the accessories and shelf supports from the cooking compartment.
- 2. Pour the previously prepared yoghurt mixture into small containers, e.g. into cups or small jars.
- 3. Cover the containers with foil, e. g. with cling film.
- **4.** Place the containers on the cooking compartment floor.
- **5.** Set the appliance according to the recommended setting.
- **6.** After making the yoghurt, leave it to cool in the refrigerator.

Yoghurt

Selection for the main oven

Food	Accessories/cookware	Shelf position	Type of heating	Temperature in °C	Cooking time in mins
Yoghurt	Individual moulds	Cooking compartment floor	1 2. &	1. 50 ¹ 2. -	1 2. 8-9 hrs

Preheat the appliance.

22.7 Test dishes

These overviews have been produced for test institutes to facilitate appliance testing in accordance with EN 60350-1.

Baking

Observe this information when baking test dishes.

General information

- The settings apply to food that is placed into a cold cooking compartment.
- Observe the notes about preheating in the tables.
 These setting values apply without rapid heating.
- When baking, use the lower of the listed temperatures to begin with.

Shelf positions

Shelf positions for baking on two levels:

Note: Items that are placed in the oven on baking trays or in baking tins/dishes at the same time will not necessarily be ready at the same time.


 Universal pan: Level 3 Baking tray: Level 1 Baking tins/dishes on the wire rack
 First wire rack: Level 3
 Second wire rack: Level 1

Shelf positions for baking on three levels:

Baking tray: Level 5
 Universal pan: Level 3
 Baking tray: Level 1

Baking with two springform cake tins:

Position baking tins/dishes either next to one another or offset on different shelves so that they are not directly one above the other in the cooking compartment.



Baking

Selection for the main oven

Food	Accessories/cookware	Shelf pos- ition	Type of heating	Temperature in °C	Cook- ing time in mins
Viennese whirls	Baking tray	3		140-150 ¹	25-35
Viennese whirls	Baking tray	3	(A)	140-150 ¹	20-30
Viennese whirls, 2 levels	Universal pan + Baking tray	3 + 1	(a)	140-150 ¹	25-35
Viennese whirls, 3 levels	Universal pan + Baking tray	5 + 3 + 1	(8)	130-140 ¹	35-55
Small cakes	Baking tray	3		150-160 ¹	20-30
Small cakes	Baking tray	3	(8)	140-150 ¹	25-35
Small cakes, 2 levels	Universal pan + Baking tray	3 + 1		140-150 ¹	25-40
Small cakes, 3 levels	Universal pan + Baking tray	5 + 3 + 1	(8)	140 ¹	30-40
Hot water sponge cake	Springform cake tin, diameter 26 cm	2		160-170 ²	25-35
Hot water sponge cake	Springform cake tin, diameter 26 cm	2	(4)	160-170	30-35
Hot water sponge cake, 2 levels	Springform cake tin, diameter 26 cm	3 + 1	(A)	150-160 ²	35-50

² Preheat the appliance. Do not use the rapid heating function.

Grilling

Selection for the main oven

Food	Accessories/cookware	Shelf pos- ition	Type of heating	Temperature in °C/grill setting	Cook- ing time in mins
Toasting bread	Wire rack	5	""	3 ¹	0.5-1.5
¹ Preheat the appliance for five minutes.	Do not use the rapid hea	ting function	١.		

Grilling

Selection for the top oven

Food	Accessories/cookware	Shelf pos- ition	Type of heating	Temperature in °C	Cook- ing time in mins
Browning toast	Wire rack	3	""	3	4-6

23 Installation instructions

Observe this information when installing the appliance.






23.1 General installation instructions

Follow these instructions before you start with the installation of the appliance.

- The safe operation of this appliance can only be guaranteed if it has been installed to a professional standard in accordance with these installation instructions. The installer shall be liable for damages incurred as a result of incorrect installation.
- Do not use the door handle for the transport or installation.
- The appliance must be transported by two people using the carry handles on the right and left.
- Check the appliance for damage after unpacking it. Do not connect the appliance if it has been damaged in transit.
- Before starting up the appliance, remove any packaging material and adhesive film from the cooking compartment and the door.
- Proceed in accordance with the installation sheets for installing accessories.
- Fitted units must be heat-resistant up to 95 °C, and adjacent unit fronts up to 70 °C.
- Do not install the appliance behind a decorative door or the door of a kitchen unit.
 There is a risk of overheating.
- Cut-out work on the units should be carried out before installing the appliance. Remove any shavings. Otherwise, the correct operation of electrical components may be adversely affected.
- The mains socket for the appliance must either be located in the hatched area a or outside of the area where the appliance is installed.

Any unsecured units must be secured to the wall using a standard bracket **b**.



- Wear protective gloves so that you do not cut yourself. Parts that are accessible during installation may have sharp edges.
- Dimensions of the figures in mm.

⚠ WARNING – Risk of fire!

It is dangerous to use an extended power cord and non-approved adapters.

- Do not use extension cables or multiple socket strips.
- ► If the power cord is too short, contact Customer Service.
- Only use adapters approved by the manufacturer.


ATTENTION!

Carrying the appliance by the door handle could break it. The door handle cannot support the weight of the appliance.

Do not carry or hold the appliance by the door handle.


23.2 Appliance dimensions

You will find the dimensions of the appliance here




23.3 Installation in a tall unit

Observe the installation dimensions and the installation instructions when installing in a tall unit.




To ventilate the appliance, there must be a gap of 20 mm between all intermediate floors and the wall.



- If the tall unit has another back panel in addition to the element back panels, this must be removed.
- Only fit the appliance up to a height which allows accessories to be easily removed.

23.4 Corner installation

Observe the installation dimensions and the installation instructions when installing in a corner.



To ensure that the appliance door can be opened, you must take the minimum dimensions into consideration when installing in a corner. The dimension a is dependent on the thickness of the unit front and the handle.

23.5 Electrical connection

In order to safely connect the appliance to the electrical system, follow these instructions.

- The appliance corresponds to protection class I and must only be operated with a protective earth connection.
- The fuse protection must correspond to the power rating specified on the appliance's rating plate and to local regulations.
- The appliance must be disconnected from the power supply whenever installation work is being carried out.
- Contact protection must be ensured during the installation.

Electrically connecting an appliance without a protective contact plug


Note: Only a licensed professional may connect the appliance. Damage caused by incorrect connection is not covered under the warranty.

An all-pole isolating switch must be integrated into the permanent electrical installation according to the installation regulations.

- 1. Identify the phase and neutral conductors in the socket.
 - The appliance may be damaged if it is not connected correctly.
- 2. Connect the hob in accordance with the connection diagram.
 - See the rating plate for the voltage.
- 3. Connect the wires of the mains power cable according to the colour coding:
 - Green/yellow = Protective conductor ⊕
 - Blue = Neutral conductor
 - Brown = Phase (external conductor)

23.6 Installing the appliance


1. Remove the transport locks on the right and left and then dispose of them.




2. The appliance must be transported by two people using the carry handles on the right and left, while securing the front of the appliance with one hand.



3. Place the appliance in the unit and fold the carry handles down.




- 4. Push the appliance in fully.
 - Do not kink or trap the connecting cable, or route it over sharp edges.
- 5. Centre the appliance.



There must be an air gap of at least 5 mm between the appliance and adjacent unit fronts.

6. Use a spirit level to adjust the appliance so that it is perfectly level.

7. Screw the appliance into place.



23.7 Removing the appliance

- 1. Disconnect the appliance from the power supply.
- 2. Undo the fastening screws.
- 3. Lift the appliance slightly and pull it out completely.



BSH Hausgeräte GmbH Carl-Wery-Straße 34

81739 München GERMANY

www.siemens-home.bsh-group.com

Valid within Great Britain: Imported to Great Britain by BSH Home Appliances Ltd. Grand Union House Old Wolverton Road Wolverton, Milton Keynes MK12 5PT United Kingdom

由博西家用电器(江苏)有限公司根据西门子股份公司的商标许可制造



9001580325 (010121)

en