

# Futher information and explanations are available online:



# **Table of contents**

1 Safety	4
1.1 General information	4
1.2 Intended use	4
1.3 Restriction on user group	4
1.4 Safe installation	5
1.5 Safe use	7
1.6 Safe cleaning and maintenance	9
2 Preventing material damage	
3 Environmental protection and	
saving energy	11
3.1 Disposing of packaging	11
3.2 Saving energy	11
3.3 Energy saving mode	12
4 Installation and connection	12
4.1 Unpacking the appliance	12
4.2 Scope of delivery	12
4.3 Requirements for the install-	
ation location	
4.4 Aligning the appliance	14
4.5 Connecting the appliance to	1 1
the electricity supply	14
5 Familiarising yourself with	
your appliance	
5.1 Appliance	
5.2 Wool basket	
5.3 Control panel	16
6 Display	17
7 Buttons	20
8 Dryness level	23
8.1 Changing the dryness level	
8.2 Adjusting the dryness level	

9.1 A	ogrammesutomatic programmesimed programmes	24
	ccessories	
11 La	aundry Preparing the laundry	26
12.1 12.2 12.3 12.4 12.5 12.6 12.7 12.8 12.9	Switching on the appliance Setting a programme Loading laundry Starting the programme Adding laundry Cancelling the programme Unloading the laundry Switching off the appliance Fluff filter	27 27 27 27 27 27 27 28 28
13.1 13.2	hildproof lock	30
14.1 14.2 14.3	Inserting the wool basket Starting a programme with the wool basket Examples of how to use the wool basket	31 31
15 Ba	asic settings	33
	Overview of the basic settings	33
15.2	Changing the basic set-tings	34

16 Cleaning and servicing	34
16.1 Tips on cleaning and care	
16.2 Base unit	34
16.3 Moisture sensor	37
17 Troubleshooting	38
18 Transportation, storage and disposal	19
18.1 Preparing the appliance for	72
transportation	42
18.2 Disposing of old appliance	
19 Customer Service	43
19.1 Product number (E-Nr.) and	4.4
production number (FD)	44
20 Consumption values	45
21 Technical data	45



# 1 Safety

Observe the following safety instructions.

#### 1.1 General information



- Read this instruction manual carefully.
- Keep the instruction manual and the product information safe for future reference or for the next owner.
- Do not connect the appliance if it has been damaged in transit.

#### 1.2 Intended use

Only use this appliance:

- For drying and freshening up fabrics that are washed with water and suitable for dryers.
- In private households and in enclosed spaces in a domestic environment.
- Up to an altitude of max. 4000 m above sea level.

# 1.3 Restriction on user group

This appliance may be used by children aged 8 or over and by people who have reduced physical, sensory or mental abilities or inadequate experience and/or knowledge, provided that they are supervised or have been instructed on how to use the appliance safely and have understood the resulting dangers.

Do not let children play with the appliance.

Cleaning and user maintenance must not be performed by children unless they are being supervised.

Keep children under the age of 3 years and pets away from the appliance.

#### 1.4 Safe installation

#### 

Incorrect installation is dangerous.

- Connect and operate the appliance only in accordance with the specifications on the rating plate.
- Connect the appliance to a power supply with alternating current only via a properly installed socket with earthing.
- ► The protective conductor system of the domestic electrical installation must be properly installed. The installation must have a sufficiently large cross section.
- ▶ When using a residual current circuit breaker, only use a type with the mark.
- ► Never equip the appliance with an external switching device, e.g. a timer or remote control.
- ▶ Never connect the appliance to a circuit that is regularly switched on and off by the energy supplier.
- ▶ When the appliance is installed, the mains plug of the power cord must be freely accessible. If free access is not possible, an all-pole isolating switch must be installed in the permanent electrical installation according to the installation regulations.
- ► When installing the appliance, check that the power cable is not trapped or damaged.

If the insulation of the power cord is damaged, this is dangerous.

- ► Never let the power cord come into contact with hot appliance parts or heat sources.
- Never let the power cord come into contact with sharp points or edges.
- ▶ Never kink, crush or modify the power cord.

#### 

It is dangerous to use an extended power cord and non-approved adapters.

- ▶ Do not use extension cables or multiple socket strips.
- Only use adapters and power cords approved by the manufacturer.

#### en Safety

▶ If the power cord is too short and a longer one is not available, please contact an electrician to have the domestic installation adapted.

# **⚠** WARNING – Risk of injury!

The high weight of the appliance may result in injury when lifted.

▶ Do not lift the appliance on your own.

If this appliance is not correctly installed in a washer-dryer stack, the installed appliance may fall.

- Only stack the dryer on a washing machine using the connection kit from the dryer manufacturer
  - → "Accessories", Page 26. No other installation method is permitted.
- ▶ Do not install the appliance in a washer-dryer stack if the dryer manufacturer does not offer a suitable connection kit.
- ▶ Do not install appliances from different manufacturers and with varying depths and widths in a washer-dryer stack.
- ▶ Do not install a washer-dryer stack on a platform; the appliances may tip over.

#### **⚠** WARNING – Risk of suffocation!

Children may put packaging material over their heads or wrap themselves up in it and suffocate.

- ► Keep packaging material away from children.
- ▶ Do not let children play with packaging material.

# **△** CAUTION – Risk of injury!

The appliance may vibrate or move when in use.

- ▶ Place the appliance on a clean, even, solid surface.
- ► Align the appliance using the appliance feet and a spirit level. If hoses and power cords have been laid incorrectly, this causes a tripping hazard.
- Lay hoses and power cords in such a way that there is no risk of tripping.

If the appliance is moved by holding onto protruding components, such as the appliance door, the parts may break off.

▶ Do not move the appliance by holding onto protruding parts.

# **△** CAUTION – Risk of cutting!

Touching sharp edges on the appliance may lead to cuts.

- ▶ Do not touch the sharp edges on the appliance.
- Wear protective gloves when installing and transporting the appliance.

#### 1.5 Safe use

#### 

If the appliance or the power cord is damaged, this is dangerous.

- ► Never operate a damaged appliance.
- ▶ Never pull on the power cord to unplug the appliance. Always unplug the appliance at the mains.
- ▶ If the appliance or the power cord is damaged, immediately unplug the power cord or switch off the fuse in the fuse box.
- ► Call customer services. → Page 43

An ingress of moisture can cause an electric shock.

- ► Only use the appliance in enclosed spaces.
- ► Never expose the appliance to intense heat or humidity.
- ▶ Do not use steam- or high-pressure cleaners, hoses or sprays to clean the appliance.

#### **△** WARNING – Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- ▶ Do not install the appliance behind a door as this may obstruct the appliance door or prevent it from opening.
- ▶ With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.

#### ↑ WARNING – Risk of suffocation!

Children may breathe in or swallow small parts, causing them to suffocate.

- ► Keep small parts away from children.
- ▶ Do not let children play with small parts.

# **⚠** WARNING – Risk of explosion!

If there is coal dust or flour in the air around the appliance, this may cause an explosion.

► Keep the area around the appliance clean during operation.

# **⚠** WARNING – Risk of poisoning!

Condensation water from this appliance is not suitable for drinking and may be contaminated with fluff.

Do not drink or reuse the condensation water from the appliance.

Detergents and care products may result in poisoning if consumed.

- ▶ If accidentally swallowed, seek medical advice.
- ► Keep detergents and care products out of the reach of children.

# **⚠** WARNING – Risk of explosion!

If there is any residual material left in the fluff filter, this may ignite during the drying process.

► Clean the fluff filter regularly.

Highly flammable objects such as lighters or matches may ignite during the drying process.

► Remove all highly flammable objects from any pockets in your laundry before the drying process.

Unwashed laundry that has come into contact with solvents, oil, wax, wax remover, paint, grease or stain remover may ignite when drying is in progress.

- ► Do not place laundry in this appliance to be dried if the laundry has not been washed first.
- Rinse the laundry thoroughly with warm water and detergent before drying it in the machine.
- ▶ Do not use the appliance if industrial chemicals have been used to clean the laundry beforehand.

#### **⚠** WARNING – Risk of fire!

If drying is interrupted early, the laundry is not cooled sufficiently and may ignite.

▶ Do not interrupt the drying programme early.

► If drying is interrupted early, remove the laundry immediately and spread it out.

# **△** CAUTION – Risk of injury!

The covering plate may break if you stand on or climb onto the appliance.

▶ Do not stand on or climb onto the appliance.

The appliance may tip over if you sit on or lean against the open door.

- ▶ Do not sit on or lean against the appliance door.
- Do not place any objects on the appliance door.

Reaching into the drum while it is still turning may cause hand injuries.

Wait for the drum to come to a complete stop before reaching inside.

### **⚠** CAUTION – Risk of burns!

The rear panel of the appliance becomes hot during operation.

- ▶ Do not touch the rear panel of the appliance when it is hot.
- ► Keep children away from the rear panel of the appliance when it is hot.
- ▶ Position the appliance with the rear panel close against a wall.

### 1.6 Safe cleaning and maintenance

#### 

Incorrect repairs are dangerous.

- ► Repairs to the appliance should only be carried out by trained specialist staff.
- ▶ Only use genuine spare parts when repairing the appliance.
- ▶ If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

An ingress of moisture can cause an electric shock.

► Do not use steam- or high-pressure cleaners, hoses or sprays to clean the appliance.

# **⚠** WARNING – Risk of injury!

The use of non-original spare parts and non-original accessories is dangerous.

► Only use the manufacturer's original spare parts and original accessories.

# **⚠** WARNING – Risk of poisoning!

Poisonous fumes may be given off if you use cleaning agents that contain solvents.

▶ Do not use cleaning agents that contain solvents.

# 2 Preventing material damage

#### **ATTENTION!**

The functionality of the appliance may be impaired if you use the wrong quantity of fabric softener, detergent, care product or cleaning agent.

Follow the dosage recommendations from the manufacturer.

Exceeding the maximum load capacity impairs the function of the appliance.

- Observe the maximum load capacity for each programme and do not exceed it.
- → "Programmes", Page 24 The function of the appliance may be impaired if the appliance overheats.
- Keep the ventilation opening on the appliance clear during operation.
- Make sure that the area is adequately ventilated.

Light objects such as hair and fluff may be sucked in from the ventilation opening on the appliance during operation and impair the function of the appliance.

- Keep the area around the appliance clean during operation.
- Keep light objects away from the appliance.

Foam and foam rubber may deform or melt during the drying process.

 Do not dry laundry that contains foam or foam rubber.

Unsuitable cleaning products may damage the surfaces of the appliance.

- Do not use harsh or abrasive detergents.
- Do not use cleaning products with a high alcohol content.
- Do not use hard scouring pads or cleaning sponges.

- Clean the appliance with nothing but water and a soft, damp cloth.
- ► Remove all detergent residue. spray residue or other residues immediately if they come into contact with the appliance.

# 3 Environmental protection and saving energy

#### 3.1 Disposing of packaging

The packaging materials are environmentally compatible and can be recycled.

 Sort the individual components by type and dispose of them separately.

#### 3.2 Saving energy

If you follow these instructions, your appliance will use less power.

Operate the appliance in a well-ventilated room and keep the ventilation opening on the appliance clear.

✓ If air exchange is impeded, this extends the programme duration and increases energy consumption.

Spin the laundry in the washing machine before drying.

 Damper laundry extends the programme duration and increases energy consumption.

Observe the programme's maximum load capacity.

- → "Programmes", Page 24
- ✓ If the maximum load is exceeded, this extends the programme duration and increases energy consumption.

After drying, clean the fluff filter → Page 28.

✓ If the fluff filter is dirty, this reduces the air flow in the appliance, extends the programme duration and increases energy consumption.

Regularly clean the base unit → Page 35.

 If the heat exchanger is dirty, this extends the programme duration and increases energy consumption.

#### 3.3 Energy saving mode

If you do not use the appliance for an extended period, it automatically switches to energy-saving mode. All displays go out and **Start/Pause** flashes.

Energy-saving mode ends when you use the appliance again.

# 4 Installation and connection

### 4.1 Unpacking the appliance

#### **ATTENTION!**

Objects remaining in the drum that are not designed for operation with the appliance may cause material damage and damage to the appliance.

- Remove these objects, along with all supplied accessories, from the drum before starting the appliance.
- Remove any packaging and protective covers completely from the appliance.
  - → "Disposing of packaging", Page 11

- 2. Check the appliance for visible damage.
- 3. Open the door.
- Remove any accessories from the drum.
- 5. Close the door.

#### 4.2 Scope of delivery

After unpacking all parts, check for any damage in transit and completeness of the delivery.

#### **ATTENTION!**

If the appliance is operated with incomplete or defective accessories, the appliance may not be able to operate properly, or this may result in material damage or damage to the appliance.

- Do not operate the appliance with incomplete or defective accessories.
- Replace the accessories in question before operating the appliance.
  - → "Accessories", Page 26

Included with the appliance	Description
	Tumble dryer
	Accompanying documents
	Wool basket with insert  → "Wool basket", Page 31

#### 4.3 Requirements for the installation location

#### **ATTENTION!**

If the appliance is tilted at an angle greater than 40°, residual water may leak out of the appliance and cause material damage.


- ► Tilt the appliance carefully.
- ► Transport the appliance in an upright position.

If residual water in the appliance freezes, this may cause damage to the appliance.

 Do not install or operate this appliance anywhere that is liable to experience frost or outdoors.

#### Installation loca- Requirements tion

On the floor



Place the appliance on a clean. level and firm surface. Align the appliance

→ Page 14.

#### Installation loca- Requirements tion

In a washer-dryer stack




Only use the original connection set from the dryer manufacturer when setting up this appliance in a washer-dryer stack.

Connection kit → Page 26

This appliance must only be stacked on a washing machine from the same manufacturer. The depth and width of this appliance must correspond with the dimensions of the washing machine. Do not place the washer-dryer stack on a platform.

#### Against a wall




Do not trap the hoses and power cord between the wall and the appliance.

### 4.4 Aligning the appliance

In order to reduce vibrations and noises, align the appliance correctly.

► To align the appliance, turn the appliance feet. Check that the appliance is level using a spirit level.



All appliance feet must stand firmly on the ground.


### 4.5 Connecting the appliance to the electricity supply

- 1. Insert the mains plug of the appliance's power cable in a socket nearby.
  - The connection details of the appliance can be found under Technical data → Page 45.
- 2. Check the mains plug is inserted properly.

# 5 Familiarising yourself with your appliance

# 5.1 Appliance


You can find an overview of the parts of your appliance here.



On certain models, specific details such as the colour and shape may differ from those pictured.

1	Ventilation opening
2	Maintenance flap on the base unit → Page 34
3	Fluff filter → Page 28
4	Door
5	Condensation container  → Page 29
6	Control panel → Page 16


#### 5.2 Wool basket



1	Securing foot
2	Wool basket
3	Insert
4	Tab for securing in the hook

### 5.3 Control panel


You can use the control panel to configure all functions of your appliance and to obtain information about the operating status.



- Programmes → Page 24
   Programme selector → Page 27
   Display → Page 17
- 4 Buttons → Page 20

# 6 Display

The display shows the current settings, options or relevant information.



Example: Display

Display	Designation	Description
0:40 1	Programme dura- tion/programme time remaining	Expected programme duration or programme time remaining in hours and minutes.
1:25	Timed programme	The timed programme is set.  → "Timed programmes", Page 25
8.0 1	Recommended load	The maximum load capacity for the selected programme in kg.
+ 0:45 <sup>1</sup>	"Ready in" time	→ "Buttons", Page 22
	Childproof lock	<ul> <li>lights up: The childproof lock is activated.</li> <li>flashes: The childproof lock is activated and the appliance has been operated.         → "Deactivating the childproof lock", Page 30     </li> </ul>
<b>•</b>	Start/Pause	Start, cancel or pause  Lights up: The programme is running and can be cancelled or paused.  Flashes: The programme can be started or continued.
<sup>1</sup> Example		

Display	Designation	Description
	Dryness level: Iron Dry	The dryness level is activated.  → "Buttons", Page 21
<b></b>	Dryness level: Cupboard Dry	The dryness level is activated.  → "Buttons", Page 21
⊞+	Dryness level: Cupboard Dry Plus	The dryness level is activated.  → "Buttons", Page 20
+1 +2 +3	Dryness level adjusted	The adjusted dryness level is activated.  → "Dryness level", Page 23
Z	Crease-reduction function	The crease-reduction function is activated.  → "Buttons", Page 21
¥	Gentle drying	Gentle drying is activated for delicate fabrics.  → "Buttons", Page 21
	Half load	Half load is activated.  → "Buttons", Page 22
94Y)	Quiet drying	Quiet drying with no audible signals is activated.  → "Buttons", Page 22
	Condensation container	Empty the condensation container  → Page 29. Insert the condensation container  → Page 30.
<u>.</u>	Fluff filter Base unit	Clean the fluff filter.  → "Cleaning the fluff filter", Page 28 Clean the base unit.  → "Base unit", Page 34
Hot	Cooling process	The laundry is cooled while the drum is rotating, in order to avoid damage to the laundry. The process can be cancelled by opening the door.  Note: Do not change the programme.
<u> </u>	Drying	Programme status
	Dryness level: Iron Dry	Programme status
<b>1</b>	Dryness level: Cupboard Dry	Programme status
Z	Anti-crease	Programme status
<b>•</b>	Pause	Programme status
<sup>1</sup> Example		

Display	Designation	Description
End	End of programme	Programme status
<sup>1</sup> Example		

# 7 Buttons

Below is an overview of the buttons and their setting options.

Button	Selection	Description
Start/Pause	<ul><li>Start</li><li>Cancel</li><li>Pause</li></ul>	Start, cancel or pause the programme.
~ 3s	<ul><li>Activate</li><li>Deactivate</li></ul>	Activate or deactivate the childproof lock. Disable the control panel to prevent unwanted or accidental operation. If the childproof lock is activated and the appliance has been switched off, the childproof lock remains activated.  → "Childproof lock", Page 30
Cupboard Dry Plus	■ Cupboard Dry Plus ■ +1 ■ +2 ■ +3	■ Selecting Cupboard Dry Plus activates the dryness level. The dryness level defines how damp or dry the laundry is after the programme ends. → "Dryness level", Page 23 ■ The dryness level can be adjusted by select- ing +1, +2 or +3. → "Adjusting the dry- ness level", Page 23

Button	Selection	Description
Cupboard Dry	■ Cupboard Dry ■ +1 ■ +2 ■ +3	■ Selecting Cupboard Dry activates the dry- ness level. The dryness level defines how damp or dry the laundry is after the programme ends. → "Dryness level", Page 23 ■ The dryness level can be adjusted by select- ing +1, +2 or +3. → "Adjusting the dry- ness level", Page 23
Iron Dry	■ Iron Dry ■ +1 ■ +2 ■ +3	<ul> <li>Selecting Iron Dry activates the dryness level.         The dryness level defines how damp or dry the laundry is after the programme ends.         → "Dryness level", Page 23     </li> <li>The dryness level can be adjusted by selecting +1 , +2 or +3 .</li> <li>→ "Adjusting the dryness level", Page 23</li> </ul>
Anti Crease	<ul><li>Activate</li><li>Deactivate</li></ul>	Activate or deactivate the crease-reduction function. Once the programme has ended, the drum moves the laundry at regular intervals for 60 minutes to prevent creasing.
Low Heat	<ul><li>Activate</li><li>Deactivate</li></ul>	Activate or deactivate gentle drying. The temperature is reduced for delicate fabrics, e.g. polyacrylic or elastane. The programme duration is extended.

#### en Buttons

Button	Selection	Description
Ready In	■ Programme end ■ Programme length	<ul> <li>Set the programme end.         The programme duration is already included in the set number of hours.         Once the programme has started, the programme duration is displayed.     </li> <li>Set the programme duration for timed programmes.         "Timed programmes", Page 25     </li> </ul>
Signal	<ul><li>Activate</li><li>Deactivate</li></ul>	Activate or deactivate operating signals and information signals.
Half Load	<ul><li>Activate</li><li>Deactivate</li></ul>	Dry individual items of laundry or small loads of laundry.

# 8 Dryness level

Each automatic programme has a specified dryness level. The dryness level defines how dry or damp your laundry is after the programme ends.

Dryness level	Laundry	Drying result
Cupboard Dry Plus	Multi-layered, thick laundry that does not dry readily.	The laundry is dry.
Cupboard Dry	Normal, single-layered laundry.	The laundry is dry.
Iron Dry	Normal, single-layered laundry	The laundry is still a little damp after drying. To prevent creasing after drying, iron the laundry or hang it up.

#### 8.1 Changing the dryness level

For some automatic programmes, you can change the dryness level so that your laundry will be drier or more damp.

- 1. Set an automatic programme. → "Automatic programmes". Page 24
- The display shows the specified dryness level.
- 2. Press Cupboard Dry , Cupboard Dry Plus or Iron Dry
- ✓ The display shows: 
  ☐, 
  ☐

  or 
  ☐

#### 8.2 Adjusting the dryness level

If the laundry feels too damp after it has been dried to a particular dryness level, you can adjust the dryness level.

- 1. Set an automatic programme. → "Automatic programmes". Page 24
- The display shows the specified dryness level.

- 2. Press Cupboard Dry Plus, Cup**board Dry** or **Iron Dry** .
- ▼ The display shows: "+1", "+2" or "+3" .

# 9 Programmes

You can dry your fabrics using either an automatic programme or a timed programme.

#### 9.1 Automatic programmes

Automatic programmes are programmes in which humidity sensors measure the residual moisture in the laundry during the drying cycle. The programme only ends once the set dryness level is reached. Each automatic programme has a dryness level → Page 23. The dryness level defines how dry or damp the laundry is after the programme ends.

#### **Tips**

- Select the dryness level according to the type of fabric or the desired drying result.
  - → "Dryness level", Page 23
- The laundry's care labels provide you with additional information about programme selection.

Programme	Description	Max. load (kg)
Cottons	Dry hard-wearing, heat-resistant fabrics made of cotton or linen.	8.0
Cottons Eco	Dry hard-wearing, heat-resistant fabrics made of cotton or linen. Energy-saving programme.	8.0
Synthetics	Dry items made of synthetic materials or blended fabrics.	3.5
Mix	Dry items made of cotton and synthetics.	3.0
Blanket/Duvet	Dry clothing, pillows, quilts or bedspreads filled with synthetic fibres. <b>Note:</b> Dry large items of laundry, blankets or pillows individually.	2.5
Lingerie	Dry delicate underwear made of lace, Lycra, satin or blended fabrics.	2.0
Anti Bacteria	Dry hard-wearing, heat-resistant fabrics made of cotton or linen.  Note: Particularly suitable for strict hygiene requirements.	4.0
Shirts 15 min	Suitable for shirts and blouses made of cotton, linen, synthetics or blended fabrics.  Note: For optimal drying results, dry a maximum of 5 shirts or 5 blouses at the same time.	1.5

Programme	Description	Max. load (kg)
	Once the laundry is dry, iron it or hang it up. The residual moisture is then distributed evenly.	
Super 40 min	Dry items made of synthetics and light cotton.	2.0
Towels	Dry hard-wearing, heat-resistant towels and dressing gowns made of cotton or linen.	6.0

#### 9.2 Timed programmes

Timed programmes are programmes with a defined or adjustable programme duration. The programme ends once this time has elapsed, even if the laundry is still not dry, for example. Timed programmes are suitable for drying individual items of laundry or thin fabrics.

Tip: The laundry's care labels provide you with additional information about programme selection.

Programme	Description	Max. load (kg)
Wool in Basket	Dry items made of wool or containing wool.	One item of laundry
	Note: Dry these items only using the wool basket.  → "Wool basket", Page 31	
© Cold	Dry all types of fabric except for wool and silk. Also suitable for freshening up or airing clothing that has hardly been worn.	3.0
© Warm	Dry all types of fabric except for wool and silk. Suitable for pre-dried or slightly damp laundry and for drying off multi-layered, thick laundry.	3.0

#### 10 Accessories

Use original accessories. These have been made especially for your appliance.

**Note:** Some accessories are available in other colours. Contact → "Customer Service", Page 43.

	Use	Order number
Connection kit	To save space, stack the appliance on a suitable washing machine of the same width and depth and that is from the same manufacturer.	WZ1141X
Wool basket	Dry or air individual woollen items, sports shoes and soft toys.	WZ20600
Y-distributor	Connect the water drain hose of an additional appliance to the same siphon outlet.	15000490
Water drain hose	Drain away excess condensation directly into the waste water system, without having to regularly empty the condensation container.	WZ20160

# 11 Laundry

#### 11.1 Preparing the laundry

#### ATTENTION!

Objects remaining in the laundry may damage the laundry and the drum.

 Remove all items from any pockets in your laundry before using the appliance.

#### Note

The appliance and fabrics are protected when you prepare your laundry.

- Brush off sand and soil
- Sort the laundry according to colour and textiles and observe the care labels
- Close all zips, Velcro fasteners, hooks and eyes
- Remove curtain fittings and lead strips
- Wash small or particularly delicate items in a mesh washing bag

- Load the laundry unfolded into the drum
- Spin the laundry before drying
- Dry woollen items, sports shoes and soft toys in the wool basket → "Wool basket". Page 31

## 12 Basic operation

#### 12.1 Switching on the appliance

**Requirement:** The appliance has been correctly installed and connected.

- → "Installation and connection", Page 12
- Turn the programme selector to a programme.

#### 12.2 Setting a programme

- 1. Turn the programme selector and set the required programme. → "Programmes", Page 24
- 2. If required, adjust the programme settings.

#### 12.3 Loading laundry

**Note:** To prevent creasing, note the maximum load for the programmes. → "Programmes". Page 24

#### Requirements

- The laundry is prepared and sor-
  - → "Laundry", Page 26
- The drum is empty.
- 1. Open the door.
- 2. Place the laundry in the drum.
- 3. Close the door. Ensure that there is no laundry trapped in the door.

#### 12.4 Starting the programme

**Requirement:** A programme is set.

- → "Setting a programme", Page 27
- Press Start/Pause .
- ✓ The display shows the programme duration or the "Ready in" time.
- After the programme has ended, the display shows: "End".

**Note:** If "Hot" appears, the appliance cools the laundry. When "Hot" goes out, the laundry has cooled down.

#### 12.5 Adding laundry

After the programme starts, you can remove or add laundry at any time.

1. Press Start/Pause .

The cooling process starts automatically after approximately 30 seconds and cools down the laundry while the drum is rotating. If you want to avoid or cancel the cooling process, open the door. → "Display", Page 18

- 2. Open the door.
- 3. Add or remove laundry.
- 4. Close the door.
- 5. Press Start/Pause.

### 12.6 Cancelling the programme

- 1. Press Start/Pause .
- 2. Open the door.
- 3. Remove the laundry. → "Unloading the laundry", Page 27

#### 12.7 Unloading the laundry

- 1. Open the door.
- 2. Remove the laundry from the drum.

# 12.8 Switching off the appliance

► Turn the programme selector to ○

#### 12.9 Fluff filter

During drying, fluff from the laundry is collected in the fluff filter. The fluff filter protects the appliance from fluff.


#### Cleaning the fluff filter

If the drying programme has finished or the display shows a notification while the appliance is in operation, clean the fluff filter.


**Note:** If you do not clean the appliance as described, the appliance's functionality may be impaired.

#### Requirements


- The display shows the following after drying: "End"
- or the display shows the following during operation:
- 1. Open the door.
- 2. Remove the fluff from the door.



3. Remove the fluff filter.




4. Remove the fluff from the recess.




Ensure that no fluff falls into the air channel.


5. Open the fluff filter.




6. Remove the fluff.




7. Clean the fluff filter thoroughly under warm, running water and then dry it off.



8. Close the fluff filter.



9. Insert the fluff filter.



10. Close the door.

#### 12.10 Condensation container

Condensation forms during drying, which your appliance uses for automatic cleaning. By default, the condensation is collected in the appliance's condensation container.

#### **Emptying the condensation** container


If the drying programme has finished or the display shows a notification while the appliance is in operation, empty the condensation container.

#### Requirements


- The display shows the following after drying: "End"
- or the display shows the following during operation: 🖺 .

#### en Childproof lock

**1.** Pull out the condensation container, keeping it level.



2. Empty the condensation container.




Make sure that you insert the condensation container before operating the appliance.

→ "Inserting the condensation container", Page 30

# Inserting the condensation container

 Push the condensation container in as far as it will go.



# 13 Childproof lock

Secure your appliance against being operated unintentionally using the controls.

# 13.1 Activating the childproof lock

- ► Press and hold the two **3s** buttons for approx. 3 seconds.
- → The control elements are locked.
- The childproof lock remains active even after the appliance has been switched off and in the event of a power cut.

### 13.2 Deactivating the childproof lock

**Requirement:** To deactivate the childproof lock, the appliance must be switched on.

- ► Press and hold the two so 3s buttons for approx. 3 seconds.
- ✓ soes out in the display.

# 14 Wool basket

Use the wool basket to gently dry delicate fabrics, soft toys or sports shoes in a stationary position.


**Note:** You can order this optional → "Accessories", Page 26 from our customer service.

# 14.1 Inserting the wool bas-


1. Open the door.

Make sure that the drum is empty.

2. Insert the feet of the wool basket into the holes in the fluff filter.



3. Insert the tab on the front of the wool basket into the upper hooks.



#### 14.2 Starting a programme with the wool basket

#### **ATTENTION!**


If items of laundry in the wool basket touch the rotating drum or the ribs of the drum, the laundry may cause material damage and damage to the appliance.

Place the items of laundry in the insert or wool basket such that they do not touch the drum or the ribs of the drum.

Requirement: The wool basket is inserted into the appliance.

→ "Inserting the wool basket", Page 31

- 1. Place the laundry into the wool basket, either directly or using the insert.
  - → "Examples of how to use the wool basket", Page 32



- 2. Close the door.
- **3.** Set the programme for the wool basket or a timed programme.
  - → "Programmes", Page 24
- 4. If necessary, adjust the duration of the timed programme.
  - → "Buttons", Page 22

Observe the recommended programme duration for items of laundry in the wool basket:

Laundry item	Programme duration in hours:minutes
Thin woollen pullover	Approx. 1:20
Thick woollen pullover	Approx. 1:30 - 3:00
Skirt	Approx. 1:00 - 1:30
Trousers	Approx. 1:00 - 1:30
Gloves	Approx. 0:30
Sports shoes	Approx. 1:30/ max. 2:00 with airing

**Tip:** Increase the programme duration for thick or multi-layered items of laundry.

- **5.** Start the programme  $\rightarrow$  *Page 27*.
- **6.** Remove the wool basket once the programme has ended.

# 14.3 Examples of how to use the wool basket

#### **ATTENTION!**

If items of laundry in the wool basket touch the rotating drum or the ribs of the drum, the laundry may cause material damage and damage to the appliance.

 Place the items of laundry in the insert or wool basket such that they do not touch the drum or the ribs of the drum.

Example	Use
Trousers or skirt	Place the items
	of laundry unfolded into the insert.
	<b>Note:</b> Spin the laundry before drying.


Example	Use
Pullover	

#### Sports shoes



Lift the tongues of the shoes. Remove the insoles or heel cushions. Place a rolled-up hand towel in the wool basket to create an inclined surface. Place the shoes on the towel with the heels facing down. Note: Do not use the insert. Do not dry leather shoes or

#### Soft toys



Place the soft toy in the wool basket.


shoes with leather parts.

Note: Do not use the insert. If you place numerous or small soft toys in the wool basket, make sure they do not fall out.

# 15 Basic settings

You can configure the basic settings for your appliance to meet your needs.


# 15.1 Overview of the basic settings



Basic setting	Programme position	Value	Description
End signal	2	0 (off) 1 (quiet) 2 (me- dium) 3 (loud) 4 (very loud)	Set the volume of the signal at the end of the programme.
Button signal	3	0 (off) 1 (quiet) 2 (me- dium) 3 (loud) 4 (very loud)	The volume of the audible signal emitted when the buttons are pressed.
Programme counter	5	42 <sup>1</sup>	Display the number of started programmes.
<sup>1</sup> Example			

#### 15.2 Changing the basic settings

1. Set the programme selector to position 1.



- 2. Press Iron Dry and, at the same time, turn the programme selector to position 2.
- The display shows the current value.
- 3. Set the programme selector to the required position.
  - → "Overview of the basic settings". Page 33
- 4. To change the value, press **Ready**
- 5. To save the changes, switch off the appliance.

# 16 Cleaning and servicing

To keep your appliance working efficiently for a long time, it is important to clean and maintain it carefully.

Note: You can find further information in the digital instruction manual by scanning the QR code in the table of contents or on siemens-home.bshgroup.com.

#### 16.1 Tips on cleaning and care

Wipe down the housing and the controls with nothing but water and a damp cloth.	This ensures the parts of the appliance will remain clean and hygienic.
Remove all detergent residue, spray residue or other residues immediately.	Fresh deposits are easier to re- move without leaving any residue.
Leave the appliance door open after use.	This allows the residual water to dry, reducing odours in the appliance.


#### 16.2 Base unit

The base unit is the accessible area. at the bottom of the appliance in which you will find the heat exchanger.

#### Opening the base unit Requirements


- The appliance has cooled down for 30 minutes.
- The appliance door is closed.

1. Open the maintenance flap.




If you place a cloth beneath the maintenance flap, you can collect the remaining water from the base unit.

2. Open the lever for the heat exchanger cover.



3. Pull out the heat exchanger cover by the handle.



#### Cleaning the base unit

You can remove any visible dirt in the base unit.

#### **ATTENTION!**


Heavy or sharp objects may damage the heat exchanger.

- ► Do not use hard, sharp or rough objects for cleaning.
- **1.** Open the base unit  $\rightarrow$  Page 34.
- 2. Clean the heat exchanger cover under running water and dry it.




Make sure that you remove all dirt from the seal.

3. Pull out the heat exchanger horizontally.




#### en Cleaning and servicing


 Clean the heat exchanger from all sides under running water and dry it.



5. Clean the opening with a soft, damp cloth.



**6.** Slide the heat exchanger in horizontally as far as it will go.




Ensure that the heat exchanger is inserted with its handle pointing downwards.

7. Close the base unit  $\rightarrow$  Page 36.


#### Closing the base unit

Requirement: The base unit is open.


- → "Opening the base unit", Page 34
- **1.** Insert the heat exchanger cover by the handle.



2. Close the lever for the heat exchanger.



3. Close the maintenance flap.



#### 16.3 Moisture sensor

The moisture sensor in this appliance measures how damp the laundry is during the drying cycle. The appliance changes the duration of the automatic programme depending on the residual moisture in the laundry.

#### Cleaning the moisture sensor

Over time, residue from limescale, detergents and care products can build up on the moisture sensor. Clean the moisture sensor regularly.


#### **ATTENTION!**

Hard or rough objects may damage the moisture sensor.

▶ Do not use hard or rough objects, abrasive cleaning products or steel wool for cleaning.

Note: If you do not clean the appliance as described, the appliance's functionality may be impaired.

- 1. Open the door.
- 2. Clean the moisture sensor with a sponae.



# 17 Troubleshooting

You can rectify minor faults on your appliance yourself. Read the troubleshooting information before contacting after-sales service. This will avoid unnecessary costs.

#### WARNING

#### Risk of electric shock!

Incorrect repairs are dangerous.

- ► Repairs to the appliance should only be carried out by trained specialist staff.
- ▶ Only use genuine spare parts when repairing the appliance.
- ► If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

Fault	Cause and troubleshooting
"Hot" and the drum rotates.	<ul><li>Cooling process active.</li><li>1. Not a fault.</li><li>2 Do not change the programme during the cooling process.</li></ul>
	<b>Note:</b> The cooling process takes up to 10 minutes. You can continue to operate the appliance.
Humming noise.	Compressor active.  ► Not a fault – normal operating noise.
The display goes out and <b>Start/Pause</b> flashes.	<ul><li>Energy-saving mode is active</li><li>▶ Press any button.</li><li>✔ The symbol lights up again.</li></ul>
	Fluff filter is soiled.  ► → "Cleaning the fluff filter", Page 28
The appliance is not working.	The mains plug of the power cord is not plugged in.  Connect the appliance to the power supply.
	The circuit breaker in the fuse box has tripped.  • Check the circuit breaker in the fuse box.
	There has been a power cut.  ► Check whether the lighting in your kitchen or other appliances are working.
Appliance paused, but the drum is rotating.	Cooling process active.  Not a fault – no action required.
Creasing.	The load is too large.  ► Observe the maximum load capacity of the  → "Programmes", Page 24.

Fault	Cause and troubleshooting	
Creasing.	<ul><li>The laundry lies in the drum for too long after drying.</li><li>1. Remove the laundry from the drum as soon as the drying programme has finished.</li><li>2. Spread the items of laundry for cooling.</li></ul>	
	Unsuitable programme for the type of fabric.  ► Set the suitable programme for the type of fabric.  → "Programmes", Page 24	
	Easy-Care fabrics are dried for too long.  ► → "Changing the dryness level", Page 23.  ► → "Adjusting the dryness level", Page 23.	
	Anti-Crease not activated.  ► Activate the Anti-Crease function.  → "Buttons", Page 21	
and programme terminated.	Condensation tank filled.  1. → "Emptying the condensation container", Page 29.  2. → "Inserting the condensation container", Page 30.  3. → "Starting the programme", Page 27.	
	<ul><li>Water drain hose is caught or jammed.</li><li>1. Ensure that the water drain hose is not kinked or trapped.</li><li>2. Route the water drain hose without kinks.</li></ul>	
	Water drain hose is not connected correctly.  ► Ensure that the water drain hose is connected correctly.	
	Water drain hose is blocked.  ► Rinse the water drain hose with tap water.	
	Foreign object is located in the base unit  1. → "Opening the base unit", Page 34.  2. Remove the foreign objects that are present.  3. → "Closing the base unit", Page 36.	
Condensation in the condensation tank even though the water	The appliance uses condensation for the automatic self-cleaning.  Not a fault – no action required.	
drain hose is connected.	Water drain hose is not connected correctly.  ► Ensure that the water drain hose is connected correctly.	
The programme does not start.	Childproof lock is activated.  ► → "Deactivating the childproof lock", Page 30	
	You have not pressed Start/Pause.	

## en Troubleshooting

Fault	Cause and troubleshooting		
The programme does	► Press Start/Pause .		
not start.	No programme set.  1. → "Setting a programme", Page 27.  2. → "Starting the programme", Page 27.		
The length of the programme changes during the drying cycle.	The programme operation is optimised electronically. This may change the programme duration.  ▶ Not a fault – no action required.		
Pumping noise.	Condensation pump active.  ► Not a fault – normal operating noise.		
Buzzing noise.	Compressor ventilation active.  Not a fault – normal operating noise.		
The drying time is too long.	Fluff filter is soiled.  ► → "Cleaning the fluff filter", Page 28		
	The ambient temperature is greater than 30 °C.  ► Ensure that the ambient temperature is lower than 30 °C.		
	The ambient temperature is lower than 15 °C.  ► Ensure that the ambient temperature is above 15 °C.		
	Insufficient air circulation at the appliance's installation location.  • Ventilate the appliance's installation location.		
	The appliance's ventilation opening is blocked.  ► Ensure that the ventilation opening of the appliance is kept clear.		
	Heat exchanger is soiled.  1. Opening the base unit.  → "Opening the base unit", Page 34.  2. Cleaning the heat exchanger.  → "Cleaning the base unit", Page 35.  3. Closing the base unit.  → "Closing the base unit", Page 36.		
Water is leaking from the appliance.	Appliance is not correctly aligned.  ► → "Aligning the appliance", Page 14		
	Water drain hose is not connected correctly.  ► Ensure that the water drain hose is connected correctly.		

Fault	Cause and troubleshooting
The laundry is too damp.	Unsuitable programme for the type of fabric.  ► Set a timed programme for the subsequent drying.  → "Programmes", Page 24
	<ul><li>There has been a power cut.</li><li>► Check whether the lighting in your kitchen or other appliances are working.</li></ul>
	The load is too large.  ► Observe the maximum load capacity of the  → "Programmes", Page 24.
	<ul> <li>After the end of the programme, warm laundry feels damper than it actually is.</li> <li>1. Remove the laundry from the drum as soon as the drying programme has finished.</li> <li>2. Spread the items of laundry for cooling.</li> </ul>
	Unsuitable dryness level set.  ► → "Changing the dryness level", Page 23.
	Drying target not adjusted.  ► → "Adjusting the dryness level", Page 23.
	Load too small.  ► Set a timed programme for the subsequent drying.  → "Programmes", Page 24
	Moisture sensor dirty.  ► → "Cleaning the moisture sensor", Page 37.
	The drying process is interrupted and the condensation tank has been filled.  1. → "Emptying the condensation container", Page 29.  2. → "Inserting the condensation container", Page 30.  3. → "Starting the programme", Page 27.

# 18 Transportation, storage and disposal

# 18.1 Preparing the appliance for transportation

**Tip:** The appliance may contain residual water, which may drip out of it when transported. The appliance should be transported upright.

#### Requirements

- The condensation container is emptied. Emptying the condensation container → Page 29
- The appliance has been switched
  - → "Switching on the appliance", Page 27
- 1. Set any programme → Page 27.
- 2. Start the programme → Page 27 and wait 5 minutes.
- The condensation is drained.
- 3. Switch off the appliance. → "Switching off the appliance", Page 28
- 4. Remove the water drain hose from the connection point.
- 5. Secure the water drain hose on the appliance against unintentional loosening.
  - Ensure that you do not bend the water drain hose.
- 6. Empty the condensation container → Page 29.
- 7. Insert the condensation container → Page 30.
- 8. Disconnect the appliance's mains plug from the power supply.
- ✓ The appliance is now ready to be transported.

# 18.2 Disposing of old appliance

Valuable raw materials can be reused by recycling.

# **⚠** WARNING Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- Do not install the appliance behind a door as this may obstruct the appliance door or prevent it from opening.
- With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.
- 1. Unplug the appliance from the mains.
- 2. Cut through the power cord.
- 3. Dispose of the appliance in an environmentally friendly manner. Information about current disposal methods are available from your specialist dealer or local authority.



This appliance is labelled in accordance with the guidelines on ewaste Management and Handling Rules 2016 concerning used electrical and electronic appliances.

The guideline determines the framework for the return and recycling of used appliances.

**Note:** This product doesn't contain any of hazardous substances as specified in the ewaste Management and Handling Rules 2016. Any disposal through unauthorized agencies/person will attract action under Environment (Protection) Act 1986.

#### Dos

- Please visit our website https:// www.siemenshome.bsh-group.in/national-e-waste-recycling-program to find out more details regarding e-waste disposal.
- Keep the product in isolated area, after it becomes non-functional/un-repairable so as to prevent its accidental breakage.
- Consult the authorized service center as to whether the Electronic Equipment can be repaired or not, before discarding.
- Consult the retailer about appliance take back schemes.

#### Don'ts

- The product should not be opened by the user himself/herself, but only by authorized service personnel.
- The product is not meant for re-sale to any unauthorized agencies/scrap dealers/kabariwalah.

- Don't dispose of the discarded Electronic Equipment in household bins or Municipal bins.
- Don't dump the discarded Flectronic Equipment in the open or in any land fill site, as this will result in contamination of the soil and the around water.
- Do not keep any replaced spare part(s) from the product in exposed area.

### 19 Customer Service

Detailed information on the warranty period and terms of warranty in your country is available from our aftersales service, your retailer or on our website.

If you contact Customer Service, you will require the product number (E-Nr.) and the production number (FD) of your appliance.

The contact details for Customer Service can be found in the enclosed Customer Service directory or on our website.

Helpline no.: 1800-209-1850 (Monday to Saturday - 8 am to (mg 8

Email ID: service.in@siemenshome.BSH-Group.com



# 19.1 Product number (E-Nr.) and production number (FD)

You can find the product number (E-Nr.) and the production number (FD) on the appliance's rating plate. Depending on the model, the rating plate is located:

- On the inside of the door.
- On the inside of the maintenance flap.
- On the rear of the appliance.

Make a note of your appliance's details and the Customer Service telephone number to find them again quickly.

# 20 Consumption values

The specified values are indicative only and were determined in accordance with the applicable standard IEC61121.

The actual values may deviate from the indicated values depending on the type of fabric, composition of laundry to be dried, residual moisture in the fabric, set degree of dryness,

amount of laundry being loaded, environmental conditions and the activation of additional functions.

The expected programme duration/"Ready in" time that is shown in the appliance display when selecting the programme is based on the spin speed in the washing machine of 1000 rpm when the appliance is delivered.

Programme	Final mois- ture level (%)	Load (kg)	Spin speed (rpm)	Initial mois- ture level (%)	Pro- gramm e dura- tion (h:min)	Energy con- sump- tion (kWh/ cycle)
Cottons + Cupboard Dry 🖽	-1.5	8.0	1400	50	2:13	4.17
Cottons + Cupboard Dry 🖽	-1.5	8.0	1000	60	2:37	4.89
Cottons + Cupboard Dry 🖽	-1.5	8.0	800	70	3:01	5.61
Cottons + Iron Dry	12.0	8.0	1400	50	1:28	2.97
Cottons + Iron Dry	12.0	8.0	1000	60	1:53	3.69
Cottons + Iron Dry	12.0	8.0	800	70	2:18	4.42
Synthetics + Cup- board Dry ⊞	2.0	3.5	800	40	0:45	1.40
Synthetics + Cup- board Dry ⊞	2.0	3.5	600	50	0:54	1.71

# 21 Technical data

Appliance height	84.2 cm
Appliance width	59.8 cm
Appliance depth	61.3 cm

Appliance depth with door closed	64.8 cm
Appliance depth with door open	109.6 cm
Weight	41.3 kg
Maximum load	8.0 kg

### en Technical data

Mains voltage	220-240 V, 50 Hz	Ar at
← Minimum installation protection	13A	Le
Nominal power	2800 W	pc

Ambient temperature	<ul><li>Minimum:</li><li>5 °C</li><li>Maximum:</li><li>35 °C</li></ul>
Length of the power cord	145 cm



BSH Hausgeräte GmbH Carl-Wery-Straße 34 81739 München, GERMANY siemens-home.bsh-group.com

Manufactured by BSH Hausgeräte GmbH under the trademark licence of Siemens AG



en