

Table of contents

1 Safety 4	11 Laundry	31
1.1 General information 4	11.1 Preparing the laundry	
1.2 Intended use 4	11.2 Sorting laundry	31
1.3 Restriction on user group 4 1.4 Safe installation	11.3 Care symbols on the care labels	32
1.5 Safe use 7	12 Basic operation	32
1.6 Safe cleaning and maintenance	12.1 Switching on the appliance	
	12.2 Setting a programme	
2 Preventing material damage 11	12.3 Loading laundry	
3 Environmental protection and saving energy11	12.4 Starting the programme	
3.1 Disposing of packaging 11	12.6 Adding laundry	
3.2 Saving energy11 3.3 Energy saving mode12	12.7 Cancelling the programme	33
	12.8 Unloading the laundry	
4 Installation and connection 12 4.1 Unpacking the appliance 12	12.10 Fluff filter	
4.2 Scope of delivery12	12.11 Condensation container	
4.3 Requirements for the install-		
ation location13	13 Childproof lock	36
4.4 Water drain hose14	lock	36
4.5 Aligning the appliance	13.2 Deactivating the childproof	-
4.6 Connecting the appliance to the electricity supply16	lock	36
	14 Basic settings	37
5 Familiarising yourself with your appliance 17	14.1 Overview of the basic set-	
5.1 Appliance 17	tings	37
5.2 Control panel18	14.2 Changing the basic set-	30
6 Display 19		
	15 Cleaning and servicing 15.1 Tips on cleaning and care	
7 Buttons 21	15.2 Base unit	
8 Dryness level23	15.3 Moisture sensor	
8.1 Changing the dryness level 23 8.2 Adjusting the dryness level 23	16 Troubleshooting	42
9 Programmes24	17 Transportation, storage and	
9.1 Automatic programmes24	disposal	46
9.2 Timed programmes28	17.1 Preparing the appliance for transportation	46
10 Accessories 30	17.2 Disposing of old appliance	

18 Customer Service	47
18.1 Product number (E-Nr.) and production number (FD)	
19 Consumption values	48
20 Technical specifications	48



1 Safety

Observe the following safety instructions.

1.1 General information



- Read this instruction manual carefully.
- Keep the instruction manual and the product information safe for future reference or for the next owner.
- Do not connect the appliance if it has been damaged in transit.

1.2 Intended use

Only use this appliance:

- For drying and freshening up fabrics that are washed with water and suitable for dryers.
- In private households and in enclosed spaces in a domestic environment.
- Up to an altitude of max. 4000 m above sea level.

1.3 Restriction on user group

This appliance may be used by children aged 8 or over and by people who have reduced physical, sensory or mental abilities or inadequate experience and/or knowledge, provided that they are supervised or have been instructed on how to use the appliance safely and have understood the resulting dangers.

Children must not play with the appliance.

Cleaning and user maintenance must not be performed by children unless they are being supervised.

Keep children under the age of 3 years and pets away from the appliance.

1.4 Safe installation

Take note of the safety instructions when installing the appliance.

Improper installation is dangerous.

- ► Connect and operate the appliance only in accordance with the specifications on the rating plate.
- ► Connect the appliance to a power supply with alternating current only via a properly installed socket with earthing.
- ► The protective conductor system of the domestic electrical installation must be properly installed. The installation must have a sufficiently large cross section.
- ▶ When using a residual current circuit breaker, only use a type with the mark.
- ► Never equip the appliance with an external switching device, e.g. a timer or remote control.
- ► Never connect the appliance to a circuit that is regularly switched on and off by the energy supplier.
- ▶ When the appliance is installed, the mains plug of the power cord must be freely accessible. If free access is not possible, an all-pole isolating switch must be installed in the permanent electrical installation according to the installation regulations.
- ▶ When installing the appliance, check that the power cable is not trapped or damaged.

If the insulation of the power cord is damaged, this is dangerous.

- ► Never let the power cord come into contact with hot appliance parts or heat sources.
- ► Never let the power cord come into contact with sharp points or edges.
- ▶ Never kink, crush or modify the power cord.

↑ WARNING – Risk of fire!

It is dangerous to use an extended power cord and non-approved adapters.

- ▶ Do not use extension cables or multiple socket strips.
- ▶ If the power cord is too short, contact Customer Service.
- ▶ Only use adapters approved by the manufacturer.

⚠ WARNING – Risk of injury!

The high weight of the appliance may result in injury when lifted.

▶ Do not lift the appliance on your own.

If this appliance is not correctly installed in a washer-dryer stack, the installed appliance may fall.

- ► Only stack the dryer on a washing machine using the connection kit from the dryer manufacturer
 - → "Accessories", Page 30. No other installation method is permitted.
- ▶ Do not install the appliance in a washer-dryer stack if the dryer manufacturer does not offer a suitable connection kit.
- ▶ Do not install appliances from different manufacturers and with varying depths and widths in a washer-dryer stack.
- ▶ Do not install a washer-dryer stack on a platform; the appliances may tip over.

↑ WARNING – Risk of suffocation!

Children may put packaging material over their heads or wrap themselves up in it and suffocate.

- ► Keep packaging material away from children.
- ▶ Do not let children play with packaging material.

△ CAUTION – Risk of injury!

The appliance may vibrate or move when in use.

- ▶ Place the appliance on a clean, even, solid surface.
- ▶ Align the appliance using the appliance feet and a spirit level. If hoses and power cords have been laid incorrectly, this causes a tripping hazard.
- ► Lay hoses and power cords in such a way that there is no risk of tripping.

If the appliance is moved by holding onto protruding components, such as the appliance door, the parts may break off.

▶ Do not move the appliance by holding onto protruding parts.

△ CAUTION – Risk of cutting!

Touching sharp edges on the appliance may lead to cuts.

▶ Do not touch the sharp edges on the appliance.

Wear protective gloves when installing and transporting the appliance.

1.5 Safe use

If the appliance or the power cord is damaged, this is dangerous.

- ▶ Never operate a damaged appliance.
- ▶ Never pull on the power cord to unplug the appliance. Always unplug the appliance at the mains.
- ▶ If the appliance or the power cord is damaged, immediately unplug the power cord or switch off the fuse in the fuse box.
- ► Call customer services. → Page 47

An ingress of moisture can cause an electric shock.

- ▶ Only use the appliance in enclosed spaces.
- ▶ Never expose the appliance to intense heat or humidity.
- ▶ Do not use steam- or high-pressure cleaners, hoses or sprays to clean the appliance.

△ WARNING – Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- ▶ Do not install the appliance behind a door as this may obstruct the appliance door or prevent it from opening.
- ▶ With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.

⚠ WARNING – Risk of suffocation!

Children may breathe in or swallow small parts, causing them to suffocate.

- ► Keep small parts away from children.
- ▶ Do not let children play with small parts.

⚠ WARNING – Risk of explosion!

If there is coal dust or flour in the air around the appliance, this may cause an explosion.

► Keep the area around the appliance clean during operation.

⚠ WARNING – Risk of poisoning!

Condensation water from this appliance is not suitable for drinking and may be contaminated with fluff.

▶ Do not drink or reuse the condensation water from the appliance.

Detergents and care products may result in poisoning if consumed.

- ▶ If accidentally swallowed, seek medical advice.
- ► Keep detergents and care products out of the reach of children.

⚠ WARNING – Risk of explosion!

If there is any residual material left in the fluff filter, this may ignite during the drying process.

► Clean the fluff filter regularly.

Highly flammable objects such as lighters or matches may ignite during the drying process.

► Remove all highly flammable objects from any pockets in your laundry before the drying process.

Unwashed laundry that has come into contact with solvents, oil, wax, wax remover, paint, grease or stain remover may ignite when drying is in progress.

- ▶ Do not place laundry in this appliance to be dried if the laundry has not been washed first.
- ► Rinse the laundry thoroughly with warm water and detergent before drying it in the machine.
- ▶ Do not use the appliance if industrial chemicals have been used to clean the laundry beforehand.

If drying is interrupted early, the laundry is not cooled sufficiently and may ignite.

- ▶ Do not interrupt the drying programme early.
- ► If drying is interrupted early, remove the laundry immediately and spread it out.

⚠ CAUTION – Risk of injury!

The covering plate may break if you stand on or climb onto the appliance.

▶ Do not stand on or climb onto the appliance.

The appliance may tip over if you sit on or lean against the open door.

- ▶ Do not sit on or lean against the appliance door.
- ▶ Do not place any objects on the appliance door.

Reaching into the drum while it is still turning may cause hand injuries.

▶ Wait for the drum to come to a complete stop before reaching inside.

The rear panel of the appliance becomes hot during operation.

- ▶ Do not touch the rear panel of the appliance when it is hot.
- ► Keep children away from the rear panel of the appliance when it is hot.
- ▶ Position the appliance with the rear panel close against a wall.

1.6 Safe cleaning and maintenance

Take note of the safety instructions when cleaning and performing maintenance work on the appliance.

Incorrect repairs are dangerous.

- ► Repairs to the appliance should only be carried out by trained specialist staff.
- ▶ Only use genuine spare parts when repairing the appliance.
- ▶ If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

An ingress of moisture can cause an electric shock.

▶ Do not use steam- or high-pressure cleaners, hoses or sprays to clean the appliance.

⚠ WARNING – Risk of injury!

The use of non-original spare parts and non-original accessories is dangerous.

► Only use the manufacturer's original spare parts and original accessories.

⚠ WARNING – Risk of poisoning!

Poisonous fumes may be given off if you use cleaning agents that contain solvents.

▶ Do not use cleaning agents that contain solvents.

2 Preventing material damage

Follow these instructions to avoid material damage and damage to the appliance.

ATTENTION!

The functionality of the appliance may be impaired if you use the wrong quantity of fabric softener, detergent, care product or cleaning agent.

► Follow the dosage recommendations from the manufacturer.

Exceeding the maximum load capacity impairs the function of the appliance.

- ▶ Observe the maximum load capacity for each programme and do not exceed it.
 - → "Programmes", Page 24

The function of the appliance may be impaired if the appliance overheats.

- ▶ During operation, keep the air inlet on the appliance clear.
- ▶ Make sure that the area is adequately ventilated.

Light objects such as hair and fluff may be sucked into the air inlet on the appliance during operation and impair the function of the appliance.

- ► Keep the area around the appliance clean during operation.
- Keep light objects away from the appliance.

Foam and foam rubber may deform or melt during the drying process.

▶ Do not dry laundry that contains foam or foam rubber.

Unsuitable cleaning products may damage the surfaces of the appliance.

- ▶ Do not use harsh or abrasive detergents.
- ▶ Do not use cleaning products with a high alcohol content.

- Do not use hard scouring pads or cleaning sponges.
- Clean the appliance with nothing but water and a soft, damp cloth.
- Remove all detergent residue, spray residue or other residues immediately if they come into contact with the appliance.

3 Environmental protection and saving energy

3.1 Disposing of packaging

The packaging materials are environmentally compatible and can be recycled.

 Sort the individual components by type and dispose of them separately.

3.2 Saving energy

If you follow these instructions, your appliance will use less power.

Operate the appliance in a well-ventilated room and keep the air inlet on the appliance clear.

✓ If air exchange is impeded, this extends the programme duration and increases energy consumption.

Spin the laundry in the washing machine before drying.

✓ If the laundry is excessively damp, this extends the programme duration and increases energy consumption.

Observe the programme's maximum load capacity.

- → "Programmes", Page 24
- If the maximum load is exceeded, this extends the programme duration and increases energy consumption.

After drying, clean the fluff filter → Page 33.

If the fluff filter is dirty, this reduces the air flow in the appliance, extends the programme duration and increases energy consumption.

Regularly clean the base unit → Page 39.

 If the heat exchanger is dirty, this extends the programme duration and increases energy consumption.

3.3 Energy saving mode

If you do not use the appliance for an extended period, it automatically switches to energy-saving mode. All displays go out and **Start Reload** flashes.

Energy-saving mode ends when you use the appliance again, e.g. if you open or close the door.

4 Installation and connection

4.1 Unpacking the appliance

Note: Observe the information on safety \rightarrow *Page 4* and preventing material damage \rightarrow *Page 11*.

ATTENTION!

Objects remaining in the drum that are not designed for operation with the appliance may cause material damage and damage to the appliance.

- Remove these objects, along with all supplied accessories, from the drum before starting the appliance.
- Remove any packaging and protective covers completely from the appliance.
 - → "Disposing of packaging", Page 11.
- Check the appliance for visible damage.
- Open the appliance door.
 → "Basic operation", Page 32
- **4.** Remove any accessories from the drum.
- 5. Close the appliance door.

4.2 Scope of delivery

After unpacking all parts, check for any damage in transit and completeness of the delivery.

Note: Observe the information on safety \rightarrow *Page 4* and preventing material damage \rightarrow *Page 11*.

ATTENTION!

If the appliance is operated with incomplete or defective accessories, the appliance may not be able to operate properly, or this may result in material damage or damage to the appliance.

- Do not operate the appliance with incomplete or defective accessories.
- Replace the accessories in question before operating the appliance.
 - → "Accessories", Page 30

Scope of delivery Tumble dryer Accompanying documents Water drain hose with connection adapter, fixing material and elbow. **Water drain hose", **Page 14Water drain hose d

4.3 Requirements for the installation location

Note: Observe the information on safety \rightarrow *Page 4* and preventing material damage \rightarrow *Page 11*.


ATTENTION!

The appliance underwent a function test before leaving the factory and may, therefore, contain residual water. This residual water may leak out if the appliance is tilted at an angle greater than 40°.

- ► Tilt the appliance carefully. If the appliance is installed in areas exposed to frost or outdoors, frozen residual water may damage the appliance and frozen hoses may crack or split.
- Do not install or operate this appliance anywhere that is liable to experience frost and/or outdoors.


Installation loca- Requirements tion

On the floor



Place the appliance on a clean, level and firm surface.
Align the appliance
→ Page 16.

In a washer-dryer stack




Only use the original connection set from the dryer manufacturer when setting up this appliance in a washer-dryer stack.

→ "Accessories", Page 30
→ "Accessories"

→ "Accessories". Page 30 This appliance must only be stacked on a washing machine from the same manufacturer. The depth and width of this appliance must correspond with the dimensions of the washing machine. Do not place the washer-dryer stack on a platform.

Against a wall



Do not trap the hoses between the wall and the appliance.

4.4 Water drain hose

Condensation forms during drying, which your appliance uses for automatic cleaning. Use the water drain hose to drain away excess condensation directly into the waste water system.

Notes

- Operate this appliance using the water drain hose provided. If you connect the water drain hose → Page 14, you do not have to regularly empty the condensation container → Page 35.
- You can order this optional → "Accessories", Page 30 from our customer service.

Connecting the water drain hose

If you do not want to regularly empty the appliance's condensation container, connect the water drain hose.

Note: Observe the information on safety → Page 4 and preventing material damage → Page 11.

ATTENTION!


When operating the appliance without the water drain hose being connected properly, liquid may leak out of the connecting piece.

▶ Before operating the appliance, connect the water drain hose properly to the connecting piece.

Requirements

- The appliance and the accessory have been unpacked.
 - → "Unpacking the appliance", Page 12
- The appliance is installed at the installation location.
 - → "Requirements for the installation location", Page 13


1. Pull out the condensation hose from the connecting piece.




The condensation hose is connected to the connecting piece at the factory.

Note: When removing the condensation hose, liquid may leak out of the connecting piece.


2. Push the condensation hose into the holder



3. Push the water drain hose as far as it will go into the connecting piece.



4. Insert the water drain hose into the hose guide.



Ensure that you do not bend the water drain hose.

- 5. Connect the appliance to the water outlet.
 - → "Water outlet connection types", Page 15

Tip: To collect condensation in the condensation container again (e. g. if you change where the appliance is located), carry out these steps in reverse order.

Water outlet connection types


Note: Observe the information on safety → Page 4 and preventing material damage → Page 11.

ATTENTION!

In the event of a blocked or covered outlet, accumulated wastewater can flow back into the appliance.

▶ Before operating the appliance, ensure that the wastewater drains away quickly and eliminate any blockages.


Drainage into a siphon.



Secure the connection point with a (12-22 mm) hose clamp. Secure the water drain hose with a hose guide at a height of at least 80 cm and no more than 100 cm.

Note: You can use the Y-distributor → Page 30 to connect the water drain hose of an additional appliance, such as a washing machine, to the same siphon outlet.

Drainage into a wash basin.




Push the water drain hose fully through the elbow → Page 13 and secure it using fixing material.

Secure the elbow at a height of no more than 100 cm.

Drainage into a gully.

Push the water drain hose fully through the elbow → Page 13




and secure it using fixing material.
Secure the elbow to the gully.

4.5 Aligning the appliance

In order to reduce vibrations and noises, align the appliance correctly.

Note: Observe the information on safety \rightarrow *Page 4* and preventing material damage \rightarrow *Page 11*.

► To align the appliance, turn the appliance feet. Check that the appliance is level using a spirit level.



All appliance feet must stand firmly on the ground.

4.6 Connecting the appliance to the electricity supply


Note: Observe the information on safety \rightarrow *Page 4* and preventing material damage \rightarrow *Page 11*.

- Insert the mains plug of the appliance's power cable in a socket nearby.
 - The connection details of the appliance can be found under Technical data \rightarrow *Page 48*.
- 2. Check the mains plug is inserted properly.

5 Familiarising yourself with your appliance

5.1 Appliance

You can find an overview of the parts of your appliance here.




On certain models, specific details such as the colour and shape may differ from those pictured.

- Air inlet
- Maintenance flap on the base unit → Page 38
- Fluff filter → Page 33

- Door
- Condensation container → Page 35
- Control panel → Page 18

5.2 Control panel

You can use the control panel to configure all functions of your appliance and to obtain information about the operating status.



- 1 Programmes → Page 24
- Programme selector

 → Page 32
- 3 Display → Page 19
- 4 Buttons → Page 21

6 Display

The display shows the current settings, options or relevant information.



Display	Designation	Description
0:40 1	Programme duration/programme time remaining	Approximate expected programme duration or programme time remaining.
1:25 🖰	Timed programme	The timed programme is set. → "Timed programmes", Page 28
10h 🕲 ¹	"Ready in" time	→ "Buttons", Page 22
~~®	Childproof lock	 ■ lights up: The childproof lock is activated. ■ flashes: The childproof lock is activated and the appliance has been operated. → "Deactivating the childproof lock", Page 36
D□	Start/Pause	 Start, cancel or pause Lights up: The programme is running and can be cancelled or paused. Flashes: The programme can be started or continued.
	Dryness level adjusted	The adjusted dryness level is activated. → "Buttons", Page 21
$Z \mapsto Z \mapsto$	Crease-reduction function	The crease-reduction function is activated.
¥.	Gentle drying	Gentle drying is activated for delicate fabrics. → "Buttons", Page 21
(以)	Quiet drying	Quiet drying with no audible signals is activated. → "Buttons", Page 22
¹ Example		

en Display

Display	Designation	Description
<u>©</u>	Washing machine spin speed	The spin speed in rpm that is set on the washing machine is activated.
\$\doldsymbol{\doldsymbol{0}}\doldsymbol{\doldsymbol{0}}\$	Condensation container	Empty the condensation container → Page 35. Insert the condensation container → Page 36.
	Fluff filter	Clean the fluff filter → Page 33.
<u>sss</u>	Drying	Programme status
	Dryness level: Iron Dry	Programme status
	Dryness level: Cupboard Dry	Programme status
Ħ	Anti-crease	Programme status
-P-	Pause	Programme status
End	End of programme	Programme status
¹ Example		

7 Buttons

Below is an overview of the buttons and their setting options.

Button	Selection	Description
Start Reload	StartCancelPause	Start, cancel or pause the programme.
≈ 3 sec.	ActivateDeactivate	Activate or deactivate the childproof lock. Disable the control panel to prevent unwanted or accidental operation. If the childproof lock is activated and the appliance has been switched off, the childproof lock remains activated. → "Childproof lock", Page 36
Drying Level ※±	■ ※ ■ ※ ■ ※	Adjust the dryness level. If the laundry feels too damp after it has been dried to a particular dryness level, you can adjust the dryness level. → "Adjusting the dryness level", Page 23
Less Ironing 27	ActivateDeactivate	Activate or deactivate the crease-reduction function. Once the programme has ended, the drum moves the laundry at regular intervals for 60 minutes or 120 minutes to prevent creasing.
Low Heat #	ActivateDeactivate	Activate or deactivate gentle drying. The temperature is reduced for delicate fabrics, e.g. polyacrylic or elastane. The programme duration is extended.

en Buttons

Button	Selection	Description
Ready In ()	1-24 hours	Set the programme end. The programme duration is already included in the set number of hours. Once the programme has started, the programme duration is displayed.
Progr. Duration ⁽⁵⁾	10 min – 3:30 h	Set the programme duration for timed programmes. → "Timed programmes", Page 28
		Note: The programme duration can be set in 10-minute increments.
Signal (1))	ActivateDeactivate	Activate or deactivate the audible signal after the programme ends.

8 Dryness level

Each automatic programme has a specified dryness level. The dryness level defines how dry or damp your laundry is after the programme ends.

Dryness level	Laundry	Drying result
Cupboard Ex- tra Dry ⊞ ⁺	Multi-layered, thick laundry that does not dry readily.	The laundry is dry.
Cupboard Dry 🖽	Normal, single-layered laundry.	The laundry is dry.
Iron Dry 🖴	Normal, single-layered laundry	The laundry is still a little damp after drying. To prevent creasing after drying, iron the laundry or hang it up.

8.1 Changing the dryness level

For some automatic programmes, you can change the dryness level so that your laundry will be drier or more damp.

► Set an automatic programme with the desired dryness level. → "Automatic programmes". Page 24

8.2 Adjusting the dryness level

If the laundry feels too damp after it has been dried to a particular dryness level, you can adjust the dryness level.

- 1. Set an automatic programme with the desired dryness level.
 - → "Automatic programmes", Page 24
- 2. Press Drying Level *±.
- ▼ The display shows: "I" ※, "II" ※ or "|||" ※.

9 Programmes

You can dry your fabrics using either an automatic programme or a timed programme.

9.1 Automatic programmes

Automatic programmes are programmes in which hulaundry during the drying cycle. The programme only midity sensors measure the residual moisture in the → Page 23. The dryness level defines how dry or Each automatic programme has a dryness level damp the laundry is after the programme ends. ends once the set dryness level is reached.

- Select the dryness level according to the type of fabric or the desired drying result.
 → "Dryness level", Page 23
 - The laundry's care labels provide you with additional information on programme selection.
 - → "Care symbols on the care labels", Page 32

Pro- gramme settings	Low Heat 🥖	•	•	•
Pro- gramme settings	Progr. Duration () (programme duration)	_	_	
Max. Io	ad (kg)	o	3,5	က
Description		Dry hard-wearing, heat-resistant fabrics made of cotton or linen.	Dry items made of synthetic materials or blended fabrics.	Dry items made of cotton and synthetics.
Programme		Cottons 協 ■ Cupboard Extra Dry □ Cupboard Dry ■ Lon Dry 🙉	 Teasy Care T-Cupboard Extra Dry T Cupboard Dry M Cupboard Dry M Iron Dry 	Mixed Fabrics %

Description	Max.	Pro- gramme	a a
	load (kg)	Low Heat Progr. Duration (programme duration)	Low Heat 🥖
Dry delicate underwear made of lace, Lycra, satin or blended fabrics.	2	_	•
Dry hard-wearing, heat-resistant fabrics made of cotton or linen.	4	_	_
Note: Particularly suitable for strict hygiene requirements.			
Dry weatherproof and outdoor clothing with a membrane coating and water-repellent fabrics.	1,5	_	•

Pro- gramme settings	Low Heat 🌾	_		•
Pr grar setti	Progr. Duration () (programme duration)	_		_
Max. loa	ad (kg)	1,5		2
Description		Dry shirts and blouses made of cotton, linen, synthetics or blended fabrics. Note: For optimal drying results, dry a maximum of 5 shirts at one time.	Once the laundry is dry, iron it or hang it up. This will allow the residual moisture to be distributed evenly.	Dry items made of synthetics and light cotton.
Programme		Shirts 15'		@ Rapid 40'

9.2 Timed programmes

once this time has elapsed, even if the laundry is still not dry, for example. Timed programmes are suitable for Timed programmes are programmes with a defined or adjustable programme duration. The programme ends drying individual items of laundry or thin fabrics.

Tip: The laundry's care labels provide you with additional information on programme selection. \rightarrow "Care symbols on the care labels", Page 32

	Pro- gramme settings	Low Heat ∉	_
Pr gran setti		Progr. Duration () (programme duration)	_
	Max. loa	ad (kg)	0,5
	iption		Dry machine-washable items made of wool or containing wool. Note: The laundry becomes fluffier but not dry.
	Description		Dry ma taining Note:
	Timed programme		Wool Finish

o- nme	Low Heat 🥖		_	•
Pro- gramme settings	Progr. Duration () (programme duration)		•	•
Max. Io	ad (kg)		ന	ю
Description		Remove laundry once the programme has ended and allow it to dry.	Dry all types of fabric except for wool and silk. Also suitable for freshening up or airing clothing that has hardly been worn.	Dry all types of fabric except for wool and silk. Suitable for pre-dried or slightly damp laundry and for drying off multi-layered, thick laundry.
Timed programme			Cold ©	Warm ©

10 Accessories

Use original accessories. These have been made especially for your appliance.

	Use	Order number
Pedestal with drawer	Install the appliance at a raised height so that it can be easily loaded and unloaded.	WZDP20D
Connection kit	To save space, stack the appliance on a suitable washing machine of the same width and depth and that is from the same manufacturer.	WZ11410
Connection kit with pull- out worktop	To save space, stack the appliance on a suitable washing machine of the same width and depth and that is from the same manufacturer. The pull-out worktop makes it easier to load and unload the appliance.	WZ20400
Wool basket	Dry or air individual woollen items, sports shoes and soft toys.	WZ20600
Y-distributor	Connect the water drain hose of an additional appliance to the same siphon outlet.	15000490
Water drain hose	Drain away excess condensation directly into the waste water system, without having to regularly empty the condensation container.	WZ20160
Filter mat	Spare part to protect against fluff for the base unit's filter system.	12007650

11 Laundry

Note: More detailed instructions for use can be found on www.siemenshome.bsh-group.com or by scanning the QR code on the title page of this user manual.

11.1 Preparing the laundry

Note: Please read the information in the sections on Safety → Page 4 and Preventing material damage → Page 11.

ATTENTION!

Objects remaining in the laundry may damage the laundry and the drum.

- ► Remove all items from any pockets in your laundry before using the appliance.
- ▶ To protect your appliance and the laundry, prepare the laundry beforehand.
 - Empty any pockets
 - Brush sand out of all collars and pockets
 - Close bed covers and cushion. covers
 - Close all zips, Velcro fasteners, hooks and eyes
 - Tie cloth belts, apron strings, etc. together or use a laundry bag.
 - Remove curtain hooks and lead strips or use a mesh laundry
 - Use a mesh laundry bag for small items of laundry, such as children's socks
 - Separate items of laundry and shake them out, or observe the programme description

- Spin the laundry before drying
- Dry woollen items, sports shoes and soft toys in the wool basket Wool basket

11.2 Sorting laundry

Note: Observe the information on safety → Page 4 and preventing material damage → Page 11.

ATTENTION!

Laundry that is unsuitable for this appliance may damage the appliance during operation.

- Sort the laundry before using the appliance in accordance with the information on the care label.
- In order to achieve an optimal drying result, sort the laundry before drying according to the following criteria.
 - Type of fabric and fibre Dry laundry of the same type of fabric and fibre together.
 - Care symbols on the care labels → Page 32
 - Thick, thin or multi-layered Dry thick, thin and multilayered items separately.
 - Description of the programmes → Page 24
 - Large and small items of laundry Dry large and small items of laundry together.
 - Individual items of laundry Dry individual items of laundry in a timed programme → Page 28.
 - Knitted fabrics, e. g. jersey garments
 - Knitted fabrics in a programme for drying delicate fabrics.

11.3 Care symbols on the care labels

Drying care symbols

Sym- bol	Fabrics	Examples
	Hard-wearing fabrics	Items made from cotton and linen, e.g. towels, bed linen, underwear
	Delicate fabrics	Items made from synthetic, blended or delicate fabrics, e.g. functional garments, shirts
	Do not tumble-dry the following fabrics:	Items made from silk, nylon, air-impermeable and rubber-coated fabrics, synthetic curtains

12 Basic operation

12.1 Switching on the appliance

Note: Observe the information on safety \rightarrow *Page 4* and preventing material damage \rightarrow *Page 11*.

Requirement: The appliance has been correctly installed and connected.

- → "Installation and connection", Page 12
- ► Turn the programme selector to a programme.

Note: The lighting for the drum goes out automatically.

12.2 Setting a programme

- Turn the programme selector and set the required programme.
 → "Programmes", Page 24
- 2. If necessary, adjust the programme settings.

12.3 Loading laundry

Notes

- Observe the information on safety
 → Page 4 and preventing material
 damage → Page 11.
- To prevent creasing, take note of the maximum load for the
 → "Programmes", Page 24.

Requirement: The laundry is prepared.

- → "Laundry", Page 31
- Open the door.
 Make sure that the drum is empty.
- 2. Place the laundry in the drum.
- 3. Close the door.

Ensure that there is no laundry trapped in the door.

12.4 Starting the programme

Note: If you want to change the time until the programme ends, set the "Ready in" time first.

- ► Press Start Reload.
- The display shows either the programme duration or the "Ready in" time.
- ✓ After the programme has ended, the display shows: "End".

12.5 Changing the activated "Ready in" time

If you have set and activated a "Ready in" time for a delayed programme start, you can change the "Ready in" time again before the programme starts.

Requirements

- The programme is set.
 - → "Setting a programme", Page 32
- The "Ready in" time is set and activated.
 - → "Buttons", Page 22
- 1. Press Start Reload.

The activated "Ready in" time is paused.

- 2. Press **Ready In** (9) repeatedly until the display indicates the desired "Ready in" time.
- 3. Press Start Reload. The changed "Ready in" time is activated.

12.6 Adding laundry

After the programme starts, you can remove or add laundry at any time.

Note: Observe the information on safety → Page 4 and preventing material damage → Page 11.

- Press Start Reload.
- 2. Open the appliance door.
- 3. Add or remove laundry.
- **4.** Close the appliance door.
- 5. Press Start Reload.

12.7 Cancelling the programme

Note: Observe the information on safety → Page 4 and preventing material damage → Page 11.

- 1. Press Start Reload.
- 2. Open the appliance door.

3. Remove the laundry → Page 33.


12.8 Unloading the laundry

Note: Observe the information on safety → Page 4 and preventing material damage → Page 11.

- 1. Open the appliance door.
- 2. Remove the laundry.

12.9 Switching off the appliance

► Turn the programme selector to Off O.



12.10 Fluff filter

During drving, fluff from the laundry is collected in the fluff filter. The fluff filter protects the appliance from fluff.

Cleaning the fluff filter


If the drying programme has finished or the display shows a notification while the appliance is in operation. clean the fluff filter.

Notes


- Observe the information on safety → Page 4 and preventing material damage → Page 11.
- If you do not clean the appliance as described, the appliance's functionality may be impaired.

Requirements


- The display shows the following after drying: "End"
- or during operation: in .
- 1. Open the door.
- 2. Remove the fluff from the door.



3. Remove the fluff filter.




4. Remove the fluff from the recess.




Ensure that no fluff falls into the air channel.


5. Open the fluff filter.




6. Remove the fluff.




Clean the fluff filter thoroughly under warm, running water and then dry it off.



8. Close the fluff filter.



9. Insert the fluff filter.



10. Close the door.

12.11 Condensation container

Condensation forms during drying, which your appliance uses for automatic cleaning. By default, the condensation is collected in the appliance's condensation container.

Note: Operate this appliance using the water drain hose provided. If you connect the water drain hose → Page 14, you do not have to reqularly empty the condensation container → Page 35.


Emptying the condensation container

If the drying programme has finished or the display shows a notification while the appliance is in operation. empty the condensation container.


Note: Observe the information on safety → Page 4 and preventing material damage → Page 11.

Requirements

- The display shows the following after drying: "End"
- or during operation: 🖦
- 1. Pull out the condensation container, keeping it level.



2. Empty the condensation container.



Make sure that you insert the condensation container before operating the appliance.


→ "Inserting the condensation container", Page 36

Inserting the condensation container

Note: Observe the information on safety \rightarrow *Page 4* and preventing material damage \rightarrow *Page 11*.

Requirement: The condensation container → *Page 35* is removed from the appliance.

Push the condensation container in as far as it will go.



- ▶ Press and hold the two ➡ 3 sec. buttons for approx. 3 seconds.

13 Childproof lock

Secure your appliance against being operated unintentionally using the controls.

13.1 Activating the childproof lock

- ► Press and hold the two **3 sec.** buttons for approx. 3 seconds.
- ▼ The controls are locked.
- The childproof lock remains active even after the appliance has been switched off.


13.2 Deactivating the childproof lock

Requirement: To deactivate the childproof lock, the appliance must be switched on.

14 Basic settings

You can configure the appliance to meet your needs.


14.1 Overview of the basic settings



Basic setting	Programme position	Value	Description
End signal	3	0 (off) 1 (quiet) 2 (me- dium) 3 (loud) 4 (very loud)	Set the volume of the signal at the end of the programme.
Button signal	4	0 (off) 1 (quiet) 2 (me- dium) 3 (loud) 4 (very loud)	The volume of the audible signal emitted when the buttons are pressed.
Washing ma- chine spin speed	2	Example: 600 (low) 1800 (high)	Set the spin speed of the washing machine. The set value increases or decreases the displayed duration of the automatic programmes.

14.2 Changing the basic settings

1. Set the programme selector to position 1.



- 2. Press Start Reload and, at the same time, turn the programme selector to position 2.
- ✓ The display shows the current value.
- 3. Set the programme selector to the required position.
- 4. To change the value, press **Progr.** Duration/Ready In.
- 5. To save the changes, switch off the appliance.

15 Cleaning and servicing

To keep your appliance working efficiently for a long time, it is important to clean and maintain it carefully.

15.1 Tips on cleaning and care

Note: Observe the information on safety → Page 4 and preventing material damage → Page 11.

Wipe down the housing and the controls with nothing but water and a damp cloth.	This ensures the parts of the appliance will remain clean and hygienic.
Remove all detergent residue, spray residue or other residues immediately.	Fresh deposits are easier to re- move without leaving any residue.
Leave the appliance door open after use.	This allows the residual water to dry, reducing odours in the appliance.

15.2 Base unit

The base unit is the accessible area at the bottom of the appliance in which you will find the heat exchanger.


Opening the base unit

Note: Observe the information on safety → Page 4 and preventing material damage → Page 11.

Requirements


- The appliance has cooled down for 30 minutes.
- The appliance door is closed.

1. Open the maintenance flap.




If you place a cloth beneath the maintenance flap, you can collect the remaining water from the base unit.

2. Open the lever for the heat exchanger cover.



3. Pull out the heat exchanger cover by the handle.



Cleaning the base unit

You can remove any visible dirt in the base unit.

Note: Observe the information on safety → Page 4 and preventing material damage → Page 11.

ATTENTION!


Heavy or sharp objects may damage the heat exchanger.

- ► Do not use hard, sharp or rough objects for cleaning.
- **1.** Open the base unit \rightarrow *Page 38*.
- 2. Clean the heat exchanger cover under running water and dry it.




Make sure that you remove all dirt from the seal.

3. Pull out the heat exchanger horizontally.




en Cleaning and servicing


 Clean the heat exchanger from all sides under running water and dry it.



5. Clean the opening with a soft, damp cloth.



6. Slide the heat exchanger in horizontally as far as it will go.




7. Close the base unit \rightarrow Page 40.


Closing the base unit

Requirement: The base unit is open. → "Opening the base unit", Page 38


1. Insert the heat exchanger cover by the handle.



2. Close the lever for the heat exchanger.



3. Close the maintenance flap.



15.3 Moisture sensor

The moisture sensor in this appliance measures how damp the laundry is during the drying cycle. The appliance changes the duration of the automatic programme depending on the residual moisture in the laundry.

Cleaning the moisture sensor

Over time, residue from limescale, detergents and care products can build up on the moisture sensor. Clean the moisture sensor regularly.

Note: Observe the information on safety → Page 4 and preventing material damage → Page 11.

ATTENTION!

Hard or rough objects may damage the moisture sensor.

▶ Do not use hard or rough objects. abrasive cleaning products or steel wool for cleaning.

Note: If you do not clean the appliance as described, the appliance's functionality may be impaired.

- 1. Open the door.
- 2. Clean the moisture sensor with a sponge.



16 Troubleshooting

You can rectify minor faults on your appliance yourself. Read the troubleshooting information before contacting after-sales service. This will avoid unnecessary costs.

. WARNING

Risk of electric shock!

Incorrect repairs are dangerous.

- ► Repairs to the appliance should only be carried out by trained specialist staff.
- ▶ Only use genuine spare parts when repairing the appliance.
- ▶ If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

Fault	Cause and troubleshooting	
Humming noise.	Compressor active. Not a fault – normal operating noise.	
The display goes out and Start Reload flashes.	Energy-saving mode is active ► Press any button. ✓ The symbol lights up again.	
	Fluff filter is soiled. ► → "Cleaning the fluff filter", Page 33	
The appliance is not working.	The mains plug of the power cord is not plugged in. Connect the appliance to the power supply.	
	The circuit breaker in the fuse box has tripped. ► Check the circuit breaker in the fuse box.	
	There has been a power cut.Check whether the lighting in your kitchen or other appliances are working.	
Creasing.	The load is too large. ► Observe the maximum load capacity of the → "Programmes", Page 24.	
	The laundry lies in the drum for too long after drying.1. Remove the laundry from the drum as soon as the drying programme has finished.2. Spread the items of laundry for cooling.	
	Unsuitable programme for the type of fabric. ► Set the suitable programme for the type of fabric. → "Programmes", Page 24	
	Easy-Care fabrics are dried for too long.	

Fault	Cause and troubleshooting			
Creasing.	→ "Changing the dryness level", Page 23.			
5 55 5	► → "Adjusting the dryness level", Page 23.			
	Anti-Crease not activated.			
함 and programme terminated.	Condensation tank filled. 1. → "Emptying the condensation container", Page 35. 2. → "Inserting the condensation container", Page 36. 3. → "Starting the programme", Page 32.			
	Water drain hose is caught or jammed.1. Ensure that the water drain hose is not kinked or trapped.2. Route the water drain hose without kinks.			
	Water drain hose is not connected correctly. ► Ensure that the water drain hose is connected correctly. → "Connecting the water drain hose", Page 14			
	Water drain hose is blocked. ► Rinse the water drain hose with tap water.			
	Foreign object is located in the base unit 1. → "Opening the base unit", Page 38. 2. Remove the foreign objects that are present. 3. → "Closing the base unit", Page 40.			
Condensation in the condensation tank even though the water	The appliance uses condensation for the automatic self-cleaning. Not a fault – no action required.			
drain hose is connected.	Water drain hose is not connected correctly. ► Ensure that the water drain hose is connected correctly. → "Connecting the water drain hose", Page 14			
The programme does not start.	Childproof lock is activated. ► → "Deactivating the childproof lock", Page 36			
	You have not pressed Start Reload . ▶ Press Start Reload .			
	No programme set. 1. → "Setting a programme", Page 32. 2. → "Starting the programme", Page 32.			
The length of the programme changes during the drying cycle.	The programme operation is optimised electronically. This may change the programme duration. ▶ Not a fault – no action required.			

en Troubleshooting

Fault	Cause and troubleshooting		
Pumping noise.	Condensation pump active. ► Not a fault – normal operating noise.		
Buzzing noise.	Compressor ventilation active. ► Not a fault – normal operating noise.		
The drying time is too long.	Fluff filter is soiled. ► → "Cleaning the fluff filter", Page 33		
	The ambient temperature is greater than 30 °C. ► Ensure that the ambient temperature is lower than 30 °C.		
	The ambient temperature is lower than 15 °C. ► Ensure that the ambient temperature is above 15 °C.		
	Insufficient air circulation at the appliance's installation location. Ventilate the appliance's installation location.		
	Appliance air inlet is blocked. ► Ensure that the air inlet on the appliance is kept clear.		
	 Heat exchanger is soiled. 1. → "Opening the base unit", Page 38. 2. Clean the heat exchanger. → "Cleaning the base unit", Page 39 3. → "Closing the base unit", Page 40. 		
Water is leaking from the appliance.	Appliance is not correctly aligned. ► Aligning the appliance		
	Water drain hose is not connected correctly. ► Ensure that the water drain hose is connected correctly. → "Connecting the water drain hose", Page 14		
The laundry is too damp.	Unsuitable programme for the type of fabric. ► Set a timed programme for the subsequent drying. → "Programmes", Page 24		
	There has been a power cut.► Check whether the lighting in your kitchen or other appliances are working.		
	The load is too large. ► Observe the maximum load capacity of the → "Programmes", Page 24.		

Fault	Cause and troubleshooting		
The laundry is too damp.	After the end of the programme, warm laundry feels damper than it actually is. 1. Remove the laundry from the drum as soon as the drying programme has finished. 2. Spread the items of laundry for cooling.		
	Unsuitable dryness level set. ► → "Changing the dryness level", Page 23.		
	Drying target not adjusted. ► → "Adjusting the dryness level", Page 23.		
	Load too small. ► Set a timed programme for the subsequent drying. → "Programmes", Page 24		
	Moisture sensor dirty. ► → "Cleaning the moisture sensor", Page 41.		
	The drying process is interrupted and the condensation tank has been filled. 1. → "Emptying the condensation container", Page 35. 2. → "Inserting the condensation container", Page 36. 3. → "Starting the programme", Page 32.		

17 Transportation, storage and disposal

You can find out here how to prepare your appliance for transportation and storage. You will also find out how to dispose of old appliances.

17.1 Preparing the appliance for transportation

Note: Observe the information on safety → Page 4 and preventing material damage → Page 11.

Tip: The appliance may contain residual water, which may drip out of it when transported. The appliance should be transported upright.

Requirements

- The condensation container is emptied. Emptying the condensation container → Page 35
- The appliance has been switched
 - → "Switching on the appliance", Page 32
- **1.** Set any programme \rightarrow *Page 32*.
- 2. Start the programme → Page 32 and wait 5 minutes.
- The condensation is drained.
- 3. Switch off the appliance. → "Switching off the appliance", Page 33
- 4. Remove the water drain hose from the connection point.
 - → "Water outlet connection types", Page 15
- 5. Secure the water drain hose on the appliance against unintentional loosening.
 - Ensure that you do not bend the water drain hose.
- **6.** Empty the condensation container → Page 35.

- 7. Insert the condensation container → Page 36.
- 8. Disconnect the appliance's mains plug from the power supply.
- ▼ The appliance is now ready to be transported.

17.2 Disposing of old appliance

Valuable raw materials can be reused by recycling.

⚠ WARNING Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- Do not install the appliance behind a door as this may obstruct the appliance door or prevent it from opening.
- With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.
- 1. Unplug the appliance from the mains.
- 2. Cut through the power cord.
- 3. Dispose of the appliance in an environmentally friendly manner. Information about current disposal methods are available from your specialist dealer or local authority.



This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and elec-

tronic appliances (waste electrical and electronic equipment - WEEE). The auideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.

Make a note of your appliance's details and the Customer Service telephone number to find them again quickly.

18 Customer Service

If you have any queries on use, are unable to rectify faults on the appliance yourself or if your appliance needs to be repaired, contact Customer Service.

Detailed information on the warranty period and terms of warranty in your country is available from our aftersales service, your retailer or on our website.

If you contact Customer Service, you will require the product number (E-Nr.) and the production number (FD) of your appliance.

The contact details for Customer Service can be found in the enclosed Customer Service directory or on our website.

18.1 Product number (E-Nr.) and production number (FD)

You can find the product number (E-Nr.) and the production number (FD) on the appliance's rating plate. Depending on the model, the rating plate is located:

- On the inside of the door.
- On the inside of the maintenance flap.
- On the rear of the appliance.

19 Consumption values

The specified values are indicative only and were determined in accordance with the applicable standard IEC61121.

The actual values may deviate from the indicated values depending on the type of fabric, composition of laundry to be dried, residual moisture in the fabric, set degree of dryness, amount of laundry being loaded, environmental conditions and the activation of additional functions.

The expected programme duration/"Ready in" time that is shown in the appliance display when selecting the programme is based on the spin speed in the washing machine of 1000 rpm when the appliance is delivered.

Programme	Final mois- ture level (%)	Load (kg)	Spin speed (rpm)	Initial mois- ture level (%)	Pro- gramm e dura- tion (h:min)	Energy con- sump- tion (kWh/ cycle)
Cottons ເເັ Cupboard Dry ⊞	0,0	9,0	1400	50	2:09	4,36
Cottons ເເັ Cupboard Dry ⊞	0,0	9,0	1000	60	2:30	5,32
Cottons ເເັ Cupboard Dry ⊞	0,0	9,0	800	70	3:01	6,02
Cottons 🛱 Iron Dry	12,0	9,0	1400	50	1:46	2,61
Cottons 🛱 Iron Dry	12,0	9,0	1000	60	2:07	4,13
Cottons 🛱 Iron Dry	12,0	9,0	800	70	2:27	4,50
	2,0	3,5	800	40	0:46	1,48
	2,0	3,5	600	50	0:56	1,74

20 Technical specifications

¹ Depending on the appliance specifications

Appliance width	59,8 cm
Appliance depth	59,9 cm
Weight	41,4 kg ¹
Maximum load	9,0 kg

Depending on the appliance specifications

Mains voltage	220-240 V, 50 Hz		
⇔ Minimum installation protection	13/10 A		
Nominal power	2800 W		
Power consumption	Off mode: 0,10 WLeft-on mode: 0,75 W		
Ambient temperature	Minimum:5 °CMaximum:35 °C		
Length of the power cable	145 cm		
Depending on the appliance specifications			

cifications





BSH Hausgeräte GmbH Carl-Wery-Straße 34 81739 München GERMANY www.siemens-home.bsh-group.com

Manufactured by BSH Hausgeräte GmbH under the trademark licence of Siemens AG



en