## **SIEMENS**

HN978GQ.1

# Oven



**EN** User manual and installation instructions





#### You can find additional information and explanations online. Scan the QR code on the title page.

Children of look



## Table of contents

INFORMATION FOR HOE

Ш	ORMATION FOR USE	10	S Chilaprool lock 2	9
1	Safety	2 19	Basic settings 2	9
2	Preventing material damage	. 7 20	Home Connect 3	1
3	Environmental protection and saving energy	. 8 21	Cleaning and servicing 3	2
4	Familiarising yourself with your appliance	. 9 22	2 "Pyrolytic activeClean" cleaning function 3	5
5	Cooking Functions	11 23	3 Cleaning aid "humidClean" 3	6
6	Accessories	13 24	Descaling 3	7
7	Before using for the first time	14 25	5 Drying function 3	7
8	Basic operation	15 26	Appliance door 3	8
9	Rapid heating	17 27	7 Rails 3	9
10	Time-setting options	17 28	3 Troubleshooting 4	0
11	Steaming	18 29	Disposal 4	3
12	Microwave	21 30	Customer Service 4	3
13	Ventilation function "Crisp Finish"	23 31		
14	Meat probe		Software 4	
15	Dishes	25 32	•	
16	Food recoginition	28	B How it works 4	5
17	Favourites	•	INSTALLATION INSTRUCTIONS 5	

## ▲ 1 Safety

Observe the following safety instructions.

#### 1.1 General information

- Read this instruction manual carefully.
- Keep the instruction manual and the product information safe for future reference or for the next owner.
- Do not connect the appliance if it has been damaged in transit.

#### 1.2 Intended use

This appliance is designed only to be built into kitchen units. Read the special installation instructions.

Only a licensed professional may connect appliances without plugs. Damage caused by incorrect connection is not covered under the warranty.

Only use this appliance:

- To prepare meals and drinks.
- For household use and similar applications, such as: In kitchens for employees in shops, offices and other commercial sectors; in aqriculture; by customers in hotels and other residential facilities; in bed and breakfasts.
- Up to an altitude of 4000 m above sea level. This appliance complies with the standards EN 55011 and CISPR 11. It is a group 2, class B product. Group 2 means that microwaves are produced for the purpose of heating food. Class B means that the appliance is suitable for private households.

#### 1.3 Restriction on user group

This appliance may be used by children aged 8 or over and by people who have reduced

physical, sensory or mental abilities or inadequate experience and/or knowledge, provided that they are supervised or have been instructed on how to use the appliance safely and have understood the resulting dangers.

Do not let children play with the appliance. Children must not perform cleaning or user maintenance unless they are at least 15 years old and are being supervised.

Keep children under the age of 8 years away from the appliance and power cable.

#### 1.4 Safe use

Always place accessories in the cooking compartment the right way round.

→ "Accessories", Page 13

#### 

Combustible objects that are left in the cooking compartment may catch fire.

- ► Never store combustible objects in the cooking compartment.
- ► If smoke is emitted, the appliance must be switched off or the plug must be pulled out and the door must be held closed in order to stifle any flames.

Loose food remnants, fat and meat juices may catch fire.

▶ Before using the appliance, remove the worst of the food residues and remnants from the cooking compartment, heating elements and accessories.

Opening the appliance door creates a draught. Greaseproof paper may come into contact with the heating element and catch fire.

- Never place greaseproof paper loosely over accessories when preheating the appliance and while cooking.
- ► Always cut greaseproof paper to size and use a plate or baking tin to hold it down.

### 

The appliance and its parts that can be touched become hot during use.

- ► Caution should be exercised here in order to avoid touching heating elements.
- ► Young children under 8 years of age must be kept away from the appliance.

Accessories and cookware get very hot.

► Always use oven gloves to remove accessories or cookware from the cooking compartment.

When the cooking compartment is hot, any alcoholic vapours inside may catch fire. The ap-

pliance door may spring open. Hot steam and jets of flame may escape.

- Only use small quantities of drinks with a high alcohol content in food.
- Do not heat spirits (≥ 15% vol.) when undiluted (e.g. for marinating or pouring over food).
- ► Open the appliance door carefully. The telescopic shelves become hot when the appliance is in use.
- ► Allow hot telescopic shelves to cool down before touching them.
- Only touch hot telescopic shelves with oven gloves.

## 

The accessible parts of the appliance become hot during operation.

- ► Never touch these hot parts.
- ► Keep children at a safe distance.

Hot steam may escape when you open the appliance door. Steam may not be visible, depending on the temperature.

- ► Open the appliance door carefully.
- ► Keep children at a safe distance. If there is water in the cooking compartment when it is hot, this may create hot steam.
- ► Never pour water into the cooking compartment when the cooking compartment is hot.

## **⚠ WARNING** – Risk of injury!

Scratched glass in the appliance door may develop into a crack.

▶ Do not use any harsh or abrasive cleaners or sharp metal scrapers to clean the glass on the oven door, as they may scratch the surface.

The appliance and its parts that can be touched may have sharp edges.

- ▶ Take care when handling and cleaning them.
- ► If possible, wear protective gloves.

The hinges on the appliance door move when the door is opened and closed, which could trap your fingers.

- ► Keep your hands away from the hinges. Components inside the appliance door may have sharp edges.
- Wear protective gloves.

Alcoholic vapours may catch fire in the hot cooking compartment, and the appliance door may spring open and may fall off. The door panels may shatter and fragment.

- → "Preventing material damage", Page 7
- Only use small quantities of drinks with a high alcohol content in food.

- Do not heat spirits (≥ 15% vol.) when undiluted (e.g. for marinating or pouring over food).
- ▶ Open the appliance door carefully.

## 

Improper repairs are dangerous.

- ► Repairs to the appliance should only be carried out by trained specialist staff.
- ► Only use genuine spare parts when repairing the appliance.
- ▶ If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

If the insulation of the power cord is damaged, this is dangerous.

- ► Never let the power cord come into contact with hot appliance parts or heat sources.
- ► Never let the power cord come into contact with sharp points or edges.
- ► Never kink, crush or modify the power cord. An ingress of moisture can cause an electric shock.
- ► Do not use steam- or high-pressure cleaners to clean the appliance.

If the appliance or the power cord is damaged, this is dangerous.

- ▶ Never operate a damaged appliance.
- ► Never pull on the power cord to unplug the appliance. Always unplug the appliance at the mains.
- ▶ If the appliance or the power cord is damaged, immediately unplug the power cord or switch off the fuse in the fuse box.
- ► Call customer service. → Page 43 Once the appliance has been installed, the openings in the back panel of the appliance must not be accessible to children.
- ▶ Read the special installation instructions.

## **⚠ WARNING – Danger: Magnetism!**

Caution: Magnetism

Caution for people with pacemakers Permanent magnets are used in the control panel. These may impair the functionality of electronic implants, e.g. pacemakers or insulin pumps.

Persons with electronic implants must stand at least 10 cm away from the control panel.

#### 

Children may put packaging material over their heads or wrap themselves up in it and suffocate.

- Keep packaging material away from children.
- ▶ Do not let children play with packaging material.

Children may breathe in or swallow small parts, causing them to suffocate.

- ► Keep small parts away from children.
- ► Do not let children play with small parts.

#### 1.5 Microwave

CAREFULLY READ THE IMPORTANT SAFETY INSTRUCTIONS AND KEEP THEM SAFE FOR FUTURE USE

## 

Using the appliance for anything other than its intended purpose is dangerous and may cause damage. For example, heated slippers and pillows filled with grain or cereal may catch fire, even several hours later.

- Never dry food or clothing with the appliance.
- ► Never heat up slippers, pillows filled with grain or cereal, sponges, damp cleaning cloths or similar with the appliance.
- ► The appliance must only be used to prepare food and drink.

Food and its packaging and containers may catch fire.

- ▶ Never heat food in heat-retaining packaging.
- ► Do not leave food unattended while it is heating in containers made of plastic, paper or other combustible materials.
- Never set the microwave power too high or the cooking time too long. Follow the instructions provided in this user manual.
- ▶ Never use the microwave to dry food.
- Never defrost or heat food with a low water content, such as bread, at too high a microwave power or for too long.

Cooking oil may catch fire.

► Never use the microwave to heat cooking oil on its own.

## 

Liquids and other food may easily explode when in containers that have been tightly sealed.

► Never heat liquids or other food in containers that have been tightly sealed.

#### 

Foods with peel or skin may burst or explode during heating, or even afterwards.

- Never cook eggs in their shell or heat hardboiled eggs in their shell.
- ▶ Never cook shellfish or crustaceans.
- Always prick the yolk of eggs before microwaving.
- ► The skin of foods that have a peel or skin, such as apples, tomatoes, potatoes and sausages, may burst. Before heating, prick the peel or skin.

Heat is not distributed evenly through baby food

- ▶ Never heat baby food in closed containers.
- ► Always remove the lid or teat.
- ► Stir or shake well after heating.
- ► Check the temperature before giving the food or drink to a child.

Heated food gives off heat. The cookware may become hot.

► Always use oven gloves to remove cookware or accessories from the cooking compartment.

Airtight packaging may burst when food is heated.

- Always follow the instructions on the packaging.
- ► Always use oven gloves to remove the dishes from the cooking compartment.

The accessible parts of the appliance become hot during operation.

- ► Never touch these hot parts.
- ► Keep children at a safe distance.

At the highest settings in microwave only mode, the drying function will automatically switch on an additional heating element to heat the cooking compartment.


- Never touch the inside surfaces of the cooking compartment or the heating elements while they are hot.
- Keep children at a safe distance.

## 

There is a possibility of delayed boiling when a liquid is heated. This means that the liquid reaches the boiling temperature without the usual steam bubbles rising to the surface. Exercise caution even when only gently shaking the container. The hot liquid may suddenly boil over and splatter.

► Always place a spoon in the container when heating liquids. This prevents delayed boil-

ing.



## 

Unsuitable cookware may crack. Porcelain or ceramic cookware can have small perforations in the handles and lid. These perforations conceal a cavity below. If moisture penetrates this cavity, it could cause the cookware to crack.

- ► Only use microwave-safe cookware. Cookware and containers made from metal or cookware with metal edging may lead to sparks being formed during simple microwave operation. The appliance is damaged.
- Never use metal containers during microwave-only operation.
- ► Only use microwave-safe cookware or use the microwave in combination with a type of heating.

#### WARNING – Risk of electric shock!

The appliance uses a high voltage.

▶ Never remove the casing.

## **⚠ WARNING** – Risk of serious harm to health!

Inadequate cleaning may destroy the surface of the appliance, reduce its service life, and lead to dangerous situations, such as escaping microwave energy.

- ► Clean the appliance on a regular basis, and remove any food residue immediately.
- ► Always keep the cooking compartment, door seal, door and hinge clean.
- → "Cleaning and servicing", Page 32
  Never operate the appliance if the cooking compartment door or the door seal is damaged. Microwave energy may escape.
- Never use the appliance if the cooking compartment door, the door seal or the plastic door frame is damaged.
- ► Any repair work must only be carried out by customer service.

Microwave energy will escape from appliances that do not have any casing.

- ► Never remove the casing.
- ► For any maintenance or repair work, contact the customer service.

#### 1.6 Steam

Follow these instructions when using a steam function.

## 

The water in the water tank may become very hot if you operate the appliance for long periods.

► Always empty the water tank after using the steam function.

Hot steam is generated in the cooking compartment.

► Do not reach into the cooking compartment when using steam.

Hot liquid may spill over the sides of the accessory when it is removed from the cooking compartment.

► Remove hot accessories with care and always wear oven gloves.

#### **⚠ WARNING – Risk of fire!**

Due to the hot surfaces, vapours from flammable liquids may catch fire in the cooking compartment (explosion). The appliance door may spring open. Hot steam and jets of flame may escape.

- ► Do not pour flammable liquids (e.g. alcoholic drinks) into the water tank.
- ► Only fill the water tank with water or with the descaling solution we have recommended.

#### 1.7 Meat probe

#### ⚠ WARNING – Risk of electric shock!

Using the wrong meat probe could damage the insulation.

► Only use the meat probe for this specific appliance.

## **⚠ WARNING** – Risk of injury!

The meat probe is sharp.

▶ Handle the meat probe with care.

## 1.8 Cleaning function

#### 

Loose food remnants, fat and meat juices may catch fire when the cleaning function is in progress.

► Before you start the cleaning function, always remove coarse dirt from the cooking compartment.

- ► Never clean accessories at the same time. The outside of the appliance gets very hot when the cleaning function is in progress.
- ► Never hang combustible objects, e.g. tea towels, on the door handle.
- ► Leave the front of the appliance clear.
- ► Keep children at a safe distance.

If the door seal is damaged, a large amount of heat is generated around the door.

- ▶ Do not scrub or remove the seal.
- Never operate the appliance if the seal is damaged or missing.

## 

The appliance gets very hot when the cleaning function is in progress. The non-stick coating on baking trays and tins is destroyed and noxious gases are released.

- ► Never clean non-stick baking trays or baking tins using the cleaning function.
- ▶ Never clean accessories at the same time.

#### 

The cleaning function heats up the cooking compartment to a very high temperature so that food left over from roasting, grilling and baking will burn off. This process releases vapours, which can irritate mucous membranes.

- ► Keep the kitchen well ventilated while the cleaning function is running.
- ▶ Do not remain in the room for long periods.
- ► Keep children and pets away.

#### **⚠ WARNING – Risk of burns!**

The cooking compartment gets very hot when the cleaning function is in progress.

- ▶ Never open the appliance door.
- ▶ Allow the appliance to cool down.
- ► Keep children at a safe distance.

⚠ The outside of the appliance gets very hot when the cleaning function is in progress.

- ▶ Never touch the appliance door.
- Allow the appliance to cool down.
- ► Keep children at a safe distance.

## 2 Preventing material damage

### 2.1 General

#### **ATTENTION**

Alcoholic vapours may catch fire in the hot cooking compartment and cause permanent damage to the appliance. The appliance door may spring open due to an explosion and it may fall off. The door panels may shatter and fragment. Due to the resulting negative pressure, the cooking compartment may become considerably deformed inwards.

Do not heat spirits (≥ 15% vol.) when undiluted (e.g. for marinating or pouring over food).

If there is water on the cooking compartment floor when operating the appliance at temperatures above 120 °C, this will damage the enamel.

- ▶ Do not use the appliance if there is water on the cooking compartment floor.
- Wipe away any water on the cooking compartment floor before operation.

Objects on the cooking compartment floor at over 50 °C will cause heat to build up. The baking and roasting times will no longer be correct and the enamel will be damaged.

- ► Do not place any accessories, greaseproof paper or foil of any kind on the cooking compartment floor.
- Only place cookware on the cooking compartment floor if a temperature under 50 °C has been set.

Using silicone moulds or any film, covers or accessories that contain silicone could damage the baking sensor. Damage may occur even if the baking sensor is not active.

- ▶ Do not use silicone moulds or any film, covers or accessories that contain silicone.
- Never place objects made of silicone in the cooking compartment.

When the cooking compartment is hot, any water inside it will create steam. The change in temperature may cause damage.

- Never pour water into the cooking compartment when it is still hot.
- Never place cookware containing water on the cooking compartment floor.

The prolonged presence of moisture in the cooking compartment leads to corrosion.

- Allow the cooking compartment to dry after use.
- Do not keep moist food in the cooking compartment for a long time with the door closed.
- Do not store food in the cooking compartment.
- ► Take care not to trap anything in the appliance door. Fruit juice dripping from the baking tray leaves stains that cannot be removed.
- ► When baking very juicy fruit flans, do not pack too much on the baking tray.
- If possible, use the deeper universal pan.

Using oven cleaner in a hot cooking compartment damages the enamel.

- Never use oven cleaner in the cooking compartment when it is still warm.
- Remove all food remnants from the cooking compartment and the appliance door before you next heat up the appliance.

If the seal is very dirty, the appliance door will no longer close properly during operation. This may damage the front of adjacent kitchen units.

- ► Keep the seal clean at all times.
- ▶ Never operate the appliance if the seal is damaged or

Sitting or placing objects on the appliance door may damage it.

- ▶ Do not place, hang or support objects on the appliance door.
- Do not place cookware or accessories on the appliance door.

With certain models, accessories may scratch the door pane when closing the appliance door.

Always push accessories fully into the cooking compartment.

The camera lens may be scratched or cloudy.

- ▶ Do not any use rough sponges.
- ► Do not use stainless steel wool.
- ► Do not use cleaning agents or descalers containing acids.
- ► Only use oven cleaner when the cooking compartment is cold and in accordance with the manufacturer's specification.

If aluminium foil comes into contact with the door pane, it could cause permanent discolouration.

▶ Do not allow aluminium foil in the cooking compartment to come into contact with the door pane.

#### 2.2 Microwave

Follow these instructions when using the microwave.

#### **ATTENTION**

Metal touching the wall of the cooking compartment will cause sparks, which may damage the appliance or the inner door pane.

► Metal (e.g. a spoon in a glass) must be kept at least 2 cm from the cooking compartment walls and the inside of the door.

Using accessories directly on top of one another causes sparks

- ▶ Do not combine the wire rack with the universal pan.
- Always place accessories on different levels.

The universal pan and baking tray are not suitable for use with microwave-only mode. Using either of these may create sparks, which will damage the cooking compartment.

- ▶ Place accessories on the wire rack supplied. Placing aluminium containers in the appliance may cause sparks, which will damage the appliance.
- ▶ Do not use aluminium containers in the appliance. Operating the appliance without food in the cooking compartment may lead to overloading.
- ► Do not switch on the microwave unless there is food inside. The only exception to this rule is when performing a short cookware test.

If you prepare microwave popcorn at a microwave power level that is too high, the door pane may crack due to overloading.

► Never set a microwave power level that is too high.

- ▶ Use a maximum microwave output of 600 watts.
- Always place the popcorn bag on a glass plate.

#### 2.3 Steam

Follow these instructions when using the steam function.

#### ATTENTION

Using cookware with rust spots may cause corrosion in the cooking compartment. Even the smallest spots of rust can cause corrosion.

► Do not use cookware with rust spots.

Hot water in the water tank may damage the steam system.

Only fill the water tank with cold water.

If there is water on the cooking compartment floor when operating the appliance at temperatures above 120 °C, this will damage the enamel.

▶ Do not use the appliance if there is water on the cooking compartment floor.  Wipe away any water on the cooking compartment floor before operation.

A lot of steam is produced during operation with the types of steam heating. Condensate that collects in the drip trough underneath the cooking compartment may overflow and damage adjacent units.

► Do not open the appliance door, or open it as infrequently as possible, while the appliance is in operation.

If descaling solution comes into contact with the control panel or other delicate surfaces, it will damage them.

- ► Remove descaling solution immediately with water. Cleaning the water tank in the dishwasher will damage it
- ▶ Do not clean the water tank in the dishwasher.
- ► Clean the water tank with a soft cloth and standard washing-up liquid.

## 3 Environmental protection and saving energy

## 3.1 Disposing of packaging

The packaging materials are environmentally compatible and can be recycled.

► Sort the individual components by type and dispose of them separately.

## 3.2 Saving energy

If you follow these instructions, your appliance will use less power.

Only preheat the appliance if the recipe or the recommended settings tell you to do so.

- → "How it works", Page 45
- ✓ Not preheating the appliance can reduce the energy used by up to 20%.

Use dark-coloured, black-coated or enamelled baking tins.

These types of baking tin absorb the heat particularly well.

Open the appliance door as little as possible during operation.

▼ This maintains the temperature in the cooking compartment and eliminates the need for the appliance to reheat.

When baking multiple dishes, do so in succession or in parallel.

The cooking compartment is heated after baking the first dish. This reduces the baking time for the subsequent cakes. For longer cooking times, you can switch the appliance off 10 minutes before the cooking time ends.

 There is sufficient residual heat to finish cooking the dish.

Remove any accessories that are not being used from the cooking compartment.

 Accessories that are not being used do not need to be heated.

Allow frozen food to defrost before cooking.

This saves the energy that would otherwise be required to defrost it.

Switch off the display in the basic settings.

- → "Basic settings", Page 29
- ✓ Energy is saved when the display is switched off.

Heat two glasses or cups of liquid at the same time.

✓ Heating several dishes at the same time requires less energy than heating dishes one after the other.

**Note:** In accordance with the EU Ecodesign Directive 2023/826, this appliance is in a different state when switched off. This is referred to below as low power mode.

Even when the main function is not active, the appliance needs energy for:

- Detecting operation of the touch keys
- Monitoring door opening
- Editing the time (without display)


By definition, therefore, there is neither an "off" nor a "standby" mode, which is why the term low power mode is used. EN IEC 60350-1:2023 must be used to measure low power mode.

## 4 Familiarising yourself with your appliance


## 4.1 Control panel

You can use the control panel to configure all functions of your appliance and to obtain information about the operating status.

On certain models, specific details such as colour and shape may differ from those pictured.




#### **Display**



→ "Display", Page 9

#### **Buttons**



→ "Buttons", Page 9

## 4.2 Display

The display is divided into different areas.

#### Status bar

The status bar is at the top of the display. You can carry out actions depending on the setting step.

Symbol	Function
$\leftarrow$	Go back one setting.
₹ <u>`</u>	Open the basic settings.

In addition to the text information, you can see the current status of different functions using symbols.

Symbol	Meaning
Time, e.g. "12min10s"	Display of the current time-setting options.  → "Time-setting options", Page 17
$\overline{\Diamond}$	Timer is activated.  → "Setting the timer", Page 18
<u></u>	The childproof lock is activated.  → "Childproof lock", Page 29

Symbol	Meaning
<u> </u>	The appliance door is locked due to the cleaning function or childproof lock.  → "Pyrolytic activeClean cleaning function", Page 35  → "Basic settings", Page 29
<b>(</b> (•	Wi-Fi signal strength for Home Connect. The more lines of the symbol are filled, the better the signal. If the symbol is struck through ≉, there is no Wi-Fi signal. If there is an "x" at the symbol ३, there is no connection to the Home Connect server.  → "Home Connect", Page 31
	Remote start with Home Connect is activated.  → "Home Connect", Page 31
	Remote diagnostics with Home Connect for maintenance is activated.  → "Home Connect ", Page 31"
<b>©</b>	The camera in the cooking compartment is activated.  → "Camera", Page 10

#### Settings area

The settings area is shown in tiles.

The individual tiles show you the current selection options and settings that have already been implemented. To select a function, press the corresponding tile. Information is also shown in tiles.

To scroll to the left or right if there are several tiles, swipe over the display.

#### Possible symbols in tiles

Symbol	Meaning
	Enter the adjustment value via the number field.
C	Reset the setting value.
X	Close the tile.

Note: A blue dot or a blue star in a tile indicates that a new function, a new favourite or an update was downloaded to your device using the Home Connect app.

#### Info line

Depending on the setting step, you can see additional information about your setting at the bottom of the display and can carry out actions.

#### 4.3 Buttons

You can use the buttons to directly select various functions.

Button	Function
	Switch the appliance on or off.  → "Basic operation", Page 15

Button	Function
<b>2</b>	Directly select the microwave operating mode.  → "Microwave", Page 21
$\overline{\bigcirc}$	Select the timer.  → "Setting the timer", Page 18
<del>~</del>	Press and hold for approx. 4 seconds: Activate or deactivate the childproof lock.  → "Childproof lock", Page 29
	Open the control panel to remove the water tank.  → "Filling the water tank", Page 18

## 4.4 Cooking compartment

Various functions in the cooking compartment provide support when operating your appliance.


## Shelf supports

The shelf supports in the cooking compartment enable you to place accessories at different heights.

→ "Accessories", Page 13

Your appliance has 5 shelf positions. The shelf positions are numbered from bottom to top.

The shelf supports are equipped with pull-out rails on one or more levels, depending on the appliance type. You can remove the shelf supports, e.g. for cleaning. → "Rails", Page 39



#### Lighting

One or more oven lights illuminate the cooking compartment.

When you open the appliance door, the light in the cooking compartment switches on. If the appliance door remains open for longer than around 18 minutes, the light switches off again.

For most operating modes, the lighting is switched on during operation. The lighting switches off again when the operation ends.

#### Camera

With the camera in the cooking compartment, you can monitor the cooking process using the Home Connect app.

With the "Dishes" operating mode, you can use the browning sensor and set the individual browning of your food. With food recoginition, the oven suggests dishes you can select from.

→ "Dishes", Page 25

→ "Food recoginition", Page 28

You can find information on operating the camera in the Home Connect app.

To use the camera, activate it in the basic settings.

→ "Basic settings", Page 29

To use food recoginition, activate food recoginition in the basic settings.

→ "Basic settings", Page 29

Note: For reasons of data privacy, note that uninvolved persons who spend time in the room could be filmed with the camera through the appliance door.

#### Cooling fan

The cooling fan switches on and off depending on the appliance's temperature. The hot air escapes above the door.

#### **ATTENTION**

Covering the ventilation slots will cause the appliance to overheat.

Do not cover the ventilation slots.

To cool down the appliance and remove residual moisture from the cooking compartment, the cooling fan runs for a certain time after operation.

Note: You can change the run-on time in the basic settings. If you frequently prepare very moist food or keep it warm in the cooking compartment, set a longer run-on

→ "Basic settings", Page 29

## Appliance door


If you open the appliance door during operation, the operation stops. If you close the appliance door, operation resumes automatically.

In microwave mode, if you close the appliance door, you must continue the operation.

#### Water tank

You need the water tank for the types of steam heating. The water tank is behind the control panel.

→ "Filling the water tank", Page 18



- Tank cover
- Opening for filling and emptying
- Handle for removing and inserting

## **5 Cooking Functions**

This is where you can find an overview of your appliance's operating modes and main functions.

Tip: Depending on the appliance type, additional or more comprehensive functions are available to you with the Home Connect app. You can find more information about this in the app.

Operating mode	Use
Types of heating	Select finely tuned types of heating for the optimal preparation of your food.  → "Types of heating", Page 11  → "Basic operation", Page 15
Dishes	Use programmed, recommended settings for various types of food.  → "Dishes", Page 25
Steam	Gently prepare food with types of steam heating.  → "Steaming", Page 18
Microwave	Cook, heat or defrost more quickly with the microwave.  → "Microwave", Page 21

Operating mode	Use
Cleaning	Select the cleaning function for the cooking compartment.  → "Pyrolytic activeClean cleaning function", Page 35  → "Cleaning aid humidClean", Page 36  → "Descaling", Page 37  → "Drying function", Page 37
Favourites	Use your own saved settings.  → "Favourites", Page 28

#### **Home Connect**

With Home Connect, you can connect and remotely control the oven with a mobile device, and use the full functionality of the appliance.

Depending on the appliance type, additional or more comprehensive functions are available for your appliance with the Home Connect app. You can find more information about this in the app.

→ "Home Connect ", Page 31

## 5.1 Types of heating

To ensure that you always find the right type of heating to cook your food, we explain the differences and applica-

The symbols for each type of heating help you to remember them.

When you select a type of heating, the appliance suggests a suitable temperature or setting. You can use these values or change them within the specified range.

For temperature settings above 275 °C and grill setting 3, the appliance reduces the temperature to approx. 275 °C or grill setting 1 after approx. 40 minutes.

Symbol	Type of heating	Temperature range	What it's used for and how it works Possible additional functions
<b>®</b>	4D hot air	30 - 275 °C	Bake or roast on one or more levels.  The fan distributes the heat from the ring-shaped heating element in the back wall evenly around the cooking compartment.
	Top/bottom heating	30 - 300 °C	Traditionally bake or roast on one level. This type of heating is especially good for cakes with moist toppings.  The heat is emitted evenly from above and below.
	Hot air gentle	125 - 250 °C	Cook selected dishes gently on one level without preheating. The fan distributes the heat from the ring-shaped heating element in the back wall evenly around the cooking compartment. The food is cooked in phases using residual heat. Always keep the appliance door closed when cooking. If you open the appliance door even briefly, the appliance will continue to heat without utilising any residual heat.  This type of heating is used to determine the energy consumption in air recirculation mode and the energy efficiency class.
	Top/bottom heat gentle	150 - 250 °C	Gently cook selected dishes. Heat is emitted from above and below. The food is cooked in phases using residual heat. Always keep the appliance door closed when cooking. If you open the appliance door even briefly, the appliance will continue to heat without utilising any residual heat. This type of heating is used to measure the energy consumption in the conventional mode.
<b>~</b>	Circulated air grilling	30 - 300 °C	Roast poultry, whole fish or larger pieces of meat.

Symbol	Type of heating	Temperature range	What it's used for and how it works Possible additional functions
			The grill element and the fan switch on and off alternately. The fan circulates the hot air around the food.
<b>**</b>	Grill, large area	Grill settings: 1 = low 2 = medium 3 = high	Grill flat items such as steak and sausages, or make toast. Gratinate food.  The entire area below the grill element becomes hot.
<b>"</b>	Grill, small area	Grill settings: 1 = low 2 = medium 3 = high	Grill small quantities, such as steak, sausages or toast. Gratinate small quantities of food.  The central area below the grill element becomes hot.
	Pizza setting	30 - 275 °C	Cook pizza or food that requires a lot of heat from below.  The bottom heating element and the ring-shaped heating element in the back wall heat the cooking compartment.
<u>»</u> *δ	CoolStart function	30 - 275 °C	For the quick preparation of frozen products without preheating. The temperature is determined by the manufacturer's specifications. Use the highest temperature specified on the packaging.
	Intensive heat	30 - 300 °C	Prepare dishes with a crispy base. The heat is emitted from above and more intensively from below.
	Low-temperature cooking	70 - 120 °C	Slowly and gently cook seared, tender pieces of meat in uncovered cookware.  The heat is emitted evenly from above and below at a low temperature.
<b>®</b>	Drying out food	30 - 130 °C	Dry herbs, fruit or vegetables.
	Bottom heating	30 - 250 °C	Final baking or cooking food in a bain marie. The heat is emitted from below.
<b>SSS</b>	Keeping warm	50 - 100 °C	Keep cooked food warm.
<b>S</b>	Preheating cookware	30 - 90 °C	Preheat cookware.

#### Types of steam heating

This is where you can find an overview of the types of steam heating and their use.

Symbol	Steam heating type	Temperature range	What it's used for and how it works Possible additional functions
2	Reheating	80 - 180 °C	Gently reheat plated meals and baked items. The steam ensures that the food does not dry out.
	Proving dough	30 - 50 °C	Leave the yeast dough to prove.  The dough rises considerably more quickly than at room temperature. The surface of the dough does not dry out.

### 5.2 Temperature

With most types of heating, you can read the current temperature in the cooking compartment and the set temperature side-by-side on the display during heating, e.g. \$ 120 °C | 210 °C.

When you preheat the appliance, the optimal time to place the meal in the oven is as soon as the heating line has completely filled and a signal tone sounds.

**Note:** Due to thermal inertia, the temperature that is displayed may differ slightly from the actual temperature inside the cooking compartment.

#### Residual heat indicator

When the appliance is switched off, the display uses the \$\square\$ symbol to show the residual heat in the cooking compartment. The further the temperature drops, the less the symbol is visible. The symbol goes out entirely at approx. 60 °C.

## 5.3 Microwave output settings

This is where you can find an overview of the different microwave output settings and recommendations on when to use them.

The microwave output settings are levels and do not always correspond to the exact wattage that the appliance uses.

Microwave output in watts	Maximum cooking time in hours	Use
90 W	1:30	Defrost delicate foods.

Microwave output in watts	Maximum cooking time in hours	Use
180 W	1:30	Defrost food and continue cooking.
360W	1:30	Cook fish and meat. Heat up delicate foods.
600 W	1:30	Heat and cook food.
800 W "Boost"	00:30	Heat liquids.

#### **Notes**

- To protect the appliance, the maximum microwave output "Boost" is gradually reduced to 600 watts dur-
- ing the first few minutes. Maximum output is made available again after a cooling period.
- The microwave output settings do not correspond with the real power consumption of the appliance.

## 6 Accessories

Use original accessories. These have been made especially for your appliance.

Note: Accessories may become deformed if they get hot. Deformation has no effect on function. As the accessory cools down, it will regain its original shape.

The accessories supplied may differ depending on the appliance model.

Accessories	Use
Wire rack	<ul> <li>Cake tins</li> <li>Ovenproof dishes</li> <li>Cookware</li> <li>Meat, e.g. roasting joints or steak</li> <li>Frozen meals</li> </ul>
Universal pan	<ul> <li>Moist cakes</li> <li>Baked items</li> <li>Bread</li> <li>Large roasts</li> <li>Frozen meals</li> <li>Catch dripping liquids, e.g. fat when grilling food on the wire rack.</li> </ul>
Baking tray	<ul><li>Tray bakes</li><li>Small baked items</li></ul>
Meat thermometer	High-precision roasting or cooking.  → "Meat probe", Page 23
Glass scraper	Only use the glass scraper to clean the camera lens.

#### 6.1 Information on accessories

Some accessories are only suitable for certain types of heating.

#### Microwave accessories

The wire rack that is supplied is only suitable for operation solely using the microwave.

Baking trays, e.g. the universal pan or the baking tray, may create sparks and are not suitable.

Observe the information about the microwave.

→ "Cookware and accessories with microwave", Page 21

## 6.2 Locking function

The locking function prevents the accessories from tilting when they are pulled out.

You can pull out the accessories approximately halfway without them tipping. The accessories must be inserted into the cooking compartment correctly for the tilt protection to work properly.


## 6.3 Sliding accessories into the cooking compartment

Always slide the accessory into the cooking compartment the right way round. This is the only way to ensure that accessories can be pulled out approximately halfway without tipping.

- **1.** Turn the accessories so that the notch ⓐ is at the rear and is facing downwards.
- 2. Insert the accessory between the two guide rods for a shelf position.


Wire rack

Insert the wire rack with the open side facing the appliance door and the curved lip — facing downwards.




Tray
E.g. universal pan or baking tray

Slide the tray in with the sloping edge towards the appliance door.



Place the accessories on the inserted pull-out rails.

Wire rack or Place the accessory so that it is inserbaking tray ted on the rear stop of the pull-out system.



**Note:** Gently push the pull-out rails back into the cooking compartment.

**3.** Push the accessory all the way in, making sure that it does not touch the appliance door.

**Note:** Take any accessories that you will not be using out of the cooking compartment while the appliance is in operation.

#### 6.4 Other accessories

You can purchase other accessories from our customer service, specialist retailers or online.

You will find a comprehensive range of products for your appliance in our brochures and online:

siemens-home.bsh-group.com

Accessories are appliance-specific. When purchasing accessories, always quote the exact product number (E no.) of your appliance.

You can find out which accessories are available for your appliance in our online shop or from our customer service.

## 7 Before using for the first time

Configure the settings for initial start-up. Clean the appliance and accessories.

## 7.1 Determining the water hardness before switching on the appliance for the first time

Before using the appliance for the first time, ask your water supplier about the hardness of your tap water. To ensure that the appliance can reliably remind you to descale it when required, you must set your water hardness range correctly.

#### **ATTENTION**

If the wrong water hardness has been set, the steam function is impaired and appliance cannot remind you to descale it at the right time.

Set the water hardness correctly.

Using unsuitable liquids may damage the appliance.

- ► Do not use distilled water or other liquids.
- ► Only use cold, fresh tap water, softened water or non-carbonated mineral water.

Malfunctions may occur when using filtered or demineralised water. The appliance may request that you top up the water tank even though it may be full, or operation with steam is cancelled after approx. two minutes.

If required, mix filtered or demineralised water with the bottled non-carbonated mineral water with a ratio of one to one.

#### **Notes**

- If you are using mineral water, set the water hardness range to "very hard". If you are using mineral water, you must only use non-carbonated mineral water.
- If your tap water is very hard, we recommend that you use softened water. If you are using only softened water, set the "softened" water hardness range.

Setting	Water hardness in mmol/l	German hardness °dH	French hardness °fH
0 (softened) <sup>1</sup>	-	-	-
1 (soft)	Up to 1.5	Up to 8.4	Up to 15
2 (medium)	1.5-2.5	8.4-14	15-25
3 (hard)	2.5-3.8	14-21.3	25-38
4 (very hard) <sup>2</sup>	Over 3.8	Over 21.3	Over 38

## 7.2 Performing initial start-up

After connecting the appliance to the power supply, you must configure the settings for its initial start-up. It may take a few minutes for the settings to appear on the display.

Note: You can also use the Home Connect app to configure the settings. When your appliance is connected, follow the instructions in the app.

- **1.** Press  $\bigcirc$  to switch the appliance on.
- ✓ The first setting appears.
- 2. If required, change the setting. Possible settings:
  - Language
  - Home Connect
  - Time
  - Date
  - Water hardness
- **3.** Use  $\rightarrow$  to switch to the next setting.
- 4. Work through the settings and make changes as re-
- After the last setting, a message appears on the display confirming that the initial start-up is complete.
- 5. To check the appliance before heating for the first time, open and close the appliance door once.

## 7.3 Cleaning the appliance before using it for the first time

Before using the appliance to cook food for the first time, you must clean the cooking compartment and accessories.

- 1. Remove the product information and the accessories from the cooking compartment. Remove any leftover packaging, such as polystyrene pellets, and any adhesive tape either in or on the appliance.
- 2. Wipe the smooth surfaces in the cooking compartment with a soft, damp cloth.
- **3.** Press ① to switch the appliance on.
- **4.** Fill the water tank.
  - → "Filling the water tank", Page 18
- **5.** Apply the following settings:

Type of heating	4D hot air ⊚	
Temperature	Maximum	
Added steam	03	
Cooking time	1 hour	

- → "Basic operation", Page 15
- **6.** Start the operation.
  - ► Ventilate the kitchen while the appliance is heating.
- Once the cooking time has elapsed, a signal tone sounds. A note appears on the display confirming that the operation has finished.
- 7. Press ① to switch the appliance off.
- 8. Once the appliance has cooled down, clean the smooth surfaces in the cooking compartment with a detergent solution and a dish cloth.
- 9. Clean the accessories thoroughly using a detergent solution and a dish cloth or soft brush.
- 10. Empty the water tank and dry the cooking compartment.
  - → "After using steam operation", Page 20

## 8 Basic operation

### 8.1 Switching on the appliance

- ▶ Press ① to switch the appliance on.
- ✓ The display shows the menu.

## 8.2 Switching off the appliance

Switch your appliance off when you are not using it. The appliance automatically switches itself off if it is not used for a certain period of time.

- ► Press ① to switch the appliance off.
- The appliance switches off. Any functions currently in progress are cancelled.
- The time or residual heat indicator appears on the display.

### 8.3 Starting the operation

You must start each operation.

#### **ATTENTION**

If there is water on the cooking compartment floor when operating the appliance at temperatures above 120 °C, this will damage the enamel.

- ► Do not use the appliance if there is water on the cooking compartment floor.
- ▶ Wipe away any water on the cooking compartment floor before operation.
- ► Use "Start" to start the operation.
- The settings appear on the display.

<sup>&</sup>lt;sup>1</sup> Only set this if you will be using solely softened water.

<sup>&</sup>lt;sup>2</sup> Also set for mineral water. Only use non-carbonated mineral water.

#### 8.4 Interrupting the operation

You can interrupt the operation and then continue again.

- **1.** To interrupt the operation, press "Stop".
- **2.** To continue the operation, press "Start".

## 8.5 Setting an operating mode

After you have switched on the appliance, the menu appears on the display.

- 1. To scroll through the various selection options, swipe to the left or right on the display.
- 2. To select a function, press the corresponding tile.
- Depending on the function, possible adjustment values or other tiles are available for selection.
- **3.** If required, press on another tile.
- **4.** To change the adjustment values:
  - ► Swipe over the blue adjustment line or push the adjustment line to the appropriate point.
  - ► Or press \mathbb{m} and enter the value directly via the number field that appears.
- **5.** Use "Start" to start the operation.
- **6.** If the operation is ended:
  - ► If required, you can select other settings and restart the operation.
  - ▶ When the food is ready, use ① to switch the appli-

Tip: You can save your settings as "Favourites"☆ and use these again.

→ "Favourites", Page 28

## 8.6 Setting the type of heating and the temperature

- 1. Press "Types of heating".
- **2.** Press the type of heating that you want to use.
- 3. Set the temperature using the adjustment line or directly via the number field E.

If required, you can implement additional settings:

- → "Rapid heating", Page 17
- → "Time-setting options", Page 17
- → "Steaming", Page 18
- → "Microwave", Page 21
- → "Ventilation function Crisp Finish", Page 23
- → "Meat probe", Page 23
- 4. Use "Start" to start the operation.
- ✓ The appliance starts heating.
- The adjustment values and how long the appliance has already been in operation are shown on the dis-
- 5. When the food is ready, use  $\odot$  to switch the appliance off.

**Note:** The most suitable type of heating for your food can be found in the type of heating description.

→ "Types of heating", Page 11

## Changing the type of heating

When you change the type of heating, the other settings are also reset.

- 1. Press "Stop".
- **2.** Press  $\leftarrow$ .
- **3.** Press the type of heating that you want to use.
- **4.** Reset the operation and use "Start" to start.

#### Changing the temperature

Once the operation has started, you can change the temperature at any time.

- **1.** Press the temperature.
- 2. Change the temperature using the adjustment line or enter it directly via the number field E.
- 3. Press "Apply".

## 8.7 Displaying information

In most cases, you can call up information about the function that you have just started. The appliance automatically displays certain information, e.g. to ask you to do/confirm something or to issue a warning.

- 1. Press i.
- ✓ If information is available, this is displayed for a few seconds.
- 2. If there is a lot of content, swipe down.
- 3. If required, close the notification using X.

## 8.8 Keeping warm over an extended period

You can use your appliance to keep meals warm for up to 24 hours without changing the behaviour of the appliance. Use the time functions and change the basic settinas.

**Note:** If you open the appliance door during operation, the appliance stops heating. When you close the appliance door, the appliance continues to heat again. To ensure that the behaviour of the appliance is not changed during operation, only open the appliance door once the set time has elapsed.

- 1. Change the "Lighting" basic setting to "Always off". → "Basic settings", Page 29
- 2. Change the "Standby screen" basic setting to "On".
- 3. Change the "Signal tone" basic setting to "Very short duration".

This will ensure that the light in the cooking compartment is always off while the appliance is in operation and when you open the appliance door. The clock display does not change. The duration of the signal tone is reduced at the end of the operation.

- 4. Set the required operating mode.
  - → "Setting an operating mode", Page 16
  - → "Setting the type of heating and the temperature", Page 16
- 5. Set the required cooking time depending on the operating mode.
  - → "Setting the cooking time", Page 17
  - → "Time-setting options", Page 17
- **6.** Use "End time" to set the time at which the operation should end.
  - → "Setting the end time", Page 17
  - → "Time-setting options", Page 17
- 7. Place the food in the cooking compartment before the appliance starts to heat.
- 8. Start the operation.
- ▼ The display shows the time remaining until the operation starts. The appliance is in standby mode.
- Once the start time has been reached, the appliance starts heating and the cooking time starts counting down.
- **9.** When the operation has ended, remove the food from the cooking compartment. The appliance automatic-

ally switches off completely after approximately 15 to 20 minutes.

**Note:** If required, change the different basic settings again.

## 9 Rapid heating

To save time, rapid heating » save time, rapid heating save time, rapid ing time for set temperatures over 100 °C.

Rapid heating is possible for the following types of heating:

- 4D hot air 🖲
- Top/bottom heating □
- Intensive heat

## 9.1 Setting rapid heating

To ensure an even cooking result, do not place the food in the cooking compartment until rapid heating has come to an end.

Note: Do not set a cooking time until rapid heating has come to an end.

- 1. Set a suitable type of heating and a temperature of at least 100 °C.
  - Rapid heating automatically switches on at temperatures of 200 °C and above.
- 2. Press "Rapid heating".
- ✓ "On" is in the tile.
- 3. Press "Start" to start the operation.
- Rapid heating starts.
- Once rapid heating has ended, a signal sounds. "Off"
- **4.** Place the food in the cooking compartment.

#### Cancelling rapid heating

- Press "Rapid heating".
- ✓ For "Rapid heating" » "Off" appears on the display.

## 10 Time-setting options

For an operation, you can set the cooking time and the time at which the operation should be finished. The timer runs independently of the operation.

Time-setting option	Use
Cooking time ⊢	If you set a cooking time, the appliance stops heating automatically once this time has elapsed.
End time →	Along with the cooking time, you can set the time at which you want the operation to end. The appliance starts up automatically so that the operation finishes at the required time.
Timer △	You can set the timer to run independently of the appliance during operation. It does not affect the appliance.

#### 10.1 Setting the cooking time

You can set the cooking time for the operation of up to 24 hours.

**Requirement:** An operating mode and temperature or setting have been set.

- 1. Press "Cooking time".
- 2. To set the cooking time, press the relevant time value, e.g. hour display "h" or minute display "min."
- ▼ The selected value is marked in blue.
- 3. Set the cooking time using the adjustment line or enter it directly via the number field \( \ext{\begin{subarray}{c} \ext{\text{min}} \ext{\text{win}} \) If required, use 5 to reset the adjustment value.
- 4. Use "Start" to start the operation.
- ▼ The appliance starts to heat and the time counts. down.
- Once the cooking time has elapsed, a signal tone sounds. A note appears on the display confirming that the operation has finished.

- **5.** Once the cooking time has elapsed:
  - ► If required, you can select other settings and restart the operation.
  - ▶ When the food is ready, use ① to switch the appliance off.

### Changing the cooking time

You can change the cooking time at any time.

- 1. Press the cooking time.
- 2. Change the cooking time using the adjustment line or enter it directly via the number field E.
- 3. Press "Apply".

## Cancelling the cooking time

You can cancel the cooking time at any time.

- 1. Press the cooking time.
- 2. Reset the cooking time using 5.

Note: For operating modes that always require a cooking time, the appliance resets the cooking time to the preset value.

3. Press "Apply".

### 10.2 Setting the end time

The appliance automatically switches itself on, and then switches itself off at the preselected end time. To enable it to do this, you set the cooking time (duration) and specify when you want your food to be ready.

#### Requirements

- An operating mode and temperature or level have been set.
- A cooking time is set.
- 1. Press "End time".
- 2. Delay the time using the adjustment line or directly via the number field E.

If required, use 5 to reset the setting value.

- 3. Press "Start" to start the operation.
- ▼ The display shows the start time. The appliance is in standby mode.
- Once the start time has been reached, the appliance starts heating and the cooking time starts counting down.
- When the time has elapsed, a signal tone sounds. A notification appears on the display confirming that the operation has finished.
- **4.** Once the cooking time has elapsed:
  - If required, you can select other settings and restart the operation.
  - When the food is ready, use ① to switch the appliance off.

#### Changing the end time

To achieve good cooking results, only change the set time before the operation starts and before the cooking time starts counting down.

- 1. Press "Stop"
- 2. Press "End time"
- 3. Change the time using the adjustment line or enter it directly via the number field ##.
- 4. Press "Start"

#### Cancelling the end time

You can delete the set time at any time.

- 1. Press "Stop"
- 2. Press "End time"
- 3. Use 5 to reset the time.

**Note:** For operating modes that always require a cooking time, the appliance resets the time at which the cooking time ends to the next possible time.

4. Press "Start"

## 10.3 Setting the timer

The timer runs independently during the operation. You can set the timer when the appliance is switched on or off, up to 24 hours. The timer has its own signal so that you can tell whether it is the timer or a cooking time that has elapsed.

- **1.** Press the  $\triangle$  button.
- 2. To set the timer, press the relevant time value on the display, e.g. hour display "h" or minute display "min".
- ▼ The selected value is marked in blue.
- 3. Set the timer \mathbb{\mathbb{m}} using the number field.

  If required, use \( \bar{\D} \) to reset the setting value.
- 4. Press "Start" to start the timer.
- ✓ The timer counts down.
- ▼ The timer remains visible on the display if the appliance is switched off.
- ✓ When the appliance is switched on, the display shows the settings for the current operation. The timer is displayed in the status bar.
- Once the timer has elapsed, a signal sounds. A message appears on the display confirming that the timer has finished.

## **Changing the timer**

You can change the timer at any time.

- **1.** Press the  $\triangle$  button.
- 2. Press "Stop".
- 3. Change the timer.
- 4. Press "Start".

## Cancelling the timer

- **1.** Press the  $\triangle$  button.
- 2. Reset the timer using 5. Reset the timer using .
- 3. Close with X

## 11 Steaming

Food can be cooked particularly gently using steam. You can use the special types of steam heating, or use steam assistance with certain types of heating.

## **⚠** WARNING – Risk of scalding!

Hot steam may escape when you open the appliance door. Steam may not be visible, depending on the temperature.

- ► Open the appliance door carefully.
- ► Keep children at a safe distance.

#### 11.1 Before using the steam function

Before using the steam function each time, make sure that your appliance is supplied with sufficient water.

#### Filling the water tank

#### 

Due to the hot surfaces, vapours from flammable liquids may catch fire in the cooking compartment (explosion). The appliance door may spring open. Hot steam and jets of flame may escape.

▶ Do not pour flammable liquids (e.g. alcoholic drinks) into the water tank.

► Only fill the water tank with water or with the descaling solution we have recommended.

#### ⚠ WARNING – Risk of burns!


The water tank may heat up while the appliance is in operation.

- Wait until the water tank has cooled down from the previous operation.
- Remove the water tank from the tank recess.


**Requirement:** The water hardness is set correctly.

- 1. Press ≡.
- ▼ The control panel pops out automatically.
- 2. Pull the control panel towards you with both hands and then push it upwards until it clicks into place ①.


3. Remove the water tank from the tank recess 2.



- **4.** Press down on the water tank lid along the seal to prevent water from leaking out of the water tank.
- 5. Remove the cover a on the water tank.
- 6. Fill the water tank with water up to the "max" b mark.



- **7.** Put the cover back into the opening on the water tank.
- 8. Insert the full water tank ①. When doing so, make sure that the water tank clicks into place behind the retainers a.



**9.** Slowly slide the control panel downwards and then push it away from you until it is closed completely.

### 11.2 Setting options with steam

There are various ways in which you can prepare your food with steam.

#### Added steam

When you cook with added steam, the appliance introduces steam into the cooking compartment at various intervals. This gives your food a crispy crust and a shiny surface. Meat stays juicy and tender, and only undergoes a minimum reduction in volume.

You can combine added steam with the following functions:

- Types of heating → Page 16
  - 4D hot air 🕲
  - Top/bottom heating
  - Circulated air grilling 3
  - Keeping warm
- → "Dishes", Page 25
- → "Meat probe", Page 23

### Steam jet

You can use the steam jet function to specifically add intensive steam at various intervals. This makes bread and bread rolls in particular wonderfully crispy and gives them a golden colour.

The appliance adds clouds of steam to the cooking compartment for approx. 3 to 5 minutes. Depending on the operation, you can activate the steam jet several times

You can add the steam jet for the following functions:

- Types of heating → Page 16
  - 4D hot air 🖲
  - − Top/bottom heating □
  - Circulated air grilling I
- → "Meat probe", Page 23

**Note:** Only use the steam jet when cooking compartment temperatures are above 120 °C.

## 11.3 Setting the type of steam heating

#### Note

Observe the instructions for the types of steam heating:

**Requirement:** The water tank has been filled. If the water tank runs dry during operation, a message appears on the display. Operation is stopped.

- → "Filling the water tank", Page 18
- 1. Press "Steam".
- 2. Press the required type of steam heating.
- 3. Set the temperature using the adjustment line or directly via the number field 鹽.
- 4. Press "Cooking time".
  - A cooking time must always be set for types of steam heating.
- **5.** To change the preset cooking time, press the relevant time value, e.g. minute display "min" or second display "s".
- The selected value is marked in blue.
- 6. Set the cooking time using the adjustment line or enter it directly via the number field ട. If required, use り to reset the setting value.
- 7. Press "Start" to start the operation.
- The appliance starts to heat and the cooking time counts down. For some types of heating, e.g. full-Steam Plus, the cooking time only starts after a heating-up time. The heating-up time depends on the volume and temperature of the food.
- When the time has elapsed, a signal tone sounds. A notification appears on the display confirming that the operation has finished.
- 8. Once the cooking time has elapsed:
  - ► If required, you can select other settings and restart the operation.
  - When the food is ready, use ① to switch the appliance off.

- Empty the water tank and dry the cooking compartment
  - → "After using steam operation", Page 20

## Changing the type of steam heating

When you change the type of steam heating, the other settings are also reset.

- 1. Press "Stop"
- 2. Press ←
- **3.** Press the required type of steam heating.
- **4.** Reset the operation and use "Start" to start.

#### Changing the temperature

Once the operation has started, you can change the temperature at any time.

- **1.** Press the temperature.
- 2. Change the temperature using the adjustment line or enter it directly via the number field \( \ext{\te}\text{\texi}\text{\text{\text{\text{\text{\text{\text{\texi}\text{\text{\texi}\text{\texit{\texi}\text{\texi}\text{\text{\texi}\text{\text{\texi}\text{\text{\
- 3. Press "Apply".

## Changing the cooking time

You can change the cooking time at any time.

- 1. Press the cooking time.
- 2. Change the cooking time using the adjustment line or enter it directly via the number field 噩.
- 3. Press "Apply".

## 11.4 Setting added steam

#### Requirements

- Observe the information about the respective operating mode.
  - → "Setting options with steam", Page 19
- The water tank has been filled. If the water tank runs dry during operation, a message appears on the display. The appliance continues to operate but without injecting steam into the cooking compartment.
  - → "Filling the water tank", Page 18
- 1. Press the operating mode that you require.
- **2.** Select the settings for the operating mode, e.g. type of heating and temperature.
- 3. Press "Added Steam" 4.
- 4. Press the required steam level.

Steam level	Added steam	_
1	Low	
2	Medium	
3	High	

- **5.** Press "Start" to start the operation.
- ✓ The appliance starts heating.
- The setting values and how long the appliance has already been in operation are shown on the display.
- When the food is ready, use ① to switch the appliance off.
- Empty the water tank and dry the cooking compartment.
  - → "After using steam operation", Page 20

#### Changing added steam

You can change or deactivate the added steam function at any time.

1. Press the steam level.

- 2. Change or deactivate added steam.
- 3. Press "Apply".

## 11.5 Setting the steam jet function

#### Requirements

- Observe the information about the respective operating mode.
  - → "Setting options with steam", Page 19
- The water tank has been filled. If the water tank runs dry during operation, a message appears on the display. Operation is stopped.
  - → "Filling the water tank", Page 18
- 1. Press the operating mode that you require.
- **2.** Select the settings for the operating mode, e.g. type of heating and temperature.
- 3. Press "Steam jet"
- **4.** Start the operation.
- 5. Press "Steam jet" at the desired time.

  Do not use the steam jet until the appliance has completely heated up.
- ▼ The appliance starts to heat the water.
- **6.** When the water is heated up, press "Steam jet" again.

**Note:** If rapid heating \* is activated, the steam jet can only be triggered once rapid heating is complete.

- ✓ The steam jet is triggered and the appliance adds clouds of steam to the cooking compartment for approx. 3 to 5 minutes.
- ✓ When the steam jet has finished, the operation continues to run as normal. Depending on the operation, the steam jet can be triggered again if necessary.
- 7. When the food is ready, use  $\circlearrowleft$  to switch the appliance off.
- Empty the water tank and dry the cooking compartment.
  - → "After using steam operation", Page 20

#### Cancelling the steam jet

You can cancel the steam jet at any time.

- 1. Press +.
- 2. Press "Steam jet" 4.
- 3. Press "Apply".
- ▼ The operation continues without the steam jet.

#### 11.6 After using steam operation

Dry the appliance after each steam operation.

**Note:** Traces of limescale may remain in the cooking compartment after operation with steam. The functionality of the appliance is not affected by this. You can remove traces of limescale using hot water or a cloth soaked in vinegar. Observe the information on cleaning. → "Cleaning and servicing", Page 32

#### **Emptying the water tank**

#### 

The water tank may heat up while the appliance is in operation.

- Wait until the water tank has cooled down from the previous operation.
- Remove the water tank from the tank recess.

#### **ATTENTION**

Drying the water tank in the hot cooking compartment leads to damage to the water tank.

► Do not dry the water tank in the hot cooking compartment.

Cleaning the water tank in the dishwasher will damage it.

- ▶ Do not clean the water tank in the dishwasher.
- Clean the water tank with a soft cloth and standard washing-up liquid.
- **1.** Use  $\square$  to open the control panel.
- 2. Remove the water tank.
- 3. Carefully remove the lid of the water tank.
- **4.** Empty the water tank, clean it with detergent and then rinse it thoroughly with clean water.
- 5. Dry all parts with a soft cloth.
- 6. Rub the seal on the lid until dry.
- 7. Leave the water tank to dry with the lid open.
- 8. Place the lid on the water tank and push down on it.
- **9.** Insert the water tank and close the control panel.

## Drying the drip trough


### WARNING − Risk of burns!

The appliance becomes hot during operation.

Allow the appliance to cool down before cleaning.

Requirement: The cooking compartment has cooled down.

- **1.** Open the appliance door.
- 2. Note: The drip trough a is underneath the cooking compartment.



Soak up the water in the drip trough a with a sponge cloth and wipe it carefully.

## Drying the cooking compartment

Dry the cooking compartment after each steam operation.

- Dry the cooking compartment by hand or use the drying function.
  - → "Drying function", Page 37

## 12 Microwave

You can use the microwave to cook, heat up, bake or defrost food very quickly.

## 12.1 Cookware and accessories with microwave

To heat food evenly and avoid damaging your appliance, it is important to only use the right cookware and accessories.

Follow the cookware manufacturer's instructions. Unless otherwise specified, place the cookware and accessory on level 2.

#### Microwave-safe cookware

Cookware made from heat-resistant, microwave-safe material:

- Glass
- Glass ceramic
- Porcelain
- Temperature-resistant plastic
- Fully glazed ceramic without cracks
- Serving dishes

Only use cookware with decorative gold or silver trim if the manufacturer guarantees its suitability for microwave use.

Supplied wire rack In microwave-only operation, sheets and trays, e.g. the universal pan or the baking tray, may create sparks and are not suitable.

These materials allow microwaves to pass through and are not damaged.

#### Cookware that is not microwave-safe

**Note:** Observe the specifications for preventing material damage.

- → "Microwave", Page 7
- Metal cookware and bakeware

Microwaves cannot pass through metal. The food is barely heated or not heated at all. Metal may create sparks in microwave-only operation.

## Cookware when adding microwave to an operating

If you switch on the microwave for another operating mode, metal is also an option, in addition to microwavesafe cookware and accessories:

- Metal cookware and bakeware Metal must be kept at least 2 cm from the cooking compartment walls and the inside of the door. Always place metal cookware or bakeware in the centre of the supplied wire rack.
- Accessories supplied:

Wire rack

Universal pan

Baking tray

### Testing cookware for microwave suitability

If you are unsure whether your cookware is suitable for use in the microwave, carry out a cookware test.

#### **ATTENTION**

Operating the appliance without food in the cooking compartment may lead to overloading.

▶ Do not switch on the microwave unless there is food inside. The only exception to this rule is when performing a short cookware test.

## 

The accessible parts of the appliance become hot during operation.

- Never touch these hot parts.
- ► Keep children at a safe distance.
- Place the empty cookware in the cooking compartment.
- **2.** Set the appliance to run for 30 seconds to 1 minute at maximum power.
- **3.** Start the operation.
- 4. Check the cookware several times:
  - If the cookware remains cold or warm to the touch, it is suitable for microwave use.
  - If the cookware becomes hot or sparks are created, stop the cookware test. The cookware is not microwave-safe.

### 12.2 Setting options with the microwave

You can use the microwave on its own or in combination with a different operating mode.

#### Microwave-only operation

The electromagnetic waves of the microwave alone generate energy and this is converted into heat in food, for example.

To prevent condensation, when the microwave output is 600 watts and "Boost", the appliance automatically switches on a heating element. The cooking compartment and the accessories become hot. The cooking result is not affected by this.

You can switch off this automatic drying function in the basic settings.

→ "Basic settings", Page 29

### **⚠** WARNING – Risk of burns!

At the highest settings in microwave only mode, the drying function will automatically switch on an additional heating element to heat the cooking compartment.

- ► Never touch the inside surfaces of the cooking compartment or the heating elements while they are hot.
- ► Keep children at a safe distance.

#### **Added microwave**

Adding the microwave to an operating mode reduces the cooking time.

You can combine the microwave with the following functions:

- Types of heating → Page 16
  - 4D hot air 🖲
  - Top/bottom heating
  - Circulated air grilling 3
  - Full-surface grill
  - Centre-area grill
- → "Dishes", Page 25
- → "Meat probe", Page 23
- → "Ventilation function Crisp Finish", Page 23

Possible microwave outputs combined with an operating mode include:

- 90 watts
- 180 watts
- 360 watts

## 12.3 Setting the microwave

#### Note

Note the correct way to operate the microwave:

- → "Safety", Page 2
- → "Preventing material damage", Page 7
- → "Microwave output settings", Page 12
- → "Cookware and accessories with microwave", Page 21
- 1. Press "Microwave".
  - ➤ Or select the microwave directly using the 

    button.
- 2. Press the required microwave output setting.
- 3. Press "Cooking time".
  - A cooking time must always be set to operate the microwave.
- **4.** To change the preset cooking time, press the relevant time value, e.g. minute display "min" or second display "s".
- ▼ The selected value is marked in blue.
- 5. Set the cooking time using the adjustment line or enter it directly via the number field ട. If required, use 5 to reset the setting value.
- 6. Press "Start" to start the operation.
- ▼ The microwave starts and the cooking time counts down. The display shows the performance reduction for the maximum microwave output "Boost".
  - → "Microwave output settings", Page 12
- When the time has elapsed, a signal sounds. A notification appears on the display confirming that the operation has finished.
- 7. Once the cooking time has elapsed:
  - ► If required, you can select other settings and restart the operation.
  - ► When the food is ready, use ① to switch the appliance off.
- **8.** If you have switched off the drying function for the microwave in the basic settings and condensation has formed in the cooking compartment, dry the cooking compartment.
  - → "Drying function", Page 37

**Note:** If you open the appliance door during operation, the operation stops. If you close the appliance door, you must continue the operation. If you have changed the basic setting for this, make sure that the microwave does not resume operation without food inside.

→ "Basic settings", Page 29

#### Changing the microwave output setting

You can change the microwave output at any time.

- 1. Press the microwave output setting.
- 2. Change the microwave output setting.
- 3. Press "Apply".

#### Changing the cooking time

You can change the cooking time at any time.

- 1. Press the cooking time.
- 2. Change the cooking time using the adjustment line or enter it directly via the number field **E**.
- 3. Press "Apply".

#### 12.4 Setting added microwave

#### Note

Note the correct way to operate the microwave:

- → "Safety", Page 2
- → "Preventing material damage", Page 7
- → "Microwave output settings", Page 12
- → "Cookware and accessories with microwave", Page 21

Requirement: Observe the information about the respective operating mode.

- → "Setting options with the microwave", Page 22
- 1. Press the operating mode that you require.
- 2. Implement the settings for the operating mode, e.g. type of heating and temperature.
- 3. Press "Added microwave" ≋.
- 4. Press the required microwave output setting.
- 5. Press "Cooking time" and set the cooking time.

- **6.** Use "Start" to start the operation.
- ▼ The appliance starts to heat and the time counts down.
- ✓ Once the cooking time has elapsed, a signal tone sounds. A notification appears on the display confirming that the operation has finished.
- 7. Once the cooking time has elapsed:
  - ► If required, you can select other settings and restart the operation.
  - ▶ When the food is ready, use ① to switch the appliance off.

## Changing added microwave

You can change or deactivate the added microwave at any time.

- 1. Press the microwave output setting.
- 2. Change or deactivate the microwave output setting.
- 3. Press "Apply".

## 13 Ventilation function "Crisp Finish"

The ventilation function "Crisp Finish" 

extracts moisture from the cooking compartment so that your meal will be more crispy.

Hot steam that may escape when the appliance door is opened is reduced.

### 13.1 Suitable types of heating with the ventilation function

Only certain types of heating are suitable for the ventilation function.

You can use the ventilation function for the following types of heating:

- 4D hot air
- Top/bottom heating □
- Intensive heat
- Pizza setting
- Circulated air grilling 🖫

## 13.2 Setting the ventilation function

You can activate the ventilation function at any time, even after the start of the operation.

1. Set a suitable type of heating and a temperature. If required, you can select other settings and combine with the ventilation function.

The added steam cannot be combined with the ventilation function.

- 2. Press "Crisp Finish".
- ✓ "On" is in the tile.
- 3. Press "Start" to start the operation.
- The appliance starts heating.
- The setting values are shown on the display.
- **4.** When the food is ready, use  $\bigcirc$  to switch the appliance off.

Note: Amplified fan noises can be heard while the appliance is in operation.

#### Cancelling the ventilation function

You can switch off the ventilation function at any time.

- ▶ Press "Crisp Finish" \( \overline{\overl
- The operation continues without the ventilation func-

## 14 Meat probe

Cook with precision by inserting the meat probe - into the food and setting a core temperature on the appliance. The meat probe measures the core temperature inside the food. Once the set core temperature has been reached in the food, the appliance automatically stops heating.

## 14.1 Suitable types of heating with the meat

Only certain types of heating are suitable for use with the meat probe.

You can use the meat probe with the following types of heating:

- 4D hot air
- Top/bottom heating□
- Bottom heat □
- Top/bottom heat gentle □
- Hot air gentle &
- Circulated air grilling 3
- Pizza setting
- Keeping warm SS
- Intensive heat ■
- Slow cooking ...
- Reheating 3

#### 14.2 Inserting the meat probe

Use the meat probe supplied or order a suitable meat probe from our customer service.

#### 

Using the wrong meat probe could damage the insulation.

▶ Only use the meat probe for this specific appliance.

#### **ATTENTION**

Otherwise the meat probe may be damaged.

- ▶ Do not trap the cable of the meat probe.
- ▶ Do not use cookware with a lid.
- ► To prevent the meat probe from being damaged by excessive heat, there must be a gap of a few centimetres between the grill element and the meat probe. The meat may expand during the cooking process.

If, during operation with the microwave, the tip of the meat probe is not fully inside the food, sparks will be created.

▶ Insert the meat probe fully into the food.

## 

The meat probe is sharp.


- ► Handle the meat probe with care.
- 1. Insert the meat probe into the food.

The meat probe has three measuring points. Ensure that at least the middle measuring point is inserted in the food.

Thin	Insert the meat probe into the thickest part
•	of the meat from the side.
meat	

Thick pieces of meat


Insert the meat probe diagonally into the meat from above, pushing it in as far as possible.



**Note:** If you want to turn the food, insert the meat probe into the side of the food so that it does not need to be removed when turning.

**Poultry** 


Insert the meat probe into the thickest part of the breast, pushing it in as far as possible. The meat probe can be inserted horizontally or vertically depending on the size and shape of the poultry.



Turn the poultry and place it on the wire rack breast-side down.

Fish

When cooking whole fish, insert the meat probe behind the fish's head in the direction of the spine, pushing it in as far as possible.



Place the fish on the wire rack in the swimming position without turning it, e.g. using half a potato as a support.

- **2.** Place the food with the meat probe into the cooking compartment.
- **3.** Plug the meat probe into the socket on the left-hand side of the cooking compartment.

**Note:** Do not remove the meat probe when turning the food. Once you have turned the food, check that the meat probe is correctly positioned in the food.

## 14.3 Setting the meat probe

You can set a core temperature of between 30  $^{\circ}\text{C}$  and 99  $^{\circ}\text{C}.$ 

#### Requirements

- The food with the meat probe is in the cooking compartment.
- The meat probe is inserted in the cooking compartment.
- 1. Press "Types of heating".
- 2. Press the type of heating that you want to use.
- 3. Set the cooking compartment temperature using the adjustment line or enter it directly via the number field

Set the cooking compartment temperature at least 10 °C higher than the core temperature.

Do not set the cooking compartment temperature to higher than 250 °C.

- 4. Press "Meat probe".
- 5. Set the core temperature using the adjustment line or enter it directly via the number field ട. If required, use 5 to reset the setting value.
- **6.** Press "Start" to start the operation.
- The appliance starts heating.
- ▼ The setting values and how long the appliance has already been in operation are shown on the display.
- Once the food reaches the core temperature, a signal sounds. A notification appears on the display confirming that the operation has finished. The appliance stops heating. With the slow cooking type of heating, the appliance continues to heat.

#### 7. MARNING – Risk of burns!

The cooking compartment, accessories and meat probe become very hot.

Always use oven gloves to remove hot accessories and the meat probe from the cooking compartment. When the core temperature is reached:

- ► If required, you can select other settings and restart the operation.
- ► When the food is ready, use ① to switch the appliance off.
- Pull the meat probe out of the socket in the cooking compartment.
- ► Pull the meat probe out of the food and remove it from the cooking compartment.

#### Tips

- You can also combine the meat probe with a different operating mode, e.g.:
  - → "Steaming", Page 18
  - → "Microwave", Page 21
  - → "Dishes", Page 25
- You can use the meat probe even if no core temperature is set. You can read off the core temperature of the food on the display and manually end the operation, if required.

#### Changing the temperature

You can change the cooking compartment temperature and the core temperature at any time after starting the operation.

- **1.** Press the cooking compartment temperature or core temperature.
- 2. Set the temperature using the adjustment line or enter it directly via the number field \( \ext{\varphi} \).
- 3. Press "Apply".

## Changing the type of heating

When you change the type of heating, the other settings are also reset.

- 1. Press "Stop".
- **2.** Press  $\leftarrow$ .
- 3. Press the type of heating that you want to use.
- 4. Reset the operation and use "Start" to start.

#### 14.4 Core temperatures of different foods

This is where you can find the suggested core temperatures for different foods.

These suggestions depend on the quality and the size/shape of the food. Do not use frozen food.

Poultry	Core temperature
-	in °C
Chicken	80 - 85
Chicken breast	75 - 80
Duck	80 - 85
Duck breast, medium rare	55 - 60
Turkey	80 - 85
Turkey breast	80 - 85
Goose	80 - 90
Pork	Core temperature in °C
Shoulder of pork	85 - 90
Fillet of pork, medium rare	62 - 70
Pork loin, well done	72 - 80
Beef	Core temperature in °C
Tenderloin or sirloin, rare	45 - 52
Tenderloin or sirloin, medium rare	55 - 62
Tenderloin or sirloin, well done	65 - 75
Veal	Core temperature in °C
	Core temperature
Veal	Core temperature in °C
Veal  Joint of veal or hock, lean	Core temperature in °C 75 - 80
Veal  Joint of veal or hock, lean  Joint of veal, shoulder	Core temperature in °C 75 - 80 75 - 80
Veal  Joint of veal or hock, lean  Joint of veal, shoulder  Veal knuckle	Core temperature in °C 75 - 80 75 - 80 85 - 90  Core temperature
Veal  Joint of veal or hock, lean  Joint of veal, shoulder  Veal knuckle  Lamb	Core temperature in °C 75 - 80 75 - 80 85 - 90  Core temperature in °C
Veal  Joint of veal or hock, lean Joint of veal, shoulder  Veal knuckle  Lamb  Leg of lamb, medium rare	Core temperature in °C 75 - 80 75 - 80 85 - 90  Core temperature in °C 60 - 65
Veal  Joint of veal or hock, lean Joint of veal, shoulder  Veal knuckle  Lamb  Leg of lamb, medium rare Leg of lamb, well done	Core temperature in °C  75 - 80  75 - 80  85 - 90  Core temperature in °C  60 - 65  70 - 80
Veal  Joint of veal or hock, lean Joint of veal, shoulder  Veal knuckle  Lamb  Leg of lamb, medium rare Leg of lamb, well done Saddle of lamb, medium rare	Core temperature in °C  75 - 80  75 - 80  85 - 90  Core temperature in °C  60 - 65  70 - 80  55 - 60  Core temperature
Veal  Joint of veal or hock, lean  Joint of veal, shoulder  Veal knuckle  Lamb  Leg of lamb, medium rare  Leg of lamb, well done  Saddle of lamb, medium rare  Fish	Core temperature in °C  75 - 80  75 - 80  85 - 90  Core temperature in °C  60 - 65  70 - 80  55 - 60  Core temperature in °C
Veal  Joint of veal or hock, lean Joint of veal, shoulder  Veal knuckle  Lamb  Leg of lamb, medium rare Leg of lamb, well done Saddle of lamb, medium rare  Fish  Fish, whole	Core temperature in °C  75 - 80  75 - 80  85 - 90  Core temperature in °C  60 - 65  70 - 80  55 - 60  Core temperature in °C  65 - 70
Veal  Joint of veal or hock, lean Joint of veal, shoulder  Veal knuckle  Lamb  Leg of lamb, medium rare Leg of lamb, well done Saddle of lamb, medium rare  Fish  Fish, whole Fish fillet	Core temperature in °C  75 - 80  75 - 80  85 - 90  Core temperature in °C  60 - 65  70 - 80  55 - 60  Core temperature in °C  65 - 70  60 - 65  Core temperature in °C

## 15 Dishes

The "Dishes" operating mode helps you to use your appliance to prepare different meals by selecting the optimum settings automatically.

#### 15.1 Cookware for dishes

The cooking result depends on the composition of the meat and the size of cookware.

You should therefore use heat-resistant cookware that is suitable for temperatures up to 300 °C. Glass or glass ceramic cookware is best. The joint should cover approx. 2/3 of the cookware base.

Cookware made from the following material is not suitable:

- Bright, shiny aluminium
- Unglazed clay
- Plastic or plastic handles

**Note:** For some dishes, the appliance switches on the microwave. A notification appears in the display stating that you should use cookware that is suitable for microwave use.

→ "Cookware and accessories with microwave", Page 21

### 15.2 Setting options for the dishes

To cook the dishes perfectly, the appliance uses different settings depending on the dish.

The display shows you the settings that are used. You can adjust certain settings. Follow the instructions on the display.

**Note:** The cooking result depends on the quality and composition of the food. Use fresh and, ideally, chilled food. Use frozen food straight from the freezer.

#### Tips and information about the settings

If you set a dish, the display shows relevant information for this dish, e.g.:

- Suitable shelf position
- Suitable accessory or cookware
- Added liquid
- Time for turning or stirring
   When this time is reached, a signal sounds.

To call up the information, press  $\blacksquare$ . Some notes are displayed automatically.

#### **Programmes**

The ideal type of heating, temperature and cooking time are preset for programmes.

To achieve an optimal cooking result, you must also set the weight, thickness or the cooking level. You can set the weight only in the intended range.

Unless otherwise indicated, set the total weight for your dish.

#### Recommended settings

For the recommended settings, the optimum type of heating is preset as a fixed value.

You can adjust the preset temperature and the cooking time.

#### **Cooking methods**

For some dishes, you can select a preferred cooking method.

Select a cooking method with the following value for conventional cooking:

Classic

Dishes with meat probe

You can use the meat probe — for some dishes.

Select a cooking method that contains the following value:

To the exact degree

You can adjust the temperature and the core temperature.

→ "Meat probe", Page 23

Dishes with steam

For some dishes, you can select a cooking method with steam  $\oplus$ . The food is cooked gently.

Select a cooking method with the following values for cooking with added steam:

- Tender and juicy
   Tender and crispy
- Tender and crispyJuicy
- Juicy and light
- Extra light Extra light and glossy
- Glossy and crispy Golden and crispy

- As if freshly baked As if freshly cooked
- Gentle

Observe the information on operating with steam.

→ "Steaming", Page 18

Dishes with microwave

For some dishes, you can select a cooking method with microwave  $\approxeq$ . The cooking time is reduced.

Select a cooking method with the following values:

- Faster
- Cooked gently and quickly

Observe the information on operating with microwave. 
→ "Microwave", Page 21

### Individual browning

For some dishes, you can set the individual browning  $\ensuremath{\mathbb{Z}}$  of your meal.

The browning sensor uses the camera in the cooking compartment to monitor the cooking process, and the appliance ends the operation once the set level of browning is reached.

To use individual browning, activate the camera in the basic settings and connect your appliance to Home Connect.

→ "Basic settings", Page 29

#### **Notes**

- To obtain sharp images for the browning sensor and to achieve consistently good results when browning your food, regularly check the camera lens and light for dirt and, if required, clean it.
  - → "Cleaning the appliance", Page 34
- In order to measure the level of browning, the appliance captures an initial photo of the food when the operation starts. Only start the operation when the food is in the cooking compartment.
- The most suitable foods are those whose level of browning significantly changes during cooking, e.g. light-coloured bread rolls.
- After starting the operation, you should no longer change the food or its position in the cooking compartment.
- Depending on the appliance type/software status, you must first download this function to your appliance. You can find more information in the Home Connect app.

#### Baking sensor

Some dishes are suitable for cooking with the baking sensor  $\boxdot$ . You do not have to implement any further settings.

The baking sensor monitors the baking process in the cooking compartment. The appliance regulates the settings automatically and ends the operation once the meal is ready.

#### Notes

- Do not use the baking sensor if the dish is already pre-baked. The baking result would no longer be satisfactory.
- No longer open the appliance door approx. 5 minutes after starting the operation with the baking sensor.
   The baking sensor mode stops.

If you have to open the appliance door, restart the operation afterwards without the cooking sensor or can-

- cel the operation and set it manually. Monitor the cooking process until the food is ready.
- To achieve an optimal baking result, use dark-coloured metal baking tins.

#### **ATTENTION**

Using silicone moulds or any film, covers or accessories that contain silicone could damage the baking sensor. Damage may occur even if the baking sensor is not active.

- ► Do not use silicone moulds or any film, covers or accessories that contain silicone.
- Never place objects made of silicone in the cooking compartment.

#### Remaining time forecast for the operation

If your appliance is connected to Home Connect, the appliance can forecast the expected remaining time for the cooking process.

The initial remaining time appears on the display after approx. 1 minute. The remaining time is continually recalculated and updated.

**Note:** The remaining time forecast is not available for all dishes.

#### 15.3 Overview of the dishes

You can find out which individual dishes are available to you on the appliance when you call up the operating mode. The dishes depend on the features of your appliance

The dishes are sorted by category and food.

**Note:** In the basic settings, you can regionally specialise the displayed dishes.

→ "Basic settings", Page 29

Category	Food
Baking sensor	Cakes Small baked items Bread, bread rolls Savoury cakes, pizza, quiche Note: This only contains dishes for cook-
	ing with the baking sensor.
Individual browning	Bread rolls (crispy bread rolls) Pizza Lasagne, deep Lasagne, shallow
	<b>Note:</b> This only includes dishes for cooking with individual browning.
Cakes	Cakes in tins Cakes on a baking tray Small baked items Biscuits
Bread, bread rolls	Bread Bread rolls
Pizza, sa- voury cakes	Pizza Savoury cakes, quiche
Bakes, soufflés	Bake, savoury, fresh, cooked ingredients Potato gratin, raw ingredients, 4 cm deep Lasagne, fresh Lasagne, chilled Bake, sweet, fresh Fruit crumble

Category	Food
	Soufflés in individual moulds
	Yorkshire pudding
Poultry	Chicken
	Duck, goose
	Turkey
Meat	Pork
	Beef
	Veal
	Lamb
	Game
	Meat dishes
Fish.	Fish, whole
	Fish fillet
Frozen	Pizza
products	Bread rolls
	Bakes
	Potato products
	Poultry, fish
Side dishes,	Vegetables
vegetables	Potatoes
	Rice
	Cereals
Reheating,	Vegetables
crisping up	Menu
	Baked items
	Side dishes
Defrosting	Bread, bread rolls
food	Cakes
	Meat, poultry
	Fish

#### 15.4 Setting a dish

- 1. Press "Dishes".
- 2. Press the required category.
- **3.** Press the required food.
- 4. Press the required dish.

**Tip:** For some dishes, you can select a preferred cooking method.

- → "Setting options for the dishes", Page 26
- ▼ The settings for the dish appear on the display.
- **5.** Adjust the settings if required.

You can adjust only certain settings depending on the dish.

- → "Setting options for the dishes", Page 26
- **6.** For information about the accessory and shelf position, for example, press <u>ii</u>.
- 7. Press "Start" to start the operation.
- The appliance starts to heat and the time counts down.
- ✓ For dishes with a baking sensor, or when using a roasting sensor (depending on the appliance equipment), no cooking time is displayed. The setting values and how long the appliance has already been in operation are shown on the display. If the appliance is connected to Home Connect, the forecast time remaining is displayed.
  - → "Remaining time forecast for the operation", Page 27
- Once the dish is ready, a signal sounds. The appliance stops heating.

- 8. Once the cooking time has elapsed:
  - ► If required, you can select other settings and restart the operation.
  - ► When the food is ready, use ① to switch the appliance off.

#### 15.5 Automatic switch-off function

The automatic switch-off function of for the dishes allows you to bake and fry without any stress.

When the operation has finished, the appliance automatically stops heating.

To achieve an optimal cooking result, remove your dish from the cooking compartment once the operation has finished.

## 16 Food recoginition

The appliance uses a camera to detect a large number of dishes and types of food in the cooking compartment.

Food recognition starts automatically after you close the appliance door. The appliance provides you with suggested suitable programmed dishes or settings.

To use food recognition, activate the camera and food recognition in the basic settings. Connect your appliance to Home Connect.

→ "Basic settings", Page 29

#### **Notes**

- For food recognition and to achieve consistently good results, regularly check the camera lens and light for dirt and clean, if required.
  - → "Cleaning the appliance", Page 34
- Depending on the appliance type/software status, you must first download this function to your appliance.
   You can find more information in the Home Connect app.

## 16.1 Setting food recoginition

When you close the appliance door, food recognition starts after the appliance is switched on or if the menu is opened and no other mode is running.

- 1. Place the food in the cooking compartment.
- 2. Close the appliance door.
- Food recoginition starts.

Press the right dish or the setting in the display and, if necessary, select the cooking method you wish to use.

**Note:** If the appliance does not detect any food, a notification appears on the display. Check the camera and light for dirt as well as the positioning of the food in the cooking compartment. Food recognition starts again after you close the appliance door. If the appliance still does not detect any food, no default settings for it are available. Set the appliance as usual.

- 4. Press "Apply".
- **5.** Adjust the settings if required.
  - → "Setting options for the dishes", Page 26
  - → "Basic operation", Page 15
- 6. Press "Start" to start the operation.
- ✓ The appliance starts heating.
- **7.** If the operation is ended:
  - If required, you can select other settings and restart the operation.
  - When the food is ready, use ① to switch the appliance off

**Note:** If a microwave cover is detected, Reheat is suggested.

#### **Cancelling dish recognition**

- ► To cancel dish recognition, press on the display.
  - ► If dish recognition has already taken place, press ←.
- ▼ The menu is displayed.

## 17 Favourites

In the "Favourites", you can save your settings and use these again.

**Note:** Depending on the appliance type/software status, you must first download this function to your appliance. You can find more information in the Home Connect app.

## 17.1 Saving favourites

You can save up to 30 different operating modes as vour favourites.

- **1.** Next to the title of the operating mode, press  $\diamondsuit$ .
- **2.** If required, change the title of the favourite using the keyboard on the display.
- 3. Press "Apply".

## 17.2 Selecting favourites

If you have saved favourites, you can use these to set the operation.

- 1. Press "Favourites".
- 2. Press the required favourites.
- 3. If required, you can change the settings.
- 4. Use "Start" to start the operation.
- ▼ The adjustment values are shown on the display.

#### Note

Pay attention to the specifications for the various operating modes:

- → "Steaming", Page 18
- → "Microwave", Page 21
- → "Ventilation function Crisp Finish", Page 23
- → "Meat probe", Page 23

#### 17.3 Changing favourites

You can change your saved favourites at any time.

- 1. Press "Favourites".
- 2. Press the required favourites.
- **3.** Next to the title of the favourite, press  $\mathcal{O}$ .
- **4.** Change the settings or the title of the favourite.
- **5.** Confirm the change.

#### **Sorting favourites**

- 1. Press "Favourites".
- **2.** Next to the title "Favourites", press  $\mathcal{O}$ .
- 3. Press and hold the tile for the required favourite and drag it to a different position.

## **Deleting favourites**

- 1. Press "Favourites".
- 2. Press ★ for the required favourite.
- 3. Confirm the deletion.

**Display** 

## 18 Childproof lock

You can secure your appliance to prevent children from accidentally switching it on or changing the settings.

## 18.1 Activate the childproof lock

The childproof lock can be activated regardless of whether the appliance is on or off.

- ▶ Press and hold 🖘 for approx. 4 seconds to activate the childproof lock.
- A confirmation message appears on the display.
- The control panel is locked. The appliance can only be switched off using .

## 18.2 Deactivating the childproof lock

You can deactivate the childproof lock at any time.

- ► Press and hold 🗝 for approx. 4 seconds to deactivate the childproof lock.
- ✓ A confirmation message appears on the display.

Selection

## 19 Basic settings

You can configure the basic settings for your appliance to meet your needs.

## 19.1 Overview of the basic settings

Here you can find an overview of the basic settings and factory settings. The basic settings depend on the features of your appliance.

You can find more information about the individual basic settings on the display using i.

Basic settings	Selection	
Language	See selection on appliance	
Home Connect	Connect the oven to a mobile device and remotely control it.  → "Home Connect ", Page 31	
Clock	Time in 24-hour format	
Date	Date in the format DD.MM.YYYY	
Display	Selection	
Brightness	■ Levels 1, 2, 3, 4 and 5 <sup>1</sup>	
Standby screen	<ul> <li>On for a limited time</li> <li>On (this setting increases energy consumption)</li> <li>Off <sup>1</sup></li> </ul>	

Clock	<ul> <li>Digital + date <sup>1</sup></li> <li>Digital</li> <li>Analogue + date</li> <li>Analogue</li> </ul>
Alignment	<ul> <li>Align the display horizontally and vertically</li> </ul>
Tone	Selection
Button tone	<ul> <li>On <sup>1</sup></li> <li>Off</li> </ul>
Volume	■ Levels 1, 2, 3, 4 and 5 <sup>1</sup>
Signal tone	<ul> <li>Very short duration</li> <li>Short duration</li> <li>Medium duration <sup>1</sup></li> <li>Long duration</li> </ul>
Appliance set- tings	Selection
Fan run-on time	<ul> <li>Minimum</li> <li>Recommended <sup>1</sup></li> <li>Long</li> <li>Very long</li> </ul>
Lighting	<ul> <li>On when cooking and when opening the door <sup>1</sup></li> <li>Only when the door is opened</li> <li>Always off</li> </ul>

Factory setting (may vary according to model)

Appliance set- tings	Selection
Microwave output presetting	<ul> <li>90 W</li> <li>180 W</li> <li>360 W</li> <li>600 W</li> <li>Boost 1</li> </ul>
Continue to microwave	<ul> <li>On</li> <li>Off <sup>1</sup></li> </ul>
Dry microwave	<ul> <li>On ¹</li> <li>Off</li> </ul>
Water hardness	<ul> <li>4 (very hard) 1</li> <li>3 (hard)</li> <li>2 (medium)</li> <li>1 (soft)</li> <li>0 (softened)</li> </ul>
Height above sea level	If calibration takes place automatically, this basic setting disappears.  • 0 m - 300 m  • 300m - 600m  • 600m - 900m  • 900m - 1200m  • 1200m - 1500m  • 1500m - 1800m  • 1800m - 2100m  • Height above sea level unknown 1 (calibration required)
Camera	<ul> <li>On</li> <li>Off <sup>1</sup></li> </ul>
food recoginition	<ul> <li>On, recommended (this setting increases energy consumption)</li> <li>Off <sup>1</sup></li> <li>On, reduced power (food recoginition requires more time after switching on)</li> </ul>
Personalisa- tion	Selection
Brand logo	<ul> <li>Display <sup>1</sup></li> <li>Do not display</li> </ul>
Operation after switch-on	<ul> <li>Main menu <sup>1</sup></li> <li>Types of heating</li> <li>Microwave</li> <li>Steaming</li> <li>Dishes</li> <li>Favourites</li> </ul>
Elapsed cook- ing time	<ul> <li>Display <sup>1</sup></li> <li>Do not display</li> </ul>
Microwave baking tray	<ul> <li>On ¹</li> <li>Off</li> </ul>
Dishes	<ul> <li>All <sup>1</sup></li> <li>No pork</li> <li>Kosher only</li> </ul>
Regional dishes	<ul> <li>All <sup>1</sup></li> <li>European dishes</li> <li>British dishes</li> </ul>

Selection
<ul> <li>Door lock + keylock</li> <li>Keylock only <sup>1</sup></li> <li>Deactivated</li> </ul>
<ul> <li>On <sup>1</sup></li> <li>Off</li> </ul>
Selection
■ Restore
<ul> <li>Appliance information</li> </ul>

## 19.2 Changing the basic settings

- 1. Press in the status bar.
- 2. Press the required basic settings area.
- 3. Press the required basic setting.
- 4. Press to select the required basic setting.
- ▼ The change is applied directly for most basic settings.
- **5.** To change additional basic settings, use  $\leftarrow$  to go back and select a different basic setting.
- **6.** To exit the basic settings, use X to go back to the main menu or switch off the appliance using  $\bigcirc$ .
- ▼ The changes are saved.

**Note:** Your changes to the basic settings will be retained even after a power failure.

<sup>&</sup>lt;sup>1</sup> Factory setting (may vary according to model)

## 20 Home Connect

This appliance is network-capable. Connecting your appliance to a mobile device lets you control its functions via the Home Connect app, adjust its basic settings and monitor its operating status.

The Home Connect services are not available in every country. The availability of the Home Connect function depends on the availability of Home Connect services in your country. You can find information about this at: www.home-connect.com.

The Home Connect app guides you through the entire login process. Follow the instructions in the Home Connect app to configure the settings.

Tip: Please also follow the instructions in the Home Connect app.

#### **Notes**

- Please note the safety precautions in this instruction manual and make sure that they are also observed when operating the appliance via the Home Connect app.
  - → "Safety", Page 2
- Operating the appliance on the appliance itself always takes priority. During this time it is not possible to operate the appliance using the Home Connect
- In networked standby mode, the appliance requires a maximum of 2 W.

## 20.1 Setting up Home Connect

#### Requirements

- The appliance is connected to the power supply and is switched on.
- You have a mobile device with a current version of the iOS or Android operating system, e.g. a smartphone.
- The appliance is receiving signals from the WLAN home network (Wi-Fi) at its installation location.
- The mobile device and the appliance are within range of your home network's Wi-Fi signal.
- **1.** Scan the following QR code.



You can install the Home Connect app and connect your appliance via the QR code.

**2.** Follow the instructions in the Home Connect app.

## 20.2 Home Connect settings

You can adjust the Home Connect settings and network settings in your appliance's basic settings. Which settings the display shows will depend on whether Home Connect has been set up and whether the appliance is connected to your home network.

Basic setting	Possible settings	Explanation
Home Connect assistant	Start the assistant Disconnect	You can connect your appliance to the Home Connect app via the Home Connect assistant.
		<b>Note:</b> If you are using the Home Connect assistant for the first time, only the "Start assistant" setting is available.
Wi-Fi	On Off	You can use the Wi-Fi to switch off the network connection for your appliance. When you have connected successfully once, you can deactivate the Wi-Fi and not lose your detailed data. As soon as you activate Wi-Fi again, the appliance connects automatically.
		<b>Note:</b> In networked standby mode, the appliance requires a maximum of 2 W.
Remote control status	Monitoring Manual remote start Permanent remote start	During monitoring, you can only view the operating status of the appliance in the app.  If you convert from monitoring or permanent remote start to manual remote start, you must activate the remote start each time. You can open the appliance door within 15 minutes of having activated remote start. Remote start will not be deactivated by this. Once 15 minutes have elapsed, opening the appliance door will deactivate manual remote start.  For permanent remote start, you can start and operate the appliance remotely at any time. If you often operate the appliance remotely, it is helpful to set the remote start to "Permanent".

## 20.3 Operating the appliance with the **Home Connect app**

You can use the Home Connect app to set and start the appliance remotely.

#### 

Combustible objects that are left in the cooking compartment may catch fire.

- Never store combustible objects in the cooking compartment.
- ▶ If smoke is emitted, the appliance must be switched off or the plug must be pulled out and the door must be held closed in order to stifle any flames.

#### Requirements

- The appliance is switched off.
- The appliance is connected to the home network and to the Home Connect app.
- In order to be able to set the appliance via the app. the manual or permanent remote start must be selected in the "Remote control status" basic setting.
- 1. To activate manual remote start, press :. You only have to confirm on the oven if you are switching from monitoring or permanent remote start to manual remote start.
  - With permanent remote start, you do not need to confirm on the oven.
- 2. Configure a setting in the Home Connect app and send it to the appliance.

#### **Notes**

- When you start the oven using the controls on the appliance itself, the remote start function is activated automatically. You can use the Home Connect app to adjust the settings or start a new pro-
- You can open the appliance door within 15 minutes of having activated remote start. Remote start will not be deactivated by this. Once 15 minutes have elapsed, opening the appliance door will deactivate manual remote start.

## 20.4 Software update

Your appliance's software can be updated using the software update function, e.g. for the purposes of optimisation, troubleshooting or security updates. This may lead to minor changes of visualizations and operation in the display.

To do this, you must be a registered Home Connect user, have installed the app on your mobile device and be connected to the Home Connect server. As soon as a software update is available, you will be informed via the Home Connect app and will be able to

start the software update via the app. Once the update has been successfully downloaded, you can start installing it via the Home Connect app if you are in your home network (Wi-Fi). The Home Connect app informs you once installation is successful.

#### Notes

- The software update consists of two steps.
  - The first step is the download.
  - The second step is the installation on your appli-
- You can continue to use your appliance as normal while updates are downloading. Depending on your personal settings in the app, software updates can also be set to download automatically.
- Installation takes a few minutes. You cannot use your appliance during installation.
- We recommend that you install security updates as soon as possible.

## 20.5 Remote diagnostics

Customer Service can use Remote Diagnostics to access your appliance if you contact them, have your appliance connected to the Home Connect server and if Remote Diagnostics is available in the country in which you are using the appliance.

Tip: For further information and details about the availability of Remote Diagnostics in your country, please visit the service/support section of your local website: www.home-connect.com.

### 20.6 Data protection

Please see the information on data protection.

The first time your appliance is registered on a home network connected to the Internet, your appliance will transmit the following types of data to the Home Connect server (initial registration):

- Unique appliance identification (consisting of appliance codes as well as the MAC address of the installed Wi-Fi communication module).
- Security certificate of the Wi-Fi communication module (to ensure a secure data connection).
- The current software and hardware version of your appliance.
- Status of any previous resetting to factory settings.

This initial registration prepares the Home Connect functions for use and is only required when you want to use the Home Connect functions for the first time.

Note: Please note that the Home Connect functions can only be utilised with the Home Connect app. Information on data protection can be retrieved in the Home Connect app.

## 21 Cleaning and servicing

To keep your appliance working efficiently for a long time, it is important to clean and maintain it carefully.

### 21.1 Cleaning products

In order to avoid damaging the various oven surfaces on the appliance, do not use unsuitable cleaning products.

#### ⚠ WARNING – Risk of electric shock!

An ingress of moisture can cause an electric shock.

► Do not use steam- or high-pressure cleaners to clean the appliance.

#### **ATTENTION**

Unsuitable cleaning agents damage the surfaces of the appliance.

- Do not use harsh or abrasive cleaning products.
- Do not use cleaning products with a high alcohol con-
- Do not use hard scouring pads or cleaning sponges.
- ► Do not use any special cleaners for cleaning the appliance while it is hot.

Using oven cleaner in a hot cooking compartment damages the enamel.

- ► Never use oven cleaner in the cooking compartment when it is still warm.
- ► Remove all food remnants from the cooking compartment and the appliance door before you next heat up the appliance.

If different cleaning agents are mixed together, there may be a chemical reaction between these.

- ► Do not mix cleaning agents.
- ► Completely remove any cleaning agent residue. Salt contained in new sponge cloths may damage sur-
- Wash new sponge cloths thoroughly before use.

#### Suitable cleaning agents

Only use cleaning agents that are suitable for the different surfaces on your appliance.

Follow the instructions on cleaning the appliance.

→ "Cleaning the appliance", Page 34

#### **Appliance front**

Surface	Suitable cleaning agents	Information
Stainless steel	<ul> <li>Hot soapy water</li> <li>Special stainless steel cleaning products suitable for hot surfaces</li> </ul>	To prevent corrosion, remove any patches of limescale, grease, starch or albumin (e.g. egg white) from stainless steel surfaces immediately.  Apply a thin layer of the stainless steel cleaning product.
Plastic or painted surfaces	<ul><li>Hot soapy water</li></ul>	Do not use glass cleaner or a glass scraper.  To avoid permanent stains, immediately remove any descaling agent that gets onto the surface.
Glass	<ul> <li>Hot soapy water</li> </ul>	Do not use glass cleaner or a glass scraper.

#### **Appliance door**

Range	Suitable cleaning agents	Information
Door panels  Hot soapy water  Oven cleaner  Steel wool	<ul> <li>Hot soapy water</li> </ul>	Do not use a glass scraper.
		<b>Tip:</b> Remove the door panels in order to clean them thoroughly. → "Appliance door", Page 38
steel: Stainl • Made	<ul><li>Made of stainless steel:</li></ul>	Do not use glass cleaner or a glass scraper. Do not use stainless steel care products.
	Stainless steel cleaner  Made from plastic: Hot soapy water	<b>Tip:</b> Remove the door cover for thorough cleaning.  → "Appliance door", Page 38
Stainless steel interior door frame	Stainless steel cleaner	Discolouration can be removed using stainless steel cleaner.  Do not use stainless steel care products.
Door handle	<ul> <li>Hot soapy water</li> </ul>	To avoid permanent stains, immediately remove any descaling agent that gets onto the surface.

#### Cooking compartment

Range	Suitable cleaning agents	Information
Enamel surfaces	<ul><li>Hot soapy water</li><li>Vinegar solution</li><li>Oven cleaner</li><li>Steel wool</li></ul>	Soak any heavily soiled areas and use a brush or steel wool. Leave the appliance door open to dry the cooking compartment after cleaning it.

## 21.2 Cleaning the appliance

In order to avoid damaging the appliance, you must clean your appliance only as specified, and with suitable cleaning products.

## **⚠** WARNING – Risk of burns!

The appliance and its parts that can be touched become hot during use.

- Caution should be exercised here in order to avoid touching heating elements.
- Young children under 8 years of age must be kept away from the appliance.

#### ⚠ WARNING – Risk of fire!

Loose food remnants, fat and meat juices may catch fire.

► Before using the appliance, remove the worst of the food residues and remnants from the cooking compartment, heating elements and accessories.

**Requirement:** Read the information on cleaning products.

→ "Cleaning products", Page 32

- Clean the appliance using hot soapy water and a dish cloth.
  - For some surfaces, you can use alternative cleaning agents.
    - → "Suitable cleaning agents", Page 33
- 2. Dry with a soft cloth.

#### Cleaning the camera lens

To ensure that the camera in the cooking compartment provides sharp images for a long time, regularly clean the camera lens.

**Note:** The camera lens is located at the top left in the back wall of the cooking compartment.

#### **ATTENTION**

Sitting or placing objects on the appliance door may damage it.

- Do not place, hang or support objects on the appliance door.
- Do not place cookware or accessories on the appliance door.

The camera lens may be scratched or cloudy.

- ▶ Do not any use rough sponges.
- ► Do not use stainless steel wool.
- Do not use cleaning agents or descalers containing acids.

- ► Only use oven cleaner when the cooking compartment is cold and in accordance with the manufacturer's specification.
- A glass scraper damages the surfaces of the appliance.
- ► Only use glass scrapers to clean the camera lens in the cooking compartment.

**Requirement:** The appliance has cooled down.

- 1. Wipe the camera lens with a soft cloth once the appliance operation has ended.
- 2. Use a glass scraper to remove any heavy soiling.

Note: The cleaning function "Pyrolytic activeClean" also cleans the camera lens.

## 22 "Pyrolytic activeClean" cleaning function

With the "Pyrolytic activeClean" cleaning function, the cooking compartment is cleaned virtually automatically. Use the cleaning function to clean the cooking compartment every two to three months. You can use the cleaning function more often, if required.

The cleaning function requires approx. 3.9 - 4.8 kilowatt hours.

## 22.1 Preparing the appliance for the cleaning function

To achieve a good cleaning result and prevent damage, prepare the appliance carefully.

#### ⚠ WARNING – Risk of fire!

Combustible objects that are left in the cooking compartment may catch fire.

- ▶ Never store combustible objects in the cooking compartment.
- ▶ If smoke is emitted, the appliance must be switched off or the plug must be pulled out and the door must be held closed in order to stifle any flames.

Loose food remnants, fat and meat juices may catch fire when the cleaning function is in progress.

- Before you start the cleaning function, always remove coarse dirt from the cooking compartment.
- Never clean accessories at the same time.

The outside of the appliance gets very hot when the cleaning function is in progress.

- Never hang combustible objects, e.g. tea towels, on the door handle.
- Leave the front of the appliance clear.
- Keep children at a safe distance.

If the door seal is damaged, a large amount of heat is generated around the door.

- ▶ Do not scrub or remove the seal.
- Never operate the appliance if the seal is damaged or
- 1. Remove the water tank from the appliance.
- 2. Remove accessories and cookware from the cooking compartment.

You can also clean the shelf supports along with the pull-out rails.

**Tip:** Also remove the shelf supports to save energy and achieve a better cleaning result in the cooking compartment.

- → "Rails", Page 39
- 3. Remove coarse dirt from the cooking compartment and from the shelf supports.

Coarse dirt may burn on, making it difficult to remove.

- 4. Use a detergent solution and a soft cloth to clean the surfaces at the edges of the cooking compartment around the door seal.
  - Do not remove or scrub the door seal.
  - Use oven cleaner to remove stubborn dirt from the inner door pane.
- **5.** Remove any objects from the cooking compartment. The cooking compartment must be empty except for the shelf supports.

#### 22.2 Setting the cleaning function

Ventilate the kitchen while the cleaning function is run-

#### ⚠ WARNING – Risk of harm to health!

The cleaning function heats up the cooking compartment to a very high temperature so that food left over from roasting, grilling and baking will burn off. This process releases vapours, which can irritate mucous membranes.

- Keep the kitchen well ventilated while the cleaning function is running.
- Do not remain in the room for long periods.
- Keep children and pets away.

#### ⚠ WARNING – Risk of burns!

The cooking compartment gets very hot when the cleaning function is in progress.

- ► Never open the appliance door.
- ► Allow the appliance to cool down.
- ► Keep children at a safe distance.

⚠ The outside of the appliance gets very hot when the cleaning function is in progress.

- Never touch the appliance door.
- Allow the appliance to cool down.
- Keep children at a safe distance.

Note: The oven light does not light up while the cleaning function is running.

#### Requirement: .

- → "Preparing the appliance for the cleaning function", Page 35
- 1. Press "Cleaning".
- 2. Press "Pyrolytic activeClean".
- 3. Press "Level" to set the cleaning setting.

Cleaning set- ting	Cleaning level	Duration in hours
1	Low	Approx. 2:15

Cleaning set- ting	Cleaning level	Duration in hours
2	High	Approx. 2:30

The duration cannot be changed.

You can delay the time at which the operation should be ready.

- → "Setting the end time", Page 17
- 4. Press "Start".
- A notification stating that you should carry out the necessary preparatory work for the cleaning function appears on the display.
- **5.** Confirm the message.
- The cleaning function starts and the duration counts down.
- ✓ For your safety, the appliance door locks once a certain temperature is reached in the cooking compartment. n appears on the display.
- A signal tone sounds when the cleaning function has finished. A message appears on the display confirming that the operation has finished.
- **6.** Press  $\bigcirc$  to switch the appliance off.
- - → "Preparing the appliance after the cleaning function", Page 36

#### Cancelling the cleaning function

You can no longer stop or change the cleaning function once it has started.

► To cancel the cleaning function, press ① to switch the appliance off.

## 22.3 Preparing the appliance after the cleaning function

- 1. Allow the appliance to cool down.
- 2. Wipe off any ash that has been left behind in the cooking compartment, on the shelf supports and around the appliance door.
  - → "Cleaning and servicing", Page 32
- 3. Slide the pull-out rails out and in several times. While the cleaning function is running, the rails may become discoloured. This discolouration does not compromise the functionality of the appliance.
- 4. Remove white residues with lemon juice. Note: White residues on the enamel surfaces may be caused by heavy soiling. These food residues are harmless. The deposits do not compromise the functionality of the appliance.

**Note:** While the cleaning function is running, the frame on the inside of the appliance door or other parts of the door that are made of stainless steel become discoloured. This discolouration does not compromise the functionality of the appliance. The discolouration can be removed using a stainless steel cleaner.

## 23 Cleaning aid "humidClean"

The cleaning aid "humidClean" 

is a guick alternative for occasionally cleaning the cooking compartment. The cleaning aid softens dirt by vaporising the soapy water. It is then easier to remove the dirt.

#### 23.1 Setting the cleaning aid

#### ⚠ WARNING – Risk of scalding!

If there is water in the cooking compartment when it is hot, this may create hot steam.

► Never pour water into the cooking compartment when the cooking compartment is hot.

Note: The oven light does not come on during the cleaning aid.

Requirement: The cooking compartment must have cooled down completely.

- 1. Remove any accessories from the cooking compart-
- 2. ATTENTION Distilled water in the cooking compartment leads to corrosion.
  - Do not use distilled water.

Mix 0.4 litres water with a drop of washing-up liquid and pour into the centre of the cooking compartment floor.

- 3. Press "Cleaning".
- 4. Press "humidClean".

The duration cannot be changed.

- 5. Press "Start".
- ✓ A notification stating that you should carry out the necessary preparatory work for the cleaning aid appears on the display.
- 6. Confirm the notification.
- ▼ The cleaning aid starts and the cooking time counts down.
- Once the cleaning aid has ended, a signal tone sounds. A notification appears on the display confirming that the operation has finished.
- **7.** Press  $\odot$  to switch the appliance off.
- - → "Cleaning the cooking compartment after using the cleaning aid", Page 36

## 23.2 Cleaning the cooking compartment after using the cleaning aid

#### **ATTENTION**

The prolonged presence of moisture in the cooking compartment leads to corrosion.

- After using the cleaning assistance, wipe the cooking compartment and allow it to dry completely.
- 1. Allow the appliance to cool down.
- 2. Wipe out the remaining water in the cooking compartment using an absorbent sponge cloth.
- 3. Clean the smooth enamel surfaces in the cooking compartment with a dish cloth or a soft brush. Remove stubborn food remnants using a stainless steel scouring pad.

- **4.** Remove limescale with a cloth soaked in vinegar, and wipe this away with clean water.
- **5.** Dry the cooking compartment with a soft cloth.
- **6.** To dry the cooking compartment completely, leave the appliance door open for approx. 1 hour or use the "Drying" function.
  - → "Setting the drying process", Page 37

### 24 Descaling

To ensure that your appliance continues to operate correctly, it must be descaled regularly.

How frequently you need to run the descaling programme depends on the water hardness and how many times you have used the steam-assisted operations. The appliance indicates when only another 5 or fewer steam-assisted operations are possible. If you do not carry out descaling, you can no longer set any operation with steam.

Descaling comprises several steps and takes approximately 70 - 95 minutes:

- Descaling (approx. 55 70 minutes)
- First rinse cycle (approx. 8 12 minutes)
- Second rinse cycle (approx. 8 12 minutes)

Carry out descaling in full.

If descaling is interrupted, you can no longer set any operation. To ensure that the appliance is ready for operation again, carry out 2 rinse cycles.

#### 24.1 Preparing descaling

#### **ATTENTION**

The length of time for which the descaler is left to work is based on the recommended, liquid descaler. Other descalers may damage the appliance.

 Only use the liquid descaler recommended by us for the descaling programme.

If descaling solution comes into contact with the control panel or other delicate surfaces, it will damage them.

- ► Remove descaling solution immediately with water.
- **1.** Mix the descaling solution:
  - 200 ml liquid descaler
  - ▶ 400 ml water
- **2.** Open the control panel.

- Remove the water tank and fill it with descaling solution.
- **4.** Once the descaling solution has been poured into the water tank, slide the tank back in.
- **5.** Close the control panel.

#### 24.2 Setting the descaling programme

#### Requirement:

- → "Preparing descaling", Page 37
- 1. Press "Cleaning".
- 2. Press "Descaling".

  The duration cannot be changed.
- 3. Press "Start".
- A message stating that you should carry out the necessary preparatory work for descaling appears on the display.
- 4. Confirm the message.
- The descaling programme starts and the duration counts down.
- Once the first part of the descaling programme has finished, a signal sounds. The appliance prompts you to carry out 2 rinse cycles.
- **5.** To rinse the appliance, for each rinse cycle:
  - Open the control panel and remove the water tank.
  - ► Thoroughly rinse the water tank and fill it with fresh water
  - ► Slide in the water tank and close the control panel.
  - ► Press "Start" to start the rinse cycle.
- A signal tone sounds when each rinse cycle has ended
- **6.** Once the second rinse cycle is complete:
  - ► Empty and dry the water tank.
    - → "Emptying the water tank", Page 20
  - ▶ Press ① to switch the appliance off.

### 25 Drying function

To prevent residual moisture, dry the cooking compartment following operation with steam or microwave-only operation.

#### **ATTENTION**

If there is water on the cooking compartment floor when operating the appliance at temperatures above 120  $^{\circ}$ C, this will damage the enamel.

- Do not use the appliance if there is water on the cooking compartment floor.
- Wipe away any water on the cooking compartment floor before operation.

### 25.1 Drying the cooking compartment

You can dry the cooking compartment by hand or use the "Drying function" function.

- 1. Allow the appliance to cool down.
- 2. Remove dirt from the cooking compartment.
- **3.** Wipe away the water in the cooking compartment.
- 4. Dry the cooking compartment.
  - ► To dry the cooking compartment, leave the appliance door open for 1 hour.
  - To use the "Drying function" function, set "Drying function".
    - → "Setting the drying process", Page 37

# Setting the drying process Requirement:

- → "Drying the cooking compartment", Page 37
- 1. Press "Cleaning".
- **2.** Press "Drying function". The duration cannot be changed.

- 3. Press "Start".
- A notification stating that you should carry out the necessary preparatory work for the drying appears on the display.
- 4. Confirm the notification.
- The drying process starts and the duration counts down.
- Once the drying has ended, a signal tone sounds. A notification appears on the display confirming that the operation has finished.
- **5.** Press  $\bigcirc$  to switch the appliance off.
- **6.** To dry the cooking compartment completely, leave the appliance door open for 1 to 2 minutes.


### 26 Appliance door

To clean the appliance door thoroughly, you can disassemble the appliance door.

#### 26.1 Removing the door cover

The stainless steel inlay in the door cover may discolour. Remove the door cover in order to clean it and the stainless steel inlay, or to remove the door panes.

- 1. Open the appliance door slightly.
- 2. Press down on the left- and right-hand sides of the door cover ①.
- Remove the door cover ② and carefully close the appliance door.



#### 26.2 Removing the door panes

#### 

Scratched glass in the appliance door may develop into a crack.

► Do not use any harsh or abrasive cleaners or sharp metal scrapers to clean the glass on the oven door, as they may scratch the surface.

The hinges on the appliance door move when the door is opened and closed, which could trap your fingers.


► Keep your hands away from the hinges. Components inside the appliance door may have sharp edges.

Wear protective gloves.


**Requirement:** The door cover has been removed.

- → "Removing the door cover", Page 38
- **1.** Undo and remove the screws ① on the left and right of the appliance door.
- 2. Place a folded-up tea towel in the appliance door.
- **3.** Close the appliance door.

4. Pull the front pane up and out 2.




- **5.** Place the front pane down on a flat surface with the door handle facing down.
- **6.** Press the intermediate pane against the appliance with one hand while pushing the left- and right-hand retainers a upwards. Do not detach the retainers a.



- 7. Remove the intermediate pane.
- 8. WARNING Risk of serious harm to health!

  If the screws are undone, the safety of the appliance can no longer be guaranteed. Microwave energy may escape.
  - Never undo the screws.

Never unscrew the four black screws on the frame.




#### 26.3 Fitting the door panes


#### **⚠ WARNING – Risk of injury!**

The hinges on the appliance door move when the door is opened and closed, which could trap your fingers.


- ► Keep your hands away from the hinges.
- Components inside the appliance door may have sharp edges.
- Wear protective gloves.
- **1.** Turn the intermediate pane until the arrow ⓐ is in the top right.




- 2. Insert the intermediate pane into the retainer at the bottom 1 and push it in firmly at the top.
- **3.** Push the left- and right-hand retainer a downwards until the intermediate pane is clamped ②.



- **4.** Attach the front pane downwards into the left- and right-hand retainers **a** ①.
- 5. Push the front pane to the appliance until the left- and right-hand hook a is opposite the support b 2.



- **6.** Push the front pane in at the bottom ① until you hear it click into place.
- 7. Open the appliance door slightly and remove the tea towel.
- **8.** Screw both screws back in on the left and right of the appliance door.
- **9.** Put the door cover in position and push down on it ② until you hear it click into place.



10. Close the appliance door.

**Note:** Do not use the cooking compartment again until the door panes have been correctly fitted.


### 27 Rails

To thoroughly clean the rails and the cooking compartment, or to replace the rails, you can remove the rails.

#### **⚠ WARNING – Risk of burns!**


The shelf supports get very hot

- ► Never touch the shelf supports when hot.
- Always allow the appliance to cool down.
- Keep children at a safe distance.
- 1. Lift the rail forwards ① and detach it ②.
- 2. Push the entire rail backwards 3 and take it out 4.




#### 27.2 Fitting the retainers

The retainers may fall out when you detach the rails. **Note:** The retainers at the front differ from those at the rear.




**1.** Hook the front retainers with the hook into the round hole at the top and set them at a slight angle ①.

2. Hook the front retainers in at the bottom and straighten them ②.




**3.** Hook the rear retainers with the hook into the top hole ① and push them into the bottom hole ②.



#### 27.3 Attaching the rails

- **1.** Hook the rear shelf support into the retainers at the top and bottom ① and pull it forwards ②.
- **2.** Hook in the rail at the front ③ and press it down ④.



### 28 Troubleshooting

You can rectify minor faults on your appliance yourself. Read the troubleshooting information before contacting aftersales service. This will avoid unnecessary costs.

#### 

Improper repairs are dangerous.

- ► Repairs to the appliance should only be carried out by trained specialist staff.
- ► If the appliance is defective, call Customer Service.
  - → "Customer Service", Page 43

#### 

Improper repairs are dangerous.

- Repairs to the appliance should only be carried out by trained specialist staff.
- ► Only use genuine spare parts when repairing the appliance.
- If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

#### 28.1 Malfunctions

Fault	Cause and troubleshooting				
The appliance is not working.	The circuit breaker in the fuse box has tripped.  • Check the circuit breaker in the fuse box.				
	There has been a power cut.  ► Check whether the lighting in your room or other appliances are working.				
	<ul> <li>Electronics fault</li> <li>1. Disconnect the appliance from the power supply for at least 30 seconds by switching off the fuse.</li> <li>2. Reset the basic settings to the factory settings.  → "Basic settings", Page 29</li> </ul>				
"Sprache Deutsch" appears in the display.	There has been a power cut.  Configure the initial configuration settings.				
The operation does not start or is interrupted.	Different causes are possible.  ► Check the notifications that appear on the display.  → "Displaying information", Page 16				
	Malfunction  ► Call .  → "Customer Service", Page 43				
Appliance does not heat up.	<ul> <li>Demo mode is switched on.</li> <li>1. Briefly disconnect the appliance from the power supply by switching the circuit breaker in the fuse box off and then on again.</li> <li>2. Switch off demo mode in the basic settings within approx. 5 minutes.</li></ul>				
	<ul> <li>There has been a power cut.</li> <li>▶ Open and close the appliance door once after a power failure.</li> <li>✔ The appliance is checked and is ready to use.</li> </ul>				
The time is not displayed when the appliance is switched off.	Basic setting has been changed.  ► Change the basic setting for the time display.  → "Basic settings", Page 29				
Appliance door cannot be opened.	The cleaning function locks the appliance door; ⊕ lights up in the display.  ► Allow the appliance to cool down until ⊕ goes out on the display.  → "Pyrolytic activeClean cleaning function", Page 35				
	The childproof lock locks the appliance door.  ► Use the substitution to deactivate the childproof lock.  → "Childproof lock", Page 29  You can switch off the lock in the basic settings.  → "Basic settings", Page 29				
Home Connect is not working properly.	Different causes are possible.  ▶ Go to www.home-connect.com.				
The control panel cannot be opened.	The circuit breaker in the fuse box has tripped.  ▶ Check the circuit breaker in the fuse box.				
	There has been a power cut.  • Check whether the lighting in your room or other appliances are working.				
	<ul> <li>Malfunction</li> <li>1. Call the after-sales service.  → "Customer Service", Page 43</li> <li>2. If there is water in the water tank, empty the water tank:  ▶ Open the appliance door.  ▶ Grip on the right and left below the control panel.  ▶ Slowly pull out the control panel and push it upwards.</li> </ul>				

Fault	Cause and troubleshooting					
The appliance requests descaling without the counter appearing in advance.	<ul> <li>The set water hardness range is too low.</li> <li>1. Descale the appliance.  → "Descaling", Page 37</li> <li>2. Check the water hardness and set this in the basic settings.  → "Basic settings", Page 29</li> </ul>					
The appliance prompts you to rinse it.	<ul> <li>→ "Basic settings", Page 29</li> <li>During the descaling, the power supply is interrupted or the appliance is switched off.</li> <li>▶ Rinse the appliance.</li> <li>→ "Descaling", Page 37</li> </ul>					
"Fill water tank" appears in the display even though the water tank has been filled.	The water tank has not clicked into place.  ► Insert the water tank correctly so that it engages in the holder.  → "Filling the water tank", Page 18					
	The water tank has fallen out. Shaking has caused parts to come loose in the water tank. The water tank is leaking.  ▶ Order a new water tank.  → "Customer Service", Page 43					
	<ul> <li>Malfunction</li> <li>Do not use deionised or filtered water.</li> <li>→ "Determining the water hardness before switching on the appliance for the first time", Page 14</li> </ul>					
	The sensor is defective.  ► Call .  → "Customer Service", Page 43					
Buttons are flashing.	Condensation has formed behind the control panel.  No action required. As soon as the condensation has evaporated, the buttons no longer flash.					
"Plopping" sounds can be heard when cooking with steam.	Water vapour requires the cold/heat effect for frozen food. No action required.					
The appliance hums during operation and after it is switched off.	Functional test of the pump creates operating noise. No action required.					
During simple microwave operation, the cooking compartment becomes hot.	The drying function is switched on.  To prevent condensation from forming when the appliance is in microwave-only mode, the appliance automatically switches on an additional heating element when it is set to 600 W or 800 W. The cooking result is not affected by this.  ► You can change the basic setting for the drying function during microwave operation.  → "Basic settings", Page 29  ► Observe the information on operating with microwave.  → "Microwave", Page 21					
Camera shield is blurry.	Camera lens is dirty.  ► Clean the camera lens.  → "Cleaning the camera lens", Page 34					
The interior lighting does not work.	Basic setting has been changed.  ► Change the basic setting for the lighting.  → "Basic settings", Page 29					
	The LED light is defective.  ► Call .  → "Customer Service", Page 43					
Maximum operating time reached.	To prevent an unwanted permanent operation, the appliance automatically stops heating after several hours if the settings are unchanged. A message appears in the display.  The point at which the maximum operating time is reached is determined by the corresponding settings for an operating mode.  1. To continue operation, switch the appliance off and on again using ○. Reset and start the operation.  2. If you do not need to use the appliance, press ○ to switch it off.  Tip: To prevent the appliance from switching off when you do not want it to, set a cooking time.  → "Time-setting options", Page 17					

#### **Fault** Cause and troubleshooting Error code made up of letters The electronics have detected a fault. and numbers appears on the dis-1. Switch the appliance off and on again. play, e.g. E0111. ✓ If the fault was a one-off, the message disappears. 2. If the message appears again, call the after-sales service. Please specify the exact error message when calling. → "Customer Service", Page 43 Settings were unsuitable. The cooking result is not satis-Adjustment values, e.g. temperature or cooking time, depend on the recipe, factory. quantity and food. Next time, set lower or higher values. Tip: A lot of other information about the preparation, corresponding adjustment values and recipes can be found in the Home Connect app or on our website siemens-home.bsh-group.com. 回綴為回 Camera lens is dirty. Clean the camera lens. → "Cleaning the camera lens", Page 34 The result of the cleaning function The cooking compartment was too dirty. is not satisfactory. Remove coarse dirt from the cooking compartment before using the cleaning Take the shelf supports out of the cooking compartment to save energy and achieve a better cleaning result in the cooking compartment. Pay attention to the cleaning and care of your appliance. → "Cleaning and servicing", Page 32

### 29 Disposal

#### 29.1 Disposing of old appliance

Valuable raw materials can be reused by recycling.

- 1. Unplug the appliance from the mains.
- 2. Cut through the power cord.
- **3.** Dispose of the appliance in an environmentally friendly manner.

Information about current disposal methods are available from your specialist dealer or local authority.



This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE).

The guideline determines the framework for the return and recycling of used appliances as applicable throughout the

### 30 Customer Service

Detailed information about the warranty period and the warranty conditions in your country is available via the QR code on the enclosed document on service contacts and warranty conditions, from our customer service or on our website.

If you contact Customer Service, you will require the product number (E-Nr.), the production number (FD) and the consecutive numbering (Z-Nr.) of your appliance.

You can find the contact details for our customer service via the QR code on the enclosed document on service contacts and warranty conditions or on our website. This product contains light sources from energy efficiency class G. These light sources are available as a spare part and should only be replaced by trained specialist staff.

You can find the information required as per Regulation (EU) 2023/826 online at siemens-home.bsh-group.com on the product and service pages for your appliance, in the area of user manuals and additional documents.


EU.

# 30.1 Product number (E-Nr.), production number (FD) and consecutive numbering (Z-Nr.)

You can find the product number (E-Nr.), the production number (FD) and the consecutive numbering (Z-Nr.) on the appliance's rating plate.

You will see the rating plate with these numbers if you open the appliance door. On some appliances with

steam-assisted cooking, you will find the rating plate behind the control panel.



Make a note of your appliance's details and the Customer Service telephone number to find them again quickly.

You can also display the appliance information in the basic settings.

→ "Basic settings", Page 29

### 31 Information regarding Free and Open Source Software

This product includes software components that are licensed by the copyright holders as free or open source software.

The applicable licence information is stored on your home appliance. You can also access the applicable licence information via your Home Connect app: "Profile -> Legal information -> Licence Information". 1 You can download the licence information on the brand product website. (Please search on the product website for your appliance model and additional documents). Alternatively, you can request the relevant information from ossrequest@bshg.com or BSH Hausgeräte GmbH, Carl-Wery-Str. 34, 81739 Munich, Germany.

The source code will be made available to you on request.

Please send your request to ossrequest@bshg.com or BSH Hausgeräte GmbH, Carl-Wery-Str.34, 81739 Munich, Germany.

Subject: "OSSREQUEST"

The cost of performing your request will be charged to you. This offer is valid for three years from the date of purchase or at least as long as we offer support and spare parts for the relevant appliance.

### 32 Declaration of Conformity

BSH Hausgeräte GmbH hereby declares that the appliance with Home Connect functionality conforms to the essential requirements and other relevant provisions of Directive 2014/53/EU.

A detailed RED Declaration of Conformity can be found online at siemens-home.bsh-group.com among the additional documents on the product page for your appliance.



Hereby, BSH Hausgeräte GmbH declares that the appliance with Home Connect functionality is in compliance with relevant statutory requirements.<sup>2</sup>

A detailed Declaration of Conformity can be found online at siemens-home.bsh-group.com/uk/ among the additional documents on the product page for your appliance.<sup>2</sup>

2.4 GHz band (2400-2483.5 MHz): Max. 100 mW

5 GHz band (5150-5350 MHz + 5470-5725 MHz): max. 200 mW

	BE	BG	CZ	DK	DE	EE	ΙE	EL	ES	
	FR	HR	IT	CY	LI	LV	LT	LU	HU	
	MT	NL	AT	PL	PT	RO	SI	SK	FI	
	SE	NO	CH	TR	IS	UK (NI)				
5 GHz W	/LAN (Wi-Fi	i): For indo	or use only	/.						
AL	ВА		MD	ME	MK	RS	UK		UA	
5 GHz W	/LAN (Wi-Fi	i): For indo	or use only	/.						

#### 32.1 Statement of Compliance for Great **Britain**

The full Statement of Compliance according to the Product Security and Telecommunications Infrastructure (Security Requirements for Relevant Connectable Products) Regulations 2023 can be found online at www.siemens-home.bsh-group.com/uk/home among

the additional documents on the product page for your device.

#### **Product type**

This statement of compliance covers the products described in this information for use whose model identifier group is seen on the title page. The full model identifier is made up of the characters before the slash in the product number (E no.) which can be found on the rat-

Depending on the appliance specifications

Only applies to Great Britain

ing plate. Alternatively, you can also find the model identifier in the first line of the UK Energy Label.

#### Name and address of manufacturer

BSH Hausgeräte GmbH, Carl-Wery-Strasse 34, 81739 München, Germany

This statement of compliance is prepared by the manufacturer.

The manufacturer, BSH Hausgeräte GmbH deems that it has complied with

- provision 5.1-1 of ETSI EN 303 645 v2.1.1 and, where relevant, provision 5.1-2 of ETSI EN 303 645
- provision 5.2-1 of ETSI EN 303 645 v2.1.1;
- provision 5.3-13 of ETSI EN 303 645 v2.1.1.

#### Support period

BSH Hausgeräte GmbH will provide security updates that are necessary to maintain the main functions free of charge until at least 28/02/2034.

### 33 How it works

Here, you can find the ideal settings for various types of food as well as the best accessories and cookware. We have perfectly tailored these recommendations to your appliance.

**Tip:** A lot of other information about the preparation, corresponding adjustment values and recipes can be found in the Home Connect app or on our website siemens-home.bsh-group.com.

#### 33.1 General cooking tips

Take note of the following information when cooking all types of food.

- The temperature and cooking time depend on the amount of food and the recipe. Settings ranges are specified for this reason. Try using the lower values to
- The setting values apply to food placed in the cooking compartment while the cooking compartment is still cold. If you want to preheat anyway, do not place accessories into the cooking compartment until it has finished preheating.
- Remove any accessories that are not being used from the cooking compartment.

#### **ATTENTION**

Acidic food may damage the wire rack

► Do not place acidic food, such as fruit or food with an acidic marinade directly on the wire rack.

#### Information for those allergic to nickel

In rare cases, small amounts of nickel may pass into the food.

You can buy suitable accessories from customer service, from specialist retailers or online.

→ "Other accessories", Page 14

**Tip:** For some food, you can use the ventilation function "Crisp Finish". For some food, you can use the ventilation function. The ventilation function "Crisp Finish" extracts moisture from the cooking compartment with increased intensity. This method is recommended for food with lots of moisture, e. g.

- for cooking on several levels
- for baked items with a moist toppings
- for meringue pastry
- when increased crispiness is required

For crispier food, we recommend switching this on in the second half of the cooking time.

→ "Ventilation function Crisp Finish", Page 23

#### 33.2 Baking tips

- Dark-coloured metal baking tins are most suitable for baking cakes, bread and other baked goods.
- Use wide, shallow cookware for bakes and gratins. Food takes longer to cook in deep, narrow cookware and it browns more on top.
- Silicone moulds are not suitable.
- If you are cooking bakes directly in the universal pan, place the universal pan into the cooking compartment at level 2.
- The setting values for bread dough apply to both dough placed on a baking tray and dough placed in a loaf tin.
- The recommended settings for baking in combination with the microwave mode are for metal baking tins.

#### **ATTENTION**

When the cooking compartment is hot, any water inside it will create steam. The change in temperature may cause damage.

- ► Never pour water into the cooking compartment when it is still hot.
- ► Never place cookware containing water on the cooking compartment floor.

#### **Shelf positions**

If you are using the 4D hot air type of heating, you can choose between shelf positions 1, 2, 3 and 4. You will obtain the best results if you use the following shelf positions.

Baking on one level	Height
Tall baked items and tins/dishes on the wire rack	2
Shallow baked items/baking tray	3
Baking on two or more levels	Height
<ul><li>2 levels</li><li>Universal pan</li><li>Baking tray</li></ul>	3
2 levels  Baking tins/dishes on 2 wire racks	3 1
3 levels  Baking tray Universal pan Baking tray	5 3 1

Baking on two or more levels	Height
4 levels	5
4 wire racks with greaseproof pa-	3
per	2
	1

Use the 4D hot air heating function.

#### Notes

- Items that are placed in the appliance on baking trays or in baking tins/dishes at the same time will not necessarily be ready at the same time.
- If you opt for cooking in combination with the microwave mode, you can only cook on one level.

#### 33.3 Roasting, braising and grilling tips

- The recommended settings are for fridge-temperature food and unstuffed, oven-ready poultry.
- Place the poultry onto the cookware breast-side or skin-side down.
- Turn roasting joints, grilled items or whole fish after approx. ½ to ¾ of the specified time.

#### Roasting on the wire rack

Food roasted on the wire rack will become very crispy on all sides. You can roast large poultry, for example, or multiple individual pieces at the same time.

- Roast pieces of a similar weight and thickness. The grilled food will brown evenly and will remain succulent and juicy.
- Place the food to be roasted directly on the wire rack.
- To catch any liquids that drip down, place the universal pan into the cooking compartment one level below the wire rack.
- Add up to ½ litre of water to the universal pan, depending on the size and type of food that you want to roast.

You can make a sauce from the juices that are collected. This also means that less smoke is produced and the cooking compartment does not become as dirty.

#### Roasting in cookware

If you cover the cookware when you cook your food, this will keep the cooking compartment cleaner.

#### General information about roasting in cookware

- Use heat-resistant, ovenproof cookware.
- Place the cookware on the wire rack.
- Glass cookware is best.
- Follow the manufacturer's instructions for your roasting dishes.

#### Roasting in uncovered cookware

- Use a deep roasting dish.
- If you do not have any suitable cookware, you can use the universal pan.

#### Roasting in covered cookware

- Use a suitable lid that seals well.
- When roasting meat, there should be at least 3 cm between the food and the lid. The meat may expand.

#### 

Very hot steam may escape when the lid is opened after cooking. Steam may not be visible, depending on the temperature.

- ► Lift the lid in such a way that the hot steam can escape away from you.
- Keep children away from the appliance.

#### Grilling

Grill food if you want it to be crispy.

The "Grill" type of heating is good for cooking thinner pieces of poultry, meat and fish such as steaks, drumsticks and burgers. It is also excellent for toasting bread.

Circulated air grilling is very well suited to cooking whole poultry and fish, as well as meat, e.g. roast pork with crackling.

- When grilling several food items, choose pieces that are of a similar weight and thickness. The grilled food will brown evenly and will remain succulent and juicy.
- Place the food to be grilled directly onto the wire rack.
- To catch any liquids that drip down, place the universal pan into the cooking compartment at least one level below the wire rack.

#### Notes

- The grill element switches on and off continuously.
   This is normal. The grill setting that you use determines how frequently this occurs.
- Smoke may be produced when grilling.

#### 33.4 Microwave cooking

If you cook food using the microwave mode, you can reduce the cooking time considerably.

#### **General information**

- When using the microwave mode, the cooking time is determined based on the total weight. If you want to cook a quantity that differs from the specified quantity, the general rule is **Double the** quantity requires just under double the cooking time.
- The food transfers heat to the cookware. The cookware may become very hot.
- The main part of the instruction manual contains information on how to configure the microwave and microwave boost oven settings.
  - → "Microwave", Page 21
  - → "Added microwave", Page 22

#### Tip

You can find more microwave recipes here:

- → "Defrosting", Page 52
- → "Warming up and reheating food", Page 52

## Cooking, braising or steaming using the microwave mode

- Use microwave-safe cookware with a lid. Alternatively, you can use a plate or special microwaveable film to cover the dish.
- For cereal products, e.g. rice, use deep cookware with a lid. Cereal products foam a lot during cooking.
   Add liquid in accordance with the instructions and in-

- formation provided in the recommended settings tables.
- Do not wash or dry food. Add 1-3 tablespoons of water or lemon juice to the food.
- Spread the food out so that as much of it as possible is in contact with the bottom of the cookware. Food that is in contact with the bottom will cook more quickly than food that is piled up.
- Use salt and seasoning sparingly. When cooking food using the microwave mode, most of the food's natural flavour will be retained.
- Turn or stir the food 2-3 times during cooking.
- After cooking, leave the food to rest for 2-3 minutes.

#### 33.5 Cooking instructions for ready meals

- The cooking result greatly depends on the quality of the food. Pre-browning and irregularities may already be present in the food before cooking.
- Do not use frozen products that are covered with a thick layer of ice. Remove any ice on the food.

- Take ready meals out of the packaging.
- If you are warming or cooking the ready meal in cookware, make sure that the cookware is heat-resistant.
- Distribute foods that are in the form of separate pieces, such as bread rolls and potato products, so that they are spread out flat and evenly on the accessory. Leave a little space between the individual pieces.
- Follow the manufacturer's instructions on the packaging.
- To achieve best results, we recommend that you reheat food or ready meals at 600 watts. If the packaging specifies a higher microwave output setting, extend the time.

#### 33.6 List of foods

Recommended settings for a variety of foods, sorted into food categories.

#### Recommended settings for various types of food

Food	Accessory/ cookware	Height	Type of heating	Temper- ature in °C/grill setting	Microwave power set- ting in W	Steam setting / Crisp Fin- ish	Cooking time in mins
Sponge cake, simple	Ring-shaped tin or Loaf tin	2	<b>®</b>	160-180	90	-	30-40
Sponge cake, delicate	Ring-shaped tin or Loaf tin	2		150-170	-	-	60-80
Sponge cake, 2 levels	Ring-shaped tin or Loaf tin	3+1	<b>(B)</b>	140-150	-	-	60-80
Fruit tart or cheese- cake with shortcrust pastry base	Springform cake tin, diameter 26 cm	2	<b>®</b>	150-170	-	-	65-85
Fruit tart or cheese-cake with shortcrust pastry base	Springform cake tin, diameter 26 cm	2	<b>®</b>	1. 160-180 <b>2.</b> 100	<b>1.</b> 180 <b>2.</b> -	-	<b>1.</b> 30-40 <b>2.</b> 20
Sponge flan, 6 eggs	Springform cake tin Ø 28 cm	2	<b>3</b>	150-160	-	-	50-60
Sponge flan, 6 eggs	Springform cake tin Ø 28 cm	2	<b>®</b>	150-170 <sup>1</sup>	_	-	30-50
Sponge flan, 6 eggs	Springform cake tin Ø 28 cm	2	<b>⊗</b>	1. 150-160 2. 150-160	-	1 Off	<b>1.</b> 10 <b>2.</b> 25-35
Shortcrust tart with moist topping	Universal pan	3		160-180	-	<b>≅</b> On	55-75
Yeast cake with moist topping	Universal pan	3		180-190	-	E On	30-40
Swiss roll	Baking tray	3	8	180-200 <sup>1</sup>	_	1	10-15
Muffins	Muffin tray	3		170-190	-	<b>-</b>	15-20

<sup>&</sup>lt;sup>1</sup> Preheat the appliance.

Food	Accessory/ cookware	Height	Type of heating	Temper- ature in °C/grill setting	Microwave power set- ting in W	Steam setting / Crisp Fin- ish	Cooking time in mins
Small yeast cakes	Baking tray	3	<b>®</b>	160-180	-	2	25-35
Biscuits	Baking tray	3	<b>®</b>	140-160	-	_	15-30
Biscuits, 2 levels	Universal pan + Baking tray	3+1	<b>8</b>	140-160	-	-	15-30
Biscuits, 3 levels	x 2 Baking tray + Universal pan	5+3+1	<ul><li>(a)</li></ul>	140-160	-	-	15-30
Meringues	Baking tray	3	<b>(A)</b>	80-90 <sup>1</sup>	-	 <b>©</b> On	120-150
Bread, 750 g	Universal pan or Loaf tin	2		1. 210-220 2. 180-190	-	3 ☑ On	<b>1.</b> 10-15 <b>2.</b> 25-35
Bread, 1500 g	Universal pan or Loaf tin	2	<b>(a)</b>	1. 210-220 2. 180-190	-	3	<b>1.</b> 10-15 <b>2.</b> 45-55
Bread, 1500 g	Universal pan or Loaf tin	2		200-210	-	-	35-45
Flatbread	Universal pan	3		220-230	-	3	20-30
Bread rolls, fresh	Baking tray	3		200-220	-	2	20-30
Pizza, fresh, on a baking tray	Baking tray	3		180-200	-	<i>≊</i> On	20-30
Pizza, fresh, on a baking tray, 2 levels	Universal pan + Baking tray	3+1		180-190	-	E On	35-45
Pizza, fresh, thin-crust, on a pizza tray	Pizza tray	2		220-230	-	-	20-30
Börek	Universal pan	3		200-210	-	=	30-40
Quiche	Dark coated quiche tin	1		200-210	-	-	40-50
Tarte flambée	Universal pan	3		280-300	1 _	-	10-18
Bake, savoury, cooked ingredients	Ovenproof dish	2	T T	150-170	-	2	40-50
Bake, savoury, cooked ingredients	Ovenproof dish	2		150-170	360	-	20-30
Lasagne, frozen, 350-450 g, 3 cm deep	Uncovered cookware	2		200-210	180	-	20-25
Lasagne, frozen, 600-1000 g, 4-5 cm deep	Uncovered cookware	2		200-210	180	-	35-45
Potato gratin, raw ingredients, 4 cm deep	Ovenproof dish	2		160-190	-	-	50-70
Potato gratin, raw ingredients, 4 cm deep	Ovenproof dish	2	<b>\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\</b>	170-190	360	-	20-25
Chicken, 1.3 kg, unstuffed	Wire rack	2	T T	200-220	-	2	60-70

<sup>&</sup>lt;sup>1</sup> Preheat the appliance.

<sup>&</sup>lt;sup>1</sup> Turn the dish 2/3 of the way through the cooking time.

Food	Accessory/ cookware	Height	Type of heating	Temper- ature in °C/grill setting	Microwave power set- ting in W	Steam setting / Crisp Fin- ish	Cooking time in mins
Vegetables, fresh, 250 g	Covered cook- ware	2	<b>2</b>	=	600	-	6-10 1
Mixed vegetables, 250 g, + 25 ml water	Covered cook- ware	2		-	600	-	8-12 1
Baked potatoes, halved, 1 kg	Universal pan	3	<b>\tilde{\</b>	200-220	360	-	15-20
Peeled boiled potatoes, quartered, 500 g	Covered cook- ware	2		-	600	-	12-15 <sup>1</sup>
Long-grain rice, 250 g + 500 ml water	Covered cook- ware	2		-	<b>1.</b> 600 <b>2.</b> 180	-	<b>1.</b> 7-9 <b>2.</b> 13-16
Millet, whole, 250 g, + 600 ml water	Covered cook- ware	2	<b>≅</b>	=	<b>1.</b> 600 <b>2.</b> 180	-	<b>1.</b> 8-10 <b>2.</b> 5-10
Polenta or maize se- molina, 125 g + 500 ml water	Covered cook- ware	2		-	600	-	6-8 1

#### **Desserts**

#### Making yoghurt

- **1.** Remove the accessories and shelves from the cooking compartment.
- 2. Heat 1 litre of whole milk (3.5% fat) to 90 °C on the hob and then leave it to cool down to 40 °C. It is sufficient to heat UHT milk to 40 °C.
- 3. Mix 150 g of chilled yoghurt into the milk.
- Pour the mixture into small containers, e.g. cups or small jars.
- 5. Cover the containers with film, e.g. cling film.
- **6.** Place the containers on the cooking compartment floor.
- 7. Use the recommended settings when configuring the appliance settings.
- **8.** After making the yoghurt, leave it to cool in the refrigerator for at least 12 hours.

#### Making blancmange from blancmange powder

- 1. Use a deep, microwave-safe receptacle.
- 2. Pour the blancmange powder and all of the milk and sugar into the receptacle and mix.
- **3.** Place the receptacle onto the wire rack and slide the rack into the cooking compartment.
- **4.** Use the recommended settings when configuring the appliance settings.

- 5. As soon as the milk starts to rise, stir thoroughly.
- **6.** Repeat the process until the required consistency is achieved.

#### Using the microwave mode to make popcorn

#### **⚠ WARNING – Risk of burns!**

Airtight packaging may burst when food is heated.

- Always follow the instructions on the packaging.
- Always use oven gloves to remove the dishes from the cooking compartment.
- **1.** Use a microwave-safe, shallow ovenproof dish. Do not use porcelain or deep plates.
- **2.** Place the popcorn bag onto the cookware in accordance with the instructions on the packaging.
- **3.** Use the recommended settings when configuring the appliance settings.
- **4.** The time may need to be adjusted, depending on the product and quantity in question.
- **5.** Remove the popcorn bag after 1½ minutes and shake it to ensure that the popcorn does not burn.
- **6.** Place the popcorn bag back into the oven and leave it to continue popping.
- **7.** Once you can only hear popping noises once every 2-3 seconds, switch off the appliance and take the popcorn bag out of the oven.
- 8. Wipe the cooking compartment clean afterwards.

#### Recommended settings for desserts and compote

Food	Accessory/ cookware	Height	Type of heating	Temper- ature in °C	Microwave power set- ting in W	Steam setting / Crisp Fin- ish	Cooking time in mins
Blancmange made from blancmange powder	Covered cook- ware	2	<b>2</b>	-	600	-	5-8 <sup>1</sup>
Yoghurt	Individual moulds	Cooking compart- ment floor		35-40	-	-	300-360

<sup>&</sup>lt;sup>1</sup> Stir the food one or two times during cooking.

Food	Accessory/ cookware	Height	Type of heating	Temper- ature in °C	Microwave power set- ting in W	Steam setting / Crisp Fin- ish	Cooking time in mins
Microwave popcorn, 1 x 100 g bag <sup>1</sup>	Uncovered cookware	2	<b>2</b>	_	600	_	4-6

#### 33.7 Special cooking methods and other applications

Information and recommended settings for special cooking methods and other applications, e.g. low-temperature cooking.

#### Low-temperature cooking

For all prime cuts which are to be cooked rare or "à point". When slow cooking at low temperatures, meat and poultry remain juicy and tender.

#### Low-temperature cooking poultry or meat

Note: When using the low-temperature cooking type of heating, you cannot delay the start of the programme by setting an end time.

**Requirement:** The cooking compartment is cold.

- 1. Use fresh, hygienically perfect meat. Pieces without bones and without a lot of connective tissue are most suitable.
- 2. Place the cookware onto the wire rack at level 2 in the cooking compartment.
- 3. Preheat the cooking compartment and cookware for approx. 15 minutes.

- 4. Sear the meat on all sides on the hob at a very high heat
- 5. Immediately place the meat into the pre-warmed cookware in the cooking compartment. To ensure that the temperature in the cooking compartment remains constant, keep the cooking compartment door closed during low-temperature cook-

#### Tips for low-temperature cooking

Here you will find tips for achieving good results when low-temperature cooking food.

Issue	Tip
You want to cook a duck breast at a low temperature.	<ul> <li>Place the cold duck breast into a pan.</li> <li>Sear the skin side first.</li> <li>Cook the duck breast at low temperature.</li> <li>After low-temperature cooking, grill the duck breast for 3 to 5 minutes until crispy.</li> </ul>
You want to serve your low-temperature cooked meat as hot as possible.	<ul> <li>Preheat the serving plate.</li> <li>Make sure that the accompanying sauces are very hot when you serve them.</li> </ul>

#### Recommended settings for low-temperature cooking

Food	Accessory/ cookware	Height	Searing time in mins	Type of heating	Temper- ature in °C	Mi- crowave power setting in W	Steam setting / Crisp Fin- ish	Cooking time in mins
Duck breast, medium rare, 300 g each	Uncovered cookware	2	6-8		90 2	-	-	45-60
Fillet of pork, whole	Uncovered cookware	2	4-6		80 <sup>2</sup>	-	-	45-70
Fillet of beef, 1 kg	Uncovered cookware	2	4-6		80 <sup>2</sup>	-	-	90-120
Veal medallions, 4 cm thick	Uncovered cookware	2	4		80 <sup>2</sup>	-	-	30-50
Saddle of lamb, boned, 200 g each	Uncovered cookware	2	4		80 <sup>2</sup>	-	_	30-45

#### Proving dough

Yeast dough proves more quickly in your appliance than at room temperature and does not dry out.

**Requirement:** The cooking compartment is cold.

1. Slide the wire rack into the cooking compartment.

2. Place the dough onto the wire rack in a bowl. Do not cover the bowl.

<sup>&</sup>lt;sup>1</sup> Place the sealed bag on the cookware.

<sup>&</sup>lt;sup>2</sup> Preheat the appliance.

- **3.** Use the recommended settings when configuring the appliance settings.
  - The values are guide values only. The temperature and proving time are dependent on the type and quantity of the ingredients.
- **4.** Do not open the appliance door while the dough is proving, otherwise moisture will escape.
- Wipe the cooking compartment dry before baking in it.

#### Recommended settings for proving dough

Food	Accessory/ cookware	Height	Type of heating	Temper- ature in °C	Microwave power set- ting in W	Steam setting / Crisp Fin- ish	Cooking time in mins
Rich dough, e.g. panettone	Bowl on wire rack	2		40-45	_	-	40-90
White bread	Bowl on wire rack	2	<u></u>	35-40	_	-	30-40

#### **Defrosting**

You can defrost frozen food in your appliance.

#### Tips for defrosting food

- You can use the "microwave" mode to defrost frozen fruit, vegetables, poultry, meat, fish or baked goods.
- Remove frozen food from its packaging before you defrost it.
- Use heat-resistant, microwave-safe cookware.
- The recommended settings are for freezer-temperature food (-18 °C).
- Defrosting works best if you divide it into more than one step. The steps are listed one after the other in the recommended settings tables.
- Stir or turn the food 1-2 times during defrosting.
   Turn large items several times. Split the food into smaller pieces as it defrosts.

   Remove pieces that have already defrosted from the cooking compartment.
- Once the food has defrosted, switch off the appliance and leave the food in the appliance for another 10 to 30 minutes to allow the temperature to equalise.

#### Recommended settings for defrosting food

Food	Accessory/ cookware	Height	Type of heating	Temper- ature in °C	Microwave power set- ting in W	Steam setting / Crisp Fin- ish	Cooking time in mins
Bread, 500 g	Uncovered cookware	2	<b>2</b>	=	<b>1.</b> 180 <b>2.</b> 90	=	<b>1.</b> 3 <b>2.</b> 10-15
Bread rolls	Wire rack	2	8	140-160	90	-	2-4
Cake, moist, 500 g	Uncovered cookware	2	<u></u>	-	<b>1.</b> 180 <b>2.</b> 90	-	<b>1.</b> 2 <b>2.</b> 10-15
Cake, dry, 750 g	Uncovered cookware	2	<u></u>	-	90	-	10-15
Chicken, whole, 1.3 kg	Uncovered cookware	2	<u> </u>	-	<b>1.</b> 180 <b>2.</b> 90	-	<b>1.</b> 10 <b>2.</b> 10-15 <sup>1</sup>
Meat, whole, e.g. joint, raw meat, 1 kg	Uncovered cookware	2		-	<b>1.</b> 180 <b>2.</b> 90	-	<b>1.</b> 15 <b>2.</b> 20-30 <sup>1</sup>
Minced meat, mixed, 500 g	Uncovered cookware	2		-	<b>1.</b> 180 <b>2.</b> 90	-	<b>1.</b> 5 <b>2.</b> 10-15 <sup>1</sup>
Fish, whole, 300 g	Uncovered cookware	2		-	<b>1.</b> 180 <b>2.</b> 90	-	<b>1.</b> 3 <b>2.</b> 10-15 <sup>1</sup>
Berries, 300 g	Uncovered cookware	2	<u></u>	-	180	-	5-10
Butter, defrosting, 125 g	Uncovered cookware	2	<b>2</b>	-	90	-	7-9

#### Warming up and reheating food

Your appliance offers you various ways of warming up or reheating food. The microwave mode heats food and drinks incredibly quickly. When reheating with added steam, the food is heated up gently and looks as though freshly prepared.

#### Warming up food using the microwave mode

Use microwave-safe cookware with a lid.

<sup>&</sup>lt;sup>1</sup> Turn the dish halfway through the cooking time.

- Turn or stir the food 2-3 times during warming.
- After warming up the food, leave it to rest for 1-2 minutes.
- The food transfers heat to the cookware. The cookware can become very hot.
- Make sure that you do the following when you are warming up baby food:
  - Place bottles on the wire rack without the teat or lid
  - Shake or stir the baby food well after warming it up.
  - Always check the temperature of the baby food.
- Wipe the cooking compartment dry after using it to warm up food.

#### 

There is a possibility of delayed boiling when a liquid is heated. This means that the liquid reaches the boiling temperature without the usual steam bubbles rising to the surface. Exercise caution even when only gently shaking the container. The hot liquid may suddenly boil over and splatter.

Always place a spoon in the container when heating liquids. This prevents delayed boiling.

#### ATTENTION

Metal touching the wall of the cooking compartment will cause sparks, which may damage the appliance or the inner door pane.

Metal (e.g. a spoon in a glass) must be kept at least 2 cm from the cooking compartment walls and the inside of the door.

#### Reheating

- Use uncovered, heat-resistant cookware that is suitable for cooking with steam.
- Use wide, shallow cookware. Cold cookware extends the reheating time.
- Place the cookware on the wire rack.
- Place food that you are not reheating in cookware (e.g. bread rolls) directly onto the wire rack at level 2.
- Do not cover the food.
- Do not open the cooking compartment door while the food is being reheated, otherwise large amounts of steam will escape.
- Wipe the cooking compartment and dry the drip trough after using it to reheat food.

#### Recommended settings for heating and reheating

Food	Accessory/ cookware	Height	Type of heating	Temper- ature in °C	Microwave power set- ting in W	Steam setting / Crisp Fin- ish	Cooking time in mins
Drinks, warming up, 200 ml	Uncovered cookware	2	<u></u>	-	Max.	-	1-3
Baby food, heating up, e.g. baby bottle, 150 ml	Uncovered cookware	2		-	360	-	1-3
Vegetables, chilled, 250 g	Covered cook- ware	2	<b>≅</b>	-	600	-	3-8
Vegetables, frozen, loose, 250 g	Covered cook- ware	2		-	600	-	8-12
Plated meal, chilled, 1 portion	Uncovered cookware	2	2	120-130	-	-	15-25
Plated meal, chilled, 1 portion	Covered cook- ware	2	<u></u>	-	600	-	4-8
Soup, stew, chilled, 400 ml	Covered cook- ware	2	<b>≅</b>	-	600	-	5-7 1
Side dishes, e.g. pasta, dumplings, potatoes, rice, chilled	Covered cook- ware	2		-	600	-	5-10
Pizza, cooked, chilled	Wire rack	2	2	170-180 <sup>2</sup>	-	=	5-15
Plated meal, frozen, 1 portion	Covered cook- ware	2		-	600	-	11-15
Soup, stew, frozen, 200 ml	Covered cook- ware	2	<b>≅</b>	-	600	-	6-8 1
Side dishes, 500 g, e.g. pasta, dumplings, potatoes, rice, frozen	Covered cook- ware	2	<b>?</b>	_	600	-	7-12

<sup>&</sup>lt;sup>1</sup> Stir the food well.

<sup>&</sup>lt;sup>2</sup> Preheat the appliance.

Food	Accessory/ cookware	Height	Type of heating	Temper- ature in °C	Microwave power set- ting in W	Steam setting / Crisp Fin- ish	Cooking time in mins
Bakes, 400 g, e.g. lasagne, potato gratin, frozen	Uncovered cookware	2		180-200	180	-	20-25
Bread rolls, baguette, baked	Wire rack	2	2	150-160	1 _	-	10-20
Pizza, cooked, frozen	Wire rack	2	2	170-180	1 _	=	5-15
Bread rolls, baguette, baked, frozen	Wire rack	2	2	160-170	1 _	-	10-20

#### **Keeping food warm**

#### Tips for keeping food warm

- Using the "Keep warm" heating function prevents condensation from forming. You will not have to wipe down the cooking compartment.
- To prevent the food from drying out, you can cover it.
- Do not keep food warming for longer than 2 hours.
- Be aware that some types of food will actually continue cooking when you are keeping them warm in the oven.

The different added steam levels are suitable for keeping the following foods warm:

- Level 1: Joints and briefly roasted food
- Level 2: Bakes and side dishes
- Level 3: Stews and soups

#### 33.8 Test dishes

The information in this section is provided for test institutes to facilitate testing of the appliance in accordance with EN 60350-1 or IEC 60350-1 and EN 60705 or IEC 60705.

#### Baking

- The setting values apply to food that is placed into a cold cooking compartment.
- Take note of the information on preheating in the recommended settings tables. These setting values apply without rapid heat-up.
- For baking, use the lower of the temperatures indicated first.
- Items that are placed in the appliance on baking trays or in baking tins/dishes at the same time will not necessarily be ready at the same time.
- Shelf positions when baking on 2 levels:
  - Universal pan: Shelf position 3
     Baking tray: Shelf position 1
  - Baking tins on the wire rack:
     First wire rack: Shelf position 3
     Second wire rack: Shelf position 1
- Shelf positions when baking on 3 levels:
  - Baking tray: Shelf position 5
  - Universal pan: Shelf position 3
  - Baking tray: Shelf position 1
- Hot water sponge cake
  - When baking on 2 levels, place the springform tins at diagonally opposite corners of the wire racks.
  - As an alternative to a pan support, you can also use the Air Fry baking tray offered by us.

#### Recommended settings for baking

Food	Accessory/ cookware	Height	Type of heating	Temper- ature in °C	Microwave power set- ting in W	Steam setting / Crisp Fin- ish	Cooking time in mins
Shortbread	Baking tray	3		140-150	2 _	_	25-40
Shortbread	Baking tray	3	(8)	140-150	2 _	_	25-40
Shortbread, 2 levels	Universal pan + Baking tray	3+1	<b>⊗</b>	140-150	2 _	-	30-40
Shortbread, 3 levels	x 2 Baking tray + Universal pan	5+3+1	<b>8</b>	130-140 3	2 _	-	35-55
Small cakes	Baking tray	3		160 <sup>2</sup>	-	-	20-30
Small cakes	Baking tray	3	(8)	150 <sup>2</sup>	-	-	25-35
Small cakes, 2 levels	Universal pan	3+1	<u></u>	150 <sup>2</sup>	_	_	25-35

<sup>&</sup>lt;sup>1</sup> Preheat the appliance.

<sup>&</sup>lt;sup>2</sup> Preheat the appliance for five minutes. Do not use the rapid heating function.

Food	Accessory/ cookware	Height	Type of heating	Temper- ature in °C	Microwave power set- ting in W	Steam setting / Crisp Fin- ish	Cooking time in mins
	+ Baking tray						
Small cakes, 3 levels	x 2 Baking tray + Universal pan	5+3+1	<b>®</b>	140 1	-	-	35-45
Hot water sponge cake	Springform cake tin, dia- meter 26 cm	2		160-170 2	2 _	-	25-35
Hot water sponge cake	Springform cake tin, dia- meter 26 cm	2	<b>®</b>	160-170 2	2 _	-	25-35
Hot water sponge cake	Springform cake tin, dia- meter 26 cm	2	<b>®</b>	1. 150-160 2. 150-160	-	1 Off	<b>1.</b> 10 <b>2.</b> 20-25
Hot water sponge cake, 2 levels	x 2 Springform cake tin, dia- meter 26 cm	3+1	<b>®</b>	150-170 <sup>2</sup>	2 _	-	30-50

#### Grilling

#### Recommended settings for grilling

Food	Accessory/ cookware	Height	Type of heating	Temper- ature in °C/grill setting	Microwave power set- ting in W	Steam setting / Crisp Fin- ish	Cooking time in mins
Toasting bread	Wire rack	5		3 <sup>3</sup>	-	-	3-5

#### Microwave cooking

• To test the microwave mode on its own, switch off the drying function in the basic settings. → Page 29

#### Recommended settings for defrosting food using the microwave

Food	Accessory/ cookware	Height	Type of heating	Temper- ature in °C	Microwave power set- ting in W	Steam setting / Crisp Fin- ish	Cooking time in mins
Meat	Uncovered cookware	2	<b>\big </b>	_	<b>1.</b> 180 <b>2.</b> 90	_	<b>1.</b> 5 <b>2.</b> 10-15

#### Recommended settings for cooking food using the microwave

Food	Accessory/ cookware	Height	Type of heating	Temper- ature in °C	Microwave power set- ting in W	Steam setting / Crisp Fin- ish	Cooking time in mins
Custard	Uncovered cookware	2		-	<b>1.</b> 360 <b>2.</b> 180	-	<b>1.</b> 20 <b>2.</b> 20-25
Sponge	Uncovered cookware	2		-	600	-	7-9

<sup>&</sup>lt;sup>1</sup> Preheat the appliance for five minutes. Do not use the rapid heating function.

Preheat the appliance. Do not use the rapid heating function.
 Do not preheat the appliance.

Food	Accessory/ cookware	Height	Type of heating	Temper- ature in °C	Microwave power set- ting in W	Steam setting / Crisp Fin- ish	Cooking time in mins
Meat loaf	Uncovered cookware	2	<b>\big </b>	_	600	_	22-27

#### Recommended settings for cooking in combination with the microwave

Food	Accessory/ cookware	Height	Type of heating	Temper- ature in °C	Microwave power set- ting in W	Steam setting / Crisp Fin- ish	Cooking time in mins
Potato gratin	Uncovered cookware	2	II	170-190	360	-	25-30
Cakes	Uncovered cookware	2	<u></u>	180-200	180	-	18-23
Chicken	Wire rack	2	w w	200-220	360	=	25-35 <sup>1</sup>

### 34 Installation instructions

Observe this information when installing the appliance.






### **⚠** 34.1 General installation instructions

Follow these instructions before you start installing the appliance.

- There should be a gap of at least 35 mm between the wall and the cabinet base as well as the rear panel of the cabinet situated above.
- Ventilation slots and intake openings must not be covered.
- The safe operation of this appliance can only be guaranteed if it has been installed to a professional standard in accordance with these installation instructions. The installer shall be liable for damages incurred as a result of incorrect installation.
- Do not use the door handle for the transport or installation.
- Check the appliance for damage after unpacking it. Do not connect the appliance if it has been damaged in transit.
- Before starting up the appliance, remove any packaging material and adhesive film from the cooking compartment and the door.

- Proceed in accordance with the installation sheets for installing accessories.
- Fitted units must be heat-resistant up to 95 °C, and adjacent unit fronts up to 70 °C.
- Do not install the appliance behind a decorative door or the door of a kitchen unit. There is a risk of overheating.
- Cut-out work on the units should be carried out before installing the appliance. Remove any shavings. Otherwise, the correct operation of electrical components may be adversely affected.
- Position the appliance on a horizontal surface.
- The mains socket for the appliance must either be located in the hatched area a or outside of the area where the appliance is in-
- 1 Any unsecured units must be secured to the 3. wall using a standard bracket b.



<sup>&</sup>lt;sup>1</sup> Turn the dish 2/3 of the way through the cooking time.

- For appliances that have a hinged switch panel, make sure that the switch panel does not hit adjacent kitchen units when you open
- Wear protective gloves so that you do not cut yourself. Parts that are accessible during installation may have sharp edges.
- Dimensions of the figures in mm.

#### 

Once the appliance has been installed, the openings in the back panel of the appliance must not be accessible to children, not even through the drawers and kitchen cabinets underneath. This must be ensured through the installation. In the case of an island unit, a closed back panel is required.

### 



Caution: Magnetism

Caution for people with pacemakers Permanent magnets are used in the control panel. These may impair the functionality of electronic implants, e.g. pacemakers or insulin pumps.

► Persons with electronic implants must stand at least 10 cm away from the control panel.

#### 

It is dangerous to use an extended power cord and non-approved adapters.

- ▶ Do not use extension cables or multiple socket strips.
- Only use adapters and power cords approved by the manufacturer.
- ▶ If the power cord is too short and a longer one is not available, please contact an electrician to have the domestic installation adapted.


#### ATTENTION

Carrying the appliance by the door handle could break it. The door handle cannot support the weight of the appliance.

▶ Do not carry or hold the appliance by the door handle.


#### 34.2 Appliance dimensions

You will find the dimensions of the appliance here



#### 34.3 Installation below a worktop


Observe the installation dimensions and the installation instructions when installing below a worktop.



- To ventilate the appliance, the intermediate floor must have a ventilation cut-out.
- The worktop must be secured to the fitted unit.
- Observe any available installation instructions for the
- Observe different national installation instructions for
- Observe the worktop depth of min. 600 mm.
- When installing under a gas hob, ensure that the appliance does not come into contact with the gas connection of the gas hob.
- If necessary, call a qualified specialist for gas installation.

#### 34.4 Installation underneath a hob

If the appliance is installed under a hob, the following minimum dimensions must be adhered to (including substructure, if applicable).




The minimum worktop thickness b a is based on the required minimum clearance a.

Hob type	a raised in mm	a flush in mm	b in mm
Induction hob	37	38	5
Full-surface induction hob	47	48	5
Gas hob	27	38	5 <sup>1</sup>
Electric hob	27	30	2


#### 34.5 Installation in a tall unit

Observe the installation dimensions and the installation instructions when installing in a tall unit.



- To ventilate the appliance, the intermediate floors must have a ventilation cut-out.
- In order to ensure sufficient ventilation of the appliance, there must be a ventilation opening of at least. 200 cm<sup>2</sup> in the base area. To do this, trim the base panel or fit a ventilation grille. Ensure that the air ex-

change is guaranteed in accordance with the diagram.




 Only fit the appliance up to a height which allows accessories to be easily removed.

#### 34.6 Installing two appliances on top of each other


Your appliance can also be installed above or below another appliance. Observe the installation dimensions

<sup>&</sup>lt;sup>1</sup> Observe different national installation instructions for the hob.

and the installation instructions when installing appliances on top of each other.




- To ventilate the appliances, the intermediate floor must have a ventilation cut-out.
- To ensure sufficient ventilation of the two appliances, there must be a ventilation opening of at least 200 cm<sup>2</sup> in the base area. To do this, trim the base panel or fit a ventilation grille.
- Ensure that air exchange is guaranteed in accordance with the diagram.



 Only fit appliances up to a height that allows accessories to be easily removed.

#### 34.7 Corner installation

Observe the installation dimensions and the installation instructions when installing in a corner.




To ensure that the appliance door can be opened. vou must take the minimum dimensions into consideration when installing in a corner. The dimension a is dependent on the thickness of the unit front and the handle.

#### 34.8 Electrical connection

In order to safely connect the appliance to the electrical system, follow these instructions.

- The appliance corresponds to protection class I and must only be operated with a protective earth connec-
- The fuse protection must correspond to the power rating specified on the appliance's rating plate and to the local regulations.
- The appliance must be disconnected from the power supply whenever installation work is being carried
- The appliance must only be connected using the power cable provided.
- The power cable must be plugged in at the rear of the appliance until you hear a clicking sound. A 3 m power cable can be obtained from customer service.



- The power cable must only be replaced with a cable from the original manufacturer. This is available from after-sales service.
- Contact protection must be guaranteed by the install-
- If the display on the appliance remains dark, it has not been connected correctly. Disconnect the appliance from the mains and check the connection.

#### Electrically connect the appliance with the protective contact plug

Note: The appliance must only be connected to a protective contact socket that has been correctly installed.

► Insert the plug into the protective contact socket. When the appliance is installed, the mains plug of the power cord must be freely accessible. If free access is not possible, an isolating switch must be integrated into the permanent electrical installation according to the installation regulations.

#### Electrically connecting an appliance without a protective contact plug

Note: Only licensed specialists may connect the appliance. Damage caused by incorrect connection is not covered under the warranty.

An isolating switch must be integrated into the permanent electrical installation according to the installation regulations.


1. Identify the phase and neutral conductors in the

The appliance may be damaged if it is not connected correctly.


- **2.** Connect the hob in accordance with the connection diagram.
  - See the rating plate for the voltage.
- **3.** Connect the wires of the mains power cable according to the colour coding:
  - ► Green/yellow = Protective conductor ⊕
  - ► Blue = Neutral conductor
  - ► Brown = Phase (external conductor)

#### 34.9 Installing the appliance

1. Slide the appliance in fully and centre it.



2. Screw the appliance into place.




**Note:** The gap between the worktop and the appliance must not be closed by additional battens.

Thermal insulation strips must not be fitted to the side panels of the surround unit.


# 34.10 For handleless kitchens with vertical bar handle strips:

**1.** Attach a suitable filling piece on both sides in order to cover any sharp edges and to guarantee safe installation.




2. Secure the filling piece to the unit.

**3.** Pre-drill the filling piece and the unit to establish a screw connection.



4. Secure the appliance using a suitable screw.



#### 34.11 Removing the appliance

- 1. Disconnect the appliance from the power supply.
- 2. Undo the fastening screws.
- 3. Lift the appliance slightly and pull it out completely.







EN Manufactured by BSH Hausgeräte GmbH under the trademark licence of Siemens AG

Valid within Great Britain:
Imported to Great Britain by
BSH Home Appliances Ltd.
Grand Union House
Old Wolverton Road
Wolverton, Milton Keynes
MK12 5PT
United Kingdom

### **BSH Hausgeräte GmbH**

Carl-Wery-Straße 34 81739 München, GERMANY siemens-home.bsh-group.com



**9001647986** (050630) REG25

en