



## Oven

HR578G5.6B

**en** User manual and installation instructions



Register your product on My Siemens and discover exclusive services and offers. siemens-home.bsh-group.com/welcome

The future moving in.

## Table of contents

#### **USER MANUAL**

1	Safety2	
2	Preventing material damage5	
3	Environmental protection and saving en- ergy	
4	Familiarising yourself with your appliance7	
5	Accessories 10	
6	Before using for the first time 11	
7	Basic operation 12	
8	Steam 12	
9	Time-setting options 14	
10	Meat thermometer 16	
11	Programme 17	
12	Childproof lock 20	
13	Rapid heating 20	
14	Sabbath mode 21	
15	Basic settings 21	
16	Home Connect 23	
17	Cleaning and servicing 25	
18	Self-cleaning 27	
19	Descaling	
20	Shelf supports 29	
21	Appliance door	
22	Troubleshooting	
23	Disposal	
24	Customer Service	
25	Declaration of Conformity 37	
26	How it works 37	
27	INSTALLATION INSTRUCTIONS	
27.1	General installation instructions 42	

## 1 Safety

Observe the following safety instructions.

## 1.1 General information

• Read this instruction manual carefully.

- Keep the instruction manual and the product information safe for future reference or for the next owner.
- Do not connect the appliance if it has been damaged in transit.

## 1.2 Intended use

This appliance is designed only to be built into kitchen units. Read the special installation instructions.

Only a licensed professional may connect appliances without plugs. Damage caused by incorrect connection is not covered under the warranty.

Only use this appliance:

- To prepare meals and drinks.
- In private households and in enclosed spaces in a domestic environment.
- Up to an altitude of max. 4000 m above sea level.

## 1.3 Restriction on user group

This appliance may be used by children aged 8 or over and by people who have reduced physical, sensory or mental abilities or inadequate experience and/or knowledge, provided that they are supervised or have been instructed on how to use the appliance safely and have understood the resulting dangers.

Children must not play with the appliance. Children must not perform cleaning or user maintenance unless they are at least 15 years old and are being supervised.

Keep children under the age of 8 years away from the appliance and power cable.

## 1.4 Safe use

Always place accessories in the cooking compartment the right way round.

→ "Accessories", Page 10

## ▲ WARNING – Risk of fire!

Combustible objects that are left in the cooking compartment may catch fire.

- Never store combustible objects in the cooking compartment.
- If smoke is emitted, the appliance must be switched off or the plug must be pulled out and the door must be held closed in order to stifle any flames.

Loose food remnants, fat and meat juices may catch fire.

Before using the appliance, remove the worst of the food residues and remnants from the cooking compartment, heating elements and accessories.

Opening the appliance door creates a draught. Greaseproof paper may come into contact with the heating element and catch fire.

- Never place greaseproof paper loosely over accessories when preheating the appliance and while cooking.
- Always cut greaseproof paper to size and use a plate or baking tin to hold it down.

## MARNING – Risk of burns!

The appliance and its parts that can be touched become hot during use.

- Caution should be exercised here in order to avoid touching heating elements.
- Young children under 8 years of age must be kept away from the appliance.

Accessories and cookware get very hot.

 Always use oven gloves to remove accessories or cookware from the cooking compartment.

When the cooking compartment is hot, any alcoholic vapours inside may catch fire.

- Only use small quantities of drinks with a high alcohol content in food.
- Open the appliance door carefully.

## MARNING – Risk of scalding!

The accessible parts of the appliance become hot during operation.

- Never touch these hot parts.
- ► Keep children at a safe distance.

Hot steam may escape when you open the appliance door. Steam may not be visible, depending on the temperature.

- Open the appliance door carefully.
- Keep children at a safe distance.

If there is water in the cooking compartment when it is hot, this may create hot steam.

 Never pour water into the cooking compartment when the cooking compartment is hot.

## ⚠ WARNING – Risk of injury!

Scratched glass in the appliance door may develop into a crack.

Do not use any harsh or abrasive cleaners or sharp metal scrapers to clean the glass on the oven door, as they may scratch the surface.

The hinges on the appliance door move when the door is opened and closed, which could trap your fingers.

► Keep your hands away from the hinges. Components inside the appliance door may have sharp edges.

Wear protective gloves.

## ▲ WARNING – Risk of electric shock!

Incorrect repairs are dangerous.

- Repairs to the appliance should only be carried out by trained specialist staff.
- Only use genuine spare parts when repairing the appliance.
- If the power cord of this appliance is damaged, it must be replaced by trained specialist staff.

If the insulation of the power cord is damaged, this is dangerous.

- Never let the power cord come into contact with hot appliance parts or heat sources.
- Never let the power cord come into contact with sharp points or edges.
- Never kink, crush or modify the power cord.

An ingress of moisture can cause an electric shock.

Do not use steam- or high-pressure cleaners to clean the appliance.

If the appliance or the power cord is damaged, this is dangerous.

- ► Never operate a damaged appliance.
- Never operate an appliance with a cracked or fractured surface.
- Never pull on the power cord to unplug the appliance. Always unplug the appliance at the mains.
- If the appliance or the power cord is damaged, immediately unplug the power cord or switch off the fuse in the fuse box.
- ► Call customer services. → Page 36

## MARNING – Danger: Magnetism!

Permanent magnets are used in the control panel or in the controls. These may affect electronic implants, e.g. heart pacemakers or insulin pumps.

 Wearers of electronic implants must stay at least 10 cm away from the control panel.

### MARNING – Risk of suffocation!

Children may put packaging material over their heads or wrap themselves up in it and suffocate.

- Keep packaging material away from children.
- Do not let children play with packaging material.

Children may breathe in or swallow small parts, causing them to suffocate.

- Keep small parts away from children.
- ► Do not let children play with small parts.

## 1.5 Halogen bulb

### ▲ WARNING – Risk of burns!

The bulbs in the cooking compartment get very hot. There is still a risk of burning for some time after they have been switched off.

- Do not touch the glass cover.
- Avoid contact with your skin when cleaning.

#### MARNING – Risk of electric shock!

When changing the bulb, the bulb socket contacts are live.

- Before replacing the bulb, ensure that the appliance is switched off in order to prevent a potential electric shock.
- Also unplug the appliance from the mains or switch off the circuit breaker in the fuse box.

## 1.6 Steam

Follow these instructions when using a steam function.

#### ▲ WARNING – Risk of scalding!

The water in the water tank may become very hot if you operate the appliance for long periods.

 Always empty the water tank after using the steam function.

Hot steam is generated in the cooking compartment.

 Do not reach into the cooking compartment when using steam. Hot liquid may spill over the sides of the accessory when it is removed from the cooking compartment.

 Remove hot accessories with care and always wear oven gloves.

## ▲ WARNING – Risk of fire!

Due to the hot surfaces, vapours from flammable liquids may catch fire in the cooking compartment (explosion). The appliance door may spring open. Hot steam and jets of flame may escape.

- Do not pour flammable liquids (e.g. alcoholic drinks) into the water tank.
- Only fill the water tank with water or with the descaling solution we have recommended.

## 1.7 Meat probe

#### ▲ WARNING – Risk of electric shock!

Using the wrong meat probe could damage the insulation.

 Only use the meat probe for this specific appliance.

## **1.8 Cleaning function**

## ▲ WARNING – Risk of fire!

Loose food remnants, fat and meat juices may catch fire when the cleaning function is in progress.

- Before you start the cleaning function, always remove coarse dirt from the cooking compartment.
- Never clean accessories at the same time. The outside of the appliance gets very hot when the cleaning function is in progress.
- Never hang combustible objects, e.g. tea towels, on the door handle.
- ► Leave the front of the appliance clear.
- ► Keep children at a safe distance.

If the door seal is damaged, a large amount of heat is generated around the door.

- Do not scrub or remove the seal.
- Never operate the appliance if the seal is damaged or missing.

# ▲ WARNING – Risk of serious harm to health!

The appliance gets very hot when the cleaning function is in progress. The non-stick coating on baking trays and tins is destroyed and noxious gases are released.

- Never clean non-stick baking trays or baking tins using the cleaning function.
- Never clean accessories at the same time.

#### MARNING – Risk of harm to health!

The cleaning function heats up the cooking compartment to a very high temperature so that food left over from roasting, grilling and baking will burn off. This process releases vapours, which can irritate mucous membranes.

- Keep the kitchen well ventilated while the cleaning function is running.
- ► Do not remain in the room for long periods.
- Keep children and pets away.

## 2 Preventing material damage

## 2.1 General

#### ATTENTION!

Objects on the cooking compartment floor at over 50 °C will cause heat to build up. The baking and roasting times will no longer be correct and the enamel will be damaged.

- Do not place any accessories, greaseproof paper or foil of any kind on the cooking compartment floor.
- Only place cookware on the cooking compartment floor if a temperature above 50 °C has been set.
   When the cooking compartment is hot, any water inside it will create steam. The change in temperature may cause damage.
- Never pour water into the cooking compartment when it is still hot.
- Never place cookware containing water on the cooking compartment floor.

The prolonged presence of moisture in the cooking compartment leads to corrosion.

- Allow the cooking compartment to dry after use.
- Do not keep moist food in the cooking compartment for a long time with the door closed.
- Do not store food in the cooking compartment.

Leaving the appliance to cool down with the door open will damage the front of neighbouring kitchen units over time.

- Always allow the cooking compartment to cool down with the door closed after cooking at high temperatures.
- Take care not to trap anything in the appliance door.
- Only leave the cooking compartment to dry with the door open if a lot of moisture was produced during operation.

## ▲ WARNING – Risk of burns!

The cooking compartment gets very hot when the cleaning function is in progress.

- Never open the appliance door.
- Allow the appliance to cool down.
- Keep children at a safe distance.

 $\triangle$  The outside of the appliance gets very hot when the cleaning function is in progress.

- Never touch the appliance door.
- Allow the appliance to cool down.
- ► Keep children at a safe distance.

Fruit juice dripping from the baking tray leaves stains that cannot be removed.

- When baking very juicy fruit flans, do not pack too much on the baking tray.
- ► If possible, use the deeper universal pan.

Using oven cleaner in a hot cooking compartment damages the enamel.

- Never use oven cleaner in the cooking compartment when it is still warm.
- Remove all food remnants from the cooking compartment and the appliance door before you next heat up the appliance.

If the seal is very dirty, the appliance door will no longer close properly during operation. This may damage the front of adjacent kitchen units.

- Keep the seal clean at all times.
- Never operate the appliance if the seal is damaged or missing.

Sitting or placing objects on the appliance door may damage it.

- Do not place or hang objects on the appliance door.
- Do not place cookware or accessories on the appliance door.

With certain models, accessories may scratch the door pane when closing the appliance door.

 Always push accessories fully into the cooking compartment.

## 2.2 Steam

Follow these instructions when using the steam function.

#### ATTENTION!

Silicone bakeware is not suitable for combined operation with steam.

Cookware must be heat- and steam-resistant.

Using cookware with rust spots may cause corrosion in the cooking compartment. Even the smallest spots of rust can cause corrosion.

Do not use cookware with rust spots.

Hot water in the water tank may damage the steam system.

Only fill the water tank with cold water.

If there is water on the cooking compartment floor when operating the appliance at temperatures above 120 °C, this will damage the enamel.

- Do not use the appliance if there is water on the cooking compartment floor.
- Wipe away any water on the cooking compartment floor before operation.

If descaling solution comes into contact with the control panel or other delicate surfaces, it will damage them.
Remove descaling solution immediately with water.

Cleaning the water tank in the dishwasher will damage it.

- Do not clean the water tank in the dishwasher.
- Clean the water tank with a soft cloth and standard washing-up liquid.

## 3 Environmental protection and saving energy

## 3.1 Disposing of packaging

The packaging materials are environmentally compatible and can be recycled.

 Sort the individual components by type and dispose of them separately.

## 3.2 Saving energy

If you follow these instructions, your appliance will use less power.

Only preheat the appliance if the recipe or the recommended settings tell you to do so.

Not preheating the appliance can reduce the energy used by up to 20%.

Use dark-coloured, black-coated or enamelled baking tins.

• These types of baking tin absorb the heat particularly well.

Open the appliance door as little as possible during operation.

 This will maintain the temperature in the cooking compartment and eliminate the need for the appliance to reheat.

When baking multiple dishes, do so in succession or in parallel.

 The cooking compartment is heated after baking the first dish. This reduces the baking time for the second cake.

If the cooking time is relatively long, you can switch the appliance off 10 minutes before the cooking time ends.

• There will be enough residual heat to finish cooking the dish.

Remove any accessories that are not being used from the cooking compartment.

 Accessories that are not being used do not need to be heated.

Allow frozen food to defrost before cooking.


 This will save the energy that would otherwise be required to defrost it.

## 4 Familiarising yourself with your appliance

## 4.1 Controls

You can use the control panel to configure all functions of your appliance and to obtain information about the operating status.

**Note:** On certain models, specific details such as colour and shape may differ from those pictured.



## 4.2 Buttons and display

You can use the buttons to set various functions for your appliance. The display shows the settings.

If a function is active, the corresponding symbol lights up in the display. The clock symbol  $\bigcirc$  only lights up when you change the time.

Symbol	Function	Use	
Ċ	Time-setting options	Select the time $\textcircled{O}$ , timer $\clubsuit$ , cooking time $\dashv$ and the end time $\dashv$ . To select the individual time-setting options, press the $\textcircled{O}$ button several times. The arrows $\diamondsuit$ above and below a symbol indicate the function to which the setting in the display corresponds.	
	Minus	Decrease the setting values.	
+	Plus	Increase the setting values.	
<u>ک</u>	Oven light	Switch the lighting in the cooking compartment on and off.	
»∭	Rapid heating	Preheat the cooking compartment rapidly without accessories.	
少	Steam assistance	ance Starts or cancels steam assistance → "Steam", Page 12	
~	Childproof lock Activate or deactivate the childproof lock.		
<b>↑</b>	Empty the water tank Prompt to empty the water tank $\rightarrow$ "After every steam operation", Page 14		
	Fill the water tank Prompt to fill the water tank → "Steam", Page 12		
calc	Descale	Prompt to descale the appliance → "Descaling", Page 28	
Eln	Descale	Descaling programme interrupted → "Descaling interrupted", Page 28	

### 4.3 Types of heating and functions

To ensure that you always use the right type of heating to cook your food, we have explained the differences and applications below.

When you select a type of heating, the appliance suggests a suitable temperature or setting. You can use these values or change them within the specified range.

Symbol	Type of heating and temperature range	What it's used for/how it works		
8	3D hot air <sup>1</sup> 30 - 275 °C	Bake and roast on one or more levels. The fan distributes the heat from the ring-shaped heating element in the back wall evenly around the cooking compartment.		
æ	Hot air gentle 125 - 275 °C	Cook selected dishes gently on one level without preheating. The fan distributes the heat from the ring-shaped heating element in the back wall evenly around the cooking compartment. The food is cooked in phases us- ing residual heat. Always keep the appliance door closed when cooking. This type of heating is used to determine the energy consumption in air recircu- lation mode and the energy efficiency class.		
Ŕ	Reheat <sup>2</sup> 80 - 180 °C	For gently reheating food or for crisping up baked goods.		
<b>»</b> ξ	coolStart function 30 - 275 °C			
8	Pizza setting 30 - 275 °C	Cook pizza or dishes that require a lot of heat from below. The bottom heating element and the ring-shaped heating element in the back wall heat the cooking compartment.		
~~	Full-surface grill Grill settings: 1 = low 2 = medium 3 = high	Grill flat items such as steak and sausages, or make toast. Gratinate food. The entire area underneath the grill element becomes hot.		

<sup>2</sup> Steam heating function (water tank must be full before appliance is operated)

Symbol	Type of heating and temperature range	What it's used for/how it works
<b>}~</b>	Hot air grilling <sup>1</sup> 30 - 275 °C	Roast poultry, whole fish and larger pieces of meat. The grill element and the fan switch on and off alternately. The fan circulates the hot air around the food.
	Top/bottom heating <sup>1</sup> 30 - 275 °C	Traditionally bake or roast on one level. This type of heating is ideal for cakes with moist toppings. The heat is emitted evenly from above and below. This type of heating is used to measure the energy consumption in the conventional mode.
		rom 80 °C and over (water tank must be filled before operating) ank must be full before appliance is operated)

#### Other functions

Here, you can find an overview of other functions of your appliance.

Symbol	Function	Use
Ρ	Programme	Use programmed setting values for various types of food. → "Programme", Page 17
Cleaning functions		<ul> <li>Self-cleaning IIII cleans the cooking compartment almost by itself. → "Self-cleaning ", Page 27</li> <li>Descaling III your appliance keeps it working properly. → "Descaling", Page 28</li> </ul>
	Remote start	Start and operate the appliance via the Home Connect app. $\rightarrow$ Page 23

Note: If you operate your appliance with the

Home Connect app, even more functions are available for you. You can find more information about this in the app.

## 4.4 Temperature and setting levels

There are different settings for the types of heating and functions.

The settings appear in the display.

The temperature can be set in 1 degree increments up to 100  $^\circ\text{C},$  and in 5 degree increments thereafter.

**Note:** For grill setting 3, the appliance lowers the setting to grill setting 1 after approx. 20 minutes.

#### **Heat-up indicator**

The appliance indicates when it is heating up. When the appliance is heating, the **!** symbol fills with colour on the display.

When you are preheating the appliance, the optimal time to place your food in the cooking compartment is as soon as the symbol is completely filled with colour.

#### **Residual heat indicator**

If you switch off the appliance, the symbol on the display shows the residual heat in the cooking compartment. The lower the temperature in the cooking compartment, the less the symbol is filled.

#### Notes

- The heat-up indicator will only show the temperature increasing for types of heating for which a temperature is set. For grill settings, for example, the heat-up indicator shows a full line from the beginning.
- If the temperature in the cooking compartment is too high when the appliance is started, *h* appears in the display for some types of heating. Switch off the appliance and allow it to cool down. Then restart operation of the appliance.

 Due to thermal inertia, the temperature displayed may differ slightly from the actual temperature inside the cooking compartment.

## 4.5 Cooking compartment

The functions in the cooking compartment make your appliance easier to use.

#### Shelf supports


The shelf supports in the cooking compartment enable you to place accessories at different heights.

→ "Accessories", Page 10

Your appliance has five shelf positions. The shelf positions are numbered from bottom to top.

Depending on the appliance, the shelf supports are fitted with pull-out rails or clip-on pull-out rails. The pullout rails are fixed in place and cannot be removed. The clip-on pull-out rails allow you to use them as you wish at all free shelf positions.

You can remove the shelf supports, e. g. for cleaning.  $\rightarrow$  "Shelf supports", Page 29



#### Lighting

The oven light lights up the cooking compartment. With most types of heating and functions, the lighting lights up during operation. The lighting goes off when operation ends.

You can switch on the lighting without heating the oven using the **Oven light** button.

#### Cooling fan

The cooling fan switches on and off depending on the appliance's temperature. The hot air escapes above the door.

## **5** Accessories

Use original accessories. These have been made especially for your appliance.

**Note:** Accessories may become deformed if they get hot. Deformation has no effect on function. As the accessory cools down, it will regain its original shape.

#### ATTENTION!

Do not cover the ventilation slot above the appliance door. The appliance overheats.

Ensure that the ventilation slots are unobstructed.

To ensure that the appliance cools down more quickly after operation, the cooling fan continues to run for a certain period afterwards.

#### Appliance door

If you open the appliance door during operation, the appliance stops heating. When you close the appliance door, the appliance continues to heat again.

The accessories supplied may differ depending on the appliance model.

Accessories	Use
Wire rack	<ul> <li>Cake tins</li> <li>Ovenproof dishes</li> <li>Cookware</li> <li>Meat, e.g. roasting joints or steak</li> <li>Frozen meals</li> </ul>
Universal pan	<ul> <li>Moist cakes</li> <li>Baked items</li> <li>Bread</li> <li>Large roasts</li> <li>Frozen meals</li> <li>Catching dripping liquids, e.g. fat when grilling food on the wire rack.</li> </ul>
Meat thermometer	High-precision roasting or cooking. → "Meat thermometer", Page 16

## 5.1 Locking function

The locking function prevents the accessories from tilting when they are pulled out.


You can pull out the accessories approximately halfway without them tipping. The accessories must be inserted into the cooking compartment correctly for the tilt protection to work properly.

# 5.2 Sliding accessories into the cooking compartment

Always slide accessories into the cooking compartment correctly. This is the only way to ensure that accessories can be pulled out approximately halfway without tipping.


- 1. Turn the accessories so that the notch a is at the rear and is facing downwards.
- **2.** Insert accessories between the two guide rods for the shelf position.

Wire rack Insert the wire rack with the open side facing the appliance door and the curved lip — facing downwards.




Baking tray E.g. universal pan or baking tray

Slide the tray, e.g. the universal pan, in with the sloping edge b facing the appliance door.



**3.** Place the accessory at the shelf positions with the pull-out rails and pull out the pull-out rails.



**Note:** The pull-out rails lock in place when they are fully pulled out. Gently push the pull-out rails back into the cooking compartment.

**4.** Push the accessory all the way in, making sure that it does not touch the appliance door.


**Note:** Take any accessories that you will not be using out of the cooking compartment while the appliance is in operation.

#### **Combining accessories**

You can combine the wire rack with the universal pan to catch any liquid that drips down.

- 1. Place the wire rack on the universal pan so that both spacers a are on the rear edge of the universal pan.
- 2. Insert the universal pan between the two guide rods for a shelf position. In so doing, the wire rack is on top of the upper guide rod.

Wire rack on universal pan



## 5.3 Other accessories

You can purchase other accessories from our aftersales service, specialist retailers or online. You will find a comprehensive range of products for your appliance in our brochures and online: www.siemens-home.bsh-group.com Accessories vary from one appliance to another. When purchasing accessories, always quote the exact product number (E no.) of your appliance. You can find out which accessories are available for your appliance in our online shop or from our aftersales service.

## 6 Before using for the first time

Configure the settings for initial start-up. Clean the appliance and accessories.

## 6.1 Initial use

You need to make settings for initial use before you can use your appliance.

#### Setting the time on the clock

Once the appliance has been connected to the mains or following a power failure, the time flashes on the display. The time starts at "12:00". Set the current time.

**Requirement:** The function selector must be set to the "Off" position **Q**.

- **1.** Use the or + button to set the time.
- **2.** Press the  $\bigcirc$  button.
- ✓ The time that is set appears on the display.

**Tip:** You can go to the basic settings  $\rightarrow$  *Page 21* to specify whether or not the time should be shown on the display.

#### Reference to setting the water hardness

- Set the water hardness.
  - → "Setting the water hardness", Page 22

# 6.2 Cleaning the appliance before using it for the first time

Clean the cooking compartment and accessories before using the appliance to prepare food for the first time.

- 1. Remove any accessories and leftover packaging, such as polystyrene pellets, from the cooking compartment.
- 2. Before heating the appliance, wipe the smooth surfaces in the cooking compartment with a soft, damp cloth.

- Fill the water tank.
   → "Filling the water tank", Page 13
- 4. Keep the room ventilated while the appliance is heating.
- 5. Set the type of heating with steam assistance and the temperature.
  - $\rightarrow$  "Steam-assisted cooking", Page 12
  - → "Basic operation", Page 12

Type of heat- ing	3D hot air
Temperature	200 °C
Cooking time	30 minutes

- 6. Switch off the appliance after the specified cooking time.
- 7. Wait until the cooking compartment has cooled down.

## 7 Basic operation

## 7.1 Switching on the appliance

- Turn the function selector to any position other than the "Off" position o.
- ✓ The appliance is switched on.

## 7.2 Switching off the appliance

- ► Turn the function selector to the "Off" position •.
- ✓ The appliance is switched off.

# 7.3 Setting the type of heating and temperature

- 1. Use the function selector to set the type of heating.
- **2.** Use the temperature selector to set the temperature or grill setting.
- ✓ The appliance starts heating after a few seconds.
- Depending on the appliance type, rapid heating »∭ automatically switches off for set temperatures of 200 °C and above for certain types of heating.
   → "Rapid heating", Page 20

## 8 Steam

You can switch on steam assistance with some heating types.

#### MARNING – Risk of scalding!

Hot steam may escape when you open the appliance door. Steam may not be visible, depending on the temperature.

- Open the appliance door carefully.
- Keep children at a safe distance.

## MARNING – Risk of burns!

The water tank may heat up while the appliance is in operation.

- Wait until the water tank has cooled down from the previous operation.
- Remove the water tank from the tank recess.

- 8. Empty the water tank and dry the cooking compartment.
  - $\rightarrow$  "After every steam operation", Page 14
- **9.** Set the type of heating with steam assistance and the temperature.

Type of heat- ing	Top/bottom heating
Temperature	240 °C
Cooking time	30 minutes

- **10.** Switch off the appliance after the specified cooking time.
- **11.** Wait until the cooking compartment has cooled down.
- **12.** Clean the smooth surfaces with soapy water and a dish cloth.
- **13.** Clean the accessories using soapy water and a dish cloth or soft brush.
- **3.** When your food is ready, switch off the appliance.

#### Tips

- The most suitable type of heating for your food can be found in the description of the type of heating.
   → "Types of heating and functions", Page 8
- You can also set a cooking time and end time on the appliance.
  - → "Time-setting options", Page 14

#### Changing the type of heating

You can change the type of heating at any time.

 Use the function selector to set the required type of heating.

#### Changing the temperature

You can change the temperature at any time.

 Use the temperature selector to set the required temperature.

## 8.1 Steam-assisted cooking

When you cook with steam assistance, the appliance introduces steam into the cooking compartment at various intervals. This gives your food a crispy crust and a shiny surface. Meat stays juicy, tender and only undergoes a minimum reduction in volume.

#### Starting steam-assisted cooking

Tip: Use the programmes or the settings in the tables.

- **1.** Fill the water tank.
  - $\rightarrow$  "Filling the water tank", Page 13
- 2. Set a suitable type of heating:
  - 3D hot air 🛞
  - Top/bottom heating
  - Hot air grilling 🖾

- 3. Set a temperature between 80 and 240 °C.
- 4. Use the  $\oplus$  button to set the steam intensity.

Intensity	Setting	
Low	少 /	
High	少2	

 The appliance starts to heat and produce steam after a few seconds.

#### Cancelling steam-assisted cooking

- ► Press the <sup>(1)</sup> button repeatedly until the steam intensity goes out in the display.
- The appliance continues to operate but without steam assistance.
  - → "After every steam operation", Page 14

#### Ending steam-assisted cooking

- 1. Switch off the appliance.
- 2. Empty the water tank and dry the cooking compartment.
  - → "After every steam operation", Page 14

#### 8.2 Reheating

With the "Reheating" (a) type of heating, you can gently reheat food that has already been cooked or crisp up day-old baked goods. The appliance switches the steam on automatically.

#### Starting reheating

**Requirement:** The cooking compartment has cooled down.

- 1. Fill the water tank.
- $\rightarrow$  "Filling the water tank", Page 13
- 2. Set the regeneration 🗟 type of heating.
- **3.** Set the temperature.
- The appliance starts to heat and produce steam after a few seconds.

#### **Ending reheating**

- **1.** Switch off the appliance.
- 2. Empty the water tank and dry the cooking compartment.
  - → "After every steam operation", Page 14

#### 8.3 Filling the water tank

#### A WARNING – Risk of fire!

Due to the hot surfaces, vapours from flammable liquids may catch fire in the cooking compartment (explosion). The appliance door may spring open. Hot steam and jets of flame may escape.

- Do not pour flammable liquids (e.g. alcoholic drinks) into the water tank.
- Only fill the water tank with water or with the descaling solution we have recommended.


#### **WARNING** – Risk of burns!

The water tank may heat up while the appliance is in operation.


- Wait until the water tank has cooled down from the previous operation.
- Remove the water tank from the tank recess.

**Requirement:** The water hardness has now been set correctly.


- $\rightarrow$  "Setting the water hardness", Page 22
- 1. Press on the water tank ① and pull the water tank out ②.



Press on the water tank lid ① and unscrew it ②.
 Fill the water tank with water up to the mark ③.



4. Press on the water tank lid ① and screw it on ②.
5. Place the water tank back in the opening and press it down until it clicks into place ③.



#### Refilling the water tank

If an audible signal sounds and "Fill water tank"  $\blacktriangleright$  appears in the display, refill the water tank.

**Note:** If you do not refill the water tank, operation of the appliance continues without steam-assisted cooking.

- **1.** Remove and refill the water tank.
- **2.** Refit the filled water tank.

## 8.4 After every steam operation

The remaining water is pumped back into the water tank after every operation with steam. Then empty and dry the water tank and the cooking compartment.

#### Emptying the water tank

#### MARNING – Risk of burns!

The water tank may heat up while the appliance is in operation.

- Wait until the water tank has cooled down from the previous operation.
- Remove the water tank from the tank recess.

#### **ATTENTION!**

Drying the water tank in the hot cooking compartment leads to damage to the water tank.

 Do not dry the water tank in the hot cooking compartment.

Cleaning the water tank in the dishwasher will damage it.

- Do not clean the water tank in the dishwasher.
- Clean the water tank with a soft cloth and standard washing-up liquid.
- 1. Press on the water tank.
- 2. Pull out the water tank.
- 3. Unscrew the lid on the water tank.
- **4.** Empty the water tank, clean it with detergent and then rinse it thoroughly with clean water.
- **5.** Dry all parts with a soft cloth.
- 6. Rub the seal on the lid until dry.
- 7. Leave the water tank to dry with the lid open.
- 8. Place the lid on the water tank and screw it on.
- 9. Insert the water tank.

#### Drying the drip trough

#### A WARNING – Risk of burns!

The appliance becomes hot during operation.

Allow the appliance to cool down before cleaning.

**Requirement:** The cooking compartment has cooled down.

## 9 Time-setting options


Your appliance has different time-setting options, with which you can control its operation.

## 9.1 Overview of the time-setting options

With the  $\ensuremath{\textcircled{}}$  button, select the different time-setting options.

Time-setting option	Use
Timer <b></b>	The timer can be set independently of the appliance when it is in opera- tion. It does not affect the appliance.
Cooking time ⊢ <del>)</del>	If you set a cooking time, operation of the appliance stops automatically once this time has elapsed.

- 1. Open the appliance door.
- 2. Note:
  - The drip trough a is underneath the cooking compartment.



Soak up the water in the drip trough a with a sponge cloth and wipe it carefully.

#### Drying the cooking compartment

#### MARNING – Risk of burns!

- The appliance becomes hot during operation.
- Allow the appliance to cool down before cleaning.

#### **ATTENTION!**

If there is water on the cooking compartment floor when operating the appliance at temperatures above 120  $^{\circ}$ C, this will damage the enamel.

- Do not use the appliance if there is water on the cooking compartment floor.
- Wipe away any water on the cooking compartment floor before operation.

**Requirement:** The cooking compartment has cooled down.

- 1. Remove any dirt from the cooking compartment.
- **2.** Dry the cooking compartment with a sponge.
- **3.** Remove limescale marks with a cloth soaked in vinegar, then rinse with clean water and dry with a soft cloth.
- **4.** Leave the appliance door open for 1 hour so that the cooking compartment dries completely.

Time-setting option	Use
End time →	For the cooking time, you can set the time at which operation ends. The appliance starts up automatically so that it finishes cooking at the re- quired time.
Time 🕒	You can set the time.

## 9.2 Setting the timer

The timer runs independently of the appliance when it is in operation. The timer can be set when the appliance is switched on or off, up to 23 hours and 59 minutes. The timer has its own audible signal so that you can tell whether it is the timer or a cooking time which has elapsed.

- 1. Press the  $^{\odot}$  button repeatedly until  $\triangle$  is highlighted in the display.
- **2.** Use the or + button to set the timer duration.

Button	Default value	
_	5 minutes	
+	10 minutes	

The timer duration can be set in 30-second increments up to 10 minutes. Above 10 minutes, the time increments become longer the higher the value.

- The timer starts and the timer duration begins to count down after a few seconds.
- An audible signal sounds and the timer duration is zero in the display when the timer duration has elapsed.
- 3. Once the timer duration has elapsed:
  - Press any button to switch off the timer.

#### Changing the timer

You can change the timer duration at any time. **Requirement:**  $\Delta$  is highlighted on the display.

- Use the or + button to change the timer duration.
- The appliance applies the change after a few seconds.

#### Cancelling the timer

You can cancel the timer duration at any time.

**Requirement:**  $\Delta$  is highlighted on the display.

- ► Use the button to reset the timer duration to zero.
- ✓ After a few seconds, the appliance applies the change and ♀ goes out.

## 9.3 Setting the cooking time

You can set a cooking time for operation of up to 23 hours 59 minutes.

**Requirement:** The type of heating and temperature or setting are set.

- 1. Press the <sup>①</sup> button repeatedly until → is highlighted in the display.
- **2.** Use the or + button to set the cooking time.

Button	Default value
_	10 minutes
+	30 minutes

The cooking time can be set in 1-minute increments up to 1 hour, and then in 5-minute increments.

- The appliance starts heating and the cooking time counts down after a few seconds.
- If the cooking time has elapsed, an audible signal sounds and the display shows the cooking time as zero.
- 3. When the cooking time has elapsed:
  - Press any button to end the audible signal before it sounds.
  - To set a cooking time again, press the + button.
  - When your food is ready, switch off the appliance.

### Changing the cooking time

You can change the cooking time at any time. **Requirement:**  $\bowtie$  is highlighted on the display.

- Change the cooking time using the or + button.
- The appliance applies the change after a few seconds.

## Cancelling the cooking time

You can cancel the cooking time at any time.

- **Requirement:**  $\bowtie$  is highlighted on the display.
- ► Reset the cooking time to zero using the button.
- After a few seconds, the appliance applies the change and continues to heat without a cooking time.

## 9.4 Setting the end time

You can delay the time at which cooking is due to finish by up to 23 hours and 59 minutes.

#### Notes

- In order to achieve a good cooking result, do not delay the end time once the appliance is already in operation.
- Food will spoil if you leave it in the oven cavity too long.

#### Requirements

- The type of heating and temperature or setting are set.
- A cooking time is set.
- 1. Press the <sup>⊙</sup> button repeatedly until → is highlighted in the display.
- **2.** Press the or + button.
- The display shows the calculated end time.
- **3.** Use the or + button to delay the end time.
- After a few seconds, the appliance applies the setting and the display shows the set end time.
- Once the calculated start time has been reached, the appliance starts heating up and the cooking time starts counting down.
- Once the time has elapsed, an audible signal sounds and the display shows the cooking time as zero.
- 4. When the cooking time has elapsed:
  - Press any button to end the signal prematurely.
  - To set another cooking time, press the + button.
  - When your food is ready, switch off the appliance.

#### Changing the end time

In order to achieve a good cooking result, you can only change the set end time before operation starts and the cooking time starts counting down.

**Requirement:**  $\rightarrow$  is highlighted on the display.

- Use the or + button to delay the end time.
- The appliance applies the change after a few seconds.

#### Cancelling the end time

You can delete the set end at any time. **Requirement:**  $\rightarrow$  is highlighted on the display.

- Reset the end time to the current time plus the set cooking time using the — button.
- After a few seconds, the appliance applies the change and starts heating up. The cooking time counts down.

## 9.5 Setting the time on the clock

Once the appliance has been connected to the mains or following a power failure, the time flashes on the display. The time starts at "12:00". Set the current time.

**Requirement:** The function selector must be set to the "Off" position <sup>o</sup>.

**1.** Use the - or + button to set the time.

## 10 Meat thermometer

Cook with precision by inserting the meat probe into the food and setting a core temperature on the appliance. Once the set core temperature has been reached in the food, the appliance stops automatically.

# 10.1 Suitable types of heating with the meat thermometer

Only certain types of heating are suitable for use with the meat thermometer.

Suitable heating functions include:

- 3D hot air 

   Image: Second state
   Image: Second state
- Pizza setting
- Hot air grilling X
- Top/bottom heating

**Note:** If the meat thermometer is being used and you select an unsuitable type of heating, a signal sounds.

## 10.2 Inserting the meat thermometer

Use the meat thermometer supplied or order a suitable meat thermometer from our after-sales service.

#### MARNING – Risk of electric shock!

Using the wrong meat probe could damage the insulation.

• Only use the meat probe for this specific appliance.

#### **ATTENTION!**

Otherwise the meat probe may be damaged.

- Do not trap the cable of the meat probe.
- To prevent the meat probe from being damaged by excessive heat, there must be a gap of a few centimetres between the grill element and the meat probe. The meat may expand during the cooking process.
- 1. Insert the meat thermometer at an angle into the thickest part of the meat.

Ensure that the tip of the meat thermometer is correctly positioned in the meat:

- The tip must be roughly in the middle of the food.
- The tip must not be inserted in the fat.
- The tip must not touch any cookware or bones.

2. Press the 🕒 button.

✓ The time that is set appears on the display.

**Tip:** You can go to the basic settings  $\rightarrow$  *Page 21* to specify whether or not the time should be shown on the display.

#### Changing the time on the clock

You can change the time on the clock at any time. **Requirement:** The function selector must be set to the "Off" position o.

- 1. Press the <sup>(C)</sup> button repeatedly until <sup>(C)</sup> is highlighted in the display.
- **2.** Use the or + button to change the time.
- The appliance applies the change after a few seconds.
- Place the food with the meat thermometer into the cooking compartment. It is best to place the food in cookware into the centre of the wire rack.
- **3.** Plug the meat thermometer into the socket on the left-hand side of the cooking compartment.

#### Notes

- If you remove the meat thermometer while the food is cooking, all the settings will be reset.
- Do not remove the meat thermometer when turning the food. Once you have turned the food, check that the meat thermometer is correctly positioned in the food.

## 10.3 Setting the meat probe

The meat probe measures the temperature inside the food between 30  $^\circ\text{C}$  and 99  $^\circ\text{C}.$ 

#### Requirements

- The food with the meat probe is in the cooking compartment.
- The meat probe is plugged in inside the cooking compartment.
- **1.** Use the function selector to set a suitable type of heating.
- lights up in the display and the core temperature display appears next to the temperature of the cooking compartment.
- 2. Use the or + button to set the core temperature. The current core temperature of the food is shown on the left, while the set core temperature is shown on the right, e.g. 15 °C|75 °C.

Note: The current core temperature only appears once it reaches 10  $\,^{\circ}\text{C}.$ 

- Use the temperature selector to set the temperature of the cooking compartment. Set the cooking compartment temperature at least 10 °C higher than the core temperature. Do not set the cooking compartment temperature to higher than 250 °C.
- The appliance starts heating after a few seconds.
- Once the food reaches the core temperature, an audible signal sounds and, in the display, the current core temperature is equal to the set core temperature, e.g. 75 °C|75 °C.

## 4. 🖄 WARNING – Risk of burns!

The cooking compartment, accessories and meat probe become very hot.

 Always use oven gloves to remove hot accessories and the meat probe from the cooking compartment.

When the core temperature is reached:

- Switch off the appliance.
- Pull the meat probe out of the socket in the cooking compartment.
- Pull the meat probe out of the food remove it from the cooking compartment.

## 11 Programme

The programmes help you to use your appliance to prepare different dishes by selecting the optimum settings automatically.

## 11.1 Cookware for programmes

You should therefore use heat-resistant cookware that is suitable for temperatures up to 300 °C. Glass or glass ceramic cookware is best. The joint should cover approx. two thirds of the cookware base. Cookware made from the following material is not suitable:

Bright, shiny aluminium

- Unglazed clay
- Plastic or plastic handles

### 11.2 Steam

For the steam function, the appliance provides you with programmes that allow you to prepare food easily and professionally.

Information about the steam functions can be found under Steam.

→ "Steam", Page 12

#### 11.3 Programme table

The programme numbers are assigned to specific foods.

No.	Food	Cookware	Weight range Weight setting	Add liquid	Shelf posi- tion	Information
01	Plaited loaf, savarin <sup>1</sup>	Baking tray with greaseproof paper	0.6-1.5 kg Weight of dough	No	3	The cooking compart- ment must be cold to begin with.
02	Proving yeast dough <sup>1</sup>	Bowl on wire rack	0.5-1.5 kg Weight of dough	No	2	The cooking compart- ment must be cold to begin with.
03	Wheat bread, multi- grain wheat bread on a baking tray <sup>1</sup>	Baking tray with greaseproof paper	0.5–2.0 kg Weight of dough	No	2	The cooking compart- ment must be cold to begin with.
04	Wheat bread, multi- grain wheat bread in a loaf tin <sup>1</sup>	Cake tin, greased and floured	0.8-2.0 kg Weight of dough	No	2	The cooking compart- ment must be cold to begin with.
05	White bread on a bak- ing tray <sup>1</sup>	Baking tray with greaseproof paper	0.5-2.0 kg Weight of dough	No	2	If you are baking two loaves at the same time, enter the weight of the heavier bread.
06	Multi-grain rye bread <sup>1</sup>	Cake tin, greased and floured	0.8–2.0 kg Weight of dough	No	2	The cooking compart- ment must be cold to begin with.
07	Flatbread <sup>1</sup>	Baking tray with greaseproof paper	0.4-1.0 kg Weight of dough	No	2	The cooking compart- ment must be cold to begin with.

#### en Programme

No.	Food	Cookware	Weight range Weight setting	Add liquid	Shelf posi- tion	Information
08	Baked potatoes, whole Unpeeled, starchy potatoes	Universal pan	0.3-1.5 kg Total weight	No	3	-
09	Vegetable stew Vegetarian	Deep roasting dish with lid	0.5-2.5 kg Total weight	As per recipe	2	Cut vegetables that take longer to cook (e.g. carrots) into smaller pieces than vegetables that take less time to cook (e.g. tomatoes)
10	Goulash Diced beef or pork, with vegetables	Deep roasting dish with lid	0.5-2.5 kg Total weight	As per recipe	2	Place the meat at the bottom and cover with vegetables Do not sear the meat beforehand
11	Fish, whole <sup>1</sup> Ready to cook, seasoned	Roasting dish without lid or bak- ing tray	0.8–1.5 kg Weight of fish	No	2	Place in the dish in a swimming position.
12	<b>Chicken, unstuffed</b> <sup>1</sup> Ready to cook, seasoned	Roasting dish without lid or bak- ing tray	0.9-1.5 kg Chicken weight	No	2	Place in the cook- ware with the breast facing up
13	<b>Chicken pieces</b> <sup>1</sup> Ready to cook, seasoned	Roasting dish without lid or bak- ing tray	0.1-0.8 kg Weight of the heaviest piece	No	3	-
14	Turkey breast Whole, seasoned	Roasting dish with glass lid	0.5-2.5 kg Turkey breast weight	Cover the bottom of the roasting dish, and add up to 250 g ve- getables if you wish	2	-
15	<b>Duck, unstuffed</b> <sup>1</sup> Ready to cook, seasoned	Roasting dish without lid or bak- ing tray	1.3-2.5 kg Duck weight	No	2	Place in the cook- ware with the breast facing up
16	Goose, unstuffed <sup>1</sup> Ready to cook, seasoned	Roasting dish without lid or bak- ing tray	2.3-4.5 kg Goose weight	No	2	Place in the cook- ware with the breast facing up
17	Goose legs Ready to cook, seasoned	Glass roasting dish without lid on wire rack	0.3-0.8 kg Weight of the heaviest piece	Cover the bottom of the roasting dish	2	-
18	<b>Pot-roasted beef</b> E.g. prime rib, shoulder, rump or mar- inated beef roast	Roasting dish with lid	0.5-2.5 kg Weight of meat	Almost cover the meat with liquid	2	Do not sear the meat beforehand
19	Fillet of beef, medium <sup>1</sup> Ready to cook, seasoned	Roasting dish without lid or bak- ing tray	0.8–2.0 kg Weight of meat	No	2	Do not sear the meat beforehand
20	Sirloin, medium Ready to cook, seasoned	Roasting pan without lid	0.5-2.5 kg Weight of meat	No	2	Place in the cook- ware with the fatty side up Do not sear the meat beforehand

No.	Food	Cookware	Weight range Weight setting	Add liquid	Shelf posi- tion	Information
21	<b>Beef roulades</b> Stuffed with vegetables or meat	Roasting dish with lid	0.5-2.5 kg Total weight of all the stuffed roul- ades	Add stock, water or an- other liquid to the dish until the beef olives are al- most covered	2	Do not sear the meat beforehand
22	Meat loaf, fresh Minced beef, pork or lamb	Roasting dish with lid	0.5-2.5 kg Roast weight	No	2	Do not sear the meat beforehand
23	<b>Leg of lamb, medium</b> Boned, seasoned	Roasting dish with lid	0.5–2.5 kg Weight of meat	Cover the bottom of the roasting dish, and add up to 250 g ve- getables if you wish	2	Do not sear the meat beforehand
24	<b>Leg of lamb, well done</b> Boned, seasoned	Roasting dish with lid	0.5–2.5 kg Weight of meat	Cover the bottom of the roasting dish, and add up to 250 g ve- getables if you wish	2	Do not sear the meat beforehand
25	<b>Joint of veal, marbled</b> E.g. saddle or topside	Roasting dish with lid	0.5–3.0 kg Weight of meat	Cover the bottom of the roasting dish, and add up to 250 g ve- getables if you wish	2	Do not sear the meat beforehand
26	<b>Joint of veal, lean</b> E.g. tenderloin or eye	Roasting dish with lid	0.5–2.5 kg Weight of meat	Cover the bottom of the roasting dish, and add up to 250 g ve- getables if you wish	2	Do not sear the meat beforehand
27	Leg of roe venison Boned, seasoned with salt	Roasting dish with lid	0.5–2.0 kg Weight of meat	Cover the bottom of the roasting dish, and add up to 250 g ve- getables if you wish	2	-
28	<b>Pork neck joint</b> <sup>1</sup> Boned, seasoned	Roasting dish without lid or bak- ing tray	0.8–2.5 kg Weight of meat	No	2	Do not sear the meat beforehand

No.	Food	Cookware	Weight range Weight setting	Add liquid	Shelf posi- tion	Information
29	Joint of pork, with crackling <sup>1</sup> E.g. shoulder, seasoned, and scored rind	Roasting dish without lid or bak- ing tray	1.0-2.0 kg Weight of meat	No	2	Place in the cook- ware fatty side up; salt the rind well
30	Pork tenderloin steak Seasoned	Roasting dish with glass lid	0.5–2.5 kg Weight of meat	Cover the bottom of the roasting dish, and add up to 250 g ve- getables if you wish	2	Do not sear the meat beforehand

<sup>1</sup> Dampfprogramm (Betrieb nur mit gefülltem Wassertank)

### 11.4 Preparing food for the programme

Use fresh and, ideally, chilled food. Use frozen food straight from the freezer.

- 1. Weigh the food.
- The weight of the food is required in order to correctly set the programme.
- 2. Add the food to the cookware.
- **3.** Place the cookware onto the wire rack. Always place the cookware into the cooking compartment while it is cold.

## 11.5 Setting a programme

The appliance selects the optimal type of heating, temperature and cooking time. All you need to do is set the weight.

#### Notes

- You can set the weight only in the intended area.
- After the programme starts, you can no longer change the programme and the weight.
- **1.** Use the function selector to set **Programme**  $\mathbb{P}$ .

- 2. Use the or + button to set the required programme.
- **3.** Use the temperature selector to set the weight of your food. Always set the next higher weight.
  - To call up the programme's cooking time, press the <sup>()</sup> button. The cooking time cannot be changed.
  - For some programmes, the <sup>(C)</sup> button can be used to delay the end.
- → "Setting the end time", Page 15
   After a few seconds, the programme starts and the cooking time counts down.
- If the programme has ended, an audible signal sounds and the display shows the cooking time as zero.
- 4. When the programme ends:
  - Press any button to end the audible signal prematurely.
  - To set a cooking time for further cooking, press the + button. The appliance continues to heat using the programme settings.
  - When your food is ready, switch off the appliance.

## 12 Childproof lock

You can secure your appliance to prevent children from accidentally switching it on or changing the settings.

**Note:** You can go to the basic settings  $\rightarrow$  *Page 21* to specify whether you want the option to set the child-proof lock.

12.1 Activating and deactivating the childproof lock

**Requirement:** The function selector must be set to the "Off" position o.

- To activate the childproof lock, press and hold the ⇔ button until ⇔ appears in the display.

## 13 Rapid heating

To save time, rapid heating can shorten the preheating time for set temperatures over 100 °C. Rapid heating is possible for the following types of heating:

- 3D hot air 🛞
- Top/bottom heating

## 13.1 Setting rapid heating

To ensure an even cooking result, do not place the food in the cooking compartment until rapid heating has come to an end.

**Note:** Do not set a cooking time until rapid heating has come to an end.

1. Set a suitable type of heating and a temperature of at least 100  $^\circ\text{C}.$ 

Rapid heating automatically switches off at temperatures of 200  $^\circ\text{C}$  and above.

## 14 Sabbath mode

You can set a time of over 70 hours using Sabbath mode. You can use **Top/bottom heating** to keep food warm between 85 °C and 140 °C during this time without having to switch the appliance on or off.

## 14.1 Starting Sabbath mode

#### Notes

- If you open the appliance door during operation, the appliance stops heating. When you close the appliance door, the appliance continues to heat again.
- Once it has started, you can no longer change or interrupt Sabbath mode.
- You cannot delay the end time for Sabbath mode.

**Requirement:** Sabbath mode is activated in the basic settings.

→ "Basic settings", Page 21

## 15 Basic settings

You can configure the appliance to meet your needs.

## 15.1 Overview of the basic settings

Here you can find an overview of the basic settings and factory settings. The basic settings depend on the features of your appliance.

Display	Basic setting	Selection
c 0 /	Signal duration upon completion of a time or timer period	l = 10 seconds 2 = 30 seconds <sup>1</sup> 3 = 2 minutes
c 0 2	Waiting time until a setting is applied	$l = 3 \text{ seconds}^1$ d = 6  seconds d = 10  seconds
c 0 3	Button tone when pressing a button	
c 0 4	Brightness of the display illumination	l = dark $a = medium^1$ a = bright
c 0 S	Time display	$\mathbf{i}$ = hide the time $\mathbf{i}$ = display the time <sup>1</sup>
<sup>1</sup> Factory <sup>2</sup> Depend	setting (may vary according to model) ling on the appliance specifications	

2. If rapid heating does not switch off automatically, press the » button.

- ✓ »∭ appears in the display.
- Rapid heating starts after a few seconds.
- ✓ Once rapid heating has ended, a signal tone sounds and the »∭ symbol goes out on the display.
- **3.** Place the food in the cooking compartment.

#### **Cancelling rapid heating**

- ► Press the »∭ button.
- The »  $\hspace{-0.1cm}$  symbol disappears from the display.
- 1. Use the function selector to set the programmes  $\mathbb{P}$ .
- ✓ SALL appears in the display.
- 2. Use the temperature selector to set the temperature.
- 3. Press the <sup>⊙</sup> button repeatedly until H is highlighted on the display.
- 4. Use the or + button to set the time.
- After a few seconds, the appliance starts heating and the cooking time counts down.
- Once the time has elapsed, the display shows the time as zero. The appliance stops heating up and responds again as usual outside of Sabbath mode.
   Switch off the appliance.

The appliance automatically switches off after approx. 10 to 20 minutes.

Display	Basic setting	Selection
c 0 6	Childproof lock can be adjusted	$   \vec{J} = no    i = yes^1    \vec{z} = yes, with locked door $
c 0 7	Interior lighting during operation	$   \vec{u} = n0    i = yes^1 $
c 0 8	Cooling fan run-on time	I = short $Z = medium^1$ Z = long H = extra-long
c 0 9	Telescopic shelves retrofitted <sup>2</sup>	$\mathbf{i}$ = no <sup>1</sup> (for rails and 1-level pull-out) <i>i</i> = yes (for 2- and 3-level pull-out)
c   0	Sabbath mode available	$   \vec{u} = no^1 $ $   \vec{l} = yes $
c	Water hardness → "Setting the water hardness", Page 22	D = softened     I = soft (up to 1.5 mmol/l)     Z = medium (1.5-2.5 mmol/l)     3 = hard (2.5-3.8 mmol/l)1     Y = very hard (above 3.8 mmol/l)
c 12	Automatic rapid heating from 200 °C <sup>2</sup>	$   \vec{u} = no    i = yes^1 $
c / 3	Reset all values to factory settings	$   \vec{J} = no^1 $ $   \vec{I} = yes $
ΗΕ	Home Connect Settings	→ "Home Connect ", Page 23

<sup>2</sup> Depending on the appliance specifications

## 15.2 Changing basic settings

Requirement: The appliance is switched off.

- 1. Press and hold the 🕒 button for approximately four seconds.
- ✓ The first basic setting appears in the display, e.g. ∠012.
- 2. Use the temperature selector to change the setting.
- Use the or + button to switch to the next basic setting.
- 4. To save the changes, press and hold the <sup>()</sup> button for approx. four seconds.

**Note:** Your changes to the basic settings will be retained even after a power failure.

# 15.3 Discarding changes to the basic settings

- Turn the function selector.
- All changes are discarded and not saved.

## 15.4 Setting the water hardness

#### **ATTENTION!**

If the wrong water hardness has been set, the appliance cannot remind you to descale it at the right time.Set the water hardness correctly.

- Using unsuitable liquids may damage the appliance.
- Do not use distilled water, highly chlorinated tap water (>40 mg/l) or other liquids.
- Only use cold, fresh tap water, softened water or non-carbonated mineral water.

#### Requirements

- Before you set the water hardness, ask your water supplier about the hardness of your tap water.
- The appliance must be switched off.
- **1.** Press and hold the <sup>(C)</sup> button for approximately four seconds.
- The first basic setting appears in the display, e.g. c012.
- 2. Use the or + button to switch to the next basic setting c !!.
- **3.** Use the temperature selector to set the water hardness.

**Tip:** If your tap water is very hard, we recommend that you use softened water. If you use only softened water, you can set your appliance to the "softened" water hardness range.

**Tip:** If you use mineral water, set the water hardness range to "very hard". If you use mineral water, you must only use non-carbonated mineral water.

Water hardness basic setting	Water hardness in mmol/l	German hardness in °dH	French hardness °fH	
$c \parallel \square =$ softened <sup>1</sup>	-	-	-	
cii i = soft	Up to 1.5	Up to 8.4	Up to 15	
c::2 = medium	1.5-2.5	8.4-14	15-25	
<sup>1</sup> Only set this if you will be using solely softened				

<sup>2</sup> Also set for mineral water. Only use non-carbon-

ated mineral water.

		French hardness °fH
2.5-3.8	14-21.3	25-38
Above 3.8	Above 21.3	Above 38
	hardness in mmol/l 2.5-3.8 Above	hardness in mmol/lhardness in °dH2.5-3.814-21.3AboveAbove

<sup>2</sup> Only set this if you will be using solely softened water.

<sup>2</sup> Also set for mineral water. Only use non-carbonated mineral water.

## 16 Home Connect

This appliance is network-capable. Connecting your appliance to a mobile device lets you control its functions via the Home Connect app, adjust its basic settings and monitor its operating status.

The Home Connect services are not available in every country. The availability of the Home Connect function depends on the availability of Home Connect services in your country. You can find information about this at: www.home-connect.com.

The Home Connect app guides you through the entire login process. Follow the instructions in the Home Connect app to configure the settings.

#### Tips

- Please consult the documents supplied by Home Connect.
- Please also follow the instructions in the Home Connect app.

#### Notes

 Please note the safety precautions in this instruction manual and make sure that they are also observed when operating the appliance via the Home Connect app.

→ "Safety", Page 2

- Operating the appliance on the appliance itself always takes priority. During this time it is not possible to operate the appliance using the Home Connect app.
- In networked standby mode, the appliance requires a maximum of 2 W.

**4.** To save the changes, press and hold the  $\bigcirc$  button for approx. four seconds.

## 16.1 Setting up Home Connect

#### Requirements

- The appliance is connected to the power supply and is switched on.
- You have a mobile device with a current version of the iOS or Android operating system, e.g. a smartphone.
- The mobile device and the appliance are within range of your home network's Wi-Fi signal.
- 1. Download the Home Connect app.



**2.** Open the Home Connect app and scan the following QR code.



3. Follow the instructions in the Home Connect app.

## 16.2 Home Connect Settings

You can adjust the settings and network settings for Home Connect in the basic settings for your appliance.

Setting	Selection or display	Explanation
HE DI	Connection to the network	☐ and ∃ are displays that you cannot set.
<sup>1</sup> Factory se	tting	

Setting	Selection or display	Explanation
HC 02	Connection to the Home Connect app	☐ and 2 are displays that you cannot set.
нс оз	Wi-Fi ♫ – Off ¼ – Activate ♫ – On	If Wi-Fi is activated, you can use Home Connect. In networked standby mode, the appliance requires a max- imum of 2 W. Z is a display that you cannot set.
HE OY	Remote start $\mathcal{D}$ – Deactivated $\mathcal{L}$ – Manual <sup>1</sup> $\mathcal{Z}$ – Permanent	When remote start is deactivated, you can only view the oper- ating status of the appliance in the app. For manual remote start, you must activate the remote start each time before you can start the appliance via the app. If you open the appliance door within 15 minutes of activating remote start or of the operation ending, remote start is deactiv- ated. For permanent remote start, you can start and operate the ap- pliance remotely at any time.
HE 05	Software update I – Update available 2 – Start update	The setting is only displayed if an update is available. I is a display that you cannot set.
HE 06	Remote Diagnostics - Not authorised - Authorised	The setting is only displayed if after-sales service is attempting to access the appliance.
<sup>1</sup> Factory set	ting	

# 16.3 Operating the appliance with the Home Connect app

You can use the Home Connect app to set and start the appliance remotely.

#### MARNING – Risk of fire!

Combustible objects that are left in the cooking compartment may catch fire.

- Never store combustible objects in the cooking compartment.
- If smoke is emitted, the appliance must be switched off or the plug must be pulled out and the door must be held closed in order to stifle any flames.

#### Requirements

- The appliance is switched on.
- The appliance is connected to your home network and to the Home Connect app.
- In order to be able to set the appliance via the app, the manual or permanent remote start must be selected in the HL DH basic setting.
- **1.** To activate the remote start, set the function selector to  $\square$ .
- 2. Implement a setting in the app and send it to the appliance.

## 16.4 Software update

Your appliance's software can be updated using the software update function, e.g. for the purposes of optimisation, troubleshooting or security updates. To do this, you must be a registered Home Connect user, have installed the app on your mobile device and be connected to the Home Connect server. As soon as a software update is available, you will be informed via the Home Connect app and will be able to start the software update via the app. Once the update has been successfully downloaded, you can start installing it via the Home Connect app if you are in your WLAN home network (Wi-Fi). The Home Connect app will inform you once installation is successful.

#### Notes

- You can continue to use your appliance as normal while updates are downloading. Depending on your personal settings in the app, software updates can also be set to download automatically.
- We recommend that you install security updates as soon as possible.

## 16.5 Remote diagnostics

Customer Service can use Remote Diagnostics to access your appliance if you contact them, have your appliance connected to the Home Connect server and if Remote Diagnostics is available in the country in which you are using the appliance.

**Tip:** For further information and details about the availability of Remote Diagnostics in your country, please visit the service/support section of your local website: www.home-connect.com

## 16.6 Data protection

Please see the information on data protection. The first time your appliance is registered on a home network connected to the Internet, your appliance will transmit the following types of data to the Home Connect server (initial registration):

- Unique appliance identification (consisting of appliance codes as well as the MAC address of the Wi-Fi communication module installed).
- Security certificate of the Wi-Fi communication module (to ensure a secure data connection).

- The current software and hardware version of your appliance.
- Status of any previous reset to factory settings.

This initial registration prepares the Home Connect functions for use and is only required when you want to use the Home Connect functions for the first time.

## 17 Cleaning and servicing

To keep your appliance working efficiently for a long time, it is important to clean and maintain it carefully.

## 17.1 Cleaning products

In order to avoid damaging the various oven surfaces on the appliance, do not use unsuitable cleaning products.

#### MARNING – Risk of electric shock!

An ingress of moisture can cause an electric shock.

 Do not use steam- or high-pressure cleaners to clean the appliance. **Note:** Please note that the Home Connect functions can only be utilised with the Home Connect app. Information on data protection can be retrieved in the Home Connect app.

#### **ATTENTION!**

Unsuitable cleaning products may damage the surfaces of the appliance.

- Do not use harsh or abrasive cleaning products.
- Do not use cleaning products with a high alcohol content.
- Do not use hard scouring pads or cleaning sponges.
- Do not use any special cleaners for cleaning the appliance while it is hot.

Using oven cleaner in a hot cooking compartment damages the enamel.

- Never use oven cleaner in the cooking compartment when it is still warm.
- Remove all food remnants from the cooking compartment and the appliance door before you next heat up the appliance.

New sponge cloths contain residues from production.

► Wash new sponge cloths thoroughly before use.

#### Suitable cleaning agents

Only use cleaning products that are suitable for the different surfaces on your appliance.

Follow the instructions on cleaning the appliance.  $\rightarrow$  "Cleaning the appliance", Page 26

#### Appliance front

Surface	Suitable cleaning agents	Information
Stainless steel	<ul> <li>Hot soapy water</li> <li>Special stainless steel cleaning products suitable for hot sur- faces</li> </ul>	To prevent corrosion, remove any patches of limescale, grease, starch or albumin (e.g. egg white) on stainless steel surfaces imme- diately. Apply a thin layer of the stainless steel cleaning product with a soft cloth.
Plastic or painted surfaces E.g. control panel	<ul> <li>Hot soapy water</li> </ul>	Do not use glass cleaner or a glass scraper.

#### Appliance door

Area	Suitable cleaning agents	Information
Door panels	<ul> <li>Hot soapy water</li> </ul>	Do not use a glass scraper or a stainless steel wool. <b>Tip:</b> Remove the door panels in order to clean them thoroughly. $\rightarrow$ "Appliance door", Page 31
Door cover	<ul> <li>Made of stainless steel: Stainless steel cleaner</li> <li>Made of plastic: Hot soapy water</li> </ul>	Do not use glass cleaner or a glass scraper. <b>Tip:</b> Remove the door cover for thorough cleaning. → "Appliance door", Page 31
Door handle	<ul> <li>Hot soapy water</li> </ul>	To avoid permanent stains, remove descaling agents from the door handle immediately.
Door seal	<ul> <li>Hot soapy water</li> </ul>	Do not remove or scrub.

#### Cooking compartment

Area	Suitable cleaning agents	Information	
Enamel surfaces	<ul><li>Hot soapy water</li><li>Vinegar water</li><li>Oven cleaner</li></ul>	Soak any heavily soiled areas and use a brush or steel wool. Leave the appliance door open to dry the cooking compartment after cleaning it. <b>Tip:</b> It is best to use the cleaning function. → "Self-cleaning ", Page 27	
		<ul> <li>Notes</li> <li>Enamel burns at very high temperatures, causing minor discolouration. The functionality of your appliance is not affected by this.</li> <li>The edges of thin trays cannot be completely enamelled and may be rough. This does not impair corrosion protection.</li> <li>Food residues will leave a white coating on the enamel surfaces. The coating does not pose a health risk. The functionality of your appliance is not affected by this. You can remove residues with lemon juice.</li> </ul>	
Glass cover for the oven light	<ul> <li>Hot soapy water</li> </ul>	Use oven cleaner to remove very heavy soiling.	
Rails	<ul> <li>Hot soapy water</li> </ul>	Soak any heavily soiled areas and use a brush or steel wool. <b>Tip:</b> Remove the shelf supports for cleaning. → "Shelf supports", Page 29	
Pull-out system	<ul> <li>Hot soapy water</li> </ul>	<ul> <li>Use a brush to remove very heavy soiling.</li> <li>Clean the pull-out rails while they are pushed in so that you do no remove the lubricant.</li> <li>Do not clean in the dishwasher.</li> <li><b>Tip:</b> Detach the pull-out system for cleaning.</li> <li>→ "Shelf supports", Page 29</li> </ul>	
Accessorles	<ul><li>Hot soapy water</li><li>Oven cleaner</li></ul>	Soak any heavily soiled areas and use a brush or steel wool. Enamelled accessories are dishwasher-safe.	
Water tank	<ul> <li>Hot soapy water</li> </ul>	To remove residual detergent after cleaning, rinse thoroughly with clean water. To dry the water tank after cleaning, leave the water tank to dry with the lid open. Dry the seal on the lid. Do not clean in the dishwasher.	
Meat probe	<ul> <li>Hot soapy water</li> </ul>	Use a brush to remove very heavy soiling. Do not clean in the dishwasher.	

## 17.2 Cleaning the appliance

In order to avoid damaging the appliance, you must clean your appliance only as specified, and with suitable cleaning products.

#### MARNING – Risk of burns!

The appliance and its parts that can be touched become hot during use.

- Caution should be exercised here in order to avoid touching heating elements.
- Young children under 8 years of age must be kept away from the appliance.

#### **WARNING** – Risk of fire!

Loose food remnants, fat and meat juices may catch fire.

Before using the appliance, remove the worst of the food residues and remnants from the cooking compartment, heating elements and accessories.

**Requirement:** Read the information on cleaning products.

- → "Cleaning products", Page 25
- **1.** Clean the appliance using hot soapy water and a dish cloth.
  - For some surfaces, you can use alternative cleaning agents.
  - → "Suitable cleaning agents", Page 25
- 2. Dry with a soft cloth.

## 18 Self-cleaning

The **Self-cleaning** cleaning function cleans the cooking compartment almost by itself.

Use the cleaning function to clean the cooking compartment every two to three months. If required, you can use the cleaning function more frequently. The cleaning function requires approx. 2.5–4.8 kilowatt hours.

# **18.1 Preparing the appliance for the cleaning function**

In order to achieve a good cleaning result, prepare the appliance carefully.

#### MARNING – Risk of fire!

Combustible objects that are left in the cooking compartment may catch fire.

- Never store combustible objects in the cooking compartment.
- If smoke is emitted, the appliance must be switched off or the plug must be pulled out and the door must be held closed in order to stifle any flames.

Loose food remnants, fat and meat juices may catch fire when the cleaning function is in progress.

- Before you start the cleaning function, always remove coarse dirt from the cooking compartment.
- ► Never clean accessories at the same time.

The outside of the appliance gets very hot when the cleaning function is in progress.

- Never hang combustible objects, e.g. tea towels, on the door handle.
- Leave the front of the appliance clear.
- Keep children at a safe distance.

If the door seal is damaged, a large amount of heat is generated around the door.

- Do not scrub or remove the seal.
- Never operate the appliance if the seal is damaged or missing.
- 1. Remove accessories and cookware from the cooking compartment.
- 2. Unhook the shelf supports and remove them from the cooking compartment.
- $\rightarrow$  "Shelf supports", Page 29
- **3.** Remove heavy soiling from the cooking compartment.
- 4. Use a detergent solution and a soft cloth to clean the surfaces at the edges of the cooking compartment around the door seal.

Do not remove or scrub the door seal.

Use oven cleaner to remove stubborn dirt from the inner door pane.

5. Remove any objects from the cooking compartment. The cooking compartment must be empty.

## 18.2 Setting the cleaning function

Ventilate the kitchen while the cleaning function is running.

#### MARNING – Risk of harm to health!

The cleaning function heats up the cooking compartment to a very high temperature so that food left over from roasting, grilling and baking will burn off. This process releases vapours, which can irritate mucous membranes.

- Keep the kitchen well ventilated while the cleaning function is running.
- Do not remain in the room for long periods.
- Keep children and pets away.

#### MARNING – Risk of burns!

The cooking compartment gets very hot when the cleaning function is in progress.

- Never open the appliance door.
- Allow the appliance to cool down.
- ► Keep children at a safe distance.

The outside of the appliance gets very hot when the cleaning function is in progress.

- Never touch the appliance door.
- Allow the appliance to cool down.
- Keep children at a safe distance.

**Note:** The oven light does not come on during the cleaning function.

**Requirement:** Prepare the appliance for the cleaning function.  $\rightarrow$  *Page* 27

- **1.** Use the function selector to set the cleaning functions  $\square$ .
- ✓ The ∠ symbol and the cleaning functions appear in the display. The first cleaning function is highlighted.
- 2. Press the + or − button repeatedly until the symbol is highlighted.
- **3.** Use the temperature selector to set the cleaning setting.

Cleaning set- ting	Cleaning level	Duration in hours
1	Lightly soiled	Approx. 1:15
2	Medium	Approx. 1:30
3	High	Approx. 2:00

Select a higher cleaning setting for very heavy or older soiling.

The duration cannot be changed.

- The cleaning function starts after a few seconds and the time counts down.
- Once the cleaning function has ended, an audible signal sounds and the display shows the duration as zero.
- **5.** Prepare the appliance for use.  $\rightarrow$  Page 28

# 18.3 Preparing the appliance for use following the cleaning function

- 1. Allow the appliance to cool down.
- 2. Wipe off any ash that has been left behind in the cooking compartment and around the appliance door with a damp cloth.

## 19 Descaling

To ensure that your appliance continues to operate correctly, it must be descaled regularly.

The frequency with which the appliance must be descaled depends on the hardness of the water used. The esymbol reminds you to run the descaling programme.

There are four steps in the descaling programme. For hygiene reasons, the descaling programme must be run through completely so that the appliance can be ready for operation again. Descaling takes around 90– 110 minutes in total:

Display	Step
1_4	First step: Descaling Approx. 65 min
2_4	Second step: Rinse cycle Approx. 9 min
3_4	Third step: Rinse cycle Approx. 9 min
4_4	Fourth step: Rinse cycle Approx. 9 min

## 19.1 First step ( /\_식)

#### **ATTENTION!**

The length of time for which the descaler is left to work is based on the recommended, liquid descaler. Other descalers may damage the appliance.

 Only use the liquid descaler recommended by us for the descaling programme.

If descaling solution comes into contact with the control panel or other delicate surfaces, it will damage them.

Remove descaling solution immediately with water.

**Note:** Do not pour more than 150 ml of liquid into the water tank throughout the descaling process.

- 1. Mixing a descaling solution:
  - 50 ml liquid descaler
    - 100 ml water
- 2. Pour the descaling solution into the water tank and insert the water tank.
- Use the function selector to set the cleaning functions ∠.
- Press the or + button repeatedly until the essential symbol is highlighted.
- 5. Turn the temperature selector.
- *G*n appears in the display. Descaling starts after a few seconds.
- At the end of the descaling programme, 2-4 appears in the display.

- Remove white residues with lemon juice.
   Note: White residues on the enamel surfaces may be caused by heavy soiling. These food residues are harmless. The deposits do not compromise the functionality of the appliance.
- Attach the shelf supports.
   → "Shelf supports", Page 29
- 6. Remove the water tank and clean thoroughly with water.

## 19.2 Second step (근\_닉)

- **1.** Fill the water tank with 150 ml water and insert it.
- At the end of the rinse cycle, ∃\_4 appears in the display.
- 2. Remove the water tank and clean thoroughly with water.

## 19.3 Third step (∃\_4)

- **1.** Fill the water tank with 150 ml water and insert it.
- ✓ At the end of the rinse cycle, 4\_4 appears in the display.
- 2. Remove the water tank and clean thoroughly with water.

## 19.4 Fourth step (ᠲ\_ᠲ)

- 1. Fill the water tank with 150 ml water and insert it.
- ✓ At the end of the rinse cycle, □□:□□ appears in the display.
- 2. Remove the water tank and clean thoroughly with water.
- **3.** Dry the water tank and re-insert it.
- Descaling is complete and the appliance is ready for use again.

## 19.5 Descaling interrupted

If descaling is interrupted (for example, due to a power failure or because the appliance is switched off), the symbol appears in the display after the appliance is switched back on. You will be prompted to rinse three times. The appliance cannot be used for other operations until the third rinse cycle comes to an end.

**Note:** If you set another operation,  $\mathcal{L}$  in (Cleaning) appears in the display. Repeat the interrupted descaling programme after rinsing.

- 1. Empty the water tank and clean thoroughly with water.
- 2. Insert the empty water tank.
- 3. Use the function selector to set descaling ed.
- **4.** Turn the temperature selector.
- ✓ <sup>□</sup>*n* appears in the display.
- After a few seconds, the appliance pumps the remaining liquid into the water tank.
- 5. Empty the water tank and clean thoroughly with water.
- 6. To rinse the steam system, run the three rinse cycles in the descaling programme.
   → "Second step (2-4)", Page 28

7. Restart descaling.

## 20 Shelf supports


To clean the rails and the cooking compartment, or to replace the rails, you can remove these.

## 20.1 Detaching the shelf supports

#### MARNING – Risk of burns!

The shelf supports get very hot


- Never touch the shelf supports when hot.
- Always allow the appliance to cool down.
- Keep children at a safe distance.
- 1. Lift the rail forwards slightly (1) and detach it (2).
- **2.** Pull the whole rail to the front ③ and remove it.



## 20.2 Attaching the shelf supports

#### Notes

- The rails only fit on the right or left.
- For both pull-out rails, ensure that you can pull them forwards and out.
- First, push the rail into the middle of the rear socket ① until the rail rests against the cooking compartment wall, and then push this back ②.
- 2. Push the rail into the front socket ③ until the rail also rests against the cooking compartment wall, and then press this downwards ④.



### 20.3 Removing the pull-out rail

#### MARNING – Risk of burns!

The shelf supports get very hot

- Never touch the shelf supports when hot.
- Always allow the appliance to cool down.
- Keep children at a safe distance.


#### **ATTENTION!**

The self-cleaning surfaces in the cooking compartment may be damaged by detaching and attaching the pullout rails.


 Detach the rails before detaching or attaching the pull-out rails.

#### Notes


- Depending on the appliance type, you must change the basic settings for the telescopic rails for appliances with rails and pull-out rails.
   → "Basic settings", Page 21
- If necessary, you can use pull-out rails on all levels.
- 1. Push on the tab marked **PUSH** behind the rail, and push the rail to the rear.




2. Keep the **PUSH** tab pushed back ① and swing the rail outwards ②.



**3.** Pull the rail out towards the front until the retainer at the back unhooks.



4. Remove the pull-out rail.




Clean the pull-out rail.
 → "Cleaning products", Page 25


## 20.4 Attaching the pull-out rail

**Note:** The pull-out rails only fit on the right or left. Make sure when you fit them that you can pull them out towards the front.


1. Insert the pull-out rail between the two bars.




2. Push the retainer a in between the lower and the upper bar.



- 3. Keep the **PUSH** tab pushed in ① and swing the pullout rail inwards until the front retainer ⓐ is located between the two bars ②.
  - Release the **PUSH** tab.



- **4.** Pull the pull-out rail out as far as it will go and slide it back in.



## 21 Appliance door

To ensure that your appliance retains its appearance and remains fully functioning for a long time, you can detach the appliance door and clean it.

## 21.1 Detaching the appliance door

#### ▲ WARNING – Risk of injury!

Components inside the appliance door may have sharp edges.

Wear protective gloves.

The hinges on the appliance door move when the door is opened and closed, which could trap your fingers.

- Keep your hands away from the hinges.
- **1.** Open the appliance door fully and push in the direction of the appliance.


### 2. A WARNING – Risk of injury!

When the hinges are not secured, they can snap shut with great force.

 Make sure that the locking levers are always either fully closed or (when detaching the oven door) fully open.


Open the locking levers on the left- and right-hand hinges.

Locking levers opened




The hinge is now secured and cannot snap shut.

Locking levers closed



secured and cannot be detached.

 The locking levers are open. The hinges are now secured and cannot snap shut. **3.** Close the appliance door fully ①. Grab hold of the appliance door with both hands (on the left and right) and pull it upwards and out ②.



4. Carefully place the appliance door on a level surface.

## 21.2 Attaching the appliance door


#### A WARNING – Risk of injury!

The hinges on the appliance door move when the door is opened and closed, which could trap your fingers.Keep your hands away from the hinges.


When the hinges are not secured, they can snap shut with great force.

- Make sure that the locking levers are always either fully closed or (when detaching the oven door) fully open.
- 1. Note: Ensure that the appliance door slides onto the hinges without any resistance. If you feel any resistance, check whether you are sliding it in at the correct opening.


Slide the appliance door straight onto the two hinges. Slide the appliance door on as far as it will go.



2. Using both hands, press down on the left and right of the door cover from above to check whether the appliance has been pushed in as far as it will go.



- **3.** Open the appliance door fully.
- 4. Close the locking levers on the left- and right-hand hinges.



- The locking levers are closed. The appliance door is secured and cannot be detached.
- 5. Close the appliance door.


## 21.3 Removing the door panes

#### MARNING – Risk of injury!

The hinges on the appliance door move when the door is opened and closed, which could trap your fingers.


Keep your hands away from the hinges.
 Components inside the appliance door may have sharp edges.

- Wear protective gloves.
- 1. Open the appliance door slightly.
- 2. Push on the left- and right-hand side of the door cover from the outside 1 until it is released.
- 3. Remove the door cover 2.




- 4. Clean the door cover.
  - → "Suitable cleaning agents", Page 25

- 5. Undoing and removing the left- and right-hand screws on the appliance door ①
- 6. Place a folded-up tea towel in the appliance door. Pull the front pane up and out ②.



- **7.** Set the front pane down on a level surface with the door handle facing down.
- Press the intermediate pane against the appliance with one hand while pushing the left- and right-hand retainers a upwards. Do not detach the retainers a.



9. Remove the intermediate pane.

#### 10. A WARNING – Risk of injury!

Scratched glass in the appliance door may develop into a crack.

 Do not use glass scrapers, sharp or abrasive cleaning aids, or harsh cleaning products.

Clean the removed door panes on both sides with glass cleaner and a soft cloth.

- **11.** Clean the appliance door. → "Suitable cleaning agents", Page 25
- **12.** Dry the door panes and refit them.
  - $\rightarrow$  "Fitting the door panes", Page 32

## 21.4 Fitting the door panes


#### MARNING – Risk of injury!

The hinges on the appliance door move when the door is opened and closed, which could trap your fingers.


Keep your hands away from the hinges.
 Components inside the appliance door may have sharp edges.

Wear protective gloves.

1. Turn the intermediate pane until the arrow a is in the top right.




- **2.** Insert ① the intermediate pane into the retainer ⓐ at the bottom and push it in firmly at the top.
- **3.** Push the left- and right-hand retainer a downwards until the intermediate pane is clamped <sup>(2)</sup>.




**4.** Attach the front pane downwards into the left- and right-hand retainers **a** ①.

 Push the front pane to the appliance until the leftand right-hand hook a is opposite the support a?



- 6. Push the front pane in at the bottom ① until you hear it click into place.
- 7. Open the appliance door slightly and remove the tea towel.
- **8.** Screw both screws back in on the left and right of the appliance door.
- **9.** Put the door cover in position and push down on it ② until you hear it click into place.



**10.** Close the appliance door.

**Note:** Do not use the cooking compartment again until the door panes have been correctly fitted.

## 22 Troubleshooting

You can rectify minor faults on your appliance yourself. Read the troubleshooting information before contacting aftersales service. This will avoid unnecessary costs.

#### ▲ WARNING – Risk of injury!

Improper repairs are dangerous.

- Repairs to the appliance should only be carried out by trained specialist staff.
- ► If the appliance is defective, call Customer Service.

## ▲ WARNING – Risk of electric shock!

Incorrect repairs are dangerous.

- Repairs to the appliance should only be carried out by trained specialist staff.
- Only use genuine spare parts when repairing the appliance.
- If the power cord of this appliance is damaged, it must be replaced by trained specialist staff.

## 22.1 Malfunctions

Fault	Cause and troubleshooting
The appliance is not working.	<ul><li>The circuit breaker in the fuse box has tripped.</li><li>Check the circuit breaker in the fuse box.</li></ul>
	<ul> <li>There has been a power cut.</li> <li>Check whether the lighting in your kitchen or other appliances are working.</li> </ul>

Fault	Cause and troubleshooting	
Appliance is not heat- ing, the colon flashes in the display and a $d$ appears.	<b>1.</b> Briefly disconnect the appliance from the power supply by switching the circuit breake	
Steam-assisted oper- ation does not start.	<ul> <li>The water tank is empty.</li> <li>Fill the water tank.</li> <li>→ "Filling the water tank", Page 13</li> <li>Descaling locks operations with steam-assisted cooking.</li> <li>Run the descaling programme in full.</li> <li>→ "Descaling", Page 28</li> </ul>	
	The steam system is defective. <ul> <li>Call the after-sales service.</li> <li>→ "Customer Service", Page 36</li> </ul>	
The appliance door cannot be opened; <-> lights up in the dis- play.	<ul> <li>The childproof lock locks the appliance door.</li> <li>► Use the ¬ button to deactivate the childproof lock.</li> <li>→ "Childproof lock", Page 20</li> </ul>	
The appliance door cannot be opened; lights up in the dis- play.	ned; 🖻 🕨 Allow the appliance to cool down until 🖻 goes out in the display.	
The time flashes in the display.	<ul> <li>There has been a power cut.</li> <li>▶ Reset the time.</li> <li>→ "Setting the time on the clock", Page 16</li> </ul>	
The time does not appear in the display when the appliance is switched off.	Change the basic setting for the time display.	
<sup>⊸</sup> lights up in the dis- play and no settings can be made on the appliance.	<ul> <li>Childproof lock is activated.</li> <li>► Use the &lt;&gt;&gt; button to deactivate the childproof lock.</li> <li>→ "Childproof lock", Page 20</li> </ul>	
<i>h</i> flashes in the display and the appliance will not start.	<ul><li>The cooking compartment is too hot for the selected operation.</li><li>1. Switch off the appliance and allow it to cool down.</li><li>2. Restart the operation.</li></ul>	
F B appears in the display.	<ul> <li>The maximum cooking time has been reached. To prevent an unwanted permanent operation, the appliance automatically stops heating after several hours if the settings are unchanged.</li> <li>► Switch off the appliance. You can configure new settings if required.</li> <li>Tip: To prevent the appliance from switching off when you do not want it to, e.g. for an extremely long preparation time, set a cooking time. → "Time-setting options", Page 14</li> </ul>	
<i>E 5 I-22</i> appears in the display.	<ul> <li>There is too much water in the steam system. The water cannot be pumped back into the water tank.</li> <li>1. Empty the water tank and insert the empty water tank. <ul> <li>→ "Emptying the water tank", Page 14</li> </ul> </li> <li>2. Reset the time. <ul> <li>→ "Setting the time on the clock", Page 16</li> </ul> </li> <li>3. Switch the appliance off and on again.</li> <li>4. Run "Descaling interrupted" in full. <ul> <li>→ "Descaling interrupted", Page 28</li> </ul> </li> </ul>	

Fault	Cause and troubleshooting	
A message with <i>E</i> appears in the display, e.g. <i>E05-32</i> .	<ul> <li>Electronics fault</li> <li>Press the <sup>①</sup> button. <ul> <li>If required, reset the time.</li> </ul> </li> <li>If the fault was a one-off, the error message disappears.</li> </ul> <li>If the error message appears again, call the after-sales service. Quote the exact error message and the E no. of your appliance. <ul> <li>"Customer Service", Page 36</li> </ul> </li>	
lights up perman- ently in the display.	The water tank is empty. ► Fill the water tank. → "Filling the water tank", Page 13	
	<ul> <li>The water tank has not been put in fully.</li> <li>Slide the water tank back in fully.</li> </ul>	
	The water tank is leaking. ► Order a new water tank.	
	<ul> <li>The sensor is defective.</li> <li>► Call the after-sales service.</li> <li>→ "Customer Service", Page 36</li> </ul>	
lights up in the display.	<ul> <li>Build-up of limescale in the appliance.</li> <li>► Run the descaling programme in full.</li> <li>→ "Descaling", Page 28</li> </ul>	
<i>L</i> in appears in the display.	<ul> <li>The power supply has been disconnected or the appliance has been switched off during the descaling process.</li> <li>▶ Run the interrupted descaling programme in full.</li> <li>→ "Descaling interrupted", Page 28</li> </ul>	
The appliance hums during operation and after it is switched off.	Functional test of the pump creates operating noise. No action required.	
During operation with steam assistance, steam escapes from the ventilation slots.	<ul> <li>Steam escapes for physical reasons.</li> <li>Wait until the cooking with steam assistance ends. After the end of cooking with steam assistance, no more steam will escape after a short time.</li> </ul>	
After using the steam assistance, the cook- ing result is too dry or too moist.	<ul><li>Steam intensity set incorrectly.</li><li>Set a higher or lower steam intensity.</li></ul>	
HomeConnect is not working correctly.	Different causes are possible. ► Go to www.home-connect.com.	

## 22.2 Replacing the oven light bulb

If the light in the cooking compartment fails, change the oven light bulb.

**Note:** Heat-resistant, 40-watt, 230 V halogen bulbs are available from the after-sales service or specialist retailers. Only use these bulbs. Hold the new halogen bulbs only with a clean, dry towel. This increases the service life of the bulb.

#### MARNING – Risk of burns!

The appliance and its parts that can be touched become hot during use.

- Caution should be exercised here in order to avoid touching heating elements.
- Young children under 8 years of age must be kept away from the appliance.

#### MARNING – Risk of electric shock!


When changing the bulb, the bulb socket contacts are live.

- Before replacing the bulb, ensure that the appliance is switched off in order to prevent a potential electric shock.
- Also unplug the appliance from the mains or switch off the circuit breaker in the fuse box.

#### Requirements

- The appliance is disconnected from the power supply.
- The cooking compartment has cooled down.
- You have a new halogen bulb to replace the old one.
- 1. Place a tea towel in the cooking compartment to prevent damage.
- 2. Turn the glass cover anti-clockwise to remove it ①.

3. Pull out the halogen bulb without turning it 2.



## 23 Disposal

Find out here how to dispose of old appliances correctly.

## 23.1 Disposing of old appliance

Valuable raw materials can be reused by recycling.

- **1.** Unplug the appliance from the mains.
- 2. Cut through the power cord.
- **3.** Dispose of the appliance in an environmentally friendly manner.

Information about current disposal methods are available from your specialist dealer or local authority.

## 24 Customer Service

If you have any queries on use, are unable to rectify faults on the appliance yourself or if your appliance needs to be repaired, contact Customer Service. Function-relevant genuine spare parts according to the corresponding Ecodesign Order can be obtained from Customer Service for a period of at least 10 years from the date on which your appliance was placed on the market within the European Economic Area.

**Note:** Under the terms of the manufacturer's warranty the use of Customer Service is free of charge.

Detailed information on the warranty period and terms of warranty in your country is available from our aftersales service, your retailer or on our website. If you contact Customer Service, you will require the product number (E-Nr.) and the production number (FD) of your appliance.

- **4.** Insert the new halogen lamp and press it firmly into the socket.
  - Make sure the pins are positioned correctly.
- Depending on the appliance model, the glass cover may have a sealing ring. Put the sealing ring in position.
- 6. Screw the glass cover on.
- 7. Take the tea towel out of the cooking compartment.
- 8. Connect the appliance to the power supply.



This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE). The guideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.

The contact details for Customer Service can be found in the enclosed Customer Service directory or on our website.

# 24.1 Product number (E-Nr.) and production number (FD)

You can find the product number (E-Nr.) and the production number (FD) on the appliance's rating plate. You will see the rating plate with these numbers if you open the appliance door.

	E-Nr:	FD:	Z-Nr:	
Type:				

Make a note of your appliance's details and the Customer Service telephone number to find them again quickly.

## 25 Declaration of Conformity

BSH Hausgeräte GmbH hereby declares that the appliance with Home Connect functionality conforms to the basic requirements and other relevant provisions of Directive 2014/53/EU.

A detailed RED Declaration of Conformity can be found online at www.siemens-home.bsh-group.com among the additional documents on the product page for your appliance.

Hereby, BSH Hausgeräte GmbH declares that the appliance with Home Connect functionality is in compliance with relevant statutory requirements.

A detailed Declaration of Conformity can be found online at www.siemens-home.bsh-group.com/uk/ among the additional documents on the product page for your appliance.



Only applies to Great Britain 2.4 GHz band (2400–2483.5 MHz): Max. 100 mW 5 GHz band (5150–5350 MHz + 5470–5725 MHz): Max. 100 mW

BE	BG	CZ	DK	DE	EE	IE	EL	ES
FR	HR	IT	CY	LI	LV	LT	LU	HU
MT	NL	AT	PL	PT	RO	SI	SK	FI
SE	NO	СН	TR	IS	UK (NI)			
AN (Wi-F	i): For indo	or use only	/.					
BA		MD	MF	MK	RS	UK		UA
	FR MT SE AN (Wi-F	FRHRMTNLSENOAN (Wi-Fi): For indo	FRHRITMTNLATSENOCHAN (Wi-Fi): For indoor use only	FRHRITCYMTNLATPLSENOCHTRAN (Wi-Fi): For indoor use only.	FRHRITCYLIMTNLATPLPTSENOCHTRISAN (Wi-Fi): For indoor use only.	FRHRITCYLILVMTNLATPLPTROSENOCHTRISUK (NI)	FRHRITCYLILVLTMTNLATPLPTROSISENOCHTRISUK (NI)AN (Wi-Fi): For indoor use only.	FRHRITCYLILVLTLUMTNLATPLPTROSISKSENOCHTRISUK (NI)AN (Wi-Fi): For indoor use only.

## 26 How it works

Here, you can find the ideal settings for various types of food as well as the best accessories and cookware. We have perfectly tailored these recommendations to your appliance.

### 26.1 Cooking tips

Observe this information when preparing food.

- The temperature and cooking time depend on the amount of food and the recipe. Settings ranges are specified for this reason. Try using the lower values to start with.
- The setting values apply to food placed in the cooking compartment while the cooking compartment is still cold. Do not slide the accessory into the cooking compartment until it has finished preheating.
- Remove any accessories that are not being used from the cooking compartment.

**Note:** During operation with steam assistance, it is desirable that there is a significant build-up of steam in the cooking compartment.

Once the cooking compartment has cooled after cooking, wipe the cooking compartment clean.

### 26.2 Notes on baking

When baking, use the shelf positions indicated.

Baking on one level	Height
Deep baked goods or tin on wire rack	2
Flat baked goods or goods in a baking tray	3

Baking on two levels	Height
Universal pan	3
Baking tray	1
Baking tins/dishes on the wire rack:	Height
First wire rack	3
Second wire rack	1
Baking on three levels	Height
Baking tray	5
Universal pan	3
Baking tray	1

#### Notes

- When baking on several layers, always use hot air. Baked goods that are placed in the oven at the same time will not necessarily be ready at the same time.
- Position baking tins/dishes either next to one another or offset on different shelves so that they are not directly one above the other in the cooking compartment.
- For best results, we recommend using dark-coloured metal bakeware.
- Steam-assisted baking is only possible on one level.

#### 26.3 Notes on roasting and grilling

The setting values are based on the assumption that unstuffed, chilled, ready-to-roast poultry, meat or fish is placed into a cold cooking compartment.

- The larger the poultry, meat or fish, the lower the cooking temperature and the longer the cooking time.
- Turn the poultry, meat or fish after approx. 1/2 to 2/3 of the time listed.
- Add a little liquid to the poultry in the cookware. Cover the bottom of the cookware with approx. 1– 2 cm of liquid.
- When you turn poultry, ensure that the breast side or skin side is underneath to begin with.
- Cooking time calculation (e.g. 20 + 35): To calculate the cooking time, assume 20 minutes per 500 g of meat plus an extra 35 minutes. For 1.5 kg, the cooking time is then 95 minutes.
- Cooking time range (e.g. 10–15): Your food will be ready within the specified range of time.

#### Steam-assisted roasting and braising

- Dishes with steam-assisted cooking and a long cooking time may empty the water tank. If necessary, refill the water tank.
- You do not need to turn the meat or fish.

#### Roasting and grilling on the wire rack

Roasting on the wire rack works particularly well for large poultry or for multiple pieces at the same time.

 Depending on the size and type of the food to be roasted, add up to 1/2 litre water to the universal pan.

You can make a sauce from the juices that are caught. This also means that less smoke is produced and the cooking compartment becomes less dirty.

- Keep the appliance door closed when using the grill.
  - Never grill with the appliance door open.
- Place the food to be grilled on the wire rack. In addition, slide the universal pan in at least one shelf position lower, with the slanted edge facing the appliance door. This means that any dripping fat is caught.

#### Roasting in cookware

When preparing food in cookware with a lid, the cooking compartment remains cleaner. Follow the manufacturer's instructions for your roasting dishes. Glass cookware is best.

#### Cookware without lid

- Use a deep roasting dish.
- Place the cookware onto the wire rack.
- If you do not have any suitable cookware, use the universal pan.

#### Cookware with lid

- Place the cookware onto the wire rack.
- Meat, poultry and fish can also become crispy in a covered roasting dish. Use a roasting dish with a glass lid. Set a higher temperature.

#### MARNING – Risk of injury!

If hot glass cookware is placed on a wet or cold surface, the glass may shatter.

 Place hot glass ovenware on a dry mat after cooking.

#### MARNING – Risk of scalding!

Very hot steam may escape when the lid is opened after cooking. Steam may not be visible, depending on the temperature.

- Lift the lid in such a way that the hot steam can escape away from you.
- ► Keep children away from the appliance.

#### 26.4 Food selection

Food	Accessories/cook- ware	Shelf pos- itions	Heating function	Temperature in °C/grill setting	Steam intens- ity	Cooking time in mins
Victoria sponge cake	2 pcs Ø 20 cm cake tin	2	۲	150-160	少 /	20-35
Rich fruit cake	Deep 23 cm dia- meter tin	2	æ	140-150	-	180-210
Fruit pie	20 cm diameter plate or pie tin	2	0	160-170	-	60-70

<sup>1</sup> Preheat the appliance.

<sup>2</sup> Preheat the appliance. Do not use the rapid heating function.

<sup>3</sup> Preheat the appliance for five minutes. Do not use the rapid heating function.

<sup>4</sup> Preheat the appliance to 150 °C using HotAir.

<sup>5</sup> Preheat the appliance for 20 minutes.

<sup>6</sup> Do not turn the food.

<sup>7</sup> Slide the universal pan underneath the wire rack.

<sup>8</sup> Add the food after approx. one hour.

<sup>9</sup> Preheat the appliance for 5 minutes.

<sup>10</sup> Preheat the appliance for three minutes.

<sup>11</sup> Turn the food occasionally.

Food	Accessories/cook- ware	Shelf pos- itions	Heating function	Temperature in °C/grill setting	Steam intens- ity	Cooking time in mins
Quiche	Quiche tin (dark- coated)	3	æ	180-200	-	40-55
(White) bread	Loaf tin (1 x 900 g or 2 x 450 g)	2	®	190-200	<b>1.</b> 少 <i>己</i> <b>2.</b> 0	<b>1.</b> 15 <b>2.</b> 15-25
(White) bread	Loaf tin (1 x 900 g or 2 x 450 g)	2		190-200	<b>1.</b> 少 / <b>2.</b> 0	<b>1.</b> 15 <b>2.</b> 15-25
Scones	Baking sheet on wire rack	3		190-200 <sup>1</sup>	-	10-15
Biscuits	Baking sheet on wire rack	3	8	140-160 <sup>2</sup>	-	10-20
Small cakes	12-cup tin	3		150 <sup>3</sup>	-	25-35
Pavlova	Baking sheet on wire rack	3	8	100-110 <sup>4</sup>	-	150-180
Yorkshire pudding	12-cup tin	3	۲	200-220 <sup>5</sup>	-	15-25
Pizza, home-made	Baking tray	3	8	190-210	-	20-30
Pizza, home-made, thin base	Round pizza tray	2	<u>®</u>	250-270	-	8-13
Victoria sponge cake, 2 levels	4 pcs Ø 20 cm cake tin	3+1	Ø	150-160 <sup>1</sup>	-	20-30
Biscuits, 2 or 3 levels	Baking sheet on wire rack	3+1 5+3+1	æ	140-160 <sup>1</sup>	-	15-25
Beef, top side/top rump	Cookware without lid	2	Ø	170	-	40+30
Lamb leg (on the bone)	Cookware without lid	2	æ	160-170	-	25+15
Pork belly	Cookware without lid	2	1. 🗔 2. 💟	<b>1.</b> 170-180 <b>2.</b> 2	-	<b>1.</b> 30+30 <sup>6</sup> <b>2.</b> 3-5
Chicken, whole	Wire rack	2	8	170-180	_	25+15 <sup>7</sup>
Turkey, crown	Wire rack	2	0	140-150	-	20+25
Turkey, whole, 4-8 kg	Wire rack	1	8	150-160	-	12+12 <sup>8</sup>
Fish, braised, whole 300 g, e. g. trout	Cookware with lid	2	æ	170-190	-	25-35
Diced meat (beef, pork, lamb), 500 g	Cookware with lid	2	æ	140	-	120-140
Complete meal with chicken	Wire rack + Wire rack +	4+1	۲	180, then 200 (Yorkshire pud- ding)		Chicken: (25+25) + 20 for Yorkshire
	Universal pan					pudding
Bacon rashers	Wire rack	3	<b></b>	3°	-	1 side 4- 5 2 side 3- 4
Sausages, thickness 2- 4 cm	Wire rack	3	<b>~</b>	3 <sup>10</sup>	-	10-20 <sup>11</sup>

<sup>1</sup> Preheat the appliance.

<sup>2</sup> Preheat the appliance. Do not use the rapid heating function.

<sup>3</sup> Preheat the appliance for five minutes. Do not use the rapid heating function.
 <sup>4</sup> Preheat the appliance to 150 °C using HotAir.
 <sup>5</sup> Preheat the appliance for 20 minutes.

6 Do not turn the food.

<sup>7</sup> Slide the universal pan underneath the wire rack.
<sup>8</sup> Add the food after approx. one hour.
<sup>9</sup> Preheat the appliance for 5 minutes. 7

<sup>10</sup> Preheat the appliance for three minutes. <sup>11</sup> Turn the food occasionally.

Food	Accessories/cook- ware	Shelf pos- itions	Heating function	Temperature in °C/grill setting	Steam intens- ity	Cooking time in mins
Pork, gammon joint	Cookware without lid	2	ž	170-180	-	25+20 <sup>6</sup>
Chicken, whole	Cookware without lid	2	**	170-180	-	20+20 <sup>7</sup>
Pork belly, 1 kg	Cookware without lid	2	) Å	160-170	<b>1.</b> 少 <i>i</i> 2. 0	<b>1.</b> 30 <b>2.</b> 50-60
Chicken, whole, 1.5 kg	Cookware without lid	2	<u>**</u>	170-180	<b>1.</b> 少 <i>i</i> 2. 0	<b>1.</b> 30 <b>2.</b> 40-50
Turkey, crown, 3 kg	Wire rack	2	8	140-150	<b>1.</b> 少 <i>i</i> 2. 0	<b>1.</b> 35 <b>2.</b> 90-130

<sup>1</sup> Preheat the appliance.

<sup>2</sup> Preheat the appliance. Do not use the rapid heating function.

<sup>3</sup> Preheat the appliance for five minutes. Do not use the rapid heating function.

<sup>4</sup> Preheat the appliance to 150 °C using HotAir.

<sup>5</sup> Preheat the appliance for 20 minutes.

<sup>6</sup> Do not turn the food.

<sup>7</sup> Slide the universal pan underneath the wire rack.

<sup>8</sup> Add the food after approx. one hour.

<sup>9</sup> Preheat the appliance for 5 minutes.

<sup>10</sup> Preheat the appliance for three minutes.

<sup>11</sup> Turn the food occasionally.

#### 26.5 Yoghurt

You can use your appliance to make your own yoghurt.

#### **Preparing yoghurt**

- 1. Remove the accessories and shelf supports from the cooking compartment.
- 2. Pour the previously prepared yoghurt mixture into small containers, e.g. into cups or small jars.
- Cover the containers with foil, e. g. with cling film.
   Place the containers on the cooking compartment
- floor.
- 5. Set the appliance according to the recommended setting.
- **6.** After making the yoghurt, leave it to cool in the refrigerator.

#### **Recommended settings for yoghurt**

Food	Accessories/cookwa	re Shelf position	Type of heating	Temperature in °C	Cooking time in mins
Yoghurt	Individual moulds	Cooking compartment floor		40-45	8-9 hrs

#### 26.6 Slow cooking

Slow cooking is a technique for cooking food over a long period at low temperatures. For this reason, it is also called "low-temperature cooking".

#### Slow cooking food

#### Requirements

- Only use fresh, clean and hygienic meat without bones.
- Only start operation when the cooking compartment has fully cooled down.

- 1. Preheat the cooking compartment and cookware for approx. 15 minutes.
- **2.** Sear the meat on all sides on the cooking zone at a very high heat.
- **3.** Immediately place the meat into the pre-warmed cookware in the cooking compartment.
- 4. Keep the appliance door closed in order to maintain an even cooking climate.

#### Recommended settings for slow cooking

Food	Accessories/cook- ware	Shelf pos- ition	Type of heating	Searing time in mins	Temperature in °C	Cooking time in mins
Duck breast, 300 g each	Cookware without lid	2		6-8	95 <sup>1</sup>	60-70
Fillet of pork, whole	Cookware without lid	2		4-6	85 <sup>1</sup>	75-100
Beef topside, 6–7 cm thick, 1.5 kg	Cookware without lid	2		6-8	100 <sup>1</sup>	160-220
Fillet of beef, 4–6 cm thick, 1 kg	Cookware without lid	2		6-8	85 <sup>1</sup>	90-150
Veal medallions, 4 cm thick	Cookware without lid	2		4	80 <sup>1</sup>	50-70
Saddle of lamb, boneless, 200 g each	Cookware without lid	2		4	85 <sup>1</sup>	30-70
<sup>1</sup> Preheat the appliance.						

#### 26.7 Test dishes

These overviews have been produced for test institutes to facilitate appliance testing in accordance with EN 60350-1.

#### Baking

Observe this information when baking test dishes.

#### **General information**

- The settings apply to food that is placed into a cold cooking compartment.
- Observe the notes about preheating in the tables. These setting values apply without rapid heating.
- When baking, use the lower of the listed temperatures to begin with.

#### Shelf positions

Shelf positions for baking on two levels:


**Note:** Items that are placed in the oven on baking trays or in baking tins/dishes at the same time will not necessarily be ready at the same time.

 Universal pan: Level 3 Baking tray: Level 1  Baking tins/dishes on the wire rack First wire rack: Level 3 Second wire rack: Level 1

Shelf positions for baking on three levels:

 Baking tray: Level 5 Universal pan: Level 3 Baking tray: Level 1

Baking with two springform cake tins: Position baking tins/dishes either next to one another or offset on different shelves so that they are not directly one above the other in the cooking compartment.



#### **Recommended settings for baking**

Accessories/cook- ware	Shelf pos- ition	Type of heating	Temperature in °C	Cooking time in mins
Baking tray	3		140-150 <sup>1</sup>	25-35
Baking tray	3	۲	140-150 <sup>1</sup>	20-30
Universal pan + Baking tray	3 + 1	æ	140-150 <sup>1</sup>	25-35
Universal pan +	5 + 3 + 1	8	130-140 <sup>1</sup>	35-55
<b>0</b> ,	3		150 <sup>1</sup>	25-35
Baking tray	3	8	140 <sup>1</sup>	25-35
	wareBaking trayBaking trayUniversal pan+Baking trayUniversal pan+Baking trayBaking trayBaking trayBaking tray	wareitionBaking tray3Baking tray3Universal pan3 + 1+Baking trayUniversal pan5 + 3 + 1+Baking trayBaking tray3	wareitionheatingBaking tray3Image: Constraint of the sector of the secto	wareitionheating°CBaking tray3 $\Box$ 140-1501Baking tray3 $\textcircled{140-1501}$ 140-1501Universal pan3 + 1 $\textcircled{140-1501}$ +Baking tray140-1501Universal pan5 + 3 + 1 $\textcircled{130-1401}$ +Baking tray130-1401Baking tray3 $\fbox{1501}$

<sup>2</sup> Preheat the appliance. Do not use the rapid heating function.

Food	Accessories/cook- ware	Shelf pos- ition	Type of heating	Temperature in °C	Cooking time in mins
Small cakes, 2 levels	Universal pan +	3 + 1	8	140 <sup>1</sup>	30-40
	Baking tray				
Small cakes, 3 levels	Universal pan +	5 + 3 + 1	8	140 <sup>1</sup>	30-40
	Baking tray				
Hot water sponge cake	Springform cake tin, diameter 26 cm	2		160-170 <sup>2</sup>	25-35
Hot water sponge cake	Springform cake tin, diameter 26 cm	2	æ	160-170	30-35
Hot water sponge cake, 2 levels	Springform cake tin, diameter 26 cm	3 + 1	٨	150-160 <sup>2</sup>	35-50
<sup>1</sup> Preheat the appliance for five m <sup>2</sup> Preheat the appliance. Do not u	inutes. Do not use the r se the rapid heating fur	rapid heating	function.		

#### **Recommended settings for grilling**

Food	Accessories/cookware	Shelf pos- ition	Type of heating	Temperature in °C/grill setting	
Toasting bread	Wire rack	5	·····	3 <sup>1</sup>	5–6
<sup>1</sup> Do not preheat the appliance.					

### 27 Installation instructions

Observe this information when installing the appliance.




### 27.1 General installation instructions

Follow these instructions before you start with the installation of the appliance.

- The safe operation of this appliance can only be guaranteed if it has been installed to a professional standard in accordance with these installation instructions. The installer shall be liable for damages incurred as a result of incorrect installation.
- Check the appliance for damage after unpacking it. Do not connect the appliance if it has been damaged in transit.
- Before starting up the appliance, remove any packaging material and adhesive film from the cooking compartment and the door.
- Proceed in accordance with the installation sheets for installing accessories.

- Fitted units must be heat-resistant up to 95 °C, and adjacent unit fronts up to 70 °C.
- Do not install the appliance behind a decorative door or the door of a kitchen unit. There is a risk of overheating.
- Cut-out work on the units should be carried out before installing the appliance. Remove any shavings. Otherwise, the correct operation of electrical components may be adversely affected.
- The mains socket for the appliance must either be located in the hatched area a or outside of the area where the appliance is installed.

Any unsecured units must be secured to the wall using a standard bracket **b**.



- Wear protective gloves so that you do not cut yourself. Parts that are accessible during installation may have sharp edges.
- Dimensions of the figures in mm.

#### ▲ WARNING – Risk of fire!

It is dangerous to use an extended power cord and non-approved adapters.

- Do not use multiple socket strips.
- Only use extension cables that are certified, have a minimum cross section of 1.5 mm<sup>2</sup> and comply with the applicable national safety requirements.
- If the power cord is too short, contact customer service.
- Only use adapters approved by the manufacturer.


#### **ATTENTION!**

Carrying the appliance by the door handle could break it. The door handle cannot support the weight of the appliance.

Do not carry or hold the appliance by the door handle.


#### 27.2 Appliance dimensions

You will find the dimensions of the appliance here



#### 27.3 Installation below a worktop


Observe the installation dimensions and the installation instructions when installing below a worktop.



- To ventilate the appliance, the intermediate floor must have a ventilation cut-out.
- In combination with induction hobs, the gap between the worktop and appliance must not be sealed using additional strips.
- The worktop must be secured to the built-in unit.
- Observe any available installation instructions for the hob.

#### 27.4 Installation in a tall unit


Observe the installation dimensions and the installation instructions when installing in a tall unit.




- To ventilate the appliance, the intermediate floors must have a ventilation cut-out.
- If the tall unit has another back panel in addition to the element back panels, this must be removed.
- Only fit the appliance up to a height which allows accessories to be easily removed.

# 27.5 Installing two appliances on top of each other

Your appliance can also be installed above or below another appliance. Observe the installation dimensions and the installation instructions when installing appliances on top of each other.




- To ventilate the appliances, the intermediate floor must have a ventilation cut-out.
- To ensure sufficient ventilation of the two appliances, there must be a ventilation opening of at least 200 cm<sup>2</sup> in the base area. To do this, trim the base panel or fit a ventilation grille.
- Ensure that air exchange is guaranteed in accordance with the diagram.



Only fit appliances up to a height that allows accessories to be easily removed.

### 27.6 Corner installation

Observe the installation dimensions and the installation instructions when installing in a corner.



 To ensure that the appliance door can be opened, you must take the minimum dimensions into consideration when installing in a corner. The dimension a is dependent on the thickness of the unit front and the handle.

### 27.7 Electrical connection

In order to safely connect the appliance to the electrical system, follow these instructions.

- The appliance corresponds to protection class I and must only be operated with a protective earth connection.
- The fuse protection must correspond to the power rating specified on the appliance's rating plate and to local regulations.
- The appliance must be disconnected from the power supply whenever installation work is being carried out.
- Забороняється використання приладу в приміщеннях, де електрична мережа не обладнана заземлювальним проводом.
- The appliance must only be connected using the power cable provided.
- The power cable must be plugged in at the rear of the appliance until you hear a clicking sound. A 3 m power cable can be obtained from the after-sales service.
- The power cable must only be replaced with a cable from the original manufacturer. This is available from after-sales service.
- Contact protection must be guaranteed by the installation.

## Electrically connect the appliance with the protective contact plug

**Note:** The appliance must only be connected to a protective contact socket that has been correctly installed.

Insert the plug into the protective contact socket. When the appliance is installed, the mains plug of the power cord must be freely accessible. If free access to the mains plug is impossible, an all-pole isolating switch must be integrated into the permanent electrical installation in accordance with the installation regulations.

## Electrically connecting an appliance without a protective contact plug

**Note:** Only a licensed professional may connect the appliance. Damage caused by incorrect connection is not covered under the warranty.

An all-pole isolating switch must be integrated into the permanent electrical installation according to the installation regulations.

1. Identify the phase and neutral conductors in the socket.

The appliance may be damaged if it is not connected correctly.


2. Connect the hob in accordance with the connection diagram.

See the rating plate for the voltage.


- **3.** Connect the wires of the mains power cable according to the colour coding:
  - Green/yellow = Protective conductor -
  - Blue = Neutral conductor
  - Brown = Phase (external conductor)

### 27.8 Installing the appliance


**1.** Slide the appliance in fully and centre it.



**2.** Screw the appliance into place.



- **3.** For handleless kitchens with vertical bar handle strips:
  - Attach a suitable filling piece ① in order to cover any sharp edges and to guarantee a safe installation.
  - Pre-drill aluminium profiles to establish a screw connection 2.
  - Secure the appliance using a suitable screw 3.



**Note:** The gap between the worktop and the appliance must not be closed by additional battens. Thermal insulation strips must not be fitted to the side panels of the surround unit.

#### 27.9 Removing the appliance

- 1. Disconnect the appliance from the power supply.
- 2. Undo the fastening screws.
- **3.** Lift the appliance slightly and pull it out completely.


**BSH Hausgeräte GmbH** Carl-Wery-Straße 34 81739 München GERMANY www.siemens-home.bsh-group.com

Valid within Great Britain: Imported to Great Britain by BSH Home Appliances Ltd. Grand Union House Old Wolverton Road Wolverton, Milton Keynes MK12 5PT United Kingdom

Manufactured by BSH Hausgeräte GmbH under the trademark licence of Siemens AG

## **9001662812** (010906) en