

Please take a few minutes to read and become familiar with the advantages of your washer dryer.

To meet the high quality demands required by Siemens, every washer dryer that leaves our factory is carefully checked to ensure that it functions correctly and is in perfect condition.

For more information on our products, accessories, replacement parts and services, see our website www.siemenshome.bsh-group.com or contact our after-sales service centres.

If the operating and installation instructions describe different models, any differences will be pointed out at the relevant points in the text.



Read these operating and installation instructions before switching on the washer dryer.

Display rules

This combination of symbol and signal word indicates a possibly dangerous situation. Not heeding the warning can cause death or injuries.

Caution!

This signal word indicates a possibly dangerous situation. Not heeding the caution can cause property and/or environmental damage.

Note/tip

Information about the optimum use of the appliance/any other useful information.

1. 2. 3. / a) b) c)

The steps are represented by numbers or letters.

_ / -

Lists are represented by a small box or a dash.

Contents

S Intended use4	Saving energy and detergent 29
Intended use	Saving energy and detergent 28 Proverview of programmes 30 Selectable programme 30 Drying table 34 Programme default settings 38 Temp.°C 35 Spin Speed 35 Finished in 35 Prevash 36 Extra Rinse 36 Extra Rinse 36 Preparing the appliance 37 Select programme/switch on
Removing the transport locks	the appliance
Getting to know the appliance	Cancel the programme
Laundry	Unbalanced load detection system

Intended use en

Emptying the detergent draw, cleaning the detergent drawer and its housing	44 45
Paults and what to do about	
them	
Emergency release	
Information on the display panel	
Faults and what to do about them	48
After-sales service	. 52
Consumption values	. 53
Technical data	. 54
Aqua Stop warranty	54
Aqua-Stop Wallality	. 54



Intended use

- This appliance is intended for private domestic use only.
- Do not install or operate this appliance anywhere that is liable to experience frost and/or outdoor conditions. There is a risk that the appliance will be damaged if residual water in it freezes. If hoses freeze up, they may crack/burst.
- This appliance must only be used for washing domestic laundry. consisting of machine-washable items and hand-washable woollens (see label on item). Using the appliance for any other purpose is outside of the scope of its intended application and is forbidden.
- This appliance must only be used for drying and freshening up domestic laundry, consisting of items that have been washed with water and are suitable for tumble drving (see label on item). Using the appliance for any other purpose is outside of the scope of its intended application and is forbidden.
- This appliance is suitable for operation with mains water and commercially available detergents and care products (must be suitable for use in washing machines).
- This appliance is intended for use up to a maximum height of 4000 metres above sea level.

Before you switch on the appliance:

Check that there is no visible damage to the appliance. Do not operate the appliance if it is damaged. Should you have any problems, please contact your specialist dealer or our customer service.

Read and follow the operating and installation instructions and all other information provided with this appliance.

Retain the documents for subsequent use or for subsequent owners.

▲ Safety instructions

The following safety information and warnings are provided to protect you from injury and to prevent material damage to your surroundings.

It is nevertheless important to take the necessary precautions and to proceed with care when installing, maintaining, cleaning and operating the appliance.

Children/people/pets

Children and other people who are unable to assess the risks involved when using the appliance may injure themselves or may find themselves in life-threatening situations. Therefore please note:

- The appliance may be used by children over the age of 8 years and by persons with reduced physical, sensory or mental capacity or by persons with a lack of experience or knowledge as long as they are supervised or have received instruction on how to use the appliance safely and they have understood the potential risks of using the appliance.
- Children must not play with this appliance.

- Do not allow children to clean or maintain this appliance unsupervised.
- Keep children under 3 years and pets away from this appliance.
- Do not leave the appliance unattended when children or other people who are unable to assess the risks are in the vicinity.

Children may lock themselves inside appliances and find themselves in a life-threatening situation.

- Do not position the appliance behind a door, as this may obstruct the appliance door or prevent it from opening completely.
- Once an appliance has reached the end of its life, pull the mains plug from the socket **before** severing the mains cable, and then destroy the lock on the appliance door.

If allowed to play with the packaging/plastic film or packing components, children may become caught in these or pull them over their heads and suffocate.

Keep packaging, plastic film and packing components away from children.

⚠ Warning Risk of poisoning!

Detergents and care products may result in poisoning if consumed.

If accidentally swallowed, seek medical advice. Keep detergents and care products out of the reach of children.

⚠ Warning Eye/skin irritation!

Contact with detergents or care products may cause eye/skin irritation.

Rinse eyes/skin thoroughly if they/it come(s) into contact with detergents or care products. Keep detergents and care products out of the reach of children.

Installation

⚠ Warning

Risk of electric shock/fire/ material damage/damage to the appliance!

If the appliance is not installed properly, this may lead to a dangerous situation. Ensure the following:

- The mains voltage on your power socket must match the rated voltage specified on the appliance (identification plate). The connected loads and the required fuse protection are specified on the identification plate.
- The appliance must not be supplied through an external switching device, such as a timer, or connected to a circuit that is regularly switched on and off by a utility.
- The mains plug and the protective contact socket must match and the earthing system must be correctly installed.
- The installation must have an adequate cross section.

- The mains plug must be freely accessible at all times. If this is not possible, in order to comply with the relevant safety regulations, a switch (all pole disconnection) must be built into the permanent installation in accordance with electrical installation regulations.
- If using a residual current circuit breaker, only use one that bears the following mark: The presence of this mark is the only way to be sure that it fulfils all the applicable regulations.

If the appliance's mains cable is altered or damaged, this may result in electric shock, short circuiting or fire due to overheating.

The mains cable must not be kinked, crushed or altered, and must not come into contact with any heat sources.

The use of extension cords or power strips may result in fire due to overheating or short circuiting.

Connect the appliance directly to an earthed socket that has been correctly installed. Do not use extension cords, power strips or multi-way couplers.

- The appliance may vibrate or move when in operation, potentially resulting in injury or material damage.
 Place the appliance on a clean, even, solid surface and, using a spirit level to guide you, level it with the screw-in feet.
- If you take hold of any of the appliance's protruding parts (e.g. the appliance door) in order to lift or move it, these parts may break off and cause injury. Do not take hold of any of the appliance's protruding parts in order to move the appliance.

- The appliance is very heavy. Lifting it may result in injury. Do not lift the appliance on your own.
- The appliance has sharp edges on which you could cut your hands.
 Do not take hold of the appliance by its sharp edges. Wear protective gloves to lift it.
- If the hoses and mains cables are not correctly routed, they may constitute a tripping hazard, which may result in injury.
 Route hoses and cables such that they do not constitute a tripping hazard.

Caution! Material damage/damage to the appliance

If the water pressure is too high or too low, the appliance may not be able to operate properly, and it may also result in material damage or damage to the appliance. Make sure that the water pressure in the water supply facility is at least 100 kPa (1 bar), and does not exceed 1000 kPa (10 bar).

- If the water hoses are altered or damaged, this may result in material damage or damage to the appliance. The water hoses must not be kinked, crushed, altered or severed.
- The use of hoses supplied by other brands to connect to the water supply may result in material damage or damage to the appliance.
 Use the hoses supplied with the appliance or genuine spare part hoses only.
 The appliance is secured for

transportation by transport

locking devices. If the

transport locking devices are not removed before the appliance is operated, this may result in damage to the appliance. It is important to completely remove all transport locking devices before using the appliance for the first time. Make sure that you retain these transport locking devices separately. It is important to refit the transport locking devices if the appliance is to be transported, in order to prevent the appliance from being damaged in transit.

Operation

Laundry that has come into contact with solvents, oil, wax, wax remover, paint, grease or stain remover may ignite when dried in the machine, or even cause the appliance to explode. Therefore please note:

- Rinse the laundry thoroughly with warm water and detergent before drying it in the machine.
- Do not place laundry in this appliance to be dried if the laundry has not been washed first.
- Do not use the appliance if industrial chemicals have been used to clean the laundry.

Laundry that has been pretreated with cleaning agents that contain solvents, e.g. stain remover/cleaning solvent, may cause an explosion in the drum. Rinse the laundry thoroughly with water before washing it in the machine.

- Certain objects may ignite when drying is in progress, or even cause the appliance to catch fire or explode.
 Remove any lighters or matches from pockets on items of clothing.
- If there is coal dust or flour in the air around the appliance, this may cause an explosion. Make sure that the area around the appliance is kept clean when it is in operation.

⚠ Warning

Risk of fire/material damage/damage to the appliance!

If a program is terminated before the drying cycle has finished, this prevents the laundry from cooling down sufficiently and may cause the laundry to ignite, or may result in material damage or damage to the appliance.

- During the last part of the drying cycle, the laundry in the drum is not heated (cooling cycle). This is to ensure that it remains at a temperature at which it will not be damaged.
- Do not switch off the appliance before the drying cycle has finished unless you remove all items of laundry from the drum immediately and spread them out (to dissipate the heat).

⚠ Warning Risk of poisoning!

Poisonous fumes may be given off by cleaning agents that contain solvents, e.g. cleaning solvent.

Do not use cleaning agents that contain solvents.

- If you support your weight/sit on the appliance door when it is open, the appliance may tip over, which may result in injury.
 - Do not support your weight on the appliance door when it is open.
- If you climb onto the appliance, the worktop may break, which may result in injury.
 Do not climb onto the appliance.
- If you reach into the drum while it is still rotating, you risk injuring your hands.
 Wait until the drum has stopped rotating.

When washing at high temperatures, there is a risk of scalding if you come into contact with hot detergent solution (e.g. when draining hot detergent solution into a washbasin).

Do not reach into the hot detergent solution.

Detergent and care products may spray out if the detergent drawer is opened while the appliance is in operation. Rinse eyes/skin thoroughly if they/it come(s) into contact with detergents or care products. If accidentally swallowed, seek medical advice.

Caution!

Material damage/damage to the appliance

- If the amount of laundry in the appliance exceeds its maximum load capacity, it may not be able to operate properly, or this may result in material damage or damage to the appliance.
 - Do not exceed the maximum load capacity of dry laundry. Make sure you comply with the maximum load capacities specified for each of the programs.
- Foam and foam rubber may deform or melt if dried in the appliance.
 - Do not dry laundry items that contain foam or foam rubber in the appliance.

If you pour the wrong quantity of detergent or cleaning agent into the appliance, this may result in material damage or damage to the appliance. Use detergents/care products/cleaning agents and softeners in accordance with the manufacturers' instructions.

Cleaning/Maintenance

The appliance is powered by electricity. There is a risk of electric shock if you come into contact with live components. Therefore please note:

- Switch off the appliance. Disconnect the appliance from the power supply (pull out the plug).
- Never take hold of the mains plug with wet hands.
- When removing the mains plug from the socket, always take hold of the plug itself and never the mains cable, otherwise this may damage the mains cable.
- Do not make any technical modifications to the appliance or its features.

- Repairs and any other work on the appliance must only be conducted by our customer service or by an electrician. The same applies for replacing the mains cable (when necessary).
- Spare mains cables can be ordered from our customer service.

Poisonous fumes may be given off by cleaning agents that contain solvents, e.g. cleaning solvent.

Do not use cleaning agents that contain solvents.

If moisture penetrates the appliance, this may cause it to short circuit.

Do not use a pressure washer, steam cleaner, hose or spray gun to clean your appliance.

The use of spare parts and accessories supplied by other brands is dangerous and may result in injury, material damage or damage to the appliance. For safety reasons, use genuine spare parts and accessories only.

Caution! Material damage/damage to the appliance

Cleaning agents and agents for pretreating laundry (e.g. stain removers, prewash sprays, etc.) may cause damage if they come into contact with the surfaces of the appliance. Therefore please note:

- Do not allow these agents to come into contact with the surfaces of the appliance.
- Clean the appliance with nothing but water and a soft, damp cloth.
- Remove any detergent, spray or other residues immediately.



Packaging/used appliance



Dispose of packaging in an environmentally-responsible manner.

The following Do's and Don'ts provide a framework for the return and recycling of used products when available in your area.

Do's

- Hand over the old/discarded electronic equipment only to authorized collection centers for disposal
- Consult the authorized service center as to whether the Electronic Equipment can be repaired or not, before discarding
- Consult the retailer about appliance take back schemes

Don'ts

- Don't dump the discarded Electronic Equipment in the open or in any land fill site, as this will result in contamination of the soil and the ground water
- Don't dispose of the discarded Electronic Equipment in household bins or Municipal bins
- The product is not meant for re-sale to any unauthorized agencies/scrap dealers
- Don't keep any replaced spare part(s) from the product in an exposed area


Tips on economical use

- Always fill the appliance with the maximum amount of laundry for each programme.
- Wash normally soiled laundry without pretreating.
- For light and normal soiling in laundry, you can save energy and detergent.
- The selectable temperatures apply to the care labels on the textiles. The temperatures in the appliance may deviate from this so that you get the optimum mix of energy-saving and washing results.
- Low power mode: If the appliance is not operated for a prolonged period (approx. 5 minutes). Appliances will switch of. To restart press On/Off button.
- If the laundry is then dried in the appliance, select the maximum possible spin speed. The less water the laundry contains, the less time and energy are required for drying. Do not dry dripping wet laundry.

Unpacking the washing maschine

Packaging material (e.g. Films, Styrofoam) can be dangerous for children. There is a risk of suffocation! Keep all packaging well away from children.


- **1.** Remove the cardboard box and styrofoam packing.
- Lift the washer dryer and remove the base packing. Make sure the small triangle foam is removed with the bottom one together. If not, lay the unit down with side surface, then remove the small foam from the unit bottom manually.
- 3. Remove the tape securing the power supply cord and drain hose.




Positioning and connecting

Standard accessories

Note: Check the appliance for transport damage. Never use a damaged appliance. If you have any complaints, contact the dealer from whom you purchased the appliance or our Customer Service.





- A Mains lead
- B Bag:
 - Installation and operating instructions
 - Customer Service location directory*
 - Warranty*
 - Supplementary sheet for the installation and operating instructions*
 - Cover caps for openings after the transport braces have been removed
- C Water inlet hose on aquaStop models*
- D Water outlet hose
- E Elbow for securing the water outlet hose*
- F Cold water inlet hose on Standard/Agua-Secure models
- Depending on the model

In addition, a hose clamp (24 - 40 mm diameter, available from specialist retailers) is required to connect the water outlet hose to a siphon.

Useful tool

- Spirit level for aligning
- Wrench with:
 - WAF13 for loosening the transport braces and
 - WAF17 for aligning the appliance feet

Safety instructions

⚠ Warning Risk of injury!

- The appliance is very heavy.
 Be careful when lifting/transporting the appliance.
- When the appliance is lifted by its protruding parts (e.g. the appliance door), the components may break off and cause injuries.
 Do not lift the appliance by protruding parts.
- If the hose and mains cables are not routed properly, there is a risk of tripping and injury.
 Lay hoses and cables in such a way that there is no risk of tripping.

Caution! Damage to the appliance

Frozen hoses may rip/burst. Do not install the appliance in areas exposed to frost or outdoors.

Caution! Water damage

The connection points for the water supply hose and water drain hose are under high water pressure. To prevent leaks and water damage, you must follow the instructions in this section.

Notes

- In addition to the safety information listed here, the local water and electricity supplier may have special requirements.
- If in doubt, have the appliance connected by a specialist.

Installation surface

Note: The appliance must be stable aligned so that it does not move around.

- The installation surface must be firm and level.
- Soft floors/floor coverings are not suitable.

Installation on a base or a wooden joist floor

Caution!

Damage to the appliance

The appliance may "wander" and tip/topple from the base when spinning. The feet of the appliance must be secured with holding brackets.

Order no. WMZ 2200, WX 975600, CZ 110600, Z 7080X0.

Note: On wooden joist floors, install the appliance:

- In a corner, if possible,
- On a water-resistant wooden board (min. 30 mm thick) which is screwed tightly to the floor.

Installing the appliance in a kitchenette



There is a risk of electric shock if you touch live components.

Do not remove the appliance covering plate.

Notes

- Recess width of 60 cm required.
- Only install the appliance underneath a continuous worktop that is securely connected to adjacent cabinets.

en


Removing the transport locks

Caution! Damage to the appliance


place.

- The appliance is secured for transportation using transport locks. If the transport locks are not removed, the appliance may become damaged when it is operated.
 Before using the appliance for the first time, make sure that you completely remove all four transport locks. Keep the locks in a safe
- To prevent transport damage from occurring if the appliance is moved at a later date, you must refit the transport locks before transporting the appliance.


Note: Keep the screws and sleeves in a safe place.




1. Take the hoses out of the holders.




2. Unscrew and remove all four transport brace screws.



a) Remove the mains cable from the holders.




b) Remove the sleeves.



- 3. Fit the covers.
- Lock the covers firmly in place by applying pressure to the snap-in hooks.

Hose and cable lengths

Connection on left side




1 ~ 140 cm

2 ~ 140 cm

3 ~ 60 cm 4 0 cm ~ 100 cm

or

Connection on right side



1 ~ 94 cm

2 ~ 195 cm

3 ~ 100 cm 4 0 cm ~ 100 cm

Note: If the supply hose is too short for your connection, you can order an extension from the after-sales service.

Slide in installation

For a slide in or build under Installation the appliance cover plate can be removed.

The appliance must be built under or built in prior to connecting to the power supply.

The appliance can be built into or under a kitchen work surface. For this purpose, a recess width of 60 cm is required.

Note:

- The washing machine must only be installed under a one-piece worktop that is permanently attached to the surrounding cabinets.
- For safety reasons in build-under installation, a metal cover must be assembled by a specialist in place of the appliance cover plate.
- The metal cover can be obtained from the Customer Service (order no. 20002788).

Water inlet

There is a risk of electric shock if you touch live components.

Do not immerse the Aqua-Stop safety valve* in water (it contains an electric valve).

* Depending on the model

Observe the following when connecting the appliance:

Notes

- Only operate the appliance using cold mains water.
- Do not connect the appliance to the mixer tap of an unpressurised hotwater boiler.

en Positioning and connecting

- Do not use a used supply hose. Only use the supply hose supplied or one that was purchased from an authorised specialist retailer.
- Do not bend, squash, modify or cut through the water supply hose (otherwise its strength is no longer guaranteed).
- Only tighten the screw connections by hand. If the screw connections are tightened too much with a tool (pliers), the thread may be damaged.

Optimum water pressure in the supply network

At least 100 kPa (1 bar)


Maximum 1000 kPa (10 bar)

When the tap is open, the water flow is at least 8 l/min.


If the water pressure is higher than this, a pressure-reducing valve must be installed.

Connection


- Connect the water supply hose to the water tap (³/₄" = 26.4 mm) and to the appliance:
 - Model: Standard



Model: Aqua-Secure



Model: Aqua-Stop



Tip: Connect also an external water filter (depending on the model) between water supply hose and tap. The filter filters dirt particles out of the water.

Water filter must be cleaned regularly to remove contaminants. This will prevent blockages. See also → separate installation and cleaning instruction for water filter.

Open the water tap carefully, checking the leak tightness of the connection points. The screw connection is under mains water pressure.

Water outlet

When you are washing at high temperatures, there is a risk of scalding if you come into contact with hot water (e.g. when draining hot water into a washbasin).

Do not reach into the hot water.

Caution! Water damage

When water is being pumped away, the outlet hose is under water pressure and may slip out of the wash basin or connection point.

Secure the drain hose so that it cannot slip out.

Caution!

Damage to the appliance/fabrics

If the end of the drain hose is immersed in the drained water, water may be sucked back into the appliance and may damage the appliance/fabrics. Make sure that:


- The plug does not block drainage from the washbasin.
- The end of the drain hose is not immersed in the drained water.
- The water drains away quickly enough.

Note: Do not kink the water drain hose or put strain on it lengthways.

Connection

Drainage into a siphon

The connection point must be secured using a hose clamp with a diameter of 24 - 40 mm (available from specialist dealers).




Drainage into a washbasin


Secure the outlet hose so that it cannot slip out.

Elbow available from after-sales service:

Individual part number 00655300



 Drainage into a plastic pipe with rubber bushing or into a drainage pit




Note: The plastic pipe is not standard accessory, available from specialist dealers.


Alignment

Level the appliance using a spirit level. Incorrect levelling may result in intense noise, vibrations and wandering.


 Loosen the lock nuts using a wrench, by turning it in a clockwise direction.



 Check the alignment of the appliance with a spirit level, and adjust it if necessary. Change the height by turning the appliance feet. All four appliance feet must stand firmly on the ground.



 Tighten the lock nut against the housing.
 In doing so, hold the foot tight and do not adjust its height.
 The lock nuts on all four appliance feet must be screwed tightly against the housing.



Electrical connection



There is a risk of electric shock if you touch live components.

- Never touch or hold the mains plug with wet hands.
- Only pull out the mains cable by the plug and never by the cable, as this could damage it.

Observe the following information and ensure that:

Notes

- The mains voltage and voltage indicated on the appliance (rating plate) are the same.
 The connected load and fuse required are specified on the rating plate.
- The appliance is only connected to an alternating current via a properly installed earthed socket.
- The mains plug fits the socket.
- The earthing system is properly installed.
- The mains cable is only replaced by a qualified electrician (if this is necessary). Replacement mains cables are available from the aftersales service.
- No multiple plugs/couplings or extension cables are used.
- The mains plug can be accessed at all times.
- The mains cable is not bent, squashed, modified, cut through, or in contact with heat sources.

Before washing for the first time

The appliance was inspected thoroughly before leaving the factory. To remove any residual test water, run the **Drum Clean** 5 programme the first time **without** laundry.

Note:

- The appliance must have been installed and connected properly.
 → "Positioning and connecting" on page 14
- Never switch on a damaged appliance.
- 1. Insert mains plug.
- 2. Turn the water tap on.
- 3. Close the door. Do not load any laundry.
- 4. Select the **Drum Clean** programme.
- 5. Open the detergent drawer.
- 6. Pour approx. 1 litre of water into dispenser II.
- Add standard detergent to dispenser Il according to manufacturer's instructions for light soiling.
 Note: To prevent frothing, use only half the recommended amount of detergent. Do not use any woollens or mild detergents.
- 8. Close the detergent drawer.
- 9. Select DII Start/Reload.
- When the programme ends, turn the programme selector to Off.

Your appliance is now ready for use.

Transportation

e.g. when moving home

Preparatory work:


- 1. Turn off the water tap.
- 2. Reduce the water pressure in the supply hose. → Page 45
- 3. Drain any residual water.
 - → Page 44
- **4.** Disconnect the appliance from the mains.
- 5. Remove the hoses.
- 6. Empty the dispensers.
 Caution!

Risk of damage to the appliance caused by detergent/fabric softener leaking from the dispensers

Leaking detergent/fabric softener can prevent the appliance from working correctly, e.g. due to damage to the electronics. Empty the dispensers before transporting the appliance.


Installing the transport locks:

- Remove the covers and keep them in a safe place.
 Note: Use a screwdriver if necessary.
- 2. Insert all four sleeves.




en Positioning and connecting


a) Clip the mains cable securely in the holders.



b) Insert and tighten the screws.



c) Clip the hoses securely in the holders.




Before switching on the appliance again:

Note: Pour approx. 1 litre of water into dispenser II, select the **Spin/Drain** programme and start.

This will prevent detergent from flowing straight into the drain during the next wash.


Getting to know the appliance

Appliance



- Detergent drawer Control panel
- Loading door Service flap

Control panel



- 1 On/Off button for switching the appliance on and off.
- Start/Reload button for starting, interrupting, (e.g. adding laundry) programme.
- 3 Drying target and drying time setting.→ Page 36
- Additional programme settings can be selected. Overview of all additional programme settings. → Page 36
- Programme default settings can be changed. Overview of all programme default settings → Page 36
- 6 Programme selector for selecting the programme.

Display panel

Programme default settings



Display	Setting	Description
* -90°	Temp.°C	Temperature that can be set in °C
Ø - 1400*	Spin Speed	Spin speed in rpm (revolutions per minute) Solution = No spin
2:30*	Programme remaining time	Programme remaining time depends on the programme selec- tion in h:min (hours:minutes)
0-24 h	Finished in	Programme ends after h (h = hours)
8,0* kg/ 5,0* kg	Maximum load for washing/dry- ing	Recommended load in kg
*	Drum Clean	Drum clean programme
 Depending on the selected model and pro- gramme. 		

Additional programme settings



Display	Setting
₼/⊞/ 2	-☆- Drying
30 60 90 120	Time Dry
₩	Extra Rinse
	Prewash
=₩	speedPerfect
☆	Memory
\approx	Child lock
AN)	Signal on/off

en

Status indicators for the programme progress (programme sequence)



Display	Setting
©	Door closed
是	Water tab closed
	Wash
EE	Rinse
©	Spin/Drain
- \ \\\	Dry



Laundry

Preparing laundry for washing

Protecting your laundry and appliance

Caution!

Damage to the appliance/textiles

Foreign objects (e.g. coins, paper clips, needles, nails) may damage the washing or components of the appliance.

The following instructions must be observed when preparing your laundry:

- Always follow the manufacturer's instructions when dosing all detergents, cleaning aids, care products and cleaning agents.
- Do not exceed maximum load. Overfilling will impair the washing result.
- Keep detergents and agents for the pretreatment of laundry (e.g. stain remover, prewash sprays, etc.) away from the surfaces of the appliance. Using a damp cloth, immediately remove any fine spray residue and other residue or droplets.
- Empty any pockets. Remove any foreign objects.
- Remove metal parts (paper clips, etc.).
- Trousers, knitwear and knitted textiles, e.g. jersey garments, T-shirts or sweatshirts, should be turned inside out.
- Ensure that underwired bras are appliance-washable.
- Wash delicates in a net or bag (tights, underwired bras, etc).
- Close zips, button up covers.
- Brush sand out of pockets and collars.
- Remove curtain fittings or place in a net/baa.

Sorting laundry

Sort your laundry according to the care instructions and manufacturer's information on the care labels. depending on:

- Type of fabric/fibre
- Colour

Note: Laundry may discolour. Wash white and coloured items separately. Wash new coloured items separately the first time you wash them.

- Soilina
 - Wash laundry with the same level of soiling together.
 - **Light**: No need to pretreat, adjust the = speedPerfect setting if necessary.
 - Normal
 - Heavy: Load less laundry, need to pretreat or soak laundry firstly.
 - Stains: Remove/pretreat stains while they are fresh. First dab with soapy water; do not rub. Then wash the items of laundry with the appropriate programme. Stubborn or dried-in stains can sometimes only be removed by washing several times.
- Symbols on the care labels
 - Suitable for normal washing process:
 - e.g. Cottons & programme A gentle washing process is
 - required; e.g.Easy Care - programme
 - An especially gentle washing process is required; e.g. Delicates/Silk 🕾 programme
 - Suitable for washing by hand; T6/7 e.g. @ Wool @ programme
 - Do not machine wash. tXI

Preparing laundry for drying

Note: To ensure an even drving result. sort the laundry according to the:

- Type of fabric
- Care symbols which are indicated on the care labels

Only dry laundry which is labelled "dryer-proof" or which has the following care symbols:

- Cottons @/Mix/Delicate/Silk/Duvet/ Hygiene 65/hygieneAir.
- : You can select Easy Care/Gentle Dry

The following textiles must not be dried:

- □ = care symbol "Do not dry"
- Delicates (silk, synthetic curtains).
- Textiles which contain foam rubber or similar materials.
- Textiles which were treated with flammable liquids, e.g. with stain remover, petroleum ether, thinners. Risk of explosion!
- Textiles which still contain hairspray or similar substances.

Notes

- Before drying, hand-washed textiles must be spun at the appropriate spin speed.
- Before drying, spin at the optimum speed. A spin speed of more than 1000 rpm is recommended for cotton, more than 800 rpm for easycare textiles.
- Do not iron washing immediately after drying. It is recommended to roll the washing up first to distribute residual moisture evenly.
- To ensure a good drying performance, quilts, terry cloths and other large textiles should be dried separately.
- Do not exceed the maximum load.

Starching

Note: Laundry should not be treated with fabric softener

- 1. Switch on the appliance.
- 2. Select the **Rinse** programme.
- 3. Measure starch into dispenser ⊕ in accordance with the manufacturer's instructions (clean first if necessary).
- 4. Touch the DM Start/Reload button.

Dyeing/bleaching

Dye should only be used in normal household quantities. Salt may damage stainless steel. Always follow the dye manufacturer's instructions.

Do **not** use the appliance to bleach clothes.



Detergent

Correct selection of detergent

The care label is crucial to ensure correct detergent selection, temperature and laundry treatment.

- Standard detergent with optical brighteners
 - suitable for heat-resistant white washing made from linen or cotton Programme: Cottons @/ cold - max. 90 °C
- **Detergent for colours without** bleach or optical brighteners suitable for coloured washing made from linen or cotton Programme: Cottons @/ cold - max. 60 °C
- Detergent for colours/delicates without optical brighteners suitable for coloured laundry made from easy-care fibres, synthetic fibres Programme: Easy Care △/

cold - max. 60 °C

- **Detergent for delicates** suitable for delicate, fine fabrics, silk or viscose Programme: Delicates/Silk // cold - max. 40 °C
- **Detergent for woollens** suitable for woollen fabrics Programme: Wool / cold - max. 30 °C

Saving energy and detergent

For light and normal soiling, you can save energy (lower washing temperature) and detergent.

Saving Soiling/note Reduced temper-Liaht ature and deter-No visible dirt or stains. Clothgent quantity as ing has taken on some body per the recomodour. e.a.: mended dosage Light summer/sports clothing (worn for a few hours) T-shirts, shirts, blouses (worn for up to one day) Guest bed linen and hand towels (used for one day) Normal Visible dirt or a few light stains, e.g.: T-shirts, shirts, blouses (sweat soaked, worn a few times) Towels, bedding (used for up to one week) Temperature as Heavy per the care label Dirt and/or stains clearly visiand detergent ble, e.g. tea towels, baby quantity as per items, work clothing the recommended dosage for heavy soiling

Note: When measuring the amount of all detergents/additives/care products and cleaning agents, please always check the manufacturer's instructions and information.

Overview of programmes

Selectable programme

Programme/Type of laundry	Options/Information	
Name of the programme Brief explanation of the programme and for which fabrics it is suitable.	Max. load for washing/ Max. load for drying Max. load as kg depending on the model and the pro- gramme	
	selectable temperature* as °C	
	selectable spin speed* in rpm	
	possible additional programme settings*	
	possible setting for drying* (De)selectable ✓, not selectable -	
	softener	
Cottons 🏗 🌣	8,0 (4,0**) kg/5,0 kg	
Hard-wearing fabrics, heat-resistant fabrics made of cotton	* - 90 °C	
or linen.	0 - 1400 rpm	
	=0 speedPerfect, Extra Rinse, U Pre-treatment	
	☆ Dry ✓ (田✓, △ ✓ , ⑥ ✓)	
	possible	
Cottons Eco ⊗	8,0 kg	
Hard-wearing fabrics, heat-resistant fabrics made of cotton or linen.	0°C	
Energy-optimised washing by reducing the temperature while	1200 - 1400 rpm	
achieving a comparable washing result for the Cottons & pro-	-	
gramme. Notes	-	
 ■ The washing temperature is lower than the selected temperature. If you want to achieve a higher water temperature, use the Cottons ☆ programme with a higher temperature as required. ■ 1200 rpm is a Time and Energy-optimised programme. 	possible	
 Depending on the model and the programme. ** Reduced load with =♥ speedPerfect additional programn 	ne setting.	

Programme/Type of laundry	Options/Information	
Easy Care 📤 🌣	4,0 kg/2,0 kg	
Textiles made of synthetic materials or blended fabrics.	* - 60 °C	
	0 - 1200 rpm	
	🕁 Extra Rinse, 🕛 Pre-treatment	
	☼ Dry ✓ (⊞✓, △ ✓ , ⋒ ✓)	
	possible	
Mix 🖫 🌣	8,0 (4,0**) kg/5,0 kg	
Mixed load of cottons and synthetic fabrics.	* - 90 °C	
	0 - 1400 rpm	
	=O speedPerfect, w Extra Rinse, U Pre-treatment	
	☆ Dry ✓ (田 ✓, △ ✓ , ♠ ✓)	
	possible	
Delicates/Silk 🛱	2,0 kg	
For delicate, washable fabrics, e.g. made of silk, satin, synthetic fibres or blends (e.g. silk blouses, silk scarves).	* -30 °C	
ilbres of pierius (e.g. siik blouses, siik scarves).	0 - 800 rpm	
	Extra Rinse	
	-	
	possible	
₩ @ Wool	2,0 kg	
Hand- or appliance-washable fabrics that are made of wool or contain wool:	* -30 °C	
particularly gentle wash programme to prevent laundry from	0 - 800 rpm	
shrinking, with longer pauses in the programme (during which	Extra Rinse	
the items rest in the water).	-	
Note: In order to prevent clothing shrink, after drying still contain a small amount of water, please take out the clothes as soon as possible after the end of the programme to dry.	possible	
₩ Rinse/Spin ⑤	8 kg/-	
For rinsing with a subsequent spin cycle.	-	
	0 - 1400 rpm	
	🕁 Extra Rinse	
	-	
	possible	

- Depending on the model and the programme.

 Reduced load with = speedPerfect additional programme setting.

Overview of programmes en

Programme/Type of laundry	Options/Information
⑤ Spin/Drain ₩	8 kg/-
For spinning with a selectable spin speed and subsequent draining. If you have selected \mathscr{O} , it will run \rightleftharpoons Drain programme, the water is only drained after rinse process, no spin	-
	0 - 1400 rpm
cycle.	
	-
	not possible
Duvet ∰	2 kg/1 kg
Appliance-washable fabrics stuffed with down, such as pillows	* - 40 °C
and duvets; also suitable for items stuffed with synthetic fibres.	0 - 800 rpm
Notes It is recommended that you pull down the coat zipper	
before drying and turn the inner layer inside out.	-☆- Dry ✓ 田
Use the special detergent for down.	not possible
ச் hygieneAir ்்	4,0 kg/4,0 kg
An innovative program, pretreat dry laundry by hot air (up to	* - 90 °C
65°C) to for additional hygienic demands, followed by a low temperature washing cycle. Achieves both hygiene effect and	0 - 1400 rpm
fabric care. Suitable for most non-delicate textile.	₩ Extra Rinse
	-☆- Dry ✔ (⊞ ✔, <i>ဩ</i> ✔, ⋒��)
	possible
₩ Hygiene 65°C 🌣	8,0/4,0 kg
Wash hard-wearing items made from cotton, linen or blended	60 °C
fabrics. Suitable for allergy sufferers and for strict hygiene requirements.	0 - 1400 rpm
Note: Once the temperature of 65° has been reached,	₩ Extra Rinse
it remains for 30' throughout the washing process.	☆ Dry ✓ (田 ✓, △ ✓ ♠ ✓)
The display shows 60°.	possible
♥ Super Quick15'/♥ Wash & Dry 60'	2,0 kg/1,0 kg
For small amount lightly soiled garments made of cotton, linen,	* - 30 °C
synthetic or blended fabrics. Approx. 15 mins for washing. If drying function is selected, it's followed by another approx. 45 mins drying process. Note: The default programme is Super Quick15'. You can	0 - 800 rpm
	₩ Extra Rinse
	☆ Dry ✓ ⊞
switch to 🖰 Wash & Dry 60' programme by touching 🔅 Dry button.	possible
* Depending on the model and the programme.	

- Depending on the model and the programme.

 Reduced load with = U speedPerfect additional programme setting.

Programme/Type of laundry	Options/Information	
ℰ Gentle Dry	3,0 kg	
Gentle dry programme for drying garments with lower temperature-by selecting to achieve automatic cupboard dry result-by selecting to achieve automatic iron dry result-by selecting to		
	-	
achieve automativ light drying.	·	
- by selecting 🗵 to achieve automatic cupboard dry result,	☆ Dry ✓ (田✓, △ ✓, ▲ ✓)	
- by selecting at to achieve automatic iron dry result.	not possible	
- by selecting 🗥 to achieve a light dry result.		
☼ Intensive Dry	5,0 kg	
Single normal dry program for drying garments with higher temperature	-	
perature., - by selecting ⊞ to achieve automatic cupboard dry result,	-	
- by selecting to achieve automatic cupocard by result.	-	
- by selecting to achieve a light dry result.	☆ Dry ✓ (⊞✓, ڪ ✓, శ ✓) ©	
- © self-defined drying time selectable from 30/60/90/120	not possible	
min		
⋄ Drum Clean	0,0 kg/-	
Special programme for drum hygiene or fluff removal.	90 °C	
Do not load any laundry. 90 °C = antibacterial programme.	-	
The Drum Clean programme indicator flashes after 25 Wash /		
Dry Programs.	-	
If Dryer function is used or low Temperature wash programme is used regulary it is strongly recommended to use the Drum		
Clean programme.	not possible	
Notes		
If no Drum Clean programme and instead a Wash /Dry		
progamme is selected Timer will be reset.		
 Special drum cleaning detergent can be used. Always follow the manufacturer's instructions when dosing 		
the detergent.		
* Depending on the model and the programme.		
** Reduced load with $= \mathbb{O}$ speedPerfect additional programn	ne setting.	

en Overview of programmes

Programme/Type of laundry	Options/Information
☆ Memory	-
With memory you can save a selected programme with your	-
favourite settings.	-
To store:	-
 Switch on the appliance. Select a programme. 	-
 If required, change the programme default settings and/or select programme additional settings. Touch and hold ☆ (Memory) button for approx. three seconds. The programme is saved with a signal. 	-
Calling up: Select Memory Program Reset: touch and hold (Memory) button again for approx. three seconds after selecting the new programme and settings.	

- * Depending on the model and the programme.
- ** Reduced load with = speedPerfect additional programme setting.

Drying table

	Estimated drying time (min)			
Recommended drying programme	Drying load (kg)	₼ (light dry)	☐ (iron dry)	⊞ (cupboard dry)
Cottons & Mix 4	1,0-2,0	40-60	50-80	65-100
	2,0-4,0	60-90	80-140	100-160
	4,0-5,0	90-140	140-200	160-270
Easy Care 📤	0,5-1,5	35-45	50-70	65-100
	1,5-2,5	45-55	70-100	100-125

- i Drying time table is only for reference. For wash + dry program, washing duration shall be added for total program time.
- i The time listed above is the reference value, the actual drying effect may be affected by the clothing type, clothing weight, dehydration degree and ambient temperature.
- i In order to achieve uniform drying effect, it is recommended to distinguish between heavy and lightweight clothing. For example, separate the thick towel and the shirt to bake.
- Cupboard dry is recommended for drying bulky or heavy clothing.
- i In order to reduce the folding of clothing after drying, it is recommended to put a small amount of clothing drying.
- i Please refer to the panel display for the drying time of the programme not mentioned in the table above.
- i Drying Time in Display is an estimated Time on a maximum recommended Drying Load. Drying time will be adjusted before end of drying time is reached.

P+ Programme default settings

You can change the default settings for selected programmes. The settings can be changed even while the selected programme is running. The effects depending on the progress of the programme.

Before and after the programme starts, you can change the temperature setting, depending on what stage the programme is in, by adjusting the desired temperature on the display.

The maximum temperature that can be set depends on the programme that has been selected.

Spin Speed

Depending on what stage the programme is in, you can change the spin speed (in rpm; revolutions per minute) before and during the programme by adjusting the desired speed on the display.

setting \mathscr{O} : \mathscr{O} ="No spin". The rinsing water is drained but there is no final spin. The laundry stays wet inside the drum, e.g. for items that should not be spun.

You can select "No spin" to prevent creasing if the laundry will not be taken out of the appliance immediately after the programme has ended.

The maximum speed that can be set depending on the model and the programme that has been selected.

(1) Finished in

Before starting the programme, you can preselect the programme end ("Finish in" time) in 1.0h (h = hour) increments.

To do this:

- Select a programme.
 The programme duration is displayed for the selected programme, e.g. 2:30 (hours:minutes).
- Select the
 Finished in button repeatedly until the required number of hours is displayed.
- Select the DM Start/Reload button.
 The programme starts.
 The selected number of hours (e.g. 8h) is shown in the display panel and counts down until the programme starts. The duration of the remaining program time is then displayed.

Note: The length of the programme is automatically adjusted when the programme is running. Changes to the programme default settings or additional programme settings may also change the programme duration.

After starting the programme (if a "Finish in" time has been selected and the programme has not yet started), you can change the preselected number of hours as follows:

- 1. Select the DI Start/Reload button.
- 3. Select the DM Start/Reload button.

Additional programme settings

Note: You can find possible additional programme settings in the overview; these differ depending on the model.

By selecting additional programme settings, you can better adapt the washing/drying process to your items of laundry.

The settings can be selected or deselected depending on the progress of the programme.

The button indicator lamps light up if a setting is activated.

The settings are not retained after the appliance is switched off.

∯ Dry

Touch **Dry** to activate or deactivate the drying function. Washing and drying without interruption is possible when the function is activated (only for **Optional drying** programmes). There are three drying target mode can be selected as desired:

① (Cupboard dry): For single-layer fabrics. Garments can be folded or hung up in a cupboard. It is the standard drying target mode. In this mode the drying time is automatically set according to the amount of laundry to be dried.

Light Dry: For dry slightly and for residual drying on a hanger.

(Iron dry): For delicate laundry. Fabrics suitable for ironing (iron fabrics in order to avoid creasing). Garments can be additionally hung up to dry.

☼ Time Dry: Time can be used according to practical needs. Drying timed is recommended to dry few clothes. The optional time is 30/60/90/120 minutes. The default spinning time is 10 minutes. Recommended capacity is 0.5kg/1.0kg/1.5kg/2kg.

The drying process would proceed followed washing process when the process when the property activated. If you only need the individual drying programme, you can select the Intensive Dry or Gentle Dry ...

Notes

- Do not exceed the maximum loads for drying.
 Overview of programmes
 → "Selectable programme" on page 30
- Maximum spin speed for programme with drying phase will be selected automatically to obtain a good drying result.

Prewash

Note: Put the detergent into dispenser **I** and **II**.

Extra Rinse

Additional rinse cycle depending on the programme; longer programme length for particularly sensitive skin and/or for areas with very soft water.

=⊕ speedPerfect

Washing in a shorter time while achieving a washing result that is consistent with the normal performance.

Touch = speedPerfect to activate or deactivate this additional programme setting.

Note: With the = speedPerfect additional programme setting activated, the maximum load of washing will be reduced, and extra water will be needed for the washing process.

Operating the appliance

Preparing the appliance

The appliance was tested before delivery. To remove residual water from the test procedure, the first wash cycle should be run without laundry using the **Drum Clean** \$ programme.

→ "Before washing for the first time" on page 21

Notes


- Never switch on a damaged appliance!
- Inform customer service!
- 1. Insert mains plug.

Marning

Risk of death from electric shock!

Risk of death if live parts are touched.

- Never pull out the mains plug by tugging the power cord.
- Insert/pull out the mains plug with dry hands only.
- 2. Turn the water tap on.



3. Open the appliance door.



Select programme/switch on the appliance

Swich on the appliance by touching power **On/Off** button.

Note: If you have activated the childproof lock, you must first deactivate it before you can set a programme.

Use the programme selector to select the required programme. The programme selector can be rotated in either direction.

The appliance is switched on.


The **programme default settings** for the selected programme alternately appear in the display panel:

- The maximum load and
- the duration of the programme and
- **..**

Placing laundry into the drum

Open the door, place laundry in the drum, make sure that no items of laundry are trapped between the door and the rubber seal, and close the door.





Notes

- Unfold and load presorted items of laundry. Mix large and small items. Washing items of different size distribute themselves better during the spin cycle. Individual items of washing may cause an unbalanced load.
- Observe the maximum specified load. Overfilling adversely affects the washing/drying result and promotes creasing.

Dosing and adding detergent and care products

Caution!

Damage to the appliance

Detergents and agents for the pretreatment of laundry (e.g. stain remover, prewash sprays, etc.) may damage the surfaces of the appliance. Keep these agents away from the surfaces of the appliance. Using a damp cloth, immediately remove any fine spray residue and other residue/droplets.

Dosing

Dose the detergents and care products according to:

- water hardness (ask your water supply company),
- the manufacturer's specifications on the packaging,
- the amount of laundry,
- soilina.

Filling the dispensers

1. Pull out the detergent drawer.


Warning

Eye / skin irritation!

If the detergent drawer is opened while the appliance is running, detergent/care product may run out. Carefully open the drawer. If detergent/care product comes into contact with eyes or skin, rinse thoroughly. If accidentally swallowed, seek

medical advice.

Pour in detergent and/or cleaning product.



Dispenser I

Detergent for pretreat and clothing disinfectant. (only for the appliance with pretreat and disinfectant function)

Dispenser ₩

Softener, starch. Do not exceed the maximum load.

Dispenser **II**

Detergent for main wash, water softener, bleach, stain remover.

Dispenser A*

For dosing liquid detergent.


Notes

- Always follow the manufacturer's instructions when dosing all detergents, cleaning aids, care products and cleaning agents.
- Dilute viscous fabric softener and fabric conditioner with water. This will prevent blockages.
- Be careful when opening the detergent drawer while the appliance is running.


Measuring aid A* for liquid detergent

*depending on the model Position the measuring aid A for measuring the correct amount of liquid detergent:

a) Pull out the detergent drawer.
 Press down the insert and fully remove the drawer.



b) Flip the measuring aid forwards and click it into place.



c) Reinsert the drawer.

Note: Do not use the measuring aid for gel detergents and washing powder, or for programmes with pretreat or when "Finish in" time is selected.

For models without a measuring aid, pour the liquid detergent into the appropriate dispenser and place it in the drum.

Starting the programme

Touch and hold **○** Start/Reload button for 1~2 seconds, then release the button. The programme starts and the appliance door is locked.

The finish-in time is shown in the display panel and counts down until the programme starts. After the programme has started, the programme duration is displayed. And the symbols for the programme progress are lighting up.

Childproof lock

You can lock the appliance to prevent the settings you have set from being changed inadvertently. To do this, activate the childproof lock.

To activate the childproof lock:

After the programme starts, Touch and hold the **Spin/Speed** and **Finish in** buttons for 3 seconds. The symbol \hookrightarrow lights up in the display panel.

■ Ights up: The childproof lock is activated and CL is flashing.

Note: When the programme ends, **End** is displayed. The door is unlocked.

symbol remain on to remind you to deactivate the childproof lock.

To deactivate the childproof lock:

Adding/removing laundry

After starting the programme (only for washing), you can add or remove laundry if necessary.

Touch the D**M** Start/Reload button for 3 sec. The appliance checks whether reloading is possible.

If the following appears on the display panel:

- The symbol disappears, reloading is possible.
- The symbol lights up, reloading is not possible.

To continue the programme, touch the Start/Reload button. The programme continues automatically.

Notes

- Do not leave the door open for too long when adding laundry as water from the laundry may leak out.
- For safety reasons, the door remains locked when the water level or temperature is high, or while the drum is turning, and it is not possible to add laundry during this time.

Changing the programme

If you have started the wrong programme by mistake, you can change the programme as follows:

- 1. Swich off the appliance by touching power On/Off button.
- 2. Swich on the appliance by touching power On/Off button
- 3. Select another programme.
- 4. Touch the Start/Reload button.

Cancel the programme

For programmes washing at high temperatures:

- 1. Swich off the appliance by touching power **On/Off** button.
- 2. Swich on the appliance by touching power On/Off button
- 3. To cool down laundry: select Rinse www
- 4. Touch the DM Start/Reload button.

For programmes washing at low temperatures:

- 1. Swich off the appliance by touching power **On/Off** button.
- 2. Swich on the appliance by touching power On/Off button
- Select ⑤ ♥ Spin/Drain.
 Touch the ▷ ♥ Start/Reload button.

For programmes in drying process:

- 1. Do not interrupt Dry program.
- 2. If absolutely necessary: touch On/Off button wait until laundry cool down. Open Door carefully. Hot air will escape.

Programme end

End lights up on the display and — and C displays are off.


If you have selected \mathcal{O} , the water is only drained after rinse process, no spin cycle.

Removing laundry/switching off the appliance

- 1. Open the door and remove the laundry.
- 2. Turn off the water tap. Note: Not required for Aqua-Stop models.

Notes

- Do not leave any items of laundry in the drum. They may shrink in the next wash or discolour another item.
- Remove any foreign objects from the drum and the rubber seal - risk of rustina.
- Wipe the rubber seal dry.



- Leave the door and detergent drawer open so that any residual water can evaporate.
- Always wait until the programme ends, as the appliance could still be locked. Then switch the appliance on and wait for it to unlock.



Appliance settings

You can change the following settings.

Mute the buzzer:

- Press and hold the Options button for 3 sec.
- Program end buzzer will be mute
- To activate the buzzer function press Option button for 3 sec.



Sensors

Unbalanced load detection system

The automatic unbalanced load detection system detects imbalances and ensures even distribution of the laundry by repeatedly starting and stopping drum spinning.

If the laundry is extremely unevenly distributed, the spin speed is reduced or the spin cycle is not performed for safety reasons.

Note: Place large and small items of laundry evenly in the drum.





There is a risk of electric shock if touch live components.

Turn the programme selector to **Off**. Pull out the mains plug.

Caution!

Fire and explosion hazard!

Toxic vapours can be produced by cleaning agents that contain solvents, e.g. cleaning solvent.

Do not use cleaning agents that contain solvents.

Caution!

The appliance may be damaged!

Cleaning agents that contain solvents. e.g. cleaning solvent, can damage surfaces and components in the appliance.

Do not use cleaning agents that contain solvents

Appliance housing/control panel

- Remove the detergent residue immediately.
- Wipe the housing and the control panel with a soft, damp cloth.
- Do not use abrasive cloths, sponges or detergents (stainless steel cleaner).
- Do not clean the appliance with a water iet.

Drum

M Warning

Risk of injury/material damage/ damage to the appliance!

Permanently washing at low temperatures and a lack of ventilation for the appliance may damage the drum and cause injury.

Regularly run a programme for cleaning the drum or wash at temperatures of at least 60°C.

Leave the appliance to dry after every operation with the door open, and leave the detergent drawer to dry.

Use chlorine-free cleaning agents, do not use steel wool.

If there are odours in the appliance, or to clean the drum, run the Drum Clean rogramme without laundry.


Descaling

Descaling should not be necessary if the detergent is measured out correctly. However, if it is required, follow the manufacturer's instructions for the descaling agent. Suitable descalers can be obtained via our website or from customer services.


Emptying the detergent draw. cleaning the detergent drawer and its housing

If the appliance contains detergent or fabric softener residues:


1. Pull out the detergent drawer. Press down the insert and fully remove the




2. To remove the insert: Push the insert upwards from below with your finger.




3. Clean the detergent dispenser tray and insert with water and a brush. and dry it. Clean the inside of the housing as well.



 Fit the insert and lock it in place (push the cylinder onto the guide pin).



5. Push in the detergent drawer.



Note: Leave the detergent drawer open so that any residual water can evaporate.


Drain pump is blocked

Note: Turn the water tap off to prevent more water from flowing in and to ensure that it is drained via the pump.

When you wash at high temperatures, the water gets very hot. If you come into contact with the hot water, you may be scalded.

Allow the water to cool down first.

 Press the power button to switch the Appliance Off.
 Pull out the mains plug. 2. Open the service flap.




3. Take the drain hose out of the retainer.

Remove the sealing cap and pour the water out into a suitable container.


Replace the sealing cap and place the drain hose back in the retainer.




4. Carefully unscrew the pump cover; residual water may leak out. Clean the interior, pump cover thread and pump housing. The impeller in the drain pump must be able to rotate.



5. Refit and screw on the pump cover.




6. Close the service flap.



Note: To prevent unused detergent from flowing straight into the drain during the next wash: Pour 1 litre of water into dispenser II and start the Prain programme.

The drain hose at the siphon is blocked

- 1. Turn the programme selector to **Off**. Pull out the mains plug.
- Loosen the hose clamp. Carefully remove the drain hose; residual water may leak out.
- 3. Clean the drain hose and siphon connecting piece.



4. Re-attach the drain hose and secure the connection point using the hose clamp.


Filter in the water supply is blocked

Release water pressure in the supply hose:


- **1.** Turn off the water tap.
- Select the Cottons (activate = speedPerfect setting) programme.
- Select the D Start/Reload button. Allow the programme to run for approx. 40 seconds.
- **4.** Press the power button to switch the appliance **Off**.
- 5. Pull out the mains plug.

Clean the filters:

1. Disconnect the hose from the rear of the appliance.




2. Use pliers to remove the filter.



3. Clean the filter with a small brush.



4. Connect the hose and check for leaks.



Paults and what to do about them

Emergency release

E.g. power outage or in the event of a loss of power

The programme continues when the power supply is restored.

However, if the laundry has to be removed, the appliance door can be opened as follows:



Warning

Risk of scalding!

When you are washing at high temperatures, there is a risk of scalding if you come into contact with hot water and laundry.

If possible, leave it to cool down first.



Risk of injury!

Reaching into the drum while it is still turning may cause hand injuries.

Do not reach into the drum when it is turnina.

Wait until the drum has stopped turning.


Caution!

Water damage!


Any escaping water may cause water damage.

Do not open the door if water can be seen through the glass.

- 1. Turn the programme selector to **Off**. Pull out the mains plug.
- 2. Open the service flap.



- Drain the water. → Page 44
 Pull the emergency release downwards with a tool and release. The door can then be opened.



Information on the display panel

en

Display	Cause/Remedy					
E:30	Door is not closed properly. Close the door and restart.					
E:10 ²	■ Lights up (no water supply): Water tap turned on? Filter in the water supply is blocked? → "Filter in the water supply is blocked" on page 45 Is the supply hose kinked or trapped?					
⊂ lights up	The childproof lock is activated – deactivate it.					
The symbol 😚 flashes	 Run the Drum Clean programme to clean and care for the drum and the outer tub. Notes Run the programme without laundry. Use washing powder or a detergent containing bleach. To prevent foaming, only use half the amount of detergent recommended by the detergent manufacturer. Do not use detergent designed for woollens or delicates. 					
E:21	 Drain pipe or water drain hose is blocked. Clean the drain pipe and the water outlet hose. Drain pipe or water drain hose is caught or jammed. Ensure that the drain pipe and water drain hose are not kinked or trapped. The drain pump is blocked. "Drain pump is blocked" on page 44 The drain hose at the siphon is blocked. "The drain hose at the siphon is blocked" on page 45 The water drain hose is connected too high. Install the water outlet hose at a maximum height of 1 meter. Page 17 					
E:12	There is water in the base trough, the appliance is leaking. Turn off the tap. Call customer services.					
E:11	Check drain hose installation. Switch off the appliance, check and reset the routing of drain hose, restart the program.					

Faults and what to do about them

Faults	Cause/Remedy
Water is leaking from the appliance.	Attach the drain hose correctly or replace it.Tighten the screw fitting on the supply hose.
The door cannot be opened.	 (Rinse hold = no final drain) is activated (depending on the module). Continue the programme by selecting

Faults	Cause/Remedy
The appliance is not filling with water. Detergent is not being dispensed.	Programme does not start?Is the tap turned on?
The programme will not start.	 Have you touched the DM Start/Reload button or selected D Finished in? Is the door closed? Childproof lock activated? Deactivate childproof lock.
The programme has started and the drum is rotating, but the drum is not filling with water.	Not a fault – Some programme specifically detect and weigh the load after the programme has started in order to calculate the optimum amount of water for washing. The drum will then start filling with water.
The water is not draining.	 Drain pipe or water drain hose is blocked. Clean the drain pipe and the water drain hose. Drain pipe or water drain hose is caught or jammed. Ensure that the drain pipe and the water drain hose are not kinked or trapped. Could the drain pump be blocked? "Drain pump is blocked" on page 44 Could the drain hose at the siphon be blocked? "The drain hose at the siphon is blocked" on page 45 Continue the programme by selecting
Water is not visible in the drum.	Not a fault – the water is below the visible area.
The wrong detergent/fabric softener has been poured into the dispenser(s).	Empty the dispenser(s), clean it/them and pour in the correct product. \longrightarrow "Emptying the detergent draw, cleaning the detergent drawer and its housing" on page 43
Detergent/fabric softener has congealed in the dispensers.	Empty the dispenser(s), clean it/them and pour in the correct product.
Foam is leaking from the detergent drawer.	Too much detergent used? Mix 1 tablespoon of fabric softener with ½ litre of water and pour into dispenser II. (Not for outdoor, sports and down-filled textiles!) Reduce detergent dosage for the next wash cycle. Use commercially available low foam detergent and care product which are suitable for machine.

en Faults and what to do about them

Faults	Cause/Remedy			
Repeated, intensive foaming.	·			
Detergent/fabric softener drips off the seal and collects on the door or in the seal fold.	There is too much detergent/fabric softener in the dispensers. Do not fill the dispensers above the max. mark.			
The spin result is not satisfactory. Laundry wet/too damp.	 Not a fault – the unbalanced load detection system has interrupted the spin cycle because the laundry is unevenly distributed. Distribute small and large items of laundry evenly in the drum. Is Easy iron additional programme setting selected (depending on the model)? Is Night Wash additional programme setting or Night Wash programme selected (depending on the model)? Is the selected speed too low? 			
The spin cycle runs several times.	Not a fault – the unbalanced load detection system is adjusting an imbalance.			
The programme is taking longer than usual.	 Not a fault – the unbalanced load detection system is adjusting an imbalance by repeatedly distributing the laundry. Not a fault – the foam detection system is activated – a rinse cycle has been switched on. 			
The length of the programme changes during the wash/dry cycle.	Not a fault – the programme sequence is optimised for the specific washing/drying process. This may change the length of the programme shown on the display panel.			
Odours, stain formation in the appliance.	Run the Drum Clean programme without laundry. Add washing powder or a detergent containing bleach. Note: To prevent foaming, only use half the amount of detergent recommended by the detergent manufacturer. Do not use detergents designed for woollens or delicates.			
Loud noises, vibrations and appliance "movement" during the spin cycle.	 Is the appliance aligned? → "Alignment" on page 20 Are the appliance's feet fixed? Secure the appliance's feet. Have the transport locks been removed? → "Removing the transport locks" on page 16 			
The display panel indicator lights do not work while the appliance is running.	 Has there been a power failure? Have the fuses blown? Reset/replace the fuses. If the fault occurs repeatedly, call customer services. 			
There is detergent residue on the laundry.	 Some phosphate-free detergents contain water-insoluble residue. Select Rinse or brush the laundry after washing. 			
Spin during the drying phase.	This is an innovative process known as thermal spinning used to reduce energy consumption during the drying phase. It is designed like this, please wait until program finished.			
Fluff found on the laundry.	Run the Drum Clean programme without laundry and detergent to remove fluff which have accumulated inside the drum during the previous drying cycle.			

Faults	Cause/Remedy		
Water inlet noise during the drying phase.	he washer dryer uses water condensation technology, water is constantly eeded to dry the laundry. Therefore the water tap must be on all the time, till ne end of the drying phase.		
Drying duration extended.	 Run the Drum Clean programme to remove fluff which has collected in the washer drum during the drying phase. If the ambient temperature is higher than 30 °C, this may extend the drying time. Insufficient air circulation in the room may increase the drying time. Ventilate the room. 		
Drying programme does not start.	Drying additional programme setting not selected?Door not closed properly?		
Creasing.	 Creasing occurs when you have exceeded the maximum load or selected the wrong program for the type of fabric. All the required information can be found in the programme overview table. Remove clothes immediately after drying; creasing may occur if they are left in the drum. 		
The drying result is not satisfactory (laundry is not dry enough).	 After the end of the programme, warm laundry feels damper than it actually is. Spread the laundry out and allow the heat to disperse. Excessively high ambient temperature (above 30 °C) or inadequate ventilation in the room in which the washer dryer is situated. The laundry has not been spun well enough before drying. Always set the highest selectable spin speed for the particular washing programme. Washer dryer overloaded: Observe the recommendations for the maximum load in the programme table and on the load display. Do not overload the washer dryer, as the maximum load for the drying phase is less than the maximum load for the wash cycle. Unload the washer dryer after washing with the maximum load and divide the laundry into two drying cycles. The power supply voltage is too low (below 200 V) – provide a suitable power supply. The water pressure is low. According to water condensing principle, low water pressure will cause evaporated steam to not condense properly and completely. The water tap is closed during drying. Due to the use of the water condensation technology for drying, please keep the connected water tap open during the drying process, otherwise proper drying cannot be guaranteed. Thick multilayered textiles or textiles with thick fillings dry easily on the surface, but not inside. This equalisation process may take longer. 		

If you cannot rectify a fault yourself (after turning the programme selector to **Off** and on again) or a repair is required:

- Turn the programme selector to **Off**. Pull out the mains plug. Turn off the tap and call customer services.



After-sales service

If you cannot rectify a fault yourself, (→ "Faults and what to do about them" on page 46), please contact our aftersales service.

We will always find an appropriate solution to avoid unnecessary visits by engineers.

Please provide the after-sales service with the product number (E-Nr.) and the production number (FD) of the appliance.

E-Nr	FD

E-Nr. Product number FD Production number

You can find this information (depending on the model):

- On the inside of the loading door
- On the back of the appliance

Trust the expertise of the manufacturer. Contact us. By doing so, you can be sure that the repairs are carried out by trained service personnel using genuine spare parts.

Consumption values

Recommended wash mode for normally soiled clothes at rated load capacity used for the evaluation of the captioned model under the Efficiency Labelling Scheme (MWELS) is **Cottons Eco 60°C** (spin speed 1400 rpm).

Energy and water consumption, programme duration and residual moisture for the main washing programmes.

Programme	Programme load	Energy*	Water con- sumption*	Programme duration*
Washing:				
Cottons 40 ° C	8,0 kg	0,768 kWh	71	1:30 h
Cottons Eco 60°C (1400 rpm)	8,0 kg	0,84 kWh	59 I	5:04 h
Mix 40°C	8,0 kg	0,754 kWh	71 I	1:22 h
Easy Care 40°C	4,0 kg	0,529 kWh	55 I	1:27 h
Delicate/Silk 30°C	2,5 kg	0,254 kWh	50 I	0:50 h
Wool 30°C	2,0 kg	0,41 kWh	60 I	1:00 h
Drying:				
Gentle Dry	3,0 kg	1,5 kWh	45 I	3:52 h
Intensive Dry	5,0 kg	4,8 kWh	57 I	4:36 h

^{*} Values determined according to the valid version of IEC60456.

EU energy label wasing performance tests according to EN50229, are conducted using specified load on Cottons $60 \, ^{\circ}\text{C}$ + eco.

^{**} Observed values may deviate from the indicated values due to influence of water pressure, hardness and inlet temperature, ambient temperature, type, amount and soiling of laundry, detergent used, fluctuations in power supply and selected additional functions.



Technical data

Dimensions:

850 mm x 595 mm x 470 mm (height x width x depth)

Weight:

65 ka

Mains connection:

Nominal voltage 220-240V, 50Hz Minimum installation protection (**⇒**)10A

Nominal power 1900 W

Water pressure:

100-1000 kPa (1-10 bar)



Aqua-Stop warranty

Only for appliances with Agua-Stop

In addition to warranty claims against the vendor based on the purchase agreement and to our appliance warranty, we will provide compensation under the following conditions:

- 1. If water damage is caused due to a fault in our Aqua-Stop system, we will compensate domestic customers for the damage caused.
- 2. The liability guarantee is valid for the service life of the appliance.
- 3. It is a prerequisite of all warranty claims that the appliance with Aqua-Stop must have been installed and connected correctly in accordance with our instructions: this also includes a correctly fitted Aqua-Stop extension (genuine accessories). Our warranty does not cover defective feed lines or fittings leading to the Agua-Stop connection at the tap.
- 4. Appliances with Aqua-Stop do not need to be supervised during operation, nor secured afterwards by turning off the tap. The tap only needs to be turned off if you are away from home for a long period, e.g. for several weeks' holiday.



BSH Hausgeräte GmbH Carl-Wery-Straße 34 81739 München GERMANY www.siemens-home.bsh-group.hk

Manufactured by BSH Hausgeräte GmbH under the trademark licence of Siemens AG

9001665582 (0108)

en