SIEMENS

WQ45G2AGDN

Tumble dryer



EN User manual and installation instructions



Further information and explanations are available online:



Table of contents

1 Safety 4 1.1 General information 4 1.2 Intended use 4	8 Dryness level. 8.1 Changing the 8.2 Adjusting the
1.3 Restriction on user group	9 Programmes 9.1 Automatic pr 9.2 Timed progra
ance 9	10 Accessories.
2 Preventing material damage 11 3 Environmental protection and saving energy	11 Laundry
4 Installation and connection124.1 Unpacking the appliance124.2 Scope of delivery124.3 Requirements for the installation location134.4 Water drain hose134.5 Aligning the appliance164.6 Connecting the appliance to the electricity supply16	settings 12.4 Loading lau 12.5 Starting the 12.6 Adding laur 12.7 Cancelling the 12.8 Unloading the 12.9 Switching of 12.10 Fluff filter 12.11 Condensa
5 Familiarising yourself with your appliance 17 5.1 Appliance 17 5.2 Wool basket 18 5.3 Control panel 18	13 Childproof lo 13.1 Activating th lock 13.2 Deactivating lock
6 Display 19 7 Buttons 22	14 Wool basket. 14.1 Inserting the 14.2 Starting a p the wool ba 14.3 Examples o

B Dryness level	25
8.1 Changing the dryness level 8.2 Adjusting the dryness level	25 25
9 Programmes	26 27
10 Accessories	29
11 Laundry 11.1 Preparing the laundry	30
12 Basic operation	30 30
settings	30 30 31 31 31 31 33
13 Childproof lock	34
13.1 Activating the childproof lock	34
13.2 Deactivating the childproof lock	34
14 Wool basket	34 34
wool basket	35

15 Basic settings	37
15.1 Overview of the basic settings	37
15.2 Changing the basic set- tings	38
16 Appliance care	38
16.1 Preparing for appliance care	38
16.2 Calling up the appliance care programme	39
16.3 Running the basic appliance care programme	
16.4 Running the intensive appli ance care programme	
17 Cleaning and servicing	41
17.1 Tips on cleaning and care . 17.2 Moisture sensor	
17.3 Condensation container filter	42
18 Troubleshooting	43
19 Transportation, storage and disposal	
19.1 Preparing the appliance for	
transportation	
20 Customer Service	49
20.1 Product number (E-Nr.) and	J
production number (FD)	
production number (FD) 21 Consumption values	49



1 Safety

Observe the following safety instructions.

1.1 General information



- Read this instruction manual carefully.
- Keep the instruction manual and the product information safe for future reference or for the next owner.
- Do not connect the appliance if it has been damaged in transit.

1.2 Intended use

Only use this appliance:

- for drying and freshening up fabrics that are washed with water and suitable for dryers.
- in private households and in enclosed spaces in a domestic environment.
- up to an altitude of max. 4000 m above sea level.

1.3 Restriction on user group

This appliance may be used by children aged 8 or over and by people who have reduced physical, sensory or mental abilities or inadequate experience and/or knowledge, provided that they are supervised or have been instructed on how to use the appliance safely and have understood the resulting dangers.

Do not let children play with the appliance.

Cleaning and user maintenance must not be performed by children unless they are being supervised.

Keep children under the age of 3 years and pets away from the appliance.

1.4 Safe installation

Incorrect installation is dangerous.

- Connect and operate the appliance only in accordance with the specifications on the rating plate.
- Connect the appliance to a power supply with alternating current only via a properly installed socket with earthing.
- ► The protective conductor system of the domestic electrical installation must be properly installed. The installation must have a sufficiently large cross section.
- ▶ When using a residual current circuit breaker, only use a type with the mark.
- ► Never equip the appliance with an external switching device, e.g. a timer or remote control.
- ► Never connect the appliance to a circuit that is regularly switched on and off by the energy supplier.
- ► When the appliance is installed, the mains plug of the power cord must be freely accessible. If free access is not possible, an all-pole isolating switch must be installed in the permanent electrical installation according to the installation regulations.
- ► When installing the appliance, check that the power cable is not trapped or damaged.

If the insulation of the power cord is damaged, this is dangerous.

- ► Never let the power cord come into contact with hot appliance parts or heat sources.
- ► Never let the power cord come into contact with sharp points or edges.
- ▶ Never kink, crush or modify the power cord.

It is dangerous to use an extended power cord and non-approved adapters.

- ▶ Do not use extension cables or multiple socket strips.
- Only use adapters and power cords approved by the manufacturer.

en Safety

▶ If the power cord is too short and a longer one is not available, please contact an electrician to have the domestic installation adapted.

⚠ WARNING – Risk of injury!

The high weight of the appliance may result in injury when lifted.

▶ Do not lift the appliance on your own.

If this appliance is not correctly installed in a washer-dryer stack, the installed appliance may fall.

- Only stack the dryer on a washing machine using the connection kit from the dryer manufacturer
 - → "Accessories", Page 29. No other installation method is permitted.
- ► Do not install the appliance in a washer-dryer stack if the dryer manufacturer does not offer a suitable connection kit.
- ▶ Do not install appliances from different manufacturers and with varying depths and widths in a washer-dryer stack.
- ▶ Do not install a washer-dryer stack on a platform; the appliances may tip over.

⚠ WARNING – Risk of suffocation!

Children may put packaging material over their heads or wrap themselves up in it and suffocate.

- ► Keep packaging material away from children.
- ▶ Do not let children play with packaging material.

△ CAUTION – Risk of injury!

The appliance may vibrate or move when in use.

- ▶ Place the appliance on a clean, even, solid surface.
- ► Align the appliance using the appliance feet and a spirit level. If hoses and power cords have been laid incorrectly, this causes a tripping hazard.
- Lay hoses and power cords in such a way that there is no risk of tripping.

If the appliance is moved by holding onto protruding components, such as the appliance door, the parts may break off.

▶ Do not move the appliance by holding onto protruding parts.

△ CAUTION – Risk of cutting!

Touching sharp edges on the appliance may lead to cuts.

- ► Do not touch the sharp edges on the appliance.
- Wear protective gloves when installing and transporting the appliance.

1.5 Safe use

⚠ WARNING – Risk of electric shock!

If the appliance or the power cord is damaged, this is dangerous.

- ► Never operate a damaged appliance.
- ► Never pull on the power cord to unplug the appliance. Always unplug the appliance at the mains.
- ▶ If the appliance or the power cord is damaged, immediately unplug the power cord or switch off the fuse in the fuse box.
- ► Call customer services. → Page 49

An ingress of moisture can cause an electric shock.

- ► Only use the appliance in enclosed spaces.
- ► Never expose the appliance to intense heat or humidity.
- ► Do not use steam- or high-pressure cleaners, hoses or sprays to clean the appliance.

△ WARNING – Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- ► Do not install the appliance behind a door as this may obstruct the appliance door or prevent it from opening.
- ▶ With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.

↑ WARNING – Risk of suffocation!

Children may breathe in or swallow small parts, causing them to suffocate.

- ► Keep small parts away from children.
- ► Do not let children play with small parts.

⚠ WARNING – Risk of explosion!

If there is coal dust or flour in the air around the appliance, this may cause an explosion.

► Keep the area around the appliance clean during operation.

⚠ WARNING – Risk of poisoning!

Condensation water from this appliance is not suitable for drinking and may be contaminated with fluff.

Do not drink or reuse the condensation water from the appliance.

Detergents and care products may result in poisoning if consumed.

- ▶ If accidentally swallowed, seek medical advice.
- ► Keep detergents and care products out of the reach of children.

⚠ WARNING – Risk of fire!

The refrigerant R290 in this appliance is environmentally friendly yet combustible and may ignite if it comes into contact with open flames or ignition sources.

► Keep naked flames and ignition sources away from the appli-



⚠ WARNING – Risk of explosion!

If there is any residual material left in the fluff filter, this may ignite during the drying process.

Clean the fluff filter regularly.

Highly flammable objects such as lighters or matches may ignite during the drying process.

► Remove all highly flammable objects from any pockets in your laundry before the drying process.

Unwashed laundry that has come into contact with solvents, oil, wax, wax remover, paint, grease or stain remover may ignite when drying is in progress.

► Do not place laundry in this appliance to be dried if the laundry has not been washed first.

- ► Rinse the laundry thoroughly with warm water and detergent before drying it in the machine.
- ▶ Do not use the appliance if industrial chemicals have been used to clean the laundry beforehand.

★ WARNING – Risk of fire!

If drying is interrupted early, the laundry is not cooled sufficiently and may ignite.

- ► Do not interrupt the drying programme early.
- ► If drying is interrupted early, remove the laundry immediately and spread it out.

△ CAUTION – Risk of injury!

The covering plate may break if you stand on or climb onto the appliance.

▶ Do not stand on or climb onto the appliance.

The appliance may tip over if you sit on or lean against the open door.

- ▶ Do not sit on or lean against the appliance door.
- ▶ Do not place any objects on the appliance door.

Reaching into the drum while it is still turning may cause hand injuries.

► Wait for the drum to come to a complete stop before reaching inside.

1.6 Safe cleaning and maintenance

Improper repairs are dangerous.

- ► Never make any technical modifications to the appliance or its features.
- ► Repairs to the appliance should only be carried out by trained specialist staff.
- ▶ Only use genuine spare parts when repairing the appliance.
- ▶ If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

en Safety

An ingress of moisture can cause an electric shock.

► Do not use steam- or high-pressure cleaners, hoses or sprays to clean the appliance.

⚠ WARNING – Risk of injury!

The use of non-original spare parts and non-original accessories is dangerous.

► Only use the manufacturer's original spare parts and original accessories.

⚠ WARNING – Risk of poisoning!

Poisonous fumes may be given off if you use cleaning agents that contain solvents.

▶ Do not use cleaning agents that contain solvents.

2 Preventing material damage

ATTENTION!

The functionality of the appliance may be impaired if you use the wrong quantity of fabric softener, detergent, care product or cleaning agent.

Follow the dosage recommendations from the manufacturer.

Exceeding the maximum load capacity impairs the function of the appliance.

- Observe the maximum load capacity for each programme and do not exceed it.
- → "Programmes", Page 26 The function of the appliance may be impaired if the appliance overheats.
- Keep the ventilation opening on the appliance clear during operation.
- Make sure that the area is adequately ventilated.

Light objects such as hair and fluff may be sucked in from the ventilation opening on the appliance during operation and impair the function of the appliance.

- ► Keep the area around the appliance clean during operation.
- Keep light objects away from the appliance.

Foam and foam rubber may deform or melt during the drying process.

► Do not dry laundry that contains foam or foam rubber.

Unsuitable cleaning products may damage the surfaces of the appliance.

- Do not use harsh or abrasive detergents.
- Do not use cleaning products with a high alcohol content.
- Do not use hard scouring pads or cleaning sponges.

- Clean the appliance with nothing but water and a soft, damp cloth.
- ► Remove all detergent residue. spray residue or other residues immediately if they come into contact with the appliance.

3 Environmental protection and saving energy

3.1 Disposing of packaging

The packaging materials are environmentally compatible and can be recycled.

 Sort the individual components by type and dispose of them separately.

3.2 Saving energy

If you follow these instructions, your appliance will use less power.

Operate the appliance in a well-ventilated room and keep the ventilation opening on the appliance clear.

✓ If air exchange is impeded, this extends the programme duration and increases energy consumption.

Spin the laundry in the washing machine before drying.

✓ Damper laundry extends the programme duration and increases energy consumption.

Observe the programme's maximum load capacity.

- → "Programmes", Page 26
- ✓ If the maximum load is exceeded, this extends the programme duration and increases energy consumption.

After drying, clean the fluff filter → Page 31.

If the fluff filter is dirty, this reduces the air flow in the appliance, extends the programme duration and increases energy consumption.

3.3 Energy saving mode

If you do not use the appliance for an extended period, it automatically switches to energy-saving mode. All displays go out and DIII Start/Reload flashes.

Energy-saving mode ends when you use the appliance again.

4 Installation and connection

4.1 Unpacking the appliance

ATTENTION!

Objects remaining in the drum that are not designed for operation with the appliance may cause material damage and damage to the appliance.

- Remove these objects, along with all supplied accessories, from the drum before starting the appliance.
- Remove any packaging and protective covers completely from the appliance.
 - → "Disposing of packaging", Page 11
- 2. Check the appliance for visible damage.
- 3. Open the door.
- Remove any accessories from the drum.
- 5. Close the door.

4.2 Scope of delivery

After unpacking all parts, check for any damage in transit and completeness of the delivery.

ATTENTION!

If the appliance is operated with incomplete or defective accessories, the appliance may not be able to operate properly, or this may result in material damage or damage to the appliance.

- Do not operate the appliance with incomplete or defective accessories
- Replace the accessories in question before operating the appliance.
 - → "Accessories", Page 29

Included with the appliance	Description
	Tumble dryer
	Accompanying documents
	Water drain hose with connection adapter, fixing material and elbow. → "Water drain hose", Page 13
	Wool basket with insert → "Wool basket", Page 34

4.3 Requirements for the installation location

ATTENTION!

If the appliance is tilted at an angle greater than 40°, residual water may leak out of the appliance and cause material damage.

- Tilt the appliance carefully.
- ► Transport the appliance in an upright position.

If residual water in the appliance freezes, this may cause damage to the appliance.


▶ Do not install or operate this appliance anywhere that is liable to experience frost or outdoors.

If the appliance is operated immediately after transportation, the refrigerant contained in the appliance may result in damage to the appliance.

► Immediately after transporting the appliance, leave it to rest for two hours before putting it into operation

Installation loca- Requirements tion

On the floor



Place the appliance on a clean, level and firm surface. Align the appliance → Page 16.

Installation loca- Requirements tion

In a washer-dryer stack




Only use the original connection set from the dryer manufacturer when setting up this appliance in a washer-dryer stack.

- Connection kit with pull-out worktop
 - → Page 29
- Connection kit → Page 29

This appliance must only be stacked on a washing machine from the same manufacturer. The depth and width of this appliance must correspond with the dimensions of the washing machine. Do not place the washer-dryer stack on a platform.

Against a wall



Do not trap the hoses and power cord between the wall and the appliance.

4.4 Water drain hose

Condensation that forms in the appliance as it dries the laundry is collected by default in the condensation

container. Use the water outlet hose to drain away excess condensation directly into the waste water system.

Notes

- Operate this appliance using the water outlet hose provided.

 → "Connecting the water drain hose", Page 14

 If you connect the water outlet hose, you do not have to regularly empty the condensation container.

 → "Emptying the condensation container", Page 33
- You can order this optional
 → "Accessories", Page 29 from
 our customer service.

Connecting the water drain hose

If you do not want to regularly empty the appliance's condensation container, connect the water outlet hose.

ATTENTION!


When operating the appliance without the water drain hose being connected properly, liquid may leak out of the connecting piece.

 Before operating the appliance, connect the water drain hose properly to the connecting piece.

Requirements

- The appliance and the accessory have been unpacked.
 - → "Unpacking the appliance", Page 12
- The appliance is installed at the installation location.
 - → "Requirements for the installation location", Page 13


1. Pull out the condensation hose from the connecting piece.




The condensation hose is connected to the connecting piece at the factory.

Note: When removing the condensation hose, liquid may leak out of the connecting piece.


2. Push the condensation hose into the holder.




3. Push the water drain hose as far as it will go into the connecting piece.




4. Empty the condensation container → Page 33.



5. Remove the stopper on the underside.



6. Insert the stopper into the recess in the top.



- Insert the condensation container → Page 34.
- 8. Connect the appliance to the water outlet.
 - → "Water outlet connection types", Page 15

Tip: To collect condensation in the condensation container again (e.g. if you change where the appliance is located), carry out these steps in reverse order.


Water outlet connection types

ATTENTION!

In the event of a blocked or covered outlet, accumulated wastewater can flow back into the appliance.

▶ Before operating the appliance, ensure that the wastewater drains away quickly and eliminate any blockages.


Drainage into a siphon.



Secure the connection point with a (12-22 mm) hose clamp. Secure the water outlet hose with a hose guide at a height of at least 80 cm and no more than 100 cm.

Note: You can use the Y-distributor → Page 29 to connect the water drain hose of an additional appliance, such as a washing machine, to the same siphon out-


Drainage into a wash basin.



Push the water drain hose fully through the elbow → Page 12 and secure it using fixing material.

Secure the elbow at a height of no more than 100 cm.

Drainage into a gully.




Push the water drain hose fully through the elbow → Page 12 and secure it usina fixina material.

Secure the elbow to the gully.

4.5 Aligning the appliance

In order to reduce vibrations and noises, align the appliance correctly.

► To align the appliance, turn the appliance feet. Check that the appliance is level using a spirit level.



All appliance feet must stand firmly on the ground.

4.6 Connecting the appliance to the electricity supply

1. Insert the mains plug of the appliance's power cable in a socket nearby.


The connection details of the appliance can be found under Technical data \rightarrow Page 51.

2. Check the mains plug is inserted properly.

5 Familiarising yourself with your appliance

5.1 Appliance


You can find an overview of the parts of your appliance here.



On certain models, specific details such as the colour and shape may differ from those pictured.

1	Ventilation opening
2	Fluff filter → Page 31
3	Door
4	Condensation container → Page 33
5	Control panel → Page 18


5.2 Wool basket



1	Securing foot
2	Wool basket
3	Insert
4	Tab for securing in the hook

5.3 Control panel


You can use the control panel to configure all functions of your appliance and to obtain information about the operating status.



- 1 Programmes → Page 26
 2 Programme selector → Page 30
- 3 Display → Page 19
- 4 Buttons → Page 22

6 Display

The display shows the current settings, options or relevant information.



Display	Description
0:40 1	Expected programme duration or programme time remaining in hours and minutes.
1:25	The timed programme is set. → "Timed programmes", Page 27
9.0 1	Recommendation for the maximum load capacity for the selected program in kg.
+ 0:45 1	Program end time → "Buttons", Page 24
~®	 Lights up: The childproof lock is activated. Flashes: The childproof lock is activated and the appliance has been operated. → "Deactivating the childproof lock", Page 34
>	Start, cancel or pause Lights up: The programme is running and can be cancelled or paused. Flashes: The programme can be started or continued.
@	The dryness level is activated. → "Buttons", Page 23
1	The dryness level is activated. → "Buttons", Page 23
¹ Example	

en Display

Display	Description
⊕ *	The dryness level is activated. → "Buttons", Page 22
+1 +2 +3	The adjusted dryness level is activated. → "Dryness level", Page 25
ZI	The crease-reduction function is activated. → "Buttons", Page 23
#	Gentle drying is activated for delicate fabrics. → "Buttons", Page 23
¹ / ₂ 4.5 kg	Half load is activated. → "Buttons", Page 24
郊	Quiet drying with no signal tones is activated. → "Buttons", Page 24
≜ ↓	Empty and insert the condensation container. → "Emptying the condensation container", Page 33
\bar{\bar{\text{\tin}\text{\tetx{\text{\tetx{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\ti}\}\tittt{\text{\text{\texi}\text{\text{\texi}\tittt{\text{\text{\text{\text{\texi}\text{\texi}\text{\text{\texi}\text{\texi}\titttt{\text{\texit{\text{\text{\texi}\text{\texi}\texit{\t	Clean the fluff filter. → "Cleaning the fluff filter", Page 31
CrE	Run the basic appliance care programme. → "Appliance care", Page 38
Hot	The cooling process cools the laundry for a few minutes while the drum is rotating, in order to avoid damage to the laundry. The cooling process can be cancelled by opening the door.
/\\	Note: Do not change the set programme.
	The automatic self-cleaning function rinses the appliance's heat exchanger.
	Note: Do not remove the condensation container and do not interrupt the programme.
<u>\$\$\$</u>	Drying Programme status
	Dryness level: Iron Dry Programme status
①	Dryness level: Cupboard Dry Programme status
Z	Crease-reduction function Programme status
>	Pause Programme status
¹ Example	

Display	Description
End	Program end Programme status
¹ Example	

7 Buttons

Below is an overview of the buttons and their setting options.

Button	Selection	Description
> Start/Reload	StartCancelPause	Start, cancel or pause the programme.
∞ 3s	ActivateDeactivate	Activate or deactivate the childproof lock. Disable the control panel to prevent unwanted or accidental operation. If the childproof lock is activated and the appliance has been switched off, the childproof lock remains activated. → "Childproof lock", Page 34
⊞* Cupboard Extra Dry	■ ⊞* Cupboard Extra Dry ■ +1 ■ +2 ■ +3	 Selecting ⊞* Cupboard Extra Dry activates the dryness level. The dryness level defines how damp or dry the laundry is after the programme ends. → "Dryness level", Page 25 The dryness level can be adjusted by selecting +1, +2 or +3. → "Adjusting the dryness level", Page 25

Button	Selection	Description
⊞ Cupboard Dry	■	■ Selecting ⊞ Cupboard Dry activates the dryness level. The dryness level defines how damp or dry the laundry is after the programme ends. → "Dryness level", Page 25 ■ The dryness level can be adjusted by selecting +1, +2 or +3. → "Adjusting the dryness level", Page 25
□ Iron Dry	■ ♠ Iron Dry ■ +1 ■ +2 ■ +3	■ Selecting ☐ Iron Dry activates the dry- ness level. The dryness level defines how damp or dry the laundry is after the programme ends. → "Dryness level", Page 25 ■ The dryness level can be adjusted by select- ing +1, +2 or +3. → "Adjusting the dry- ness level", Page 25
∠ Less Ironing	ActivateDeactivate	Activate or deactivate the crease-reduction function. Once the programme has ended, the drum moves the laundry at regular intervals for 120 minutes to prevent creasing.
	ActivateDeactivate	Activate or deactivate gentle drying. The temperature is reduced for delicate fabrics, e.g. polyacrylic or elastane. The programme duration is extended.

en Buttons

Button	Selection	Description
③ Ready In	■ Programme end time ■ Programme duration	 Set the programme end time. The programme duration is already included in the set number of hours. Once the programme has started, the programme duration is displayed. Set the programme duration for timed programmes. → "Timed programmes", Page 27
郊 Signal	ActivateDeactivate	Activate or deactivate operating signals and information signals.
[®] Half Load	ActivateDeactivate	Dry individual items of laundry or small loads of laundry.

8 Dryness level

Each automatic programme has a specified dryness level. The dryness level defines how dry or damp your laundry is after the programme ends.

Dryness level	Laundry	Drying result
	Multi-layered, thick laundry that does not dry readily.	The laundry is dry.
	Normal, single-layered laundry.	The laundry is dry.
🕮 Iron Dry	Normal, single-layered laundry.	The laundry is still slightly damp. To prevent creasing after drying, iron the laundry or hang it up.

8.1 Changing the dryness level

For some automatic programmes, you can change the dryness level so that your laundry will be drier or more damp.

- 1. Set an automatic programme. → "Automatic programmes", Page 26
- ▼ The display shows the specified dryness level.
- 2. Press III Cupboard Dry , III Cupboard Extra Dry or in Iron Dry .
- ✓ The display shows
 ☐,
 ☐

 or
 △

3. Press the set drying target again to adjust the dryness level.

✓ The display shows "+1", "+2" or "+3" .

8.2 Adjusting the dryness level

If the laundry feels too damp after it has been dried to a particular dryness level, you can adjust the dryness level.

- 1. Set an automatic programme. → "Automatic programmes", Page 26
- The display shows the specified dryness level.
- 2. Press III Cupboard Dry, III Cupboard Extra Dry or in Iron Dry .

9 Programmes

You can dry your fabrics using either an automatic programme or a timed programme.

9.1 Automatic programmes

Automatic programmes are programmes in which humidity sensors measure the residual moisture in the laundry during the drying cycle. The programme only ends once the set dryness level is reached. Each automatic programme has a dryness level → Page 25. The dryness level defines how dry or damp the laundry is after the programme ends.

Tips

- Select the dryness level according to the type of fabric or the desired drying result.
 - → "Dryness level", Page 25
- The laundry's care labels provide you with additional information about programme selection.

Programme	Description	Max. load
		(kg)
Cotton	Dry hard-wearing, heat-resistant fabrics made of cotton or linen.	9.0
Cotton Eco	Dry hard-wearing, heat-resistant fabrics made of cotton or linen. Energy-saving programme.	9.0
Easy Care	Dry items made of synthetic materials or blended fabrics.	3.5
Mix	Dry items made of cotton and synthetics.	3.0
Bed linen	Dry duvet covers, pillowcases and sheets made of cotton.	3.5
	Note: The drum movement is optimised for drying large items of laundry.	
Lingerie	Dry delicate underwear made of lace, Lycra, satin or blended fabrics.	2.0
Hygiene	Dry hard-wearing, heat-resistant fabrics made of cotton or linen.	4.0
	Note: Particularly suitable for strict hygiene requirements.	
Outdoor	Dry weatherproof and outdoor clothing with a membrane coating and water-repellent fabrics.	1.5

Programme	Description	Max. load
		(kg)
Pillows	Dry pillows stuffed with down or synthetic fibres.	One pillow
	Note: Once the programme has ended, shake the pillows to distribute the stuffing and eliminate any pockets of moisture.	
Shirts	Suitable for shirts and blouses made of cotton, linen, synthetics or blended fabrics.	1.5
	Note: For optimal drying results, dry a maximum of 5 shirts or 5 blouses at the same time.	
	Once the laundry is dry, iron it or hang it up. The residual moisture is then distributed evenly.	
Super 40'	Dry items made of synthetics and light cotton.	2.0
Towels	Dry hard-wearing, heat-resistant towels and dressing gowns made of cotton or linen.	6.0

9.2 Timed programmes

Timed programmes are programmes with a defined or adjustable programme duration. The programme ends once this time has elapsed, even if the laundry is still not dry, for example. Timed programmes are suitable for drying individual items of laundry or thin fabrics.

Tip: The laundry's care labels provide you with additional information about programme selection.

Programme	Description	Max. load (kg)
Wool in Basket	Dry items made of wool or containing wool.	One item of laundry
	Note: Dry these items only using the wool basket. → "Wool basket", Page 34	
Time Program Warm	Dry all types of fabric except for wool and silk. Suitable for pre-dried or slightly damp laundry and for drying off multi-layered, thick laundry.	3.0

en Programmes

Programme	Description	Max. load (kg)
i	Note: This programme is suitable for drying using the wool basket. → "Wool basket", Page 34	

10 Accessories

Use original accessories. These have been made especially for your appliance.

Note: Some accessories are available in other colours. Contact → "Customer Service", Page 49.

	Use	Order number
Connection kit	To save space, stack the appliance on a suitable washing machine of the same width and depth and that is from the same manufacturer.	WZ27410
Connection kit with pull- out worktop	To save space, stack the appliance on a suitable washing machine of the same width and depth and that is from the same manufacturer. The pull-out worktop makes it easier to load and unload the appliance.	WZ27400
Wool basket	Dry or air individual woollen items, sports shoes and soft toys.	WZ20600
Y-distributor	Connect the water drain hose of an additional appliance to the same siphon outlet.	15000490
Appliance care product	Spare part for the intensive appliance care function.	00311829
Platform	Install the appliance at a raised height so that it can be easily loaded and unloaded.	WZDP20D

11 Laundry

11.1 Preparing the laundry

ATTENTION!

Objects remaining in the laundry may damage the laundry and the drum.

 Remove all items from any pockets in your laundry before using the appliance.

Note

The appliance and fabrics are protected when you prepare your laundry.

- Brush off sand and soil
- Sort the laundry according to colour and textiles and observe the care labels
- Close all zips, Velcro fasteners, hooks and eyes
- Remove curtain fittings and lead strips
- Load the laundry unfolded into the drum
- Spin the laundry before drying
- Dry woollen items, sports shoes and soft toys in the wool basket → "Wool basket", Page 34

12 Basic operation

12.1 Switching on the appliance

Requirement: The appliance has been correctly installed and connected.

- → "Installation and connection", Page 12
- Turn the programme selector to a programme.

Note: The lighting for the drum goes out automatically.

12.2 Setting a programme

- **1.** Turn the programme selector and set the required programme.
 - → "Programmes", Page 26
- 2. If required, adjust the programme settings.
 - → "Adjusting the programme settings", Page 30

12.3 Adjusting the programme settings

Depending on the programme and programme progress, you can adjust or activate/deactivate the settings.

Requirement: A programme is set. → "Setting a programme", Page 30

► Adjust the programme settings.
→ "Buttons", Page 22

Note: The programme settings are not saved permanently for the programme.

12.4 Loading laundry

Note: To prevent creasing, note the maximum load for the programmes. → "Programmes", Page 26

Requirements

- The laundry is prepared and sorted.
 - → "Laundry", Page 30
- The drum is empty.
- **1.** Open the door.
- **2.** Place the laundry in the drum.
- Close the door.Ensure that there is no laundry trapped in the door.

12.5 Starting the programme

Requirement: A programme is set. → "Setting a programme", Page 30

▶ Press ▷II Start/Reload .

- ✓ The display shows the programme duration or the programme end time.
- ✔ After the programme has ended, the display shows: "End".

Note: If "Hot" appears, the appliance cools the laundry. When "Hot" goes out, the laundry has cooled down.

12.6 Adding laundry

After the programme starts, you can remove or add laundry at any time.

1. Press ▷III Start/Reload

The cooling process starts automatically after approximately 30 seconds and cools down the laundry while the drum is rotating. If vou want to avoid or cancel the cooling process, open the door. → "Display", Page 20

- 2. Open the door.
- 3. Add or remove laundry.
- 4. Close the door.
- 5. Press MStart/Reload

12.7 Cancelling the programme

- 1. Press ▷II Start/Reload .
- 2. Open the door.
- 3. Remove the laundry. → "Unloading the laundry". Page 31

12.8 Unloading the laundry

- 1. Open the door.
- 2. Remove the laundry from the drum.

12.9 Switching off the appliance

► Turn the programme selector to ○

12.10 Fluff filter

During drying, fluff from the laundry is collected in the fluff filter. The fluff filter protects the appliance from fluff.


Cleaning the fluff filter

If the drying programme has finished or the display shows a notification while the appliance is in operation, clean the fluff filter.


Note: If you do not clean the appliance as described, the appliance's functionality may be impaired.

Requirements

- The display shows the following after drying: "End"
- or the display shows the following during operation: .
- 1. Open the door.
- **2.** Remove the fluff from the door




3. Remove the two-part fluff filter.




en Basic operation

4. Remove the fluff from the recess.




Ensure that no fluff falls into the air channel.


5. Disconnect the two-part fluff filter.




6. Open the two fluff filters.




7. Remove the fluff.




8. Clean the two fluff filters thoroughly under warm, running water and then dry them off.



9. Close the two fluff filters and put them together.



10. Insert the two-part fluff filter.



11. Close the door.

12.11 Condensation container

Condensation that forms in the appliance as it dries the laundry is collected by default in the condensation container.

Note: Operate this appliance using the water outlet hose provided.

→ "Connecting the water drain hose". Page 14

If you connect the water outlet hose, vou do not have to regularly empty the condensation container.

→ "Emptying the condensation container", Page 33


Emptying the condensation container

If the drying programme has finished or the display shows a notification while the appliance is in operation. empty the condensation container.


Requirements

- The display shows the following after drying: "End"
- or the display shows the following during operation: 🖺.

1. Pull out the condensation container, keeping it level.



2. Empty the condensation container.




Check the condensation container filter → Page 42 regularly and clean the filter if it is dirty.

Make sure that you insert the condensation container before operating the appliance.

→ "Inserting the condensation container", Page 34

Inserting the condensation container

 Push the condensation container in as far as it will go.



13 Childproof lock

Secure your appliance against being operated unintentionally using the controls.

13.1 Activating the childproof lock

- ▶ Press and hold the two 🖘 3s buttons for approx. 3 seconds.
- The control elements are locked.
- ▼ The childproof lock remains active even after the appliance has been switched off and in the event of a power cut.

13.2 Deactivating the childproof lock

Requirement: To deactivate the childproof lock, the appliance must be switched on.

- ▶ Press and hold the two so 3s buttons for approx. 3 seconds.
- ✓ so goes out in the display.


14 Wool basket

Use the wool basket to gently dry delicate fabrics, soft toys or sports shoes in a stationary position.


Note: You can order this optional → "Accessories", Page 29 from our customer service.

14.1 Inserting the wool basket

- 1. Open the door. Ensure that the drum is empty.
- 2. Insert the feet of the wool basket into the holes from the door openina.



3. Insert the tab on the front of the wool basket into the upper hooks.



14.2 Starting a programme with the wool basket


ATTENTION!

If items of laundry in the wool basket touch the rotating drum or the ribs of the drum, the laundry may cause material damage and damage to the appliance.

Place the items of laundry in the insert or wool basket such that they do not touch the drum or the ribs of the drum.

Requirement: The wool basket is inserted into the appliance.

- → "Inserting the wool basket", Page 34
- **1.** Place the laundry into the wool basket, either directly or using the insert.
 - → "Examples of how to use the wool basket", Page 35



- 2. Close the door.
- 3. Set a programme that is suitable for drying with the wool basket.
 - Observe the programme description.
 - → "Timed programmes", Page 27
- 4. If required, adjust the duration of the programme.
 - → "Buttons", Page 24

Observe the recommended programme duration for items of laundry in the wool basket:

Laundry item	Programme duration in hours:minutes
Thin woollen pullover	Approx. 1:20
Thick woollen pullover	Approx. 1:30 - 3:00
Skirt	Approx. 1:00 - 1:30
Trousers	Approx. 1:00 - 1:30
Gloves	Approx. 0:30
Sports shoes	Approx. 1:30/ max. 2:00 with airing

Tip: Increase the programme duration for thick or multi-layered items of laundry.

- **5.** Start the programme \rightarrow Page 30.
- 6. Remove the wool basket once the programme has ended.

14.3 Examples of how to use the wool basket

ATTENTION!

If items of laundry in the wool basket touch the rotating drum or the ribs of the drum, the laundry may cause material damage and damage to the appliance.


Place the items of laundry in the insert or wool basket such that they do not touch the drum or the ribs of the drum.

Example	Use
Trousers or skirt	Place the items
	of laundry unfolded into the in-
	sert.
	Note: Spin the
	laundry before
	drying.

Example

Use

Pullover




Sports shoes



Lift the tongues of the shoes. Remove the insoles or heel cushions. Place a rolled-up hand towel in the wool basket to create an inclined surface. Place the shoes on the towel with the heels facing down.

Note: Do not use the insert. Do not dry leather shoes or shoes with leather parts.

Soft toys




Place the soft toy in the wool basket.

Note: Do not use the insert. If you place numerous or small soft toys in the wool basket, make sure they do not fall out.

15 Basic settings

You can configure the basic settings for your appliance to meet your needs.


15.1 Overview of the basic settings



Basic setting	Programme position	Value	Description
End signal	2	0 (off) 1 (quiet) 2 (me- dium) 3 (loud) 4 (very loud)	Set the volume of the signal at the end of the programme.
Button signal	3	0 (off) 1 (quiet) 2 (me- dium) 3 (loud) 4 (very loud)	The volume of the audible signal emitted when the buttons are pressed.
Programme counter	5	42 ¹	Display the number of started programmes.
¹ Example			

15.2 Changing the basic settings

1. Set the programme selector to position 1



- 2. Press Pron Dry and, at the same time, turn the programme selector to position 2.
- ▼ The display shows the current value.
- 3. Set the programme selector to the required position.
 - → "Overview of the basic settings", Page 37
- 4. To change the value, press \odot Ready In .
- 5. To save the changes, switch off the appliance.

16 Appliance care

The appliance offers cleaning programmes for basic and intensive appliance care.

16.1 Preparing for appliance care

Preparing the appliance for the appliance care programme

Prepare the appliance before running the appliance care programme.


Requirements

- The drum is empty.
- The appliance is switched off.
- 1. Clean the fluff filter. → "Cleaning the fluff filter", Page 31
- 2. Pull out the condensation container horizontally and empty it. → "Emptying the condensation container", Page 33


Preparing the condensation container for the appliance care programme

If you are draining the condensation water from the appliance using the drain hose, prepare the condensation container before running the appliance care programme.

1. Remove the stopper from the recess in the top.



2. Insert the stopper on the underside.




3. Clean the filter in the condensation container.

16.2 Calling up the appliance care programme

Requirement: The appliance care programme is ready.

- → "Preparing for appliance care", Page 38
- 1. Set the programme to position 1.



- 2. Press and hold A Iron Dry and set the programme to position 4.
- 3. Release Pron Dry.
- ✓ "CP1" and the programme duration alternate on the display.

16.3 Running the basic appliance care programme

To remove any dirt deposits in the appliance, you can run the basic appliance care programme.

Notes

■ The basic appliance care programme runs for approximately 1 hour.

After a lengthy period of use, the appliance reminds you to run the basic appliance care programme. Before the programme starts or after the programme has ended. the display shows the notification "CrE" . This notification appears repeatedly until you have run the basic appliance care programme through to the end.

Requirements

- The appliance care programme is readv.
 - → "Preparing for appliance care", Page 38
- The appliance care programme is now called up.
 - → "Calling up the appliance care programme", Page 39
- 1. Pour approx. 1.5 litres of hot mains water into the condensation container.
 - Hold the filled condensation container level so that no liquid spills
- 2. Insert the condensation container so that it locks into place.
- 3. Press DI Start/Reload.
- ▼ The appliance care programme starts and a signal tone sounds.
- ✓ "End" appears on the display and a signal tone sounds once the appliance care programme has ended.
- 4. Pull out the condensation container horizontally and empty it. → "Emptying the condensation container", Page 33
- 5. If you are draining the condensation water using the drain hose:
 - Remove the stopper from the underside of the condensation container.
 - Insert the stopper into the recess on the top of the condensation container.

- **6.** Insert the condensation container so that it locks into place.
- Switch off the appliance.
 → "Switching off the appliance",
 Page 31

16.4 Running the intensive appliance care programme

You can run the intensive appliance care programme to remove any stubborn dirt deposits in the appliance and odours after a downtime of more than one month.

Notes

- The intensive appliance care programme runs for approximately 4 hours and must not be cancelled.
- When you run the intensive appliance care programme, you need the original appliance care product.
 - → "Accessories", Page 29

⚠ WARNING Risk of injury!

The use of non-original spare parts and non-original accessories is dangerous.

 Only use the manufacturer's original spare parts and original accessories.

Starting the intensive appliance care programme

Requirements

- The appliance care programme is ready.
 - → "Preparing for appliance care", Page 38
- The appliance care programme is now called up.
 - → "Calling up the appliance care programme", Page 39

- 1. Press +.
- ▼ "CP2" and the programme duration alternate on the display.
- 2. ATTENTION! The functionality of the appliance may be impaired if you use the wrong quantity of fabric softener, detergent, care product or cleaning agent.
- ► Follow the dosage recommendations from the manufacturer.

Pour a bottle of the appliance care product and approx. 1.5 litres of hot mains water into the condensation container.

Hold the filled condensation container level so that no liquid spills out.

- **3.** Insert the condensation container so that it locks into place.
- 4. Press ▷II Start/Reload.
- The appliance care programme starts and a signal tone sounds.
- After around 3 hours, the appliance pauses the appliance care programme and the remaining programme duration flashes on the display.
- 5. Pull out the condensation container horizontally and empty it.
- Pour approx. 1.5 litres of hot mains water into the condensation container.
- Carefully swing the condensation container horizontally and empty it to rinse out any remaining appliance care product.

Continuing the intensive appliance care programme

 Pour approx. 1.5 litres of hot mains water into the condensation container.

Hold the filled condensation container level so that no liquid spills out.

- 2. Insert the condensation container so that it locks into place.
- 3. Press **▷III Start/Reload**.
- ▼ The appliance care programme continues.
- ✓ "End" appears on the display and a signal tone sounds once the appliance care programme has ended.
- 4. Pull out the condensation container horizontally and empty it.
- 5. If you are draining the condensation water using the drain hose:
 - Remove the stopper from the underside of the condensation container.
 - Insert the stopper into the recess on the top of the condensation container.
- 6. Insert the condensation container so that it locks into place.
- 7. Switch off the appliance. → "Switching off the appliance", Page 31

17 Cleaning and servicing

To keep your appliance working efficiently for a long time, it is important to clean and maintain it carefully.

17.1 Tips on cleaning and care

Wipe down the housing and the controls with nothing but water clean and hyand a damp cloth.

This ensures the parts of the appliance will remain gienic.

Remove all detergent residue, spray residue or other residues immediately.	Fresh deposits are easier to remove without leaving any residue.
Leave the appliance door open after use.	This allows the residual water to dry, reducing odours in the appliance.

17.2 Moisture sensor

The moisture sensor in this appliance measures how damp the laundry is during the drying cycle. The appliance changes the duration of the automatic programme depending on the residual moisture in the laundry.

Cleaning the moisture sensor

Over time, residue from limescale, detergents and care products can build up on the moisture sensor. Clean the moisture sensor regularly.

ATTENTION!

Hard or rough objects may damage the moisture sensor.

 Do not use hard or rough objects, abrasive cleaning products or steel wool for cleaning.

Note: If you do not clean the appliance as described, the appliance's functionality may be impaired.

1. Open the door.

2. Clean the moisture sensor with a sponge.




17.3 Condensation container filter

During drying, fluff from the laundry gets into the condensation. The filter in the condensation container protects the appliance from fluff.


Clean the filter for the condensation tank.

The filter is cleaned automatically when the condensation container is emptied. Check the filter regularly and clean the filter if it is dirty.


Empty the condensation container.
 → "Emptying the condensation container", Page 33



2. Remove the filter.



- **3.** Clean the filter under warm, running water or in the dishwasher.
- 4. Slide in the filter as far as it will go.



Insert the condensation container.
 → "Inserting the condensation container", Page 34

18 Troubleshooting

You can rectify minor faults on your appliance yourself. Read the troubleshooting information before contacting after-sales service. This will avoid unnecessary costs.



. WARNING

Risk of electric shock!

Incorrect repairs are dangerous.

- ► Repairs to the appliance should only be carried out by trained specialist staff.
- ► Only use genuine spare parts when repairing the appliance.
- ► If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

Fault	Cause and troubleshooting
"Hot" and the drum rotates.	Cooling process active.1. Not a fault.2. Do not change the programme during the cooling process.
	Note: The cooling process takes up to 10 minutes. You can continue to operate the appliance.
Humming noise.	Compressor active. Not a fault – normal operating noise.
The display goes out and DII Start/Reload flashes.	Energy-saving mode is active ► Press any button. ✓ The display lights up again.
"CrE"	 After a period of operation, the appliance automatically recommends that you run the basic appliance care programme. ▶ Running the basic appliance care programme on the appliance. → "Appliance care", Page 38
i <u>®</u>	Fluff filter is soiled. ► → "Cleaning the fluff filter", Page 31
The appliance is not working.	The mains plug of the power cord is not plugged in. Connect the appliance to the power supply.
	The circuit breaker in the fuse box has tripped. • Check the circuit breaker in the fuse box.
	There has been a power cut.Check whether the lighting in your room or other appliances are working.

Fault	Cause and troubleshooting			
Appliance paused, but the drum is rotating.	Cooling process active. Not a fault – no action required.			
Creasing.	The load is too large. ► Observe the maximum load capacity of the → "Programmes", Page 26.			
	 The laundry lies in the drum for too long after drying. Remove the laundry from the drum as soon as the drying programme has finished. Spread the items of laundry for cooling. 			
	Unsuitable programme for the type of fabric. ► Set the suitable programme for the type of fabric. → "Programmes", Page 26			
	Easy-Care fabrics are dried for too long. ► → "Changing the dryness level", Page 25. ► → "Adjusting the dryness level", Page 25.			
	Anti-Crease not activated. ► Activate the Anti-Crease function. → "Buttons", Page 23			
🖺 and programme terminated.	Condensation tank filled. 1. → "Emptying the condensation container", Page 33. 2. → "Inserting the condensation container", Page 34. 3. → "Starting the programme", Page 30.			
	 Water drain hose is caught or jammed. 1. Ensure that the water drain hose is not kinked or trapped. 2. Route the water drain hose without kinks. 			
	Water drain hose is not connected correctly. ► Ensure that the water drain hose is connected correctly. → "Connecting the water drain hose", Page 14			
	Water drain hose is blocked. ➤ Rinse the water drain hose with tap water.			
	The filter for the condensation tank is soiled. ► → "Clean the filter for the condensation tank.", Page 42.			
Condensation in the condensation tank even though the water	The remaining volume of condensation may remain in the condensation container. Not a fault – no action required.			
drain hose is connected.	Water drain hose is not connected correctly.			

Fault	Cause and troubleshooting		
Condensation in the condensation tank even though the water drain hose is connected.	 Ensure that the water drain hose is connected correctly. → "Connecting the water drain hose", Page 14 		
The programme does not start.	Childproof lock is activated. ▶ → "Deactivating the childproof lock", Page 34		
	▷II Start/Reload has not been pressed.▶ Press ▷II Start/Reload .		
	No programme set. 1. → "Setting a programme", Page 30. 2. → "Starting the programme", Page 30.		
The length of the programme changes during the drying cycle.	The programme operation is optimised electronically. This may change the programme duration. ► Not a fault – no action required.		
Pumping noise.	Condensation pump active. Not a fault – normal operating noise.		
Buzzing noise.	Compressor ventilation active. ► Not a fault – normal operating noise.		
The drying time is too long.	Fluff filter is soiled. ► → "Cleaning the fluff filter", Page 31		
	The ambient temperature is greater than 30 °C. ► Ensure that the ambient temperature is below 30 °C.		
	The ambient temperature is lower than 15 °C. ► Ensure that the ambient temperature is above 15 °C.		
	Insufficient air circulation at the appliance's installation location. • Ventilate the appliance's installation location.		
	The appliance's ventilation opening is blocked. ► Ensure that the ventilation opening of the appliance is kept clear.		
	 Heat exchanger is soiled. Running the basic appliance care programme on the appliance. → "Appliance care", Page 38 		

Fault	Cause and troubleshooting			
<u>/</u> N. ■	Automatic self-cleaning function rinses the appliance's heat exchanger. 1. Not a fault. 2. Do not pull out the condensation tank. 3. Do not cancel the programme.			
Water is leaking from the appliance.	Appliance is not correctly aligned. ► → "Aligning the appliance", Page 16			
	 Water drain hose is not connected correctly. ► Ensure that the water drain hose is connected correctly. → "Connecting the water drain hose", Page 14 			
The laundry is too damp.	Unsuitable programme for the type of fabric. ► Set a timed programme for the subsequent drying. → "Programmes", Page 26			
	There has been a power cut. ➤ Check whether the lighting in your room or other appliances are working.			
	The load is too large. ► Observe the maximum load capacity of the → "Programmes", Page 26.			
	 After the end of the programme, warm laundry feels damper than it actually is. 1. Remove the laundry from the drum as soon as the drying programme has finished. 2. Spread the items of laundry for cooling. 			
	Unsuitable dryness level set. ► → "Changing the dryness level", Page 25.			
	Drying target not adjusted. ► → "Adjusting the dryness level", Page 25.			
	Load too small. ► Set a timed programme for the subsequent drying. → "Programmes", Page 26			
	Moisture sensor dirty. → "Cleaning the moisture sensor", Page 41.			
	The drying process is interrupted and the condensation tank has been filled. 1. → "Emptying the condensation container", Page 33. 2. → "Inserting the condensation container", Page 34. 3. → "Starting the programme", Page 30.			

Fault	Cause and troubleshooting
Odours have formed in the appliance.	Stubborn dirt in the appliance or an extended appliance downtime of more than one month. ► Run the intensive appliance care programme. → "Appliance care", Page 38

19 Transportation, storage and disposal

19.1 Preparing the appliance for transportation

ATTENTION!

If the appliance is operated immediately after transportation, the refrigerant contained in the appliance may result in damage to the appliance.

► Immediately after transporting the appliance, leave it to rest for two hours before putting it into operation.

Tip: The appliance may contain residual water, which may drip out of it when transported. The appliance should be transported upright.

Requirements

- The condensation container is emptied. Emptying the condensation container → Page 33
- The appliance has been switched
 - → "Switching on the appliance", Page 30
- 1. Set any programme → Page 30.
- 2. Start the programme → Page 30 and wait 5 minutes.
- The condensation is drained.
- **3.** Switch off the appliance. → "Switching off the appliance", Page 31
- 4. Remove the water drain hose from the connection point.
 - → "Water outlet connection types", Page 15
- 5. Secure the water drain hose on the appliance against unintentional loosening.
 - Ensure that you do not bend the water drain hose.

- 6. Empty the condensation container → Page 33.
- 7. Insert the condensation container → Page 34.
- 8. Disconnect the appliance's mains plug from the power supply.
- ✓ The appliance is now ready to be transported.

19.2 Disposing of old appliance

Valuable raw materials can be reused by recycling.

⚠ WARNING Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- Do not install the appliance behind a door as this may obstruct the appliance door or prevent it from openina.
- ► With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.

⚠ WARNING Risk of fire!

The refrigerant R290 used in this appliance is environmentally friendly. It is however flammable and may ignite if appliances are not disposed of properly.

- Dispose of the appliance properly.
- ► Do not damage the tubing of the refrigerant circuit.
- 1. Unplug the appliance from the mains.
- 2. Cut through the power cord.
- 3. Dispose of the appliance in an environmentally friendly manner.

Information about current disposal methods are available from your specialist dealer or local authority.



This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE). The guideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.

20.1 Product number (E-Nr.) and production number (FD)

You can find the product number (E-Nr.) and the production number (FD) on the appliance's rating plate. Depending on the model, the rating plate is located:

- On the inside of the door.
- On the inside of the maintenance
- On the rear of the appliance.

Make a note of your appliance's details and the Customer Service telephone number to find them again auickly.

20 Customer Service

Function-relevant genuine spare parts according to the corresponding Ecodesign Order can be obtained from Customer Service for a period of at least 10 years from the date on which your appliance was placed on the market within the European Economic Area.

Note: Under the terms of the manufacturer's warranty the use of Customer Service is free of charge.

Detailed information on the warranty period and terms of warranty in your country is available from our aftersales service, your retailer or on our website.

If you contact Customer Service, you will require the product number (E-Nr.) and the production number (FD) of your appliance.

The contact details for Customer Service can be found in the enclosed Customer Service directory or on our website.

21 Consumption values

The Cotton Eco programme (denoted by the arrow symbol) is suitable for drying cotton laundry with a normal dampness level, and is the most efficient programme for drying damp cotton laundry in terms of combined energy consumption.

The consumption values for this programme that are declared on the energy label refer to a moisture content of the laundry of 60%.

The values specified for other programmes are indicative only and were determined in accordance with the applicable standard EN61121.

The actual values may deviate from the indicated values depending on the type of fabric, composition of laundry to be dried, residual moisture in the fabric, set degree of dryness, amount of laundry being loaded, environmental conditions and the activation of additional functions. The expected programme dura-

tion/"Ready in" time that is shown on the appliance display when selecting the programme is based on the spin speed in the washing machine of 1000 rpm when the appliance is delivered.

Programme	Final mois- ture level (%)	Load (kg)	Spin speed (rpm)	Initial mois- ture level (%)	Pro- gramm e dura- tion (h:min)	Energy con- sump- tion (kWh/ cycle)
Cotton + ⊞ Cup- board Dry	-1.5	9.0	1400	50	3:16	1.54
Cotton + ⊞ Cup- board Dry	-1.5	4.5	1400	50	2:23	0.98
Cotton + ⊞ Cup- board Dry	-1.5	9.0	1000	60	3:38	1.78
Cotton + ⊞ Cup- board Dry	-1.5	4.5	1000	60	2:36	1.12
Cotton + ⊞ Cup- board Dry	-1.5	9.0	800	70	4:00	2.01
Cotton + I Cup- board Dry	-1.5	4.5	800	70	2:49	1.27
Cotton Eco	0.0	9.0	1400	50	2:52	1.36
Cotton Eco	0.0	4.5	1400	50	1:54	0.78
Cotton Eco	0.0	9.0	1000	60	3:15	1.60
Cotton Eco	0.0	4.5	1000	60	2:05	0.89
Cotton Eco	0.0	9.0	800	70	3:38	1.84
Cotton Eco	0.0	4.5	800	70	2:16	1.00

Programme	Final mois- ture level (%)	Load (kg)	Spin speed (rpm)	Initial mois- ture level (%)	Pro- gramm e dura- tion (h:min)	Energy con- sump- tion (kWh/ cycle)
Cotton + 🕮 Iron Dry	12.0	9.0	1400	50	2:05	0.96
Cotton + 🕮 Iron Dry	12.0	4.5	1400	50	1:22	0.54
Cotton + 🕮 Iron Dry	12.0	9.0	1000	60	2:28	1.21
Cotton + 🕮 Iron Dry	12.0	4.5	1000	60	1:35	0.68
Cotton + 🕮 Iron Dry	12.0	9.0	800	70	2:51	1.45
Cotton + 🕮 Iron Dry	12.0	4.5	800	70	1:48	0.82
Easy Care + 🗉 Cupboard Dry	2.0	3.5	800	40	1:08	0.42
Easy Care + 🗉 Cupboard Dry	2.0	3.5	600	50	1:20	0.52

$\boldsymbol{\alpha}$	T	L	: I	data
77	ΙΔΓ	nn	ıraı	пата
			ıvaı	uala

Appliance height	84.2 cm
Appliance width	59.8 cm
Appliance depth	61.3 cm
Appliance depth with door closed	64.8 cm
Appliance depth with door open	109.6 cm
Weight	56.4 kg
Weight Maximum load	56.4 kg 9.0 kg
Maximum load	9.0 kg 220-240 V,

Power consumption	Off mode: 0.30 WLeft-on mode: 0.30 W
Ambient temperature	Minimum:5 °CMaximum:35 °C
Length of the power cord	145 cm

This product contains light sources from energy efficiency class F. These light sources are available as a spare part and must only be replaced by trained specialist staff.

en Technical data

You can find more information about your model online at https://eprel.ec.europa.eu/1. This web address is linked to the official EU EPREL product database. Please then follow the instructions on searching for the model. The model identifier is made up of the characters before the slash in the product number (E-Nr.) on the rating plate. Alternatively, you can also find the model identifier in the first line of the EU energy label.

¹ Only applies to countries in the European Economic Area







EN Manufactured by BSH Hausgeräte GmbH under the trademark licence of Siemens AG

Valid within Great Britain: Imported to Great Britain by BSH Home Appliances Ltd. Grand Union House Old Wolverton Road Wolverton, Milton Keynes MK12 5PT United Kingdom

BSH Hausgeräte GmbH

Carl-Wery-Straße 34 81739 München, GERMANY siemens-home.bsh-group.com



9001884571

(030823)