SIEMENS

WQ46B2CXGB

Tumble dryer



EN User manual and installation instructions



Further information and explanations are available online:



Table of contents

1 Safety	. 4 8.4 . 4 8.6 . 5 9 10 . 9
2 Preventing material damage	11 11
3 Environmental protection and saving energy	11 11 11 11 11 12 11
4 Installation and connection	12 11
 4.1 Unpacking the appliance 4.2 Contents of package 4.3 Requirements for the installation location 4.4 Water outlet hose 4.5 Aligning the appliance 4.6 Connecting the appliance to the electricity supply 	12 11 12 11 12 13 11 16 11 16 12 12
5 Familiarising yourself with	17
your appliance	17 17 13 18 13 18
6 Display	19
7 Buttons	21 14

8 Programmes	25
8.1 Automatic programmes	2526
9 Accessories	28
10 Laundry 10.1 Preparing the laundry	29
11 Basic operation	29 29 30 30 30 30 30 31 31 31
12.1 Changing the dryness level 12.2 Adjusting the dryness level	33 34 34
13 Childproof lock	34
13.1 Activating the childproof lock	34
13.2 Deactivating the childproof lock	34
14 Crease-removal function	34
14.1 Starting a programme with the crease-removal function14.2 Filling the water tank	35 35

en



1 Safety

Observe the following safety instructions.

1.1 General information



- Read this instruction manual carefully.
- Keep the instruction manual and the product information safe for future reference or for the next owner.
- Do not connect the appliance if it has been damaged in transit.

1.2 Intended use

Only use this appliance:

- for drying and freshening up fabrics that are washed with water and suitable for dryers.
- in private households and in enclosed spaces in a domestic environment.
- Up to an altitude of 4000 m above sea level.

1.3 Restriction on user group

This appliance may be used by children aged 8 or over and by people who have reduced physical, sensory or mental abilities or inadequate experience and/or knowledge, provided that they are supervised or have been instructed on how to use the appliance safely and have understood the resulting dangers.

Do not let children play with the appliance.

Cleaning and user maintenance must not be performed by children unless they are being supervised.

Keep children under the age of 3 years and pets away from the appliance.

1.4 Safe installation

Incorrect installation is dangerous.

- Connect and operate the appliance only in accordance with the specifications on the rating plate.
- Connect the appliance to a power supply with alternating current only via a properly installed socket with earthing.
- ► The protective conductor system of the domestic electrical installation must be properly installed. The installation must have a sufficiently large cross section.
- ▶ When using a residual current circuit breaker, only use a type with the mark.
- ► Never equip the appliance with an external switching device, e.g. a timer or remote control.
- ► Never connect the appliance to a circuit that is regularly switched on and off by the energy supplier.
- ► When the appliance is installed, the mains plug of the power cord must be freely accessible. If free access is not possible, an all-pole isolating switch must be installed in the permanent electrical installation according to the installation regulations.
- ► When installing the appliance, check that the power cable is not trapped or damaged.

If the insulation of the power cord is damaged, this is dangerous.

- ► Never let the power cord come into contact with hot appliance parts or heat sources.
- ► Never let the power cord come into contact with sharp points or edges.
- ▶ Never kink, crush or modify the power cord.

It is dangerous to use an extended power cord and non-approved adapters.

- ▶ Do not use extension cables or multiple socket strips.
- Only use adapters and power cords approved by the manufacturer.

en Safety

▶ If the power cord is too short and a longer one is not available, please contact an electrician to have the domestic installation adapted.

⚠ WARNING – Risk of injury!

The heavy weight of the appliance may result in injury when lifted.

▶ Do not lift the appliance on your own.

If this appliance is not correctly installed in a washer-dryer stack, the installed appliance may fall.

- Only stack the dryer on a washing machine using the connection kit from the dryer manufacturer
 - → "Accessories", Page 28. No other installation method is permitted.
- ► Do not install the appliance in a washer-dryer stack if the dryer manufacturer does not offer a suitable connection kit.
- ▶ Do not install appliances from different manufacturers and with varying depths and widths in a washer-dryer stack.
- ▶ Do not install a washer-dryer stack on a platform; the appliances may tip over.

⚠ WARNING – Risk of suffocation!

Children may put packaging material over their heads or wrap themselves up in it and suffocate.

- ► Keep packaging material away from children.
- ► Do not let children play with packaging material.

△ CAUTION – Risk of injury!

The appliance may vibrate or move when in use.

- ▶ Place the appliance on a clean, even, solid surface.
- ► Align the appliance using the appliance feet and a spirit level. If hoses and power cords have been laid incorrectly, this causes a tripping hazard.
- Lay hoses and power cords in such a way that there is no risk of tripping.

If the appliance is moved by holding onto protruding components, such as the appliance door, the parts may break off.

▶ Do not move the appliance by holding onto protruding parts.

△ CAUTION – Risk of cutting!

Touching sharp edges on the appliance may lead to cuts.

- ► Do not touch the sharp edges on the appliance.
- Wear protective gloves when installing and transporting the appliance.

1.5 Safe use

⚠ WARNING – Risk of electric shock!

If the appliance or the power cord is damaged, this is dangerous.

- ► Never operate a damaged appliance.
- ► Never pull on the power cord to unplug the appliance. Always unplug the appliance at the mains.
- ▶ If the appliance or the power cord is damaged, immediately unplug the power cord or switch off the fuse in the fuse box.
- ► Call customer services. → Page 49

An ingress of moisture can cause an electric shock.

- ► Only use the appliance in enclosed spaces.
- ► Never expose the appliance to intense heat or humidity.
- ► Do not use steam- or high-pressure cleaners, hoses or sprays to clean the appliance.

△ WARNING – Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- ► Do not install the appliance behind a door as this may obstruct the appliance door or prevent it from opening.
- ▶ With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.

↑ WARNING – Risk of suffocation!

Children may breathe in or swallow small parts, causing them to suffocate.

- ► Keep small parts away from children.
- ► Do not let children play with small parts.

⚠ WARNING – Risk of explosion!

If there is coal dust or flour in the air around the appliance, this may cause an explosion.

► Keep the area around the appliance clean during operation.

⚠ WARNING – Risk of poisoning!

Condensation water from this appliance is not suitable for drinking and may be contaminated with fluff.

Do not drink or reuse the condensation water from the appliance.

Detergents and care products may result in poisoning if consumed.

- ▶ If accidentally swallowed, seek medical advice.
- ► Keep detergents and care products out of the reach of children.

⚠ WARNING – Risk of fire!

The refrigerant R290 in this appliance is environmentally friendly yet combustible and may ignite if it comes into contact with open flames or ignition sources.

► Keep naked flames and ignition sources away from the appli-



⚠ WARNING – Risk of explosion!

If there is any residual material left in the fluff filter, this may ignite during the drying process.

Clean the fluff filter regularly.

Highly flammable objects such as lighters or matches may ignite during the drying process.

► Remove all highly flammable objects from any pockets in your laundry before the drying process.

Unwashed laundry that has come into contact with solvents, oil, wax, wax remover, paint, grease or stain remover may ignite when drying is in progress.

► Do not place laundry in this appliance to be dried if the laundry has not been washed first.

- ► Rinse the laundry thoroughly with warm water and detergent before drying it in the machine.
- ▶ Do not use the appliance if industrial chemicals have been used to clean the laundry beforehand.

★ WARNING – Risk of fire!

If drying is interrupted early, the laundry is not cooled sufficiently and may ignite.

- ► Do not interrupt the drying programme early.
- ► If drying is interrupted early, remove the laundry immediately and spread it out.

△ CAUTION – Risk of injury!

The covering plate may break if you stand on or climb onto the appliance.

▶ Do not stand on or climb onto the appliance.

The appliance may tip over if you sit on or lean against the open door.

- ▶ Do not sit on or lean against the appliance door.
- ▶ Do not place any objects on the appliance door.

Reaching into the drum while it is still turning may cause hand injuries.

► Wait for the drum to come to a complete stop before reaching inside.

1.6 Safe cleaning and maintenance

Improper repairs are dangerous.

- ► Never make any technical modifications to the appliance or its features.
- ► Repairs to the appliance should only be carried out by trained specialist staff.
- ▶ Only use genuine spare parts when repairing the appliance.
- ▶ If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

en Safety

An ingress of moisture can cause an electric shock.

- ► Before cleaning, pull out the mains plug or switch off the fuse in the fuse box.
- ► Do not use steam- or high-pressure cleaners, hoses or sprays to clean the appliance.

⚠ WARNING – Risk of injury!

The use of non-original spare parts and non-original accessories is dangerous.

➤ Only use the manufacturer's original spare parts and original accessories.

⚠ WARNING – Risk of poisoning!

Poisonous fumes may be given off if you use cleaning agents that contain solvents.

► Do not use cleaning agents that contain solvents.

2 Preventing material damage

ATTENTION!

The functionality of the appliance may be impaired if you use the wrong quantity of fabric softener, detergent, care product or cleaning agent.

Follow the dosage recommendations from the manufacturer.

Exceeding the maximum load capacity impairs the function of the appliance.

- Observe the maximum load capacity for each programme and do not exceed it.
- → "Programmes", Page 25 The function of the appliance may be impaired if the appliance overheats.
- Keep the ventilation opening on the appliance clear during operation.
- Make sure that the area is adequately ventilated.

Light objects such as hair and fluff may be sucked in from the ventilation opening on the appliance during operation and impair the function of the appliance.

- Keep the area around the appliance clean during operation.
- Keep light objects away from the appliance.

If you operate the appliance without a fluff guard (e.g. fluff filter, fluff collector, filter mat, etc., depending on appliance specifications), or if the fluff quard is incomplete or defective, this may result in damage to the appliance.

Do not operate the appliance without a fluff guard, or with a fluff guard that is incomplete or defective.

Foam and foam rubber may deform or melt during the drying process.

Do not dry laundry that contains foam or foam rubber.

Unsuitable cleaning products may damage the surfaces of the appli-

- ▶ Do not use harsh or abrasive detergents.
- Do not use cleaning products with a high alcohol content.
- Do not use hard scouring pads or cleaning sponges.
- Clean the appliance with nothing but water and a soft, damp cloth.
- ► Remove all detergent residue, spray residue or other residues immediately if they come into contact with the appliance.

3 Environmental protection and saving energy

3.1 Disposing of packaging

The packaging materials are environmentally compatible and can be recycled.

 Sort the individual components by type and dispose of them separately.

3.2 Saving energy

If you follow these instructions, your appliance will use less power.

- Operate the appliance in a wellventilated room and keep the ventilation opening on the appliance clear.
- Spin the laundry in the washing machine before drying.
- For each drying process, use the maximum load for the programs. Programmes → Page 25

- Do not exceed the programme's maximum load capacity. Programmes → Page 25
- After drying, clean the lint screen. → "Cleaning the fluff filter", Page 31
- Deactivate Wi-Fi on the appliance if it is not being used.
 - → "Deactivating Wi-Fi on the appliance", Page 39

3.3 Energy saving mode

If you do not use the appliance for a brief period, it automatically switches to energy-saving mode. All displays go out and \triangleright flashes.

Energy-saving mode ends when you use the appliance again.

If you do not use the appliance for an extended period, it automatically switches to standby mode.

4 Installation and connection

4.1 Unpacking the appliance

ATTENTION!

Objects remaining in the drum that are not designed for operation with the appliance may cause material damage and damage to the appliance.

- Remove these objects, along with all supplied accessories, from the drum before starting the appliance.
- 1. Remove any packaging and protective covers completely from the appliance.
 - → "Disposing of packaging", Page 11
- 2. Check the appliance for visible damage.
- **3.** Open the door. \rightarrow Page 30

- 4. Remove any accessories from the drum.
- 5. Close the door.

4.2 Contents of package

After unpacking all parts, check for any damage in transit and completeness of the delivery.

ATTENTION!

If the appliance is operated with incomplete or defective accessories, the appliance may not be able to operate properly, or this may result in material damage or damage to the appliance.

- Do not operate the appliance with incomplete or defective accessories.
- Replace the accessories in question before operating the appliance.
 - → "Accessories", Page 28

The delivery consists of the following:

- Tumble dryer
- Accompanying documents
- Water jug
 - → "Filling the water tank", Page 35
- Wool basket with insert
 - → "Wool basket", Page 36
- Water outlet hose with connection adapter, fixing material and elbow.
 - → "Water outlet hose", Page 13

4.3 Requirements for the installation location

ATTENTION!

If the appliance is tilted at an angle greater than 40°, residual water may leak out of the appliance and cause material damage.

► Tilt the appliance carefully.

Transport the appliance in an upright position.

If residual water in the appliance freezes, this may cause damage to the appliance.

 Do not install or operate this appliance anywhere that is liable to experience frost or outdoors.

If the appliance is operated immediately after transportation, the refrigerant contained in the appliance may result in damage to the appliance.

 Immediately after transporting the appliance, leave it to rest for two hours before putting it into operation.

Installation location	Requirements
On the floor	Place the appliance on a clean, level and firm surface. Align the appliance → Page 16.

Installation loca- Requirements tion


In a washer-dryer stack

Only use the original connection set from the dryer manufacturer when setting up this appliance in a washer-dryer stack.

- Connection kit with pull-out worktop
 - → Page 28
- Connection kit → Page 28

This appliance must only be stacked on a washing machine from the same manufacturer. The depth and width of this appliance must correspond with the dimensions of the washing machine. Do not place the washer-dryer stack on a platform.

Against a wall



Do not trap the hoses and power cord between the wall and the appliance.

4.4 Water outlet hose

Condensation that forms in the appliance as it dries the laundry is collected by default in the condensation

container. Use the water outlet hose to drain away excess condensation directly into the waste water system.

Note

■ Operate this appliance using the water outlet hose provided.

→ "Connecting the water outlet hose", Page 14

If you connect the water outlet hose, you do not have to regularly empty the condensation container.

→ "Emptying the condensation container", Page 33

Connecting the water outlet hose

If you do not want to regularly empty the appliance's condensation container, connect the water outlet hose.

ATTENTION!


When operating the appliance without the condensation hose or water outlet hose being connected properly, liquid may leak out of the connecting piece.

 Before operating the appliance, connect the condensation hose or water outlet hose properly to the connecting piece.

Requirements

- The appliance and the accessory have been unpacked.
 - → "Unpacking the appliance", Page 12
- The appliance is installed at the installation location.
 - → "Requirements for the installation location", Page 12


1. Pull out the condensation hose from the connecting piece.




The condensation hose is connected to the connecting piece at the factory.

Note: When removing the condensation hose, liquid may leak out of the connecting piece.


2. Push the condensation hose into the holder.



3. Push the water outlet hose as far as it will go into the connecting piece.



- 4. Empty the condensation container. → "Emptying the condensation container", Page 33
- 5. Remove the stopper from the underside 1 and insert it in the recess in the top 2.



- **6.** Insert the condensation container. → "Inserting the condensation container", Page 33
- 7. Connect the appliance to the water drain.
 - → "Water outlet connection types", Page 15

Tip: To collect condensation in the condensation container again (e.g. if vou change where the appliance is located), carry out these steps in reverse order.


Water outlet connection types

ATTENTION!

In the event of a blocked or covered outlet, accumulated wastewater can flow back into the appliance.

► Before operating the appliance, ensure that the wastewater drains away quickly and eliminate any blockages.


Drainage into a siphon.



Secure the connection point with a (12-22 mm) hose clamp. Secure the water outlet hose with a hose guide at a height of at least 80 cm and no more than 100 cm.

Note: You can use the Y-distributor → Page 28 to connect the water outlet hose of an additional appliance, such as a washing machine, to the same siphon outlet.

Drainage into a wash basin.




Push the water outlet hose fully through the elbow and secure it using fixing material. Secure the elbow

at a height of no more than 100 cm.

Drainage into a gully.

Push the water outlet hose fully through the el-

en Installation and connection




bow and secure it using fixing material. Secure the elbow to the gully.

4.5 Aligning the appliance

In order to reduce vibrations and noises, align the appliance correctly.

To align the appliance, turn the appliance feet. Check that the appliance is level using a spirit level.



All appliance feet must stand firmly on the ground.


4.6 Connecting the appliance to the electricity supply

- Insert the mains plug of the appliance's power cable in a socket nearby.
 - The connection details of the appliance can be found under Technical data \rightarrow *Page 52*.
- 2. Check the mains plug is inserted properly.

5 Familiarising yourself with your appliance

5.1 Appliance

You can find an overview of the parts of your appliance here.




On certain models, specific details such as the colour and shape may differ from those pictured.

1	Ventilation opening
2	Fluff filter → Page 31
3	Door

4	Condensation container → Page 32
5	Control panel → Page 18

5.2 Control panel

You can use the control panel to configure all functions of your appliance and to obtain information about the operating status.



- Programmes → Page 25
- Programme selector → Page 29
- Buttons → Page 21 and display → Page 19

5.3 Operating logic

Some areas of the display are buttons and respond to touch. You can activate, deactivate or change settings by pressing the buttons. The activated settings are highlighted in colour on the display.

ATTENTION!

Pressing on the display with force may cause damage.

- Do not apply heavy pressure on the display.
- Do not press on the display using pointed or sharp objects.

Changing a setting value

If you activate certain settings, the display shows selection buttons and you can change the setting value.

 Press the selection buttons → Page 21.

The display shows the setting value.

6 Display


The display shows the current settings, options or relevant information.

Depending on the programme status, the display shows some information in the 88:88 area, e.g. End.

Note: Additional functions may be available as a result of software updates.

→ "Installing the software update", Page 39

If a software update is available, you can find further information in the Home Connect app.



Example: Display

Indicator	Description
0:40 1	Expected programme duration or programme time remaining in hours and minutes.
9.01	Recommendation for the maximum load capacity for the selected program in kg.
(9 10h 1	Program end time → "Buttons", Page 24
=(1)	Shortened programme duration is activated. → "Buttons", Page 23
☆	Save a programme. → "Buttons", Page 22
~	 Lights up: The childproof lock is activated. Flashes: The childproof lock is activated and the appliance has been operated. → "Deactivating the childproof lock", Page 34
¹ Example	

en Display

Indicator	Description
	The dryness level is activated. → "Buttons", Page 22
1	The dryness level is activated. → "Buttons", Page 22
⊕+	The dryness level is activated. → "Buttons", Page 22
ZI	The crease-reduction function is activated. → "Buttons", Page 23
¥	Gentle drying is activated for delicate fabrics. → Page 24
½	Half load is activated. → Page 24
Ð	You can remove or add laundry, and interrupt the current programme. → Page 30
	Empty and insert the condensation container. → Page 33
	Clean the fluff filter → Page 31.
CArE	Run the basic appliance care programme. → Page 41
\bigcirc	Fill the water tank for the crease-removal function. → Page 35
Hot	The cooling process cools the laundry independently of the programme status for a few minutes while the drum is rotating, in order to avoid damage to the laundry. The cooling process can be cancelled by opening the door. Note: Do not change the set programme.
‡	Change the basic settings. → Page 41
ō [*] ō	Intelligent programme recommendation is activated. → Page 24
	 Lights up: The appliance is connected to your home network via Wi-Fi. Flashes: The appliance is trying to connect to your home network via Wi-Fi. → "Home Connect ", Page 38
	Remote start is activated. → Page 24
Ŋ	Settings that are not available on the appliance have been set via the Home Connect app. You can find more information in the Home Connect app.
X	Programme status: Crease-reduction function
	Programme status: Pause
End	Programme status: Programme end
¹ Example	

Below is an overview of the buttons and their setting options.

Note: Additional functions may be available as a result of software updates. → "Installing the software update", Page 39

If a software update is available, you can find further information in the Home Connect app.

Button	Selection	Description
	StartCancelPause	Start, cancel or pause the programme. If is displayed, you can pause the programme. If is displayed, you can start the programme.
ம் (mains switch)	 Switch on Standby mode Restart the appliance 	Switch on the appliance or put it in standby mode. If the control panel does not respond, press and hold ⊕ for approximately 5 seconds to restart the appliance. → "The display and buttons do not respond.", Page 46
≈ 3 sec.	ActivateDeactivate	Activate or deactivate the childproof lock. Disable the control panel to prevent unwanted or accidental operation. If the childproof lock is activated and the appliance has been switched off, the childproof lock remains activated. → "Childproof lock", Page 34
\$	Multiple selection	To change a setting, press the ∧ or ∨ selection button until the display shows the required setting.

en Buttons

Button	Selection	Description
Basic Settings	Multiple selection	→ "Basic settings", Page 40
Favourite	SavingSetting	Press the button for approx. 3 seconds to save your customised program settings. → "Saving the programme settings", Page 29 If you briefly press the button, you can set customised program settings for your program.
⊞* Cupboard Extra Dry	ActivateDeactivate	The dryness level defines how damp or dry the laundry is after the programme ends. → "Dryness level", Page 33
⊞ Cupboard Dry	ActivateDeactivate	The dryness level defines how damp or dry the laundry is after the programme ends. → "Dryness level", Page 33
🖴 Iron Dry	ActivateDeactivate	The dryness level defines how damp or dry the laundry is after the programme ends. → "Dryness level", Page 33
5 Shirts [®] £	ActivateDeactivate	Adjust the set programme with crease-removal function smartFinish ♣ . Observe the programme description. → "Programmes", Page 25 Suitable for dry shirts and blouses that have not been worn for long or at all. Suitable for 2 to 5 items of laundry.

Button	Selection	Description
Business *T	■ Activate ■ Deactivate	Adjust the set programme with crease-removal function smartFinish ☆ . Observe the programme description. → "Programmes", Page 25 Suitable for dry suits or skirts that have not been worn for long or at all and that are labelled "Dry clean only". Suitable for one suit or two items of laundry.
1 Shirt 空	ActivateDeactivate	Adjust the set programme with crease-removal function smartFinish [⊕] . Observe the programme description. → "Programmes", Page 25 Suitable for dry shirts and blouses that have not been worn for long or at all. Suitable for one item of laundry.
Less Ironing	ActivateDeactivate	Activate or deactivate the crease-reduction function. Once the programme has ended, the drum moves the laundry at regular intervals for 120 minutes to prevent creasing.
varioSpeed	ActivateDeactivate	Activate or deactivate a shorter programme duration. Note: The energy consumption increases. This does not impair the drying result.

en Buttons

Button	Selection	Description
Low Heat	■ Activate ■ Deactivate	Activate or deactivate gentle drying. The temperature is reduced for delicate fabrics, e.g. polyacrylic or elastane. The programme duration is extended.
Ready In	Up to 24 hours	Set the programme end time. The programme duration is already included in the set number of hours. Once the programme has started, the programme duration is displayed.
Half Load	ActivateDeactivate	Dry individual items of laundry or small loads of laundry.
intelligentDry	Activate	After you have washed your laundry in the washing machine, the dryer recommends a suitable programme for drying the laundry. Note: The washing machine must be compatible with Home Connect. The washing machine and dryer must be connected to your home network and registered in your Home Connect app.
Remote Start 🗇	ActivateDeactivateOpening the Home Connect set- tings	Activate or deactivate remote start. → Page 39

8 Programmes

You can dry your fabrics using either an automatic programme or a timed programme.

Note: Additional functions may be available as a result of software updates.

→ "Installing the software update", Page 39

If a software update is available, you can find further information in the Home Connect app.

8.1 Automatic programmes

Automatic programmes are programmes in which humidity sensors measure the residual moisture in the laundry during the drying cycle. The programme only ends once the set dryness level is reached. Each automatic programme has a dryness level → Page 33. The dryness level defines how dry or damp the laundry is after the programme ends

Tips

- Select the dryness level according to the type of fabric or the desired drying result.
 - → "Dryness level", Page 33
- The laundry's care labels provide you with additional information about programme selection.

Programme	Description	Max. load (kg)
Cottons	Dry hard-wearing, heat-resistant fabrics made of cotton or linen.	9.0
Cottons Eco	Dry hard-wearing, heat-resistant fabrics made of cotton or linen. Energy-saving programme.	9.0
Easy Care	Dry items made of synthetic materials or blended fabrics.	3.5
Mixed Fabrics	Dry items made of cotton and synthetics.	3.0
Bed linen	Dry duvet covers, pillowcases and sheets made of cotton. Note: The drum movement is optimised	3.5
	for drying large items of laundry.	
Hygiene	Dry hard-wearing, heat-resistant fabrics made of cotton or linen. Note: Particularly suitable for strict hy-	4.0
	giene requirements.	
Outdoor	Dry weatherproof and outdoor clothing with a membrane coating and water-repellent fabrics.	1.5

en Programmes

Programme	Description	Max. load
Shirts	Suitable for shirts and blouses made of cotton, linen, synthetics or blended fabrics. Note: For optimal drying results, dry a maximum of 5 shirts or 5 blouses at the same time. Once the laundry is dry, iron it or hang it up. The residual moisture is then distributed evenly.	(kg) 1.5
Rapid 40'	Dry items made of synthetics and light cotton.	1.0
Towels	Dry hard-wearing, heat-resistant towels and dressing gowns made of cotton or linen.	6.0
smartFinish 省	Reduce creasing and airborne odours. → "Crease-removal function", Page 34 To adjust the programme with crease-removal function, press the corresponding button. → "Buttons", Page 21	-
App programs →=	Select additional programmes directly via the Home Connect app. A description of the programmes can be found in the Home Connect app. Note: Your appliance must be connected to your home network and registered in your Home Connect app. → "Home Connect", Page 38	-

8.2 Timed programmes

Timed programmes are programmes with a defined or adjustable programme duration. The programme ends once this time has elapsed, even if the laundry is still not dry, for example. Timed programmes are suitable for drying individual items of laundry or thin fabrics.

Tip: The laundry's care labels provide you with additional information about programme selection.

Programme	Description	Max. load
		(kg)
Wool in Basket	Dry items made of wool or containing wool.	One item of laundry
	Note: Dry these items only using the wool basket.	
	→ "Wool basket", Page 36	
Warm [©]	Dry all types of fabric except for wool and silk. Suitable for pre-dried or slightly damp laundry and for drying off multi-layered,	3.0
	thick laundry.	
	Note: This programme is suitable for drying using the wool basket. → "Wool basket", Page 36 If you are using the wool basket, you can also dry fabrics made from wool using this programme.	
App programs →=	Select additional programmes directly via the Home Connect app. A description of the programmes can be found in the Home Connect app. Note: Your appliance must be connected to your home network and registered in your Home Connect app. → "Home Connect", Page 38	_

9 Accessories

Use original accessories. These have been made especially for your appliance.

Note: Some accessories are available in other colours. Contact → "Customer Service", Page 49.

	Use	Order number
Connection kit	To save space, stack the appliance on a suitable washing machine of the same width and depth and that is from the same manufacturer.	WZ27510
Connection kit with pull- out worktop	To save space, stack the appliance on a suitable washing machine of the same width and depth and that is from the same manufacturer. The pull-out worktop makes it easier to load and unload the appliance.	WZ27500
Wool basket	Dry or air individual woollen items, sports shoes and soft toys.	WZ20600
Y-distributor	Connect the water outlet hose of an additional appliance to the same siphon outlet.	15000490
Appliance care product	Spare part for the intensive appliance care function.	00311829
Platform	Install the appliance at a raised height so that it can be easily loaded and unloaded.	WZDP20D

10 Laundry

10.1 Preparing the laundry

ATTENTION!

Objects remaining in the laundry may damage the laundry and the drum.

 Remove all items from any pockets in your laundry before using the appliance.

Note

The appliance and fabrics are protected when you prepare your laundry.

- Brush off sand and soil
- Sort the laundry according to colour and textiles and observe the care labels
- Close all zips, hook and loop fasteners, hooks and eyes
- Remove curtain fittings and lead strips
- Load the laundry unfolded into the drum
- Spin the laundry before drying
- Dry woollen items, sports shoes and soft toys in the wool basket → "Wool basket", Page 36

11 Basic operation

11.1 Switching on the appliance

Note: If you switch the appliance on the first time after you have connected it to the electrical system, the switch-on process takes up to one minute.

Requirement: The appliance has been correctly installed and connected. → *Page 12*

► Press 🛈.

The switch-on process takes a few seconds.

Note: The lighting for the drum goes out automatically.

11.2 Setting a programme

- Turn the programme selector and set the required programme.
 - → "Programmes", Page 25
- The display shows the programme settings.
- 2. Adjust the programme settings. → "Buttons", Page 21

Observe the information about operating logic \rightarrow *Page 18*. The programme settings are not saved permanently for the programme.

11.3 Saving the programme settings

You can save your individual programme settings as favourites.

Requirement: A programme is set. → *Page 29*


Press and hold Favourite for approx. 3 seconds.

Press **Favourite** to call up the saved programme.


Note: To overwrite the saved programme, repeat the steps above.

11.4 Opening the door

1. Take hold of the door's recessed grip and pull on the door.



2. Open the door.



11.5 Loading laundry

Note: To prevent creasing, note the maximum load for the programmes. → "Programmes". Page 25

Requirements

- The laundry is prepared and sorted
 - → "Laundry", Page 29
- The drum is empty.
- 1. Open the door. → Page 30
- 2. Place the laundry in the drum.
- 3. Close the door.

Ensure that there is no laundry trapped in the door.

11.6 Starting the programme

Requirement: A programme is set.

- → Page 29
- ► Press 🛮 🖒 .
- The display shows the programme duration or the programme end time.
- ✓ After the programme has ended, the display shows: "End " .

Note: When "Hot" is shown on the display, the appliance cools the laundry.

When "Hot" goes out, the laundry has cooled down.

11.7 Adding laundry

After the programme starts, you can remove or add laundry at any time.

1. Press **□ >** .

The cooling process starts automatically after approximately 30 seconds and cools down the laundry while the drum is rotating. If you want to avoid or cancel the cooling process, open the door.

→ Page 20

- 2. Open the door. → Page 30
- 3. Add or remove laundry.
- 4. Close the door.
- **5.** Press **1 1 .** .

11.8 Cancelling the programme

- **1.** Press **1 1 .**
- 2. Open the door. → Page 30
- 3. Remove the laundry. → Page 30

11.9 Unloading the laundry

- 1. Open the door. → Page 30
- 2. Remove the laundry from the drum.

11.10 Put the appliance into standby mode

► Press 🛈.

11.11 Fluff filter

During drying, fluff from the laundry is collected in the fluff filter. The fluff filter protects the appliance from fluff.


Cleaning the fluff filter

If the drying programme has finished or the display shows a notification while the appliance is in operation, clean the fluff filter.


Note: If you do not clean the appliance as described, the appliance's functionality may be impaired.

Requirements


- The display shows the following after drying: "End "
- or the display shows the following during operation: **\overline{\overli**
- 1. Open the door.
- 2. Remove the fluff from the door.



3. Remove the two-part fluff filter.




4. Remove the fluff from the recess.




Ensure that no fluff falls into the air channel.


5. Disconnect the two-part fluff filter.




6. Open the two fluff filters.




7. Remove the fluff.




8. Clean the two fluff filters thoroughly under warm, running water and then dry them off.



9. Close the two fluff filters and put them together.



10. Insert the two-part fluff filter.



11. Close the door.

11.12 Condensation container

Condensation that forms in the appliance as it dries the laundry is collected by default in the condensation container.

Note: Operate this appliance using the water outlet hose provided.

→ "Connecting the water outlet hose", Page 14

If you connect the water outlet hose, you do not have to regularly empty the condensation container.


→ "Emptying the condensation container", Page 33

Emptying the condensation container


If the drying programme has finished or the display shows a notification while the appliance is in operation, empty the condensation container.

Requirements

- The display shows the following after drying: "End "
- or the display shows the following during operation: 🖺 .
- 1. Pull out the condensation container, keeping it level.



2. Empty the condensation container.




Check the condensation container filter regularly and clean the filter if it is dirty. → Page 44 Make sure that you insert the condensation container before operat-

ing the appliance. → Page 33

Inserting the condensation container

 Push the condensation container in as far as it will go.



12 Dryness level

Each automatic programme has a specified dryness level. The dryness level defines how dry or damp your laundry is after the programme ends.

Dryness level	Description
⊕ ⁺	For multi-layered, thick laundry that does not dry readily.
1	For normal, single- layered laundry.
	For normal, single- layered laundry. The laundry is still slightly damp after the programme ends. To prevent creasing after drying, iron the laundry or hang it up.

12.1 Changing the dryness level

For some automatic programmes, you can change the dryness level so that your laundry will be drier or more damp.

- 1. Set an automatic programme. → Page 25
- The display shows the specified dryness level.
- 2. Press ⊞ Cupboard Dry , ⊞ Cupboard Extra Dry or ☐ Iron Dry .

12.2 Adjusting the dryness level

If the laundry feels too damp after it has been dried to a particular dryness level, you can adjust the dryness level.

Note: You can also adjust the dryness level in the basic settings.

- **1.** Set an automatic programme. → Page 25
- ✓ The display shows the specified dryness level.
- 2. Press and hold I Cupboard Dry, □ Cupboard Extra Dry or
 □ Iron Dry for approx. 3 seconds.
- 3. Press ∧ or ∨ to adjust the dryness level.
- 4. Press and hold the selected dryness level for approx. 3 seconds to return to the automatic programme.

13 Childproof lock

Secure your appliance against being operated unintentionally using the controls.

13.1 Activating the childproof lock

- ▶ Press and hold <=> 3 sec. for approx. 3 seconds.
- ▼ The control elements are locked.
- ▼ The childproof lock also remains activated when the appliance is in standby mode and in the event of a power cut.

13.2 Deactivating the childproof lock

Requirement: To deactivate the childproof lock, the appliance must be switched on.

- ▶ Press and hold 🗝 3 sec. for approx. 3 seconds.
- ✓ so goes out on the display.

14 Crease-removal function

In order to reduce creasing and airborne odours, such as cigarette smoke, you can use a programme

with a crease-removal function for any dry laundry that has not been worn for long or at all.

14.1 Starting a programme with the crease-removal function

Note

Wash items of laundry that have traces of sweat, perfume or deodorant before wearing them again. Do not use dryer cleaning sets. Do not use a programme with the crease-removal function for the following fabrics:

- Wool, leather and viscose
- Fabrics with parts made from metal, wood or plastic
- Waxed jackets and oilskin jackets

Requirement: The laundry is placed in the appliance. → Page 30

- 1. Set a programme with crease-removal function. → Page 25
- 2. If required, adjust the set programme with crease-removal function. → Page 21
- **3.** Start the programme. \rightarrow *Page 30* If the water tank is empty, the display shows: 4.
 - → "Filling the water tank", Page 35
 - The average programme duration of the crease-removal function is approx. 45 minutes and may be longer or shorter depending on the ambient temperature.
- After the programme has ended, the display shows: "End ".
- **4.** Remove the laundry. → Page 30 The results of the crease-removal function may vary depending on the type of fabric, the amount of laundry and the selected programme.

- Remove the laundry immediately after the programme has ended to prevent creasing.
- 5. Hang up the items of laundry and pull them into shape.

14.2 Filling the water tank

Your appliance removes the creases from rarely worn clothing using cold mains water. If the display shows a notification while the appliance is in operation, fill the water tank.

ATTENTION!

Operating the appliance with water that is dirty or too hot may result in damage to the appliance.


- Only fill the water tank with cold drinking water.
- Never use condensed water, distilled water, additives or descaler for the crease-removal function.

Requirements

- A programme with the crease-removal function has been started. → Page 35
- The display shows: ◊.
- The condensation container → Page 32 is removed from the appliance.

en Wool basket

 Add approx. 180 ml cold mains water through the front opening, using the water jug provided.



Observe the mark for filling the water tank next to the front opening. If \lozenge does not go out on the display, align the appliance correctly. \rightarrow "Aligning the appliance", Page 16

- ✓ ogoes out on the display.
- Insert the condensation container.→ Page 33
- 3. Start the programme. → Page 30


15 Wool basket

Use the wool basket to gently dry delicate fabrics, soft toys or sports shoes in a stationary position.


15.1 Inserting the wool basket

Open the door.
 Ensure that the drum is empty.

Insert the feet of the wool basket into the holes from the door opening.



Insert the tab on the front of the wool basket into the upper hooks.



15.2 Starting a programme with the wool basket

ATTENTION!


If items of laundry in the wool basket touch the rotating drum or the ribs of the drum, the laundry may cause material damage and damage to the appliance.

Place the items of laundry in the insert or wool basket such that they do not touch the drum or the ribs of the drum.

Requirement: The wool basket is inserted into the appliance.

→ Page 36

1. Place the laundry into the wool basket, either directly or using the insert. → Page 37



- 2. Close the door.
- 3. Set a programme that is suitable for drving with the wool basket.

Observe the programme description. → Page 26

4. If required, adjust the duration of the programme.

Observe the recommended programme duration for items of laundry in the wool basket:

Laundry item	Programme duration in hours:minutes			
Thin woollen pullover	Approx. 1:20			
Thick woollen pullover	Approx. 1:30 - 3:00			
Skirt	Approx. 1:00 - 1:30			
Trousers	Approx. 1:00 - 1:30			
Gloves	Approx. 0:30			
Sports shoes	Approx. 1:30/ max. 2:00 with airing			

Tip: Increase the programme duration for thick or multi-layered items of laundry.

5. Start the programme. → Page 30

6. Remove the wool basket once the programme has ended.

15.3 Examples of how to use the wool basket

ATTENTION!

If items of laundry in the wool basket touch the rotating drum or the ribs of the drum, the laundry may cause material damage and damage to the appliance.

► Place the items of laundry in the insert or wool basket such that they do not touch the drum or the ribs of the drum

Trousers or skirt

Use Place the items

of laundry unfolded into the insert.

Note: Spin the laundry before drying.

Pullover

Example



Example

Sports shoes




Lift the tongues of the shoes. Remove the insoles or heel cushions. Place a rolled-u hand towel in the

Use

cushions.
Place a rolled-up hand towel in the wool basket to create an inclined surface.
Place the shoes on the towel with the heels facing down.

Note: Do not use the insert. Do not dry leather shoes or shoes with leather parts.

Soft toys



Place the soft toy in the wool basket.

Note: Do not use the insert. If you place numerous or small soft toys in the wool basket, make sure they do not fall out.

16 Home Connect

This appliance is network-capable. Connecting your appliance to a mobile device lets you control its functions via the Home Connect app, adjust its basic settings and monitor its operating status.

The Home Connect services are not available in every country. The availability of the Home Connect function depends on the availability of Home Connect services in your country. You can find information about this at: www.home-connect.com.

The Home Connect app guides you through the entire login process. Follow the instructions in the Home Connect app to configure the settings.

Tip: Please also follow the instructions in the Home Connect app.

Notes

- Please note the safety precautions in this instruction manual and make sure that they are also observed when operating the appliance via the Home Connect app. → "Safety", Page 4
- Operating the appliance on the appliance itself always takes priority.
 During this time it is not possible to operate the appliance using the Home Connect app.

16.1 Setting up the Home Connect app

- Install the Home Connect app on your mobile device.
- 2 Start the Home Connect app and set up access for Home Connect. The Home Connect app guides you through the entire login process.

16.2 Setting up Home Connect

Requirements

- The Home Connect app has been installed on your mobile device.
- The appliance is receiving signals from the WLAN home network (Wi-Fi) at its installation location.
- Press and hold Remote Start ☐ for approx. 3 seconds.
- Follow the instructions in the Home Connect app.

16.3 Activating Wi-Fi on the appliance

- 1. Press and hold Remote Start for approx. 3 seconds.
- **2.** Press **Remote Start** \Box repeatedly until the display shows "oFF".
- **3.** Press **□** to activate the Wi-Fi.
- ✓ The display shows "on".

Notes

- If the Wi-Fi is activated, the display alternately shows "on" and the signal strength of the Wi-Fi connection.
- To exit the Home Connect settings, press and hold Remote Start for approx. 3 seconds.

16.4 Deactivating Wi-Fi on the appliance

- 1. Press and hold Remote Start for approx. 3 seconds.
- **2.** Press **Remote Start** \Box repeatedly until the display shows "on".
- **3.** Press $\mathbb{I} \triangleright$ to deactivate the Wi-Fi.
- ✓ The display shows "oFF".

Note: To exit the Home Connect settings, press and hold Remote Start for approx. 3 seconds.

16.5 Installing the software update

Note: If a software update is available, a message appears in the Home Connect app.

- ➤ To install the software update, follow the instructions in the Home Connect app.
- ▼ The control panel is partially locked during the installation.

✓ In the event of a malfunction, installation may take up to 40 minutes. Do not reset the network settings or the appliance to the factory settings.

16.6 Resetting the appliance network settings

- 1. Press and hold Remote Start for approx. 3 seconds.
- 2. Press Remote Start repeatedly until the display shows "rES".
- **3.** Press and hold \mathbb{D} for approx. 3 seconds.
- ✓ The network settings are reset.

16.7 Remote start

Enable the appliance for remote start via the Home Connect app.

Note

Remote start will be deactivated in the following circumstances:

- The appliance door is opened.
- $|| \triangleright ||$ is pressed.
- Remote Start 🗅 is pressed.
- Following a power cut.

Activating remote start

Requirements

- The appliance door is closed.
- The refresher tank is not empty.
- ▶ Press Remote Start □ .
- ✓ □ lights up and the appliance is enabled for remote start via the Home Connect app.

Deactivating remote start

- ▶ Press Remote Start □.

16.8 Intelligent programme recommendation

When you activate the intelligent programme recommendation, your appliance recommends a suitable programme for drying the laundry once you have washed your laundry in the washing machine.

Intelligent programme recommendation

Requirements

- Your washing machine has the Home Connect function.
- Your washing machine and your dryer must be connected to your home network and registered in your Home Connect app.
- 1. Press intelligentDry.
- The appliance detects a suitable programme. To cancel the process, set a different programme or switch the appliance to standby mode.
- ✓ If the appliance finds a suitable programme, the display for the programme lights up and the programme information is displayed.
- If the appliance does not find a suitable programme, a signal tone sounds and the display shows "-
- **2.** Press **□ >** .

16.9 Remote diagnostics

Customer Service can use Remote Diagnostics to access your appliance if you contact them, have your appliance connected to the Home Connect server and if Remote Diagnostics is available in the country in which you are using the appliance.

Tip: For further information and details about the availability of Remote Diagnostics in your country, please

visit the service/support section of vour local website: www.home-connect.com.

16.10 Data protection

Please see the information on data protection.

The first time your appliance is registered on a home network connected to the Internet, your appliance will transmit the following types of data to the Home Connect server (initial registration):

- Unique appliance identification (consisting of appliance codes as well as the MAC address of the Wi-Fi communication module installed).
- Security certificate of the Wi-Fi communication module (to ensure a secure data connection).
- The current software and hardware version of your appliance.
- Status of any previous reset to factory settings.

This initial registration prepares the Home Connect functions for use and is only required when you want to use the Home Connect functions for the first time

Note: Please note that the Home Connect functions can only be utilised with the Home Connect app. Information on data protection can be retrieved in the Home Connect app.

17 Basic settings

You can configure the basic settings for your appliance to meet your needs.


Note: You can also adjust the the basic settings in the Home Connect app.

17.1 Overview of the basic settings

Note: Additional functions may be available as a result of software updates.

→ "Installing the software update", Page 39

If a software update is available, you can find further information in the Home Connect app.



Programme selector with programme positions

- Set the volume of the signal at the end of the programme: 0 (off) to 4 (very loud)
- Set the volume of the signal tone emitted when the buttons are pressed: 0 (off) to 4 (very loud)
- 3 Set the display brightness: 1 (low) to 4 (very high)
- Adjust the dryness level → Page 33: 0 (dry) to 3 (driest)
- Start the basic (CP1) or intensive (CP2) appliance care programme. → "Appliance care", Page 41
- Display the number of started programmes (PC).
- Restore the appliance to the factory settings (rES).

17.2 Changing the basic settings

- 1. To call up the basic settings, press Basic Settings .
- 2. Use the programme selector to select the required basic setting. → Page 41
- 3. Adjust the basic setting:
 - To change the value, press ^ or 🗸
 - To reset the appliance to the factory settings, press and hold
- **4.** To exit the basic settings, press Basic Settings .

18 Appliance care

The appliance offers cleaning programmes for basic and intensive appliance care.

18.1 Preparing for appliance care

Preparing the appliance for the appliance care programme

Prepare the appliance before running the appliance care programme.


Requirements

- The drum is empty.
- The appliance is in standby mode.
- 1. Clean the fluff filter → Page 31.
- 2. Pull out the condensation container horizontally and empty it. → Page 33

Preparing the condensation container for the appliance care programme

If you drain the condensation from the appliance using the drain hose, prepare the condensation container before running the appliance care programme.

 Remove the stopper from the recess in the top ① and insert it in the underside ②.



Clean the filter in the condensation container.

18.2 Calling up the appliance care programme

Requirement: The appliance care programme is ready. → *Page 41*

- Press ७.
 The switch-on process takes a few seconds.
- 2. Press Basic Settings .
- 3. Set the programme to position 5.
- ▼ "CP1" and the programme duration alternate on the display.

18.3 Running the basic appliance care programme

To remove light dirt deposits in the appliance, you can run the basic appliance care programme.

Notes

- The basic appliance care programme runs for approximately 1 hour.
- After a lengthy period of use, the appliance reminds you to run the basic appliance care programme. Before the programme starts or after the programme has ended, the display shows the notification "CArE". This notification appears repeatedly until you have run the basic appliance care programme through to the end.

Requirements

- The appliance care programme is ready. → Page 41
- The appliance care programme is called up. → Page 42
- Pour approx. 1.5 litres of hot mains water into the condensation container.
 - Hold the filled condensation container level so that no liquid spills out.
- 2. Insert the condensation container so that it locks into place.
- **3.** Press **1 1 1 .**
- The appliance care programme starts and a signal tone sounds.
- "End " appears on the display and a signal tone sounds once the appliance care programme has ended.
- Pull out the condensation container horizontally and empty it.
- If you drain the condensation using the drain hose, remove the stopper from the underside of the condens-

- ation container land insert it into the recess in the top of the condensation container. → Page 42
- 6. Insert the condensation container so that it locks into place.
- 7. Put the appliance into standby mode. → Page 31

18.4 Running the intensive appliance care pro**aramme**

You can run the intensive appliance care programme to remove any stubborn dirt deposits in the appliance and odours after a downtime of more than one month.

Notes

- The intensive appliance care programme runs for approximately 4 hours and must not be cancelled.
- When you run the intensive appliance care programme, you need the original appliance care product → Page 28.

Starting the intensive appliance care programme

Requirements

- The appliance care programme is ready. → Page 41
- The appliance care programme is called up. → Page 42
- 1. Press ✓.
- tion alternate on the display.
- 2. Pour a bottle of the appliance care product and approx. 1.5 litres of hot mains water into the condensation container.
 - Hold the filled condensation container level so that no liquid spills out.
- 3. Insert the condensation container so that it locks into place.
- **4.** Press **1 >** .

- ✓ The appliance care programme starts and a signal tone sounds.
- ✓ After around 3 hours, the appliance pauses the appliance care programme and the remaining programme duration flashes on the display.
- 5. Pull out the condensation container horizontally and empty it.
- **6.** Pour approx. 1.5 litres of hot mains water into the condensation container.
- **7.** Carefully swivel the condensation container horizontally and empty it to rinse out any remaining appliance care product.

Continuing the intensive appliance care programme

- 1. Pour approx. 1.5 litres of hot mains water into the condensation container.
 - Hold the filled condensation container level so that no liquid spills
- Insert the condensation container so that it locks into place.
- **3.** Press **1 1 1 .** .
- ▼ The appliance care programme continues.
- ✓ "End " appears on the display and a signal tone sounds once the appliance care programme has ended.
- 4. Pull out the condensation container horizontally and empty it.
- 5. If you drain the condensation using the drain hose, remove the stopper from the underside of the condensation container land insert it into the recess in the top of the condensation container. → Page 42
- 6. Insert the condensation container so that it locks into place.
- **7.** Put the appliance into standby mode. → Page 31

19 Cleaning and servicina

To keep your appliance working efficiently for a long time, it is important to clean and maintain it carefully.

19.1 Moisture sensor

The moisture sensor in this appliance measures how damp the laundry is during the drying cycle. The appliance changes the duration of the automatic programme depending on the residual moisture in the laundry.

Cleaning the moisture sensor

Over time, residue from limescale, detergents and care products can build up on the moisture sensor. Clean the moisture sensor regularly.


ATTENTION!

Hard or rough objects may damage the moisture sensor.

▶ Do not use hard or rough objects, abrasive cleaning products or steel wool for cleaning.

Note: If you do not clean the appliance as described, the appliance's functionality may be impaired.

- 1. Open the door.
- 2. Clean the moisture sensor with a sponge.




19.2 Condensation container filter

During drying, fluff from the laundry gets into the condensation. The filter in the condensation container protects the appliance from fluff.


Clean the filter for the condensation tank.

The filter is cleaned automatically when the condensation container is emptied. Check the filter regularly and clean the filter if it is dirty.

- 1. Empty the condensation container. → Page 33
- 2. Remove the filter.



- 3. Clean the filter under warm, running water or in the dishwasher.
- 4. Slide in the filter as far as it will go.



5. Insert the condensation container. → Page 33

20 Troubleshooting

You can rectify minor faults on your appliance yourself. Read the troubleshooting information before contacting after-sales service. This will avoid unnecessary costs.

. WARNING

Risk of electric shock!

Improper repairs are dangerous.

- ► Never make any technical modifications to the appliance or its features.
- Repairs to the appliance should only be carried out by trained specialist staff.
- ► Only use genuine spare parts when repairing the appliance.
- ▶ If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

Fault	Cause and troubleshooting		
The display goes out and $\mathbb{I} \triangleright$ flashes.	Energy-saving mode is active ► Press II ▷.		
"Hot" and the drum rotates.	Not a fault. The cooling process is active. No action required.		
	Note: Do not change the programme during the cooling process. The cooling process takes up to 10 minutes.		
and programme terminated.	The condensation container is full. ► Empty the condensation container. → Page 33		
	The water outlet hose is not connected correctly, or is kinked or trapped. ► Check the installation of the water outlet hose. → Page 13		
	Water outlet hose is blocked. ► Rinse the water outlet hose with tap water.		
	The filter for the condensation tank is soiled. ► Clean the filter for the condensation container. → Page 44		
"CArE"	The basic appliance care programme should be run. ► Run the basic appliance care programme → Page 41.		
is a second of the second of t	Fluff filter is soiled. ► Clean the fluff filter. → Page 31		

Fault	Cause and troubleshooting
\bigcirc_{δ}	The water tank for the crease-removal function is empty. ► Fill the water tank. → Page 35
The display and buttons do not respond.	Software fault. 1. To restart the appliance, press and hold \circ for approximately 5 seconds. 2. If the fault occurs again, disconnect the appliance from the power supply for at least 30 seconds. Unplug the appliance from the mains or switch off the circuit breaker in the fuse box.
Home Connect is not working properly.	Different causes are possible. 1. Reset the appliance network settings. → Page 39 2. Set up Home Connect again. → Page 38 Go to www.home-connect.com.
Water overflows when filling the water tank.	The water tank is completely full. No action required. Note: The overflowing water is harmless. Do not pour
	any more water into the water tank. The water tank filter is soiled. Clean the water tank filter.
The programme does not start.	Childproof lock is activated. ► Deactivate the childproof lock. → Page 34
	Ready In is activated. ➤ Check whether Ready In is activated. → Page 24
The length of the programme changes during the drying cycle.	Not a fault. The programme sequence is optimised electronically. No action required.
The drying time is too long.	Fluff filter is soiled. ► Clean the fluff filter. → Page 31
	The ambient temperature is lower than 15 °C or higher than 30 °C. ► Ensure that the ambient temperature is between 15 °C and 30 °C.
	The air circulation at the appliance's installation location is insufficient. • Ventilate the appliance's installation location.
	Insufficient condensation for the automatic self-cleaning function when permanently drying small loads of laundry or when permanently using the crease-removal function.

Fault	Course and troublesheating			
The drying time is too	Cause and troubleshooting ➤ Regularly dry a load weighing more than 3 kg of			
long.	damp laundry until the programme ends.			
	 The appliance's ventilation opening is blocked. Ensure that the ventilation opening of the appliance is kept clear. 			
	 Heat exchanger is soiled. Run the basic appliance care programme → Page 41. 			
The crease-removal function takes too long.	A low ambient temperature extends the duration of the crease-removal function. No action required.			
Humming, whirring or pumping noises.	Not a fault. The compressor, compressor ventilation or condensation pump is active. No action required.			
The laundry is too damp.	The selected programme is unsuitable for the type of fabric. ► Set a time programme for subsequent drying. → Page 26			
	The load is too large. ► Observe the programme's maximum load capacity. → Page 25			
	After the end of the programme, warm laundry feels damper than it actually is.1. Remove the laundry from the drum as soon as the drying programme has finished.2. Spread the items of laundry for cooling.			
	The selected dryness level is unsuitable. ► Change the dryness level. → Page 34			
	The dryness level is not adjusted. ► Adjust the dryness level. → Page 34			
	The load is too small. ► Set a time programme for subsequent drying. → Page 26			
	The moisture sensor is dirty. ► Clean the moisture sensor. → Page 44			
	The appliance has interrupted the drying process due to the condensation container being full. ► Empty the condensation container. → Page 33			

en Troubleshooting

Fault	Cause and troubleshooting					
Creasing.	The selected programme is unsuitable for the type of fabric.					
	► Set a suitable programme. → Page 25					
	The load is unsuitable.					
	 Observe the programme's maximum load capacity. → Page 25 					
	Prepare the laundry. → Page 29					
	The laundry lies in the drum for too long after drying.1. Remove the laundry from the drum as soon as the drying programme has finished.2. Spread the items of laundry for cooling.					
	Easy Care fabrics have been dried for too long. ► Change or adjust the dryness level. → Page 33					
	The crease-reduction function is not activated. ► Activate the crease-reduction function. → Page 21					
Water is leaking from the appliance.	Appliance is not correctly aligned. ► Align the appliance. → Page 16					
	Water outlet hose is not connected correctly. ► Check the installation of the water outlet hose. → Page 13					
Condensation collects in the condensation container despite the water outlet hose being connected.	Not a fault. The remaining volume of condensation may remain in the condensation container. No action required.					
	Water outlet hose is not connected correctly. ► Check the installation of the water outlet hose. → Page 13					
Odours have formed in the appliance.	Stubborn dirt in the appliance or an extended appliance downtime of more than one month. ► Run the intensive appliance care programme. → Page 41					

21 Transportation, storage and disposal

21.1 Disposing of old appliance

Valuable raw materials can be reused by recycling.

WARNING Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- Do not install the appliance behind a door as this may obstruct the appliance door or prevent it from openina.
- With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.

⚠ WARNING Risk of fire!

The refrigerant R290 used in this appliance is environmentally friendly. It is however flammable and may ignite if appliances are not disposed of properly.

- Dispose of the appliance properly.
- Do not damage the tubing of the refrigerant circuit.
- 1. Unplug the appliance from the mains.
- 2. Cut through the power cord.
- 3. Dispose of the appliance in an environmentally friendly manner. Information about current disposal methods are available from your specialist dealer or local authority.



This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE). The auideline determines the framework for the return and recycling of used appliances as applicable throughout the FU.

22 Customer Service

Function-relevant genuine spare parts according to the corresponding Ecodesign Order can be obtained from Customer Service for a period of at least 10 years from the date on which your appliance was placed on the market within the European Economic Area.

Note: Under the terms of the manufacturer's warranty the use of Customer Service is free of charge.

Detailed information on the warranty period and terms of warranty in your country is available from our aftersales service, your retailer or on our website.

If you contact Customer Service, you will require the product number (E-Nr.), the production number (FD) and the consecutive numbering (Z-Nr.) of your appliance.

The contact details for Customer Service can be found in the enclosed Customer Service directory or on our website.

22.1 Product number (E-Nr.), production number (FD) and consecutive numbering (Z-Nr.)

You can find the product number (E-Nr.), the production number (FD) and the consecutive numbering (Z-Nr.) on the appliance's rating plate.

Depending on the model, the rating plate is located:

- On the inside of the door.
- On the inside of the maintenance flap.
- On the rear of the appliance.

Make a note of your appliance's details and the Customer Service telephone number to find them again quickly.

23 Consumption values

The **Cottons Eco** programme (denoted by the arrow symbol) is suitable for drying cotton laundry with a normal dampness level, and is the most efficient programme for drying damp cotton laundry in terms of combined energy consumption. The consumption values for this programme that are declared on the energy label refer to a moisture content of the laundry of 60%.

The values specified for other programmes are indicative only and were determined in accordance with the applicable standard EN61121.

The actual values may deviate from the indicated values depending on the type of fabric, composition of laundry to be dried, residual moisture in the fabric, set degree of dryness, amount of laundry being loaded, environmental conditions and the activation of additional functions. The expected programme dura-

tion/"Ready in" time that is shown on the appliance display when selecting the programme is based on the spin speed in the washing machine of 1000 rpm when the appliance is delivered.

Programme	Final mois- ture level (%)	Load (kg)	Spin speed (rpm)	Initial mois- ture level (%)	Pro- gramm e dura- tion (h:min)	Energy con- sump- tion (kWh/ cycle)
Cottons + II Cupboard Dry	-1.5	9.0	1400	50	4:07	1.35
Cottons + II Cupboard Dry	-1.5	4.5	1400	50	2:57	0.89
Cottons + ⊞ Cup- board Dry	-1.5	9.0	1000	60	4:36	1.55
Cottons + II Cup- board Dry	-1.5	4.5	1000	60	3:13	0.98
Cottons + II Cup- board Dry	-1.5	9.0	800	70	5:05	1.75
Cottons + 🗉 Cup- board Dry	-1.5	4.5	800	70	3:29	1.08
Cottons Eco C	0.0	9.0	1400	50	3:49	1.24
Cottons Eco C	0.0	4.5	1400	50	2:18	0.70
Cottons Eco C	0.0	9.0	1000	60	4:20	1.44
Cottons Eco C	0.0	4.5	1000	60	2:36	0.80
Cottons Eco C	0.0	9.0	800	70	4:51	1.64
Cottons Eco C	0.0	4.5	800	70	2:54	0.90

Programme	Final mois- ture level	Load (kg)	Spin speed (rpm)	Initial mois- ture level	Pro- gramm e dura- tion	Energy con- sump- tion
	(%)			(%)	(h:min)	(kWh/ cycle)
Cottons + 🕮 Iron Dry	12.0	9.0	1400	50	2:38	0.81
Cottons + 🕮 Iron Dry	12.0	4.5	1400	50	1:40	0.48
Cottons + 🕮 Iron Dry	12.0	9.0	1000	60	3:08	1.01
Cottons + 🕮 Iron Dry	12.0	4.5	1000	60	1:56	0.58
Cottons + 🕮 Iron Dry	12.0	9.0	800	70	3:37	1.21
Cottons + 🖴 Iron Dry	12.0	4.5	800	70	2:13	0.68
Easy Care + ⊞ Cupboard Dry	2.0	3.5	800	40	1:19	0.37
Easy Care + ⊞ Cupboard Dry	2.0	3.5	600	50	1:34	0.45

24 Technica	l data
Appliance height	84.2 cm
Appliance width	59.8 cm
Appliance depth	61.3 cm
Appliance depth with door closed	66.5 cm
Appliance depth with door open	110.5 cm
Weight	56.4 kg
Maximum load	9.0 kg
Mains voltage	220-240 V, 50 Hz
■ Minimum installation protection	10 A
Nominal power	600 W

Power consumption	Standby mode: 0.30 WLeft-on mode: 0.30 W
Ambient temperature	Minimum:5 °CMaximum:35 °C
Length of the power cord	180 cm

This product contains light sources from energy efficiency class F. These light sources are available as a spare part and must only be replaced by trained specialist staff.

More information about your model can be found online at https:// eprel.ec.europa.eu/gr/1782061¹. This web address is linked to the official EU EPREL product database.

25 Declaration of Conformity

BSH Hausgeräte GmbH hereby declares that the appliance with Home Connect functionality conforms to the essential requirements and other relevant provisions of Directive 2014/53/FU.

A detailed RFD Declaration of Conformity can be found online at siemens-home.bsh-group.com among the additional documents on the product page for your appliance.



Hereby, BSH Hausgeräte GmbH declares that the appliance with Home Connect functionality is in compliance with relevant statutory requirements.2

A detailed Declaration of Conformity can be found online at siemenshome.bsh-group.com/uk/ among the additional documents on the product page for your appliance.2

UK

2.4 GHz band (2400-2483.5 MHz): Max. 100 mW 5-GHz band (5150-5350 MHz + 5470-5725 MHz): max. 150 mW

	BE	BG	CZ	DK	DE	EE	IE	EL	ES
	FR	HR	IT	CY	LI	LV	LT	LU	HU
	MT	NL	AT	PL	PT	RO	SI	SK	FI
	SE	NO	CH	TR	IS	UK (NI)			
5 GHz WLAN (Wi-Fi): For indoor use only.									
AL	ВА	M	D	ME	MK	RS	UK		UA
5 GHz WLAN (Wi-Fi): For indoor use only.									

25.1 Statement of Compliance for Great Britain

The full Statement of Compliance according to the Product Security and Telecommunications Infrastructure (Security Requirements for Relevant Connectable Products) Regulations 2023 can be found online at www.siemens-home.bsh-group.com/

uk/home among the additional documents on the product page for your appliance.

Product type

This statement of compliance covers the products described in this information for use whose model identifier group is seen on the title page. The full model identifier is made up of the characters before the slash in the

Only applies to countries in the European Economic Area

Only applies to Great Britain

en Declaration of Conformity

product number (E no.) which can be found on the rating plate. Alternatively, you can also find the model identifier in the first line of the UK Energy Label.

Name and address of manufacturer BSH Hausgeräte GmbH, Carl-Wery-Strasse 34, 81739 München, Germany

This statement of compliance is prepared by the manufacturer.

The manufacturer, BSH Hausgeräte GmbH deems that it has complied with

- provision 5.1-1 of ETSI EN 303 645 v2.1.1 and, where relevant, provision 5.1-2 of ETSI EN 303 645 v2.1.1;
- provision 5.2-1 of ETSI EN 303 645 v2.1.1:
- provision 5.3-13 of ETSI EN 303 645 v2.1.1.

Support period

BSH Hausgeräte GmbH will provide security updates that are necessary to maintain the main functions free of charge until at least 28/02/2034.



EN Manufactured by BSH Hausgeräte GmbH under the trademark licence of Siemens AG

Valid within Great Britain: Imported to Great Britain by BSH Home Appliances Ltd. Grand Union House Old Wolverton Road Wolverton, Milton Keynes MK12 5PT United Kingdom

BSH Hausgeräte GmbH

Carl-Wery-Straße 34 81739 München, GERMANY siemens-home.bsh-group.com



9001931242

(040716)