SIEMENS

ED8..HWC..

Induction hob



EN Information for Use





You can find additional information and explanations online. Scan the QR code on the title page.



Table of contents

1	Safety 2	16	Childproof lock	. 11
2	Avoiding material damage 4	17	Pause	. 12
3	Environmental protection and saving energy 5	18	Individual safety switch-off	. 12
4	Suitable cookware 5	19	Basic settings	. 12
5	Familiarising yourself with your appliance 6	20	Cookware test	. 13
6	Before using for the first time 7	21	Home Connect	. 14
7	Software update 7	22	Hob-based hood control	. 15
8	Basic operation 8	23	Cleaning and servicing	. 16
9	Favourite button 9	24	Troubleshooting	. 17
10	combiZone9	25	Disposal	. 19
11	Time-setting options9	26	Customer Service	. 19
12	powerBoost 10	27	Information regarding Free and Open Source	
13	shortBoost 10		Software	19
14	Keep-warm function 11	28	Declaration of Conformity	
	fryingSensor 11	29	Test dishes	. 20

▲ 1 Safety

Observe the following safety instructions.

1.1 General information

- Read this instruction manual carefully.
- Keep the instructions, the appliance and the product information safe for future reference or for the next owner.
- Do not connect the appliance if it has been damaged in transit.

1.2 Intended use

Only a licensed professional may connect appliances without plugs. Damage caused by incorrect connection is not covered under the warrantv.

The appliance can only be used safely if it is correctly installed according to the safety instructions. The installer is responsible for ensuring that the appliance works perfectly at its installation location.

Only use this appliance:

■ To prepare meals and drinks.

- Under supervision. Never leave the appliance unattended when cooking for short periods.
- in private households and in enclosed spaces in a domestic environment.
- Up to an altitude of 4000 m above sea level. Do not use the appliance:
- With an external timer or a separate remote control. This does not apply if operation with appliances included in EN 50615 is switched off.

If you wear an active implantable medical device (e.g. a pacemaker or defibrillator), check with your doctor that it complies with Council Directive 90/385/EEC of 20th June 1990, EN 45502-2-1 and EN 45502-2-2, and that it has been chosen, implanted and programmed in accordance with VDE-AR-E 2750-10. If these conditions are satisfied, and if, in addition, non-metal cooking utensils and cookware with non-metal handles are used, it is safe to use this induction hob as intended.

1.3 Restriction on user group

This appliance may be used by children aged 8 or over and by people who have reduced physical, sensory or mental abilities or inadequate experience and/or knowledge, provided that they are supervised or have been instructed on how to use the appliance safely and have understood the resulting dangers.

Do not let children play with the appliance. Children must not perform cleaning or user maintenance unless they are at least 15 years old and are being supervised.

Keep children under the age of 8 years away from the appliance and power cable.

1.4 Safe use

Leaving fat or oil cooking on an unattended hob can be dangerous and may lead to fires.

- Never leave hot oil or fat unattended.
- Never attempt to extinguish a fire using water; instead, switch off the appliance and then cover with a lid or a fire blanket.

The cooking surface becomes very hot.

- Never place flammable objects on the cooking surface or in its immediate vicinity.
- ► Never place objects on the cooking surface. The appliance will become hot.
- ► Do not keep combustible objects or aerosol cans in drawers directly underneath the hob. Hob covers can cause accidents, for example due to overheating, catching fire or materials shattering.
- ▶ Do not use hob covers.

After every use, switch off the hob using the main switch.

▶ Do not wait until the hob turns off automatically as there are no longer any pots and pans on it.

Food may catch fire.

The cooking process must be monitored. A short process must be monitored continuously.

△ WARNING – Risk of burns!

The appliance and its parts that can be touched become hot during use, particularly the hob surround, if fitted.

- ► Caution should be exercised here in order to avoid touching heating elements.
- ► Young children under 8 years of age must be kept away from the appliance.

Hob guards may cause accidents.

► Never use hob guards.

The appliance becomes hot during operation.

► Allow the appliance to cool down before cleaning.

Metal objects on the hob quickly become very hot.

► Never place metal objects (such as knives, forks, spoons and lids) on the hob.

⚠ WARNING – Risk of electric shock! Improper repairs are dangerous.

- ► Repairs to the appliance should only be carried out by trained specialist staff.
- ► Only use genuine spare parts when repairing the appliance.
- ▶ If the power cord or the appliance power cable of this appliance is damaged, it must be replaced with a special power cord or special appliance power cable, which is available from the manufacturer or its Customer Service.
- ► If the power cord of this appliance is damaged, it must be replaced by trained specialist staff.

If the appliance or the power cord is damaged, this is dangerous.

- ▶ Never operate a damaged appliance.
- ▶ If the surface is cracked, you must switch off the appliance in order to prevent a possible electrical shock. To do this, switch off the appliance via the fuse in the fuse box rather than at the main switch.
- Never pull on the power cord to unplug the appliance. Always unplug the appliance at the mains.
- ► If the appliance or the power cable is damaged, immediately switch off the fuse in the fuse box.
- ► Call customer service. → Page 19
 An ingress of moisture can cause an electric shock.
- ► Do not use steam- or high-pressure cleaners to clean the appliance.

The insulation on cables of electrical appliances may melt if it touches hot parts of the appliance.

Never bring electrical appliance cables into contact with hot parts of the appliance.

If metallic objects come into contact with the fan that is located on the underside of the hob, this may cause an electric shock.

► Do not store long, pointed metallic objects in the drawers below the hob.

Saucepans may suddenly jump due to liquid between the saucepan base and the hotplate.

- Always keep hotplates and saucepan bases
- ► Never use icy-cold cookware that has been in the freezer.

When cooking in a bain marie, the hob and cooking container could shatter due to overheating.

- ► The cooking container in the bain marie must not directly touch the bottom of the water-filled pot.
- ► Only use heat-resistant cookware.

An appliance with a cracked or broken surface can cause cuts.

 Do not use the appliance if it has a cracked or broken surface.

Children may put packaging material over their heads or wrap themselves up in it and suffocate.

- ► Keep packaging material away from chil-
- Do not let children play with packaging ma-

Children may breathe in or swallow small parts, causing them to suffocate.

- ► Keep small parts away from children.
- Do not let children play with small parts.

2 Avoiding material damage

This is where you can find the most common causes of damage and tips on how to avoid them.

Damage	Cause	Measure	
Stains	Unsupervised cooking process.	Monitor the cooking process.	
Stains, blisters	Spilled food, especially food with a high sugar content.	Remove immediately with a glass scraper.	
Stains, blisters or fractures in the glass	Defective cookware, cookware with melted enamel or cookware with copper or aluminium base.	Use suitable cookware that is in a good condition.	
Stains, discolouration	Unsuitable cleaning methods.	Only use cleaning agents that are suitable for glass ceramic, and only clean the hob when it is cold.	
Blisters or fractures in the glass	Knocks or falling cookware, cooking accessories or other hard or pointed objects.	When cooking, do not hit the glass or let objects fall onto the hob.	
Scratches, discolouration	Rough cookware bases or moving the cookware on the hob.	- Check the cookware. Lift the cookware when moving it.	
Scratches	Salt, sugar or sand.	Do not use the hob as a work surface or storage space.	
Damage to the appliance	Cooking with frozen cookware.	Never use frozen cookware.	
Damage to the cookware or the appliance	Cooking without contents.	Never place or heat empty cookware on a hot cooking zone.	
Glass damage	Melted material on the hot cooking zone or hot pot lid on the glass.	Do not place greaseproof paper or aluminium foil nor plastic containers or pot lids on the hob.	
Overheating	Hot cookware on the control panel or on the frame.	Never place hot cookware on these areas.	

ATTENTION

A fan is located on the underside of this hob.

- ▶ If a drawer is located on the underside of the hob, do not store any small or pointed objects, paper or tea
- towels in it. These objects may be sucked in and damage the fan or impair the cooling.
- There must be a clearance of at least 2 cm between the contents of the drawer and the fan entry point.

3 Environmental protection and saving energy

3.1 Disposing of packaging

The packaging materials are environmentally compatible and can be recycled.

 Sort the individual components by type and dispose of them separately.

3.2 Saving energy

If you follow these instructions, your appliance will use less energy.

Select the cooking zone to match the size of your pan. Centre the cookware on the hob.

Use cookware whose base diameter is the same diameter as the hotplate.

Tip: Cookware manufacturers often give the upper diameter of the saucepan. It is often larger than the base diameter.

 Unsuitable cookware or incompletely covered cooking zones consume a lot of energy.

Cover saucepans with suitable lids.

 Cooking without a lid consumes considerably more energy.

Lift lids as infrequently as possible.

✓ When you lift the lid, a lot of energy escapes.

Using a glass lid

✓ You can see into the pan through a glass lid without having to lift it.

Use pots and pans with flat bases.

✓ Uneven bases increase energy consumption.

Use cookware that is suitable for the quantity of food.

✓ Large items of cookware containing little food need more energy to heat up.

Cook with only a little water.

▼ The more water there is in the cookware, the more energy that is required to heat it up.

Turn down to a lower power level early on.

✓ If you use an ongoing power level that is too high, you will waste energy.

4 Suitable cookware

Cookware that is suitable for induction cooking must have a ferromagnetic base, i.e. it must be attracted by a magnet. The base must also match the size of the cooking zone. If cookware is not detected on a cooking zone, place this on the cooking zone with the next smallest diameter.

4.1 Size and characteristics of the cookware

To be able correctly detect the cookware, you must take the size and the material of the cookware into consideration. All cookware bases must be perfectly flat and smooth.

Use Cookware test to check whether the cookware is suitable.

→ "Cookware test", Page 13

Cookware	Materials	Properties
Recommended cook-ware	Stainless steel cookware in a sandwich design that distributes the heat well.	This cookware distributes the heat evenly, heats up quickly, and ensures that it can be detected easily.
	Ferromagnetic cookware made of enamelled steel, cast iron or special induction cookware made of stainless steel.	This cookware distributes the heat evenly, heats up quickly, and ensures that it can be detected.
Suitable	The base is not fully ferromagnetic.	If the ferromagnetic area is smaller than the base of the cookware, only the area that is ferromagnetic heats up. As a result, the heat is not distributed evenly.
	Cookware bases that contain aluminium.	These cookware bases reduce the ferromagnetic area, which means that less power is emitted to the cookware. This cookware may not be sufficiently detected or may not be detected at all, and therefore does not heat sufficiently.
Not suitable	Cookware made from normal thin steel, glass, clay, copper or aluminium.	


Notes

- Do not use adapter plates between the hob and the cookware.
- Do not heat up empty cookware and do not use cookware with a thin base, as this may become very hot.

5 Familiarising yourself with your appliance

5.1 Control panel

Individual details, such as colour and shape, may differ from the figure.



Letters	Designation
Α	Main switch
В	Control panel
С	Cooking zone

Note: Always keep the control panel clean and dry.

Tip: Do not place any cookware near the displays or buttons. The electronics may overheat.

Touch fields

When you switch on the hob, the symbols for the controls available at this time light up.

Sensor	Function
①	Main switch
_	Select a cooking zone
	Settings area
boost	powerBoost
+	Automatic linking/separating of cooking zones
<u></u>	fryingSensor
<u>(b)</u>	Timer functions

Sensor	Function
00	Pause
	Childproof lock
☆	Favourite button
<u></u>	Connectivity

Indicators/symbols

Display		Function
	 →	Switch-off timer
	1	fryingSensor
	1-9	Power levels
~		Childproof lock

Buttons in connection with Home Connect


As soon as the connection to Home Connect has been established, the following buttons and displays are available:

Sensor	Function
D	Accept settings from another appliance

If a lights up, search for further information in the Home Connect app.

5.2 Distribution of the cooking zones

The specified power has been measured with the standard pots which are described in IEC/EN 60335-2-6. The power may vary depending on the size of the cookware or cookware material.



Highest setting	
Power level 9 powerBoost	2000 W 3100 W
Power level 9 powerBoost	1600 W 2200 W
Power level 9 powerBoost	2500 W 3700 W
Power level 9 powerBoost	2500 W 3700 W
Power level 9	3600 W
	Power level 9 powerBoost Power level 9 powerBoost Power level 9 powerBoost Power level 9 powerBoost

At power level 9, the hob reaches the power indicated in the table in order to reduce the preheating times and keeps them running for a certain time, provided the other cooking zone on the same side is not in use.

5.3 Cooking zone

Before you start cooking, check whether the size of the cookware fits the cooking zone that you want to use for cooking:

Area	ea Cooking zone type		
0/8 8	Single-circuit cooking zone		
8	Combi cooking zone → Page 9		

5.4 Residual heat indicator

The hob has a residual heat indicator for each cooking zone. Do not touch the cooking zone if the residual heat indicator is lit.

Display	Meaning
Н	The cooking zone is hot.
h	The cooking zone is warm.

6 Before using for the first time

Observe the following recommendations.

6.1 Initial cleaning

Remove any leftover packaging from the hob surface and wipe the surface with a damp cloth. You can find a list of recommended detergents on the official website siemens-home.bsh-group.com.

More information on care and cleaning. → Page 16

6.2 Cooking with induction

In comparison to conventional hobs, induction technology brings with it a series of changes and has a number of benefits such as time savings when cooking and frying, energy savings as well as greater ease of cleaning and care. It also offers improved heat control as the heat is generated directly in the cookware.

6.3 Cookware

You can find a list of recommended cookware on the official website siemens-home.bsh-group.com. Further information on suitable cookware. \rightarrow *Page 5*

6.4 Setting Home Connect

When you first switch on the appliance, you will be prompted to set your home network. Flights up for a few seconds on the display panel.

To begin the connection to Home Connect, touch ? and proceed in accordance with the information in the

To end the setting, switch off the hob.

You can also adjust the Home Connect setting at a different time.

7 Software update

If the appliance is connected to Home Connect, some functions may be available with a software update.

More information on the availability of additional functions can be found on the website siemens-home.bshgroup.com

8 Basic operation

8.1 Switching on the hob

▶ Touch ①.

A signal sounds. The symbols for the cooking zones and the currently available functions light up. 2 lights up in the cooking zone displays.

✓ The hob is ready to use.

reStart

► If you switch the appliance on within four seconds of switching it off, the hob operates with the settings that were previously set.

8.2 Switching the hob off

- ► Touch ① until the displays go out.
- All cooking zones are switched off.

Note: If all of the cooking zones are switched off for longer than 59 seconds, the hob is automatically switched off.

8.3 Setting the power level in the cooking zones

The cooking zone has 17 power levels, which are displayed from 1 to 9 with intermediate values. Select the

best power level for the food and the planned cooking process.

- **1.** Touch the required cooking zone display \mathcal{C}
- ✓
 ☐ and
 ☐ get brighter.
- 2. Select the required power level in the settings area.
- ✓ The power level has been set.

Note: If no cookware is placed on the cooking zone or the pot is not suitable, the selected power level flashes. After a certain period of time, the cooking zone switches itself off.

quickStart

► If you set one or more items of cookware on any cooking zone before switching on the appliance, the hob detects this and automatically selects the cooking zone for one of the items of cookware. Then select the power level in the next 59 seconds, or the hob will switch off.

Changing the power level and switching off the cooking zone

- **1.** Select the cooking zone.
- **2.** Select the required power level or set it to \mathcal{I}
- ▼ The cooking zone's power level is changed or the cooking zone is switched off.

8.4 Cooking recommendations

The table shows which power level (_=≡) is suitable for which food. The cooking time (⊕min) may vary depending on the type, weight, thickness and quality of the food. To preheat, set power level 8-9.

	_==	() min
Melting		
Butter, honey, gelatine	1 - 2	=
Heating and keeping warm		
Boiled sausages 1	3 - 4	=
Defrosting and heating		
Spinach, frozen	3 - 4	15 - 25
Poaching, simmering		
Potato dumplings ¹	4.5 - 5.5	20 - 30
Whisked sauces, e.g. Béarnaise sauce, Hollandaise sauce	3 - 4	8 - 12
Boiling, steaming, braising		
Rice, with double the volume of water	2.5 - 3.5	15 - 30
Unpeeledboiled pots	4.5 - 5.5	25 - 35
Pasta 1	6 - 7	6 - 10
Soups	3.5 - 4.5	15 - 60
Vegetables	2.5 - 3.5	10 - 20
Stew in a pressure cooker	4.5 - 5.5	-
Stewing		
Pot roast	4 - 5	60 - 100

	_==	(5) min
Goulash ²	3 - 4	50 - 60
Braising/frying with a small amount of fat 1		
Escalope, plain or breaded	6 - 7	6 - 10
Steak (3 cm thick)	7 - 8	8 - 12
Poultry breast (2 cm thick)	5 - 6	10 - 20
Hamburgers (2 cm thick)	6 - 7	10 - 20
Fish and fish fillet, breaded	6 - 7	8 - 20
Prawns and scampi	7 - 8	4 - 10
Sautéing fresh vegetables and mushrooms	7 - 8	10 - 20
Frozen dishes, e.g. stir-fries	6 - 7	6 - 10
Omelette (cooked one after the other)	3.5 - 4.5	3 - 10
Deep-frying, 150–200 g per portion in 1–2 l oil, deep-fat fried in portions ¹		
Frozen products, e.g. chips, chicken nuggets	8 - 9	-
Vegetables, mushrooms, breaded, beer-battered or tempura	6 - 7	-

¹ Without lid

² Preheat to power level 8 - 8.5

	_==	() min
Small baked items, e.g. doughnuts, battered fruit	4 - 5	-

9 Favourite button

You can use the function to select two functions or cooking settings which can then be quickly accessed on ☆.

9.1 Assigning Favourite button functions

Requirement: Connect the appliance to Home Connect. You can find more information about this under Home Connect

- 1. To assign ☆ functions, open the Home Connect app and follow the instructions.
- 2. As soon as you have assigned the functions, you can use them:
- ✓ Function 1: Press ☆ briefly.
- ✓ Function 2: Press and hold ☆.

Note: If you have not assigned any functions, ☆ switches off once the hob is switched on.


10 combiZone


It allows two cooking zones of the same size to be combined, with the same power level being switched on in both. This is intended in particular for cooking with long cookware.

This function allows you to cook with one item of cookware that occupies one cooking zone and that can be moved from one zone to another for increased convenience. In this case, the two zones also retain the same power level and the same settings.

10.1 Positioning the cookware

Use cookware that fits into the cooking zones.





10.2 Switching on combiZone

- 1. Select one of the two cooking zones and set the power level.
- **2.** Press **₽**.
- The function is activated.

10.3 Switching off combiZone

- ► Touch #.
- ✓ The function is switched off.
- The two cooking zones once again operate independently of one another.

11 Time-setting options

Your hob has various functions for setting the cooking time:

- Switch-off timer
- Timer

The \odot button is assigned to the Switch-off timer function by default. However, you can also assign one of the above-mentioned functions to the sensor. You can change these settings via the Home Connect app or in the basic settings \rightarrow *Page 12*.

11.1 Switch-off timer

Allows you to programme a cooking time for one or more cooking zones and their automatic switch-off once the time set has elapsed.

Switching on Switch-off timer

- 1. Select the cooking zone and the required power level.
- 2. Touch O.
- ✓ I→I and □:□□ light up.
- 3. Within the next 10 seconds, set the required cooking time in the settings area.
- 4. Touch (5) to confirm.
- ▼ The cooking time begins to elapse. An audible signal sounds 1 minute before the selected time elapses. You can check the status of the food and, if required, extend the cooking time.
- Once the cooking time has elapsed, the cooking zone is switched off and a signal sounds.

Notes

If a cooking time has been programmed in a cooking zone in which the fryingSensor is activated, the programmed cooking time will start to count down as

soon as the selected temperature level has been reached.

To switch the display between the operating temperature fryingSensor and the programmed cooking time, press the selected temperature.

Changing or switching off Switch-off timer

- 1. Select the cooking zone and then touch \odot .
- 2. To switch off the function, change the cooking time or set it to \$20.

11.2 Timer

Enables a clock to be activated. This function operates independently of the cooking zones and other settings. It does not automatically switch off the cooking zones.

Switching on Timer

Requirement: Assign the function to \odot .

- 1. Press (9.
- 2. Select the required time.
- ✓ The time starts to elapse.
- A signal tone sounds and the displays flash once the time has elapsed.


Changing or switching off the Timer

- 1. Press O.
- 2. To switch off the function, change the cooking time or set it to 2:00.

12 powerBoost

The PowerBoost function enables you to heat up large quantities of water faster than when using \Im .

This function is available for all cooking zones, provided the other cooking zone on the same side is not in use. Otherwise, *b* and *g* flash on the display for the selected cooking zone. *g* is then set automatically without activating the function.



12.1 Switching on powerBoost

- 1. Select the cooking zone.
- 2. Touch boost
- ✓ The b display lights up.
- The function is activated.

12.2 Switching off powerBoost

- 1. Select the cooking zone.
- 2. Touch boost.
- ✓ The b display goes out and the cooking zone switches back to power level 3
- ✓ The function is switched off.


Note: In certain circumstances, the appliance switches this function off to protect the electronic elements inside the hob.

13 shortBoost

You can use this function to heat up pans more quickly than with 9. Do not use the powerBoost function with frying pans – this may damage the coating.

You can activate the function via Home Connect or Favourite button.

This function is available for all cooking zones, provided the other cooking zone on the same side is not in use. Otherwise, *P* and *S* flash on the display for the selected cooking zone. *S* then switches on automatically.



13.1 Recommended applications

- Do not place a lid on the pan.
- Never leave pans unattended when they are heating up.

- Only use cold pans.
- Use pans with a completely flat base. Do not use pans with a thin base.

13.2 Switching on shortBoost

Requirement: Assign the function to \diamondsuit .

- → "Favourite button", Page 9
- 1. Select the cooking zone.
- **2.** Touch ☆.
- ✔ P lights up.
- ✓ The function is activated.

13.3 Switching off shortBoost

- 1. Select the cooking zone.
- **2.** Select the power level.
- ✓ P goes out
- ✓ The function is switched off.

Note: To avoid high temperatures, this function automatically switches itself off after 30 seconds.

14 Keep-warm function

You can use this function to melt chocolate or butter, and to keep meals warm.

You can activate the function via Home Connect or Favourite button.

14.1 Switching on Keep-warm function

Requirement: Assign the function to ☆. .

- → "Favourite button", Page 9
- 1. Select the required cooking zone.

- 2. Touch ☆. L lights up.
- ✓ The function is switched on.

14.2 Switching off Keep-warm function

- 1. Select the cooking zone.
- 2. Set to 2 L goes out.
- The function is switched off.

15 fryingSensor

This function allows you to melt, prepare sauces, sauté, deep fry or fry while keeping the temperature under control.

Instead of constantly adjusting the power level during cooking, select the required target temperature once at the start. The sensors under the glass ceramic measure the temperature of the cookware and keep this constant throughout the entire cooking process.

This function is available on all cooking zones marked with this symbol 4-.

Functions	Temperature
Melting	70 - 80 °C
Preparing sauces	110 - 120 °C
Frying	140 °C
Frying	160 °C
Frying	180 - 200 °C
Frying	220 °C

15.1 Recommended cookware

Special cookware has been developed for this function, which delivers the best results.

The recommended cookware is available from customer service, specialist retailers or our online shop siemenshome.bsh-group.com.

Note: You can also use other cookware. Depending on the composition of the cookware, the achieved temperature may differ from the selected temperature level.

15.2 Switching on the fryingSensor

- 1. Place the empty cookware on a cooking zone.
- 2. Select the cooking zone.
- **3.** Press **₺**—.
- ✓ I, Ł and the preset temperature light up on the display for the selected cooking zone.
- 4. Select the temperature by swiping your finger over the settings area.
- ✓ I flashes until the set temperature is reached again.
- The selected temperature and the development of the temperature reached in the pan flash alternately until the selected temperature has been reached.
- ▼ The temperature shown on the displays is approximate and may differ from the actual temperature in the
- Once the temperature has been reached, a signal tone sounds and I as well as the temperature symbol stop flashing.
- 5. Add the frying fat and then the food to the frying pan.

Note: If you need to cook with more than 250 ml oil, add the oil and wait a few seconds before you add the

15.3 Switching off fryingSensor

► Select the cooking zone and touch ♣...

15.4 Recommendations for cooking with fryingSensor

The enclosed documentation contains a table with recommendations for cooking with fryingSensor.

16 Childproof lock

The hob is equipped with a childproof lock. You can use this to prevent children from switching on the hob.

16.1 Switching on Childproof lock

Requirement: The hob must be switched off.

- 1. To switch on the hob. touch ①.
- 2. Touch and hold II for 4 seconds.
- ✓ □ lights up for 10 seconds.
- The hob is locked

16.2 Deactivating the childproof lock

- **1.** To switch on the hob, touch ①.
- 2. Touch and hold II for 4 seconds.
- ✓ The lock is released.

16.3 Automatic childproof lock

You can also activate the childproof lock automatically every time the hob is switched off.

You can find out how to switch the function on and off in the "Basic settings" section \rightarrow Page 12.

17 Pause

You can use the function to pause and resume active cooking processes for up to 10 minutes without changing the settings you have selected.

You can switch the function on to clean the control panel, for example.

17.1 Activating the Pause function

- ► Press 🗓.
- All active cooking processes are stopped. The settings are retained.
- ▼ The function is activated.

17.2 Deactivating the Pause function

- ► Touch II.
- ▼ The function is switched off. The cooking processes continue.

Note: After approximately 10 minutes, the cooking zone automatically switches off.

18 Individual safety switch-off

Activate the safety function if one cooking zone is in operation for an extended period and you do not change any settings. The cooking zone displays FB and switches itself off.

The time depends on the selected power level.

Power level	Time
1.0 - 1.5	10 hours

Power level	Time	
2.0 - 3.5	5 hours	
4.0 - 5.0	4 hours	
5.5 - 6.5	3 hours	
7.0 - 7.5	2 hours	
8.0 - 9.0	1 hour	

Press any button to switch on the cooking zone.

19 Basic settings

You can configure the basic settings for your appliance to meet your needs.

19.1 Overview of the basic settings

Display	Setting	Value
<u> </u>	Childproof lock → "Childproof lock", Page 11	 □ - Manual.¹ I - Automatic. - Function switched off.
c 2	Audible signals	 B - The confirmation signal, the fault signal and the signal for incorrect use are deactivated. I - The fault signal is activated. 2 - The confirmation signal and the signal for incorrect use are activated. 3 - All signal tones are switched on ¹.
c 3	Volume of the audible signals	I - Quiet. Z - Medium.¹ 3 - Loud.
<u>c</u> δ	Assign one of the time-setting programme functions to ⑤ on the control panel. → "Time-setting options", Page 9	I - Switch-off timer. ¹ ≥ - Timer.
c 7	Power limitation This enables you to limit the total power of	The power is increased by 500 W with each level. \Box – Switched off. Maximum power of the hob ¹ .

¹ Factory setting

12

Display	Setting	Value
	the hob, if required, due to the circumstances of your electrical installation. Observe the regulations of the local electricity suppliers. The available settings depend on the maximum power of the hob. You can find more information on the rating plate. If the function is switched on and the hob has reached the set power limit, the required and permitted power level flashes and you cannot select a higher power level.	## 1000 W. Lowest power setting. ## 15 - 1500 W. ## 3 - 3000 W. ## 3.5 - 3500 W. ## - 4000 W. ## 45 - 4500 W. ## 5 - Maximum power of the hob.
c 8	Demo mode Demonstration mode for the hob: When you switch on the hob, dE lights up for a few seconds and the cooking zones do not heat up.	☐ - Switched off. ¹ I - Switched on.
c 12	Cookware test You can use this function to test the quality of the cookware. → "Cookware test", Page 13	☐ - Not suitable. I - Not optimal. Z - Suitable.
c 18 - c 22	cookConnect System The settings are configured based on the extractor hood model.	→ "Overview of the hood control settings", Page 16
c 0	Restoring factory settings	3 - Individual settings ¹.I - Factory settings.

19.2 To go to the basic settings

Requirement: The hob must be switched off.

- 1. To switch on the hob. touch ①.
- 2. Within the next 10 seconds, touch and hold @ for 4 seconds.

Product information	Display
Customer service directory	81.
Production number	Fd
Production number 1	02-
Production number 2	<i>0</i> 5

▼ The first four displays provide the product information. Touch (9) to view the individual displays.

- 3. Touch © to access the basic settings.
- \checkmark c ! and \Box light up as a presetting.
- **4.** Touch [©] repeatedly until the desired setting appears.
- 5. Select the required setting in the settings area.
- 6. Touch and hold \odot for 4 seconds.
- ✓ This saves the settings.

19.3 Discarding changes to the basic settings

- ► Touch ①.
- All changes are discarded and not saved.

20 Cookware test

The quality of the cookware has a major influence on the speed and the result of the cooking process. You can use this function to test the quality of the cookware.

Before the test, ensure that the diameter of the cookware base corresponds to the diameter of the cooking zone being used.

Access is via the basic settings. → Page 12

20.1 Carrying out Cookware test

1. At room temperature, place the cookware with approx. 200 ml water in the centre of the cooking zone that best fits the base of the cookware in terms of size.

- 2. Call up the basic settings and select *c* ∤ ≥.
- 3. Touch the settings area. u flashes in the cooking
- ✓ The function is switched on.
- ✓ After 20 seconds, the result appears in the cooking. zone displays.

20.2 Checking the result

You can see what the result means for the quality and speed of the cooking process in the following table.

Result

The cookware is not suitable for the cooking zone and therefore does not heat up.

¹ Factory setting

Result

- The cookware is taking longer to heat up than expected and cooking is not progressing as well as it ought to.
- The cookware is heating up correctly and cooking is progressing well.

Note: If you have any unfavourable results, reposition the cookware on a smaller cooking zone, if available. To reactivate this function, touch the settings area.

21 Home Connect

This appliance is network-capable. Connecting your appliance to a mobile device lets you control its functions via the Home Connect app, adjust its basic settings and monitor its operating status.

The Home Connect services are not available in every country. The availability of the Home Connect function depends on the availability of Home Connect services in your country. You can find information about this at: www.home-connect.com.

The Home Connect app guides you through the entire login process. Follow the instructions in the Home Connect app to configure the settings.

Tip: Please also follow the instructions in the Home Connect app.

Notes

- Please note the safety precautions in this instruction manual and make sure that they are also observed when operating the appliance via the Home Connect app.
 - → "Safety", Page 2
- Operating the appliance on the appliance itself always takes priority. During this time it is not possible to operate the appliance using the Home Connect app.
- In networked standby mode, the appliance requires a maximum of 2 W.

21.1 Setting up Home Connect

Requirements

- The appliance is connected to the power supply and is switched on.
- You have a mobile device with a current version of the iOS or Android operating system, e.g. a smartphone
- The appliance is receiving signals from the WLAN home network (Wi-Fi) at its installation location.
- The mobile device and the appliance are within range of your home network's Wi-Fi signal.
- 1. Scan the following QR code.



You can install the Home Connect app and connect your appliance via the QR code.

2. Follow the instructions in the Home Connect app.

21.2 Wi-Fi symbol 🛜

The Wi-Fi indicator on the main screen changes according to the status and quality of the connection and the availability of the Home Connect server.

়ি status	Description
Lights up steadily at half brightness.	No network connection saved.
Flashes at full brightness.	Network connection is being established.
Lights up steadily at full brightness.	Network connection saved and Wi-Fi active.
Flashes.	Network settings are reset.
Switched off.	Network not active.

21.3 Adding or removing a Wi-Fi home network

The following overview shows how to add or remove a Wi-Fi home network.

Wi-Fi home network status	Action
No Wi-Fi home network stored.	To add the Wi-Fi home network, briefly press 奈.
The Wi-Fi home network has now been saved.	To pair another appliance, press and hold 奈.
The Wi-Fi home network has now been saved.	To reset the Wi-Fi home network settings, press and hold 후. If 후 flashes, press and hold 후 again.

21.4 Switching off the network connection

- The connection to the Wi-Fi network is switched off and the network connections are disconnected.

Note: To switch the network connection back on, see . → "Adding or removing a Wi-Fi home network", Page 14

21.5 Changing settings via the Home Connect app

You can use the Home Connect app to change the settings for the cooking zones and send them to the hob.

Requirement: The hob is connected to the Wi-Fi and to the Home Connect app.

- 1. Select the setting in the Home Connect app and send it to the hob.
 - Follow the instructions in the Home Connect app. Settings that you send from the Home Connect app to the hob must be confirmed on the hob.
- As soon as cooking settings are transmitted to a cooking zone, the display starts to flash, depending on the setting.
- **2.** Press ▷ to confirm the setting.
- 3. To discard the setting, press any other touch field on the hob.

21.6 Activating Bluetooth® detection

This wireless technology enables automatic presence detection. Provided you are near the hob, you no longer need to confirm settings from your mobile device on the hob. If you send settings to a cooking zone, you can confirm these directly from your mobile device.

Requirements

- The hob is connected to the Wi-Fi and to the Home Connect app.
- The Bluetooth® system is connected to the mobile device.
- The user is near the hob.
- 1. Open the Home Connect app.
- 2. In order to set Bluetooth® detection, follow the instructions in the Home Connect app.

Note: The Bluetooth® connection is deactivated if the hob is disconnected and switches to energy-saving mode. The Bluetooth® connection can also be deactivated via the Home Connect app.

21.7 Software update

Your appliance's software can be updated using the software update function, e.g., for the purposes of optimisation, troubleshooting or security updates. To do this, you must be a registered Home Connect user, have installed the app on your mobile device and be connected to the Home Connect server. As soon as a software update is available, you will be informed via the Home Connect app and will be able to start the software update via the app. Once the update has been successfully downloaded, you can start installing it via the Home Connect app if you are in your

home network (Wi-Fi). The Home Connect app informs

you once installation is successful.

Notes

- The software update consists of two steps.
 - The first step is the download.
 - The second step is the installation on your appliance.
- You can continue to use your appliance as normal while updates are downloading. Depending on your personal settings in the app, software updates can also be set to download automatically.
- Installation takes a few minutes. You cannot use your appliance during installation.
- We recommend that you install security updates as soon as possible.

21.8 Remote diagnostics

Customer Service can use Remote Diagnostics to access your appliance if you contact them, have your appliance connected to the Home Connect server and if Remote Diagnostics is available in the country in which you are using the appliance.

Tip: For further information and details about the availability of Remote Diagnostics in your country, please visit the service/support section of your local website: www.home-connect.com.

21.9 Data protection

Please see the information on data protection.

The first time your appliance is registered on a home network connected to the Internet, your appliance will transmit the following types of data to the Home Connect server (initial registration):

- Unique appliance identification (consisting of appliance codes as well as the MAC address of the installed Wi-Fi communication module).
- Security certificate of the Wi-Fi communication module (to ensure a secure data connection).
- The current software and hardware version of your appliance.
- Status of any previous resetting to factory settings.

This initial registration prepares the Home Connect functions for use and is only required when you want to use the Home Connect functions for the first time.

Note: Please note that the Home Connect functions can only be utilised with the Home Connect app. Information on data protection can be retrieved in the Home Connect app.

22 Hob-based hood control

If the hob and the extractor hood are Home Connectcompatible, connect the appliances in the Home Connect app. To do this, connect the two appliances to Home Connect and follow the instructions in the app.

- Using the controls on the extractor hood always takes priority. It is not possible to use the hob-based hood control during this time.
- You can only connect to the extractor hood via the Home Connect app.

22.1 Controlling the extractor hood via the hob

In the basic settings for your hob, you can adjust the behaviour of your extractor hood depending on whether the hob or individual cooking zones are switched on or

You can select other settings using the controls on the

Note: If you cannot find these settings for your hob, check the settings of the extractor hood in the Home Connect app to configure the connection.

Connecting the fan

► In order to set the hood from the hob, you must first assign the hood function to Favourite button.

→ "Favourite button", Page 9

If you assign the hood function, you can choose between setting the fan, automatic mode or the hood lighting.

Setting the fan

Requirement: The function is assigned to Favourite button.

- 1. Press ☆.
- **2.** Select the required setting in the settings area. You can select the following settings:

H00	Fan off
H01	Fan setting 1
HB2	Fan setting 2
H03	Fan setting 3
HPI	Intensive mode 1

KP2	Intensive mode 2
H-R	Automatic mode

Note: Available depending on extractor hood model.

- The fan is switched on.
- 3. Press ☆ to switch off the fan.

Switching on automatic mode

You can set automatic mode using the hob's control panel.

Requirement: The function is assigned to Favourite button

- **1.** To switch on automatic mode, press \diamondsuit .
- 2. To switch off automatic mode, press ☆.

Setting the hood lighting

You can switch the hood light on and off using the hob's control panel.

Requirement: The function is assigned to Favourite button.

- **1.** To switch the lighting on, press \triangle .
- 2. To switch the lighting off, press ☆ again.

22.2 Overview of the hood control settings

In the basic settings for your hob, depending on the extractor hood model, you can adjust the behaviour of your extractor hood depending on whether the hob or individual cooking zones are switched on or off. If you cannot find these settings for your hob, check the settings of the extractor hood in the Home Connect app to configure the connection. The display shows this setting only when the appliance has been connected to the extractor hood.

Indicator	Setting	Value			
c 18	Setting for whether and how the fan switches on automatically.	Automatic fan start-up 3 – Switched off. The extractor hood must be switched on manually, if required. 1 – Switched on in manual mode. The extractor hood is switched on at a specified setting when a cooking zone is switched on. 2 1, – Switched on in automatic mode. In automatic mode, the extractor hood switches itself on when one of the cooking zones is switched on. 2			
c20	Setting for whether and how the fan is to run on after switching off the hob.	Fan run-on \$\mathcal{U}\$ - Fan switches off when the hob is switched off \$\epsilon\$ - Switched on with standard fan run-on \$\mathcal{Z}\$ - No change to the settings \$\mathcal{J}\$ \frac{1}{1}\$ - Switched on in automatic mode \$\frac{2}{2}\$			
c21	The lighting switches itself on when the hob is switched on.	Switching the lighting on automatically $G - Switched$ off $I^{-1} - Switched$ on			
c22	The lighting switches itself off when the hob is switched off.	Switching the lighting off automatically $I = I$ - Switched off $I = I$ - Switched on			

23 Cleaning and servicing

To keep your appliance working efficiently for a long time, it is important to clean and maintain it carefully.

23.1 Glass-protect-surface

The glass on the hob comes with a coating that increases resistance against scratches.

¹ Factory setting

² Depending on the appliance specifications

Preventing damage to the surface

Before you use the appliance for the first time, clean the surface with a soft cloth and a commercially available glass ceramic cleaner.

- Do not use the hob as a work surface or storage space.
- Prevent food from coming into contact with the hotplate since this may lead to permanent discolouration of the surface.
- Carefully remove any food residue, sugar, plastic, aluminium foil and spilled food immediately with a glass scraper.
- Immediately remove the coarse dirt, salt and sugar from the cooking surface.
- Do not use cookware with a rough base.
- Lift the cookware when moving it.
- Do not use a scraper that is in poor condition.

23.2 Cleaning products

You can obtain suitable cleaning products and glass scrapers from customer service, the online shop or a retailer.

ATTENTION

Unsuitable cleaning products may damage the surfaces of the appliance.

- ► Never use unsuitable cleaning products.
- ► Do not use cleaning products while the hob is still hot. This may cause marks on the surface.

Unsuitable cleaning products

- Undiluted detergent
- Detergent intended for dishwashers
- Abrasive cleaning products
- Aggressive cleaning products such as oven spray or stain remover

- Abrasive sponges
- High-pressure or steam jet cleaners
- Basic products such as degreasing agents

23.3 Cleaning the hob

Clean the hob after every use to prevent cooking residues from getting burnt on.

Requirement: The hob must be cold. Do not allow the hob to cool down if it has sugar stains, rice starch, plastic or aluminium foil on it.

- 1. Remove heavy soiling using a glass scraper.
- 2. Spray the entire surface with soapy water or commercially available detergent. Only use cleaning agents for glass ceramic cooktops if there is stubborn dirt.
 - ► Apply the cleaning agent evenly and gently.
 - ► Follow the cleaning instructions on the packaging of the cleaning product.
 - ► You can achieve good cleaning results using a special sponge for glass ceramic.
- 3. Wipe it with a damp cloth and dry it with a cloth.

Tips

- If you keep the base of the cookware clean, the hob surface remains in a good condition.
- Using LED or halogen bulbs improves the lighting conditions and avoids reflections or colour variations on the hob.

23.4 Cleaning profiles

Clean the profiles if they are dirty or stained after use.

Note: Do not use a glass scraper.

- 1. Clean using warm soapy water and a soft cloth. Wash new sponge cloths thoroughly before use.
- 2. Dry with a soft cloth.

24 Troubleshooting

You can rectify minor faults on your appliance yourself. Read the troubleshooting information before contacting aftersales service. This will avoid unnecessary costs.

⚠ WARNING – Risk of injury!

Improper repairs are dangerous.

- Repairs to the appliance should only be carried out by trained specialist staff.
- If the appliance is defective, call Customer Service.
 - → "Customer Service", Page 19

⚠ WARNING – Risk of electric shock!

Improper repairs are dangerous.

- ► Repairs to the appliance should only be carried out by trained specialist staff.
- Only use genuine spare parts when repairing the appliance.
- If the power cord or the appliance power cable of this appliance is damaged, it must be replaced with a special power cord or special appliance power cable, which is available from the manufacturer or its Customer Service.
- If the power cord of this appliance is damaged, it must be replaced by trained specialist staff.

24.1 Warnings

Notes

- If E or F appears in the displays, press and hold the sensor for the respective cooking zone and read the fault code.
- If the fault code is not listed in the following table, disconnect the hob from the power supply and wait 30 seconds before reconnecting it. If this display appears again, contact Customer Service and specify the exact fault code.

- If an error occurs, the appliance does not switch to standby mode.
- In order to protect the appliance's electronic parts from overheating or surge currents, the hob may temporarily reduce the power level.

24.2 Information on the display panel

Fault	Cause and troubleshooting				
No displays light up.	The power supply has been disconnected. ► Use other electrical appliances to check whether there has been a power failure.				
	The appliance has not been connected as shown in the circuit diagram. • Connect the appliance in accordance with the circuit diagram.				
	Electronics fault ▶ If you are unable to rectify the fault, inform the technical after-sales service.				
The displays flash.	The control panel is wet or an object is covering it. • Dry the control panel or remove the object.				
F2, F 4, E 1015, E 8201, E 8208	 The electronics have overheated and one or all of the cooking zones have been switched off. Wait until the electronics have cooled down sufficiently. Then touch any button on the control panel. 				
F5 + power level and audible signal	There is hot cookware in the vicinity of the control panel. This may cause the electronics to overheat. • Remove the cookware. The fault display goes out shortly afterwards. You can continue to cook.				
F5 and signal tone	There is hot cookware in the vicinity of the control panel. The cooking zone has been switched off to protect the electronics. • Remove the cookware. Wait a few seconds. Touch any button. When the fault display goes out, you can continue cooking.				
F 1/F6	 The cooking zone has overheated and has been switched off to protect the work surface. Wait until the electronics have cooled down sufficiently before switching the cooking zone back on. 				
F8	 The cooking zone has been operating continuously for an extended period. Individual safety switch-off is switched on. Touch any button to switch off the display so that you can set the cooking zone. 				
E 9000/E90 IO	The operating voltage is incorrect and outside of the normal operating range. Contact your energy supplier.				
U400/E9011	 The hob is not connected correctly. Disconnect the hob from the mains. Connect the hob in accordance with the circuit diagram. 				
d E	Demo mode is activated. Switch off demo mode in the basic settings.				
-	Childproof lock is activated. Childproof lock deactivate				
Home Connect is not working properly.	Different causes are possible. • Go to www.home-connect.com.				
The hood control is not working properly.	The hood control functions do not switch on. Resetting and re-pairing the settings of the Wi-Fi home network				
Animations on the 000 displays	In certain circumstances, the hob can perform self-maintenance tasks, e.g. a firmware update, optimisation or troubleshooting. • Wait until the process is complete and only then switch the hob on.				

24.3 Normal noises from your appliance

An induction hob may sometimes cause noises or vibrations, such as buzzing, crackling, hissing noises, fan noises or rhythmic noises.

25 Disposal

25.1 Disposing of old appliance

Valuable raw materials can be reused by recycling.

- 1. Unplug the appliance from the mains.
- 2. Cut through the power cord.
- 3. Dispose of the appliance in an environmentally friendly manner.
 - Information about current disposal methods are available from your specialist dealer or local authority.



This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE). The guideline determines the framework for the return and recycling of used appliances as applicable throughout the

26 Customer Service

Function-relevant genuine spare parts according to the corresponding Ecodesign Order can be obtained from Customer Service for a period of at least 10 years from the date on which your appliance was placed on the market within the European Economic Area.

Note: Under the terms of the manufacturer's warranty the use of Customer Service is free of charge.

Detailed information about the warranty period and the warranty conditions in your country is available via the QR code on the enclosed document on service contacts and warranty conditions, from our customer service or on our website.

If you contact Customer Service, you will require the product number (E-Nr.), the production number (FD) and the consecutive numbering (Z-Nr.) of your appliance.

You can find the contact details for our customer service via the QR code on the enclosed document on service contacts and warranty conditions or on our website. You can find the information required as per Regulations (EU) 66/2014 and (EU) 2023/826 online at

siemens-home.bsh-group.com on the product and service pages for your appliance, in the area of user manuals and additional documents.

26.1 Product number (E-Nr.), production number (FD) and consecutive numbering (Z-Nr.)

You can find the product number (E-Nr.), the production number (FD) and the consecutive numbering (Z-Nr.) on the appliance's rating plate.

The rating plate can be found:

- on the appliance certificate.
- on the lower section of the hob.

The product number (E no.) can also be found on the glass ceramic. You can also display the customer service index (KI) and the production number (FD) in the basic settings. → Page 12

Make a note of your appliance's details and the Customer Service telephone number to find them again quickly.

27 Information regarding Free and Open Source Software

This product includes software components that are licensed by the copyright holders as free or open source

The applicable licence information is stored on your home appliance. You can also access the applicable licence information via your Home Connect app: "Profile -> Legal information -> Licence Information". 1 You can download the licence information on the brand product website. (Please search on the product website for your appliance model and additional documents). Alternatively, you can request the relevant information from ossrequest@bshg.com or BSH Hausgeräte GmbH, Carl-Wery-Str. 34, 81739 Munich, Germany.

The source code will be made available to you on re-

Please send your request to ossrequest@bshg.com or BSH Hausgeräte GmbH, Carl-Wery-Str.34, 81739 Munich, Germany.

Subject: "OSSREQUEST"

The cost of performing your request will be charged to you. This offer is valid for three years from the date of purchase or at least as long as we offer support and spare parts for the relevant appliance.

¹ Depending on the appliance specifications

28 Declaration of Conformity

BSH Hausgeräte GmbH hereby declares that the appliance with Home Connect functionality conforms to the essential requirements and other relevant provisions of Directive 2014/53/EU.

A detailed RED Declaration of Conformity can be found online at siemens-home.bsh-group.com among the additional documents on the product page for your appliance.



Hereby, BSH Hausgeräte GmbH declares that the appliance with Home Connect functionality is in compliance with relevant statutory requirements.

A detailed Declaration of Conformity can be found online at siemens-home.bsh-group.com/uk/ among the additional documents on the product page for your appliance. 1



2.4 GHz band (2400-2483.5 MHz): Max. 100 mW 5-GHz band (5150-5350 MHz + 5470-5725 MHz): max. 130 mW

BE	BG	CZ	DK	DE	EE	ΙE	EL	ES
FR	HR	IT	CY	LI	LV	LT	LU	HU
MT	NL	AT	PL	PT	RO	SI	SK	FI
SE	NO	CH	TR	IS	UK (NI)			,
/LAN (Wi-F	i): For indo	or use only	′ .					
ВА		MD	ME	MK	RS	UK		UA
	FR MT SE /LAN (Wi-F	FR HR MT NL SE NO /LAN (Wi-Fi): For indo	FR HR IT MT NL AT SE NO CH /LAN (Wi-Fi): For indoor use only	FR HR IT CY MT NL AT PL SE NO CH TR //LAN (Wi-Fi): For indoor use only.	FR HR IT CY LI MT NL AT PL PT SE NO CH TR IS //LAN (Wi-Fi): For indoor use only.	FR HR IT CY LI LV MT NL AT PL PT RO SE NO CH TR IS UK (NI) //LAN (Wi-Fi): For indoor use only.	FR HR IT CY LI LV LT MT NL AT PL PT RO SI SE NO CH TR IS UK (NI) //LAN (Wi-Fi): For indoor use only.	FR HR IT CY LI LV LT LU MT NL AT PL PT RO SI SK SE NO CH TR IS UK (NI) //LAN (Wi-Fi): For indoor use only.

5 GHz WLAN (Wi-Fi): For indoor use only.

28.1 Statement of Compliance for Great **Britain**

Product type

This statement of compliance covers the products described in this information for use whose model identifier group is seen on the title page. The full model identifier is made up of the characters before the slash in the product number (E no.) which can be found on the rating plate. Alternatively, you can also find the model identifier in the first line of the UK Energy Label.

Name and address of manufacturer

BSH Hausgeräte GmbH, Carl-Wery-Strasse 34, 81739 München, Germany

This statement of compliance is prepared by the manufacturer.

The manufacturer, BSH Hausgeräte GmbH deems that it has complied with

- provision 5.1-1 of ETSI EN 303 645 v2.1.1 and, where relevant, provision 5.1-2 of ETSI EN 303 645
- provision 5.2-1 of ETSI EN 303 645 v2.1.1;
- provision 5.3-13 of ETSI EN 303 645 v2.1.1.

Support period

BSH Hausgeräte GmbH will provide security updates that are necessary to maintain the main functions free of charge until at least 28/02/2034.

29 Test dishes

These recommended settings are intended for test institutes to facilitate the testing of our appliances. The tests were carried out using our cookware sets for induction hobs. If required, these accessory sets can be purchased at a later point from specialist retailers, or through our technical after-sales service or our online shop.

29.1 Melting the chocolate coating

Ingredients: 150 g dark chocolate (55% cocoa).

16 cm saucepan without lid

- Boiling: Power level 1.5

29.2 Heating and keeping lentil stew warm

Recipe in accordance with DIN 44550 Initial temperature 20 °C Heating up without stirring

- 16 cm saucepan with lid, amount: 450 g
 - Heating up: Duration 1 min. 30 sec., power level 9
 - Simmering: Power level 1.5
- 20 cm saucepan with lid, amount: 800 g
 - Heating up: Duration 2 min. 30 sec., power level 9

¹ Only applies to Great Britain

- Simmering: Power level 1.5

29.3 Heating and keeping lentil stew warm

E.g.: Lentil diameter 5-7 mm. Initial temperature 20 °C Stir after heating for 1 minute

- 16 cm saucepan with lid, amount: 500 g
 - Heating up: Duration approx. 1 min. 30 sec., power level 9
 - Simmering: Power level 1.5
- 20 cm saucepan with lid, amount: 1 kg
 - Heating up: Duration approx. 2 min. 30 sec., power level 9
 - Simmering: Power level 1.5

29.4 Béchamel sauce

Milk temperature: 7 °C

■ 16 cm saucepan without lid, ingredients: 40 g butter, 40 g flour, 0.5 I milk with 3.5% fat content and a pinch of salt

Preparing Béchamel sauce

- 1. Melt the butter, stir in the flour and salt, and heat up the mixture.
 - ► Heating up: Duration 6 min., power level 2
- 2. Add the milk to the roux and bring to the boil, stirring continuously.
 - ► Heating up: Duration 6 min. 30 sec., power level 7
- 3. Once the Béchamel sauce comes to the boil, leave it on the cooking zone for a further two minutes.
 - ► Simmering: Power level 2

29.5 Cooking rice pudding with the lid on

Milk temperature: 7 °C

- 1. Heat the milk until it starts to rise up. Heat up without a lid. Stir after heating for 10 min.
- 2. Set the recommended power level and add rice, sugar and salt to the milk.

The cooking time, including heating up, is approx. 45 minutes.

- 16 cm saucepan, ingredients: 190 g short-grain rice, 90 g sugar, 750 ml milk with 3.5% fat content and 1 g salt
 - Heating up: Duration approx. 5 min. 30 sec., power level 8.5
 - Simmering: Power level 3
- 20 cm saucepan, ingredients: 250 g short-grain rice, 120 g sugar, 1 I milk with 3.5% fat content and 1.5 g
 - Heating up: Duration approx. 5 min. 30 sec., power level 8.5
 - Simmering: Power level 3, stir after 10 minutes

29.6 Cooking rice pudding without a lid

Milk temperature: 7 °C

- 1. Add the ingredients to the milk and heat the mixture up while stirring continuously.
- 2. Once the milk has reached approx. 90 °C, select the recommended power level and leave it to simmer on a low heat for approx. 50 minutes.
- 16 cm saucepan without lid, ingredients: 190 g shortgrain rice, 90 g sugar, 750 ml milk with 3.5% fat content and 1 g salt

- Heating up: Duration approx. 5 min. 30 sec., power level 8.5
- Simmering: Power level 3
- 20 cm saucepan without lid, ingredients: 250 g shortgrain rice, 120 g sugar, 1 l milk with 3.5% fat content and 1.5 g salt
 - Heating up: Duration approx. 5 min. 30 sec., power level 8.5
 - Simmering: Power level 2.5

29.7 Cooking rice

Recipe in accordance with DIN 44550 Water temperature: 20 °C

- 16 cm saucepan with lid, ingredients: 125 g longgrain rice, 300 g water and a pinch of salt
 - Heating up: Duration approx. 2 min. 30 sec., power level 9
 - Simmering: Power level 2
- 20 cm saucepan with lid, ingredients: 250g long-grain rice, 600 g water and a pinch of salt
 - Heating up: Duration approx. 2 min. 30 sec., power level 9
 - Simmering: Power level 2.5

29.8 Roasting a pork loin

Initial temperature of the loin: 7 °C

- 24 cm pan without lid, ingredients: 3 pork loins, total weight approx. 300 g, 1 cm thick, and 15 g sunflower
 - Heating up: Duration approx. 1 min. 30 sec., power level 9
 - Simmering: Power level 7

29.9 Preparing crêpes

Recipe in accordance with DIN EN 60350-2

- 24 cm pan without lid, ingredients: 55 ml batter per crêpe
 - Heating up: Duration 1 min. 30 sec., power level 9
 - Simmering: Power level 7

29.10 Deep-fat frying frozen chips

- Pot dia. 20 cm without lid: ingredients: 2 I sunflower oil. For each frying time: 200 g frozen chips, 1 cm thick.
 - Heating up: Power level 9, until the oil temperature reaches 180 °C.
 - Simmering: Power level 9





EN Manufactured by BSH Hausgeräte GmbH under the trademark licence of Siemens AG

Valid within Great Britain:
Imported to Great Britain by
BSH Home Appliances Ltd.
Grand Union House
Old Wolverton Road
Wolverton, Milton Keynes
MK12 5PT
United Kingdom

BSH Hausgeräte GmbH

Carl-Wery-Straße 34 81739 München, GERMANY siemens-home.bsh-group.com



9001958807 (050401) REG25

en