

SN25EC13CE

# Dishwasher



**EN** Information for Use






Register your appliance on My Siemens and discover exclusive services and offers.

You can find additional information and explanations online. Scan the QR code on the title page.

## Table of contents

1 Safety	3
1.1 General information	
1.2 Intended use	
1.3 Restriction on user group	
1.4 Safe installation	
1.5 Safe use	
1.6 Damaged appliance	
1.7 Risk to children	7
2 Preventing material damage	
2.1 Safe installation	
2.2 Safe use	. 9
3 Environmental protection and	
saving energy	10
3.1 Disposing of packaging	
3.2 Saving energy	10
3.3 Sensors	10
3.4 autoOpen Dry	11
4 Installation and connection	
4.1 Scope of supply	11
4.2 Installing and connecting the	
appliance	11
4.3 Drainage connection	11
4.4 Drinking water connection	12
4.5 Electrical connection	12
5 Familiarising yourself with	
your appliance	
5.1 Appliance	13
5.2 Controls	
6 Programmes	
6.1 Information for test institutes	18
6.2 Favourite 🛱	18
7 Additional functions	19
8 Features	
8.1 Top basket	
8.2 Etagere	
8.3 glassZone	



13 Tableware	30
13.1 Damage to glass and table-	
ware	30
13.2 Arrange tableware	31

- 13.3 Removing tableware ...... 32
- 14.3 Setting additional functions .. 33

• ~

<ul> <li>14.4 Setting timer programming</li> <li>14.5 Starting the programme</li> <li>14.6 Activating button lock</li> <li>14.7 Deactivate button lock</li> <li>14.8 Interrupting programme</li> <li>14.9 Terminate programme</li> <li>14.10 Switching off appliance</li> </ul>	33 33 33 33 34 34
15 Basic settings	34
<ul><li>15.1 Overview of the basic set- tings</li><li>15.2 Changing basic settings</li></ul>	34 37
16 Home Connect	37
16.1 Setting up Home Connect	37
16.2 Remote Start 🗋	38
16.3 Smart Start <sup>1</sup>	38
16.4 Data protection	38
17 Cleaning and servicing	39
17.1 Cleaning the tub	39
17.2 Cleaning products	39
17.3 Tips on appliance care	39
17.4 Machine Care 🛱	39
17.5 Filter system	41
17.6 Cleaning spray arms	42

	43
18 Troubleshooting	43
18.1 Clean wastewater pump	49
19 Transportation, storage and	
disposal	50
19.1 Removing the appliance	50
19.2 Protect appliance from	
frost	50
19.3 Transporting the appliance	50
19.4 Disposing of old appliance	51
20 Customer Service	51
20.1 Product number (E-Nr.), pro- duction number (FD) and	
consecutive numbering (Z-	
consecutive numbering (Z- Nr.)	51
consecutive numbering (Z- Nr.) 20.2 AQUA-STOP guarantee	
Nr.)	52
Nr.) 20.2 AQUA-STOP guarantee	52 <b>52</b>
Nr.) 20.2 AQUA-STOP guarantee 21 Technical specifications 21.1 Information regarding Free	52 <b>52</b> 53
<ul> <li>Nr.)</li> <li>20.2 AQUA-STOP guarantee</li> <li><b>21 Technical specifications</b></li> <li>21.1 Information regarding Free and Open Source Software</li> </ul>	52 52 53 53

## 1 Safety

Observe the following safety instructions.

## 1.1 General information

- Read this instruction manual carefully.
- Keep the instruction manual and the product information safe for future reference or for the next owner.
- Do not connect the appliance if it has been damaged in transit.

<sup>&</sup>lt;sup>1</sup> Depending on the appliance specifications

## 1.2 Intended use

Only use this appliance:

- For cleaning household tableware.
- in closed rooms in the home and with similar applications, e.g.: in canteens in shops, offices and other work environments; in agricultural businesses; use by customers in hotels, motels and other typical home environments; in bed and breakfasts.
- Up to an altitude of 4000 m above sea level.

## 1.3 Restriction on user group

This appliance may be used by children aged 8 or over and by people who have reduced physical, sensory or mental abilities or inadequate experience and/or knowledge, provided that they are supervised or have been instructed on how to use the appliance safely and have understood the resulting dangers.

Do not let children play with the appliance.

Cleaning and user maintenance must not be performed by children unless they are being supervised.

Keep children under the age of 8 years away from the appliance and power cable.

## 1.4 Safe installation

## ⚠ WARNING – Risk of injury!

Improper installation may cause injury.

When installing and connecting the appliance, follow the instructions in the manual and installation instructions.

## $\triangle$ WARNING – Risk of electric shock!

Incorrect installation is dangerous.

- Connect and operate the appliance only in accordance with the specifications on the rating plate.
- ► Always use the supplied power cable for the new appliance.
- Connect the appliance to a power supply with alternating current only via a properly installed socket with earthing.
- The protective conductor system of the domestic electrical installation must be properly installed.
- Never equip the appliance with an external switching device, e.g. a timer or remote control.

- When the appliance is installed, the mains plug of the power cord must be freely accessible. If free access is not possible, an isolating switch must be integrated into the permanent electrical installation according to the installation regulations.
- When installing the appliance, check that the power cable is not trapped or damaged.

Cutting through the supply hose or immersing the Aqua-Stop valve in water is dangerous.

- Never immerse the plastic housing in water. The plastic housing on the supply hose contains an electric valve.
- Never cut through the supply hose. The supply hose contains electric power cables.

#### ▲ WARNING – Risk of fire!

It is dangerous to use an extended power cord and non-approved adapters.

- ► Do not use extension cables or multiple socket strips.
- Only use adapters and power cords approved by the manufacturer.
- If the power cord is too short and a longer one is not available, please contact an electrician to have the domestic installation adapted.

Contact between the appliance and installation lines may lead to a defect in these lines, e.g. gas pipes and power lines. Gas from a corroded gas pipe can ignite. A damaged power line can cause a short circuit.

 Check that there is a distance of at least 5 cm between the appliance and installation lines.

#### 

If the appliance is not installed properly, this may result in burns.

With free-standing appliances, ensure that they are installed with the back panel against a wall.

## 1.5 Safe use

## ▲ WARNING – Risk of serious harm to health!

Failure to comply with safety instructions and directions for use on packagings of detergent and rinse aid products may cause serious harm to health.

 Follow the safety instructions and directions for use on the packagings of detergent and rinse aid products.

## ⚠ WARNING – Risk of explosion!

Adding solvents to the interior of the appliance may cause explosions.

► Never add solvents to the interior of the appliance.

Highly caustic alkaline or highly acidic cleaning agents in conjunction with aluminium parts in the interior of the appliance may cause explosions.

Never use highly caustic alkaline or highly acidic cleaning agents, in particular commercial or industrial products, in conjunction with aluminium parts (e.g. grease filters of extractor hoods or aluminium pans), e.g. for the Machine Care programme.

## ⚠ WARNING – Risk of injury!

Leaving the appliance door open may result in injury.

- Only open the appliance door to load or unload tableware in order to prevent accidents, e.g. through tripping.
- ► Do not sit or stand on the appliance door when open. Knives and utensils with sharp points can cause injuries.
- Arrange knives and utensils with sharp points in the cutlery basket with the points downwards, on the knife shelf or in the cutlery drawer.

## 

If you open the appliance door while the programme is running, hot water may splash out of the appliance.

 Open the appliance door carefully if the programme is still running.

## 

Overfilling the Baskets may cause the appliance to tip up.

► Never overfill the Baskets with free-standing appliances.

#### 

An ingress of moisture can cause an electric shock.

- Only use the appliance in enclosed spaces.
- Never expose the appliance to intense heat or humidity.
- Do not use steam- or high-pressure cleaners to clean the appliance.
- If the insulation of the power cord is damaged, this is dangerous.
- Never let the power cord come into contact with hot appliance parts or heat sources.
- Never let the power cord come into contact with sharp points or edges.
- ► Never kink, crush or modify the power cord.

## 1.6 Damaged appliance

#### 

If the appliance or the power cord is damaged, this is dangerous.

- ► Never operate a damaged appliance.
- ► Never operate an appliance with a cracked or fractured surface.
- Never pull on the power cord to unplug the appliance. Always unplug the appliance at the mains.
- If the appliance or the power cord is damaged, immediately unplug the power cord or switch off the fuse in the fuse box and turn off the water tap.
- ► Call customer service. → Page 51

Improper repairs are dangerous.

- Repairs to the appliance should only be carried out by trained specialist staff.
- Only use genuine spare parts when repairing the appliance.
- If the power cord or the appliance power cable of this appliance is damaged, it must be replaced with a special power cord or special appliance power cable, which is available from the manufacturer or its Customer Service.

## 1.7 Risk to children

### 

Children may put packaging material over their heads or wrap themselves up in it and suffocate.

► Keep packaging material away from children.

► Do not let children play with packaging material.

Children may breathe in or swallow small parts, causing them to suffocate.

- ► Keep small parts away from children.
- ► Do not let children play with small parts.

Children may become trapped in the appliance and suffocate.

- Use the childproof lock if fitted.
- ► Never let children play with or operate the appliance.

## ⚠ WARNING – Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.

## ⚠ WARNING – Risk of crushing!

With higher-level appliances, children can become crushed between the appliance door and cabinet doors underneath.

 Keep an eye on children when opening and closing the appliance door.

### ⚠ WARNING – Risk of chemical burns!

Rinse aid and detergent may cause chemical burns to the mouth, throat and eyes.

- ► Keep children away from detergent and rinse aid products.
- Keep children away from the appliance when open. The water in the interior of the dishwasher is not drinking water. It may contain residues of detergents and rinse aid.

## ⚠ WARNING – Risk of injury!

Children may get their fingers caught in the slots of the tablet collecting tray and injure themselves.

► Keep children away from the appliance when open.

# 2 Preventing material damage

#### 2.1 Safe installation

#### ATTENTION

Improper installation of the appliance may cause damage.

- If the dishwasher is installed above or below other domestic appliances, follow the information on installation in combination with a dishwasher in the installation instructions for the individual appliances.
- If there is no information or if the installation instructions do not include the relevant information, contact the manufacturer of these appliances to check that the dishwasher can be installed above or below these appliances.
- If no information is available from the manufacturer, the dishwasher should not be installed above or below such appliances.
- To ensure the safe operation of all domestic appliances, continue following the installation instructions for the dishwasher.
- Do not install the dishwasher under a hob.
- Do not install the dishwasher near heat sources, e.g. radiators, heat storage tanks, ovens or other appliances that generate heat.

Contact between the appliance and water pipes may lead to corrosion of these pipes, possibly causing them to leak.

 Check that there is a distance of at least 5 cm between the appliance and the water pipe. The pipes supplied for the drinking water and waste water connections are not affected here. Modified or damaged water hoses may result in material damage and damage to the appliance.

- Never kink, crush, modify or cut through water hoses.
- Only use the water hoses supplied with the appliance or genuine spare hoses.
- Never re-use water hoses that have been used before.

If the water pressure is too high or too low, the appliance may not be able to operate properly.

- Make sure that the water pressure in the water supply system is min. 50 kPa (0.5 bar) and max. 1000 kPa (10 bar).
- If the water pressure exceeds the maximum value specified, a pressure-reducing valve must be installed between the drinking water connection and the hose set of the appliance.

#### 2.2 Safe use

#### ATTENTION

Escaping water vapour can damage fitted units.

 When the programme ends, leave the appliance to cool down for a while before opening the door.
 Special salt for dishwashers can

damage the tub due to corrosion.

To make sure that any special salt that escapes is washed out of the tub, add the special salt to the dispenser for special salt immediately before the programme starts.

Detergent may damage the water softening system.

 Only fill the dispenser of the water softening system with special dishwasher salt.

Unsuitable cleaning agents may damage the appliance.

Do not use a steam cleaner.

- So as not to scratch the finish on the appliance, do not use sponges with a rough surface or abrasive cleaning agents.
- To prevent corrosion, do not use sponge cloths on dishwashers with a stainless steel front or rinse such cloths thoroughly several times before using them for the first time.

## 3 Environmental protection and saving energy

#### 3.1 Disposing of packaging

The packaging materials are environmentally compatible and can be recycled.

 Sort the individual components by type and dispose of them separately.

#### 3.2 Saving energy

If you follow these instructions, your appliance will use less electricity and less water.

Use the Eco 50  $^\circ$  programme.

The Eco 50° programme is energy-efficient and environmentally friendly.

→ "Programmes", Page 17

If you do not have much tableware to wash, use the additional Half Load function.<sup>1</sup>

- The programme will adjust to a lower load and consumption will be reduced.
  - → "Additional functions", Page 19

Change the sensor setting to the default.

Consumption is reduced.

→ "Sensors", Page 10

#### 3.3 Sensors

The sensors adjust the programme sequence and strength in the automatic programmes depending on the level and type of soiling.

The sensor has different sensitivity settings that can be changed in the basic settings.

→ "Changing basic settings", Page 37

Sensor set- ting	Description
SE:00	Optimum setting for a mixed load and heav- ily soiled tableware. Saves both energy and water.
SE:01	Adjusts the pro- gramme strength for effective removal of food remnants even with low soiling levels. Energy and water consumption are ad- justed accordingly.
SE:02	Adjusts the pro- gramme strength for difficult conditions of use, e.g. stubborn dried-on food rem- nants. Recommended setting when using or- ganic or ecological detergents containing low levels of active agents. Energy and water consumption are adjusted accord- ingly.

<sup>&</sup>lt;sup>1</sup> Depending on the appliance specifications

## 3.4 autoOpen Dry

The appliance door opens automatically during the drying phase. This ensures a particularly economical drying result.

For best drying results wait until the end of programme before unloading the tableware. The programme has ended when the display shows "00h:00m".

If automatic door opening is deactivated, energy consumption increases and the drying phase is usually shortened.

 $\rightarrow$  "Overview of the basic settings", Page 34

If this additional function has been selected, automatic door opening is deactivated.

→ "Additional functions", Page 19

#### 4 Installation and connection

To ensure proper operation, connect the appliance to the power and water supply correctly. Observe the specified criteria and the installation instructions.

### 4.1 Scope of supply

After unpacking all parts, check for any damage in transit and completeness of the delivery.

If you have any complaints, contact the dealer who sold you the appliance or our Customer Service.

**Note:** The appliance has been tested at the factory to check it is in working order. It is possible that water has left marks on the appliance. These

marks will disappear after the first wash cycle.

The delivery consists of the following:

- Dishwasher
- Operating instructions
- Installation Instructions
- Further information documents
- Installation material
- Salt filling aid funnel<sup>1</sup>
- Mains cable
- Quick reference guide

## 4.2 Installing and connecting the appliance

You can position your built-under or integrable appliance in a fitted kitchen between wooden and plastic walls.

- **1.** Follow the safety instructions.  $\rightarrow$  *Page 3*
- **2.** Follow the instructions for electrical connection.
- **3.** Check the Scope of supply and the condition of the appliance.
- Consult the installation instructions for the installation dimensions required.
- Make the appliance level using the height-adjustable feet. Make sure that the appliance is standing on the floor securely.
- **6.** Install the drainage connection.  $\rightarrow$  *Page 12*
- Install the drinking water connection. → Page 12
- **8.** Connect the appliance to the power supply.

#### 4.3 Drainage connection

Connect your appliance to drainage connection so dirty water is discharged via the wash cycle.

<sup>&</sup>lt;sup>1</sup> Depending on the appliance specifications

#### Installing the drainage connection

- **1.** Consult the installation instructions supplied for the steps required here.
- 2. Connect the wastewater hose to the outlet connection of the siphon using the enclosed parts.
- **3.** When doing so, check that the wastewater hose is not kinked, crushed or twisted.
- 4. Also check that there is no cover in the drainage system preventing the wastewater from being discharged.

## 4.4 Drinking water connection

Connect your appliance to a drinking water connection.

#### Installing the drinking water connection

**Note:** If you are replacing the appliance, you must use a new water supply hose.

**1.** Consult the installation instructions supplied for the steps required here.

- 2. Connect the appliance to the drinking water connection using the enclosed parts.
  - Observe the Technical data.
- **3.** When doing so, check that the drinking water connection is not kinked, crushed or twisted.

## 4.5 Electrical connection

## Connecting the appliance to the electricity supply


#### Notes

- Follow the Safety instructions → Page 4.
- Please note that the water safety system is only functional if there is a power supply.
- 1. Insert the non-heating appliance plug of the power cable into the appliance.
- Insert the mains plug of the appliance's power cable in a socket nearby.
   The connection data of the appliance can be found on the rating plate.
- **3.** Check the mains plug is inserted properly.

## 5 Familiarising yourself with your appliance

#### 5.1 Appliance

You can find an overview of the parts of your appliance here.



1	Rating plate	Rating plate with E number and FD number $\rightarrow$ Page 51. The data you need for Customer Service $\rightarrow$ Page 51.
2	Detergent dispenser	Add detergent to the detergent dispenser. $\rightarrow$ "Detergent", Page 28
3	Bottom basket	Bottom basket → Page 22

#### en Familiarising yourself with your appliance

4	Dispenser for special salt	Add special salt to the dispenser for spe- cial salt. → "Water softening system", Page 24
5	Lower spray arm	The lower spray arm washes the tableware in the bottom basket. If the tableware has not been washed prop- erly, clean the spray arms. $\rightarrow$ "Cleaning spray arms", Page 42
6	Tablet collecting tray	During the wash cycle tablets automatically fall out of the detergent dispenser into the tablet collecting tray where they can fully dissolve.
7	Top basket	Top basket → <i>Page 20</i>
8	Cutlery drawer	Cutlery drawer → <i>Page 23</i>
9	Top spray arm	The top spray arm cleans the tableware in the upper part of the appliance. If the tableware has not been washed prop- erly, clean the spray arms. $\rightarrow$ "Cleaning spray arms", Page 42
10	Cutlery shelf <sup>1</sup>	Cutlery shelf $\rightarrow$ Page 21
11	Upper spray arm	The upper spray arm washes the tableware in the top basket. If the tableware has not been washed prop- erly, clean the spray arms. $\rightarrow$ "Cleaning spray arms", Page 42
12	Filter system	Filter system → Page 41
13	Dispenser for rinse aid	Add rinse aid to the dispenser for rinse aid. $\rightarrow$ "Rinse aid system", Page 26

#### 5.2 Controls

You can use the control panel to configure all functions of your appliance and to obtain information about the operating status.

<sup>&</sup>lt;sup>1</sup> Depending on the appliance specifications

With some buttons you can perform different functions.

C total and the second		4 5 6 7 8 - + - + - + - + - + - + - + - + - + - +
1	ON/OFF button () and reset button Reset 4 sec.	Switching on the appliance $\rightarrow$ Page 32 Switching off the appliance $\rightarrow$ Page 34 Terminating the programme $\rightarrow$ Page 34
2	Programme buttons	Programmes → <i>Page 17</i>
3	Display	The display shows information about progress of the programme, the remaining running time or the basic settings. You can change the basic settings via the display and the setting buttons. → "Changing basic settings", Page 37
4	Special salt refill indicator	Water softening system → "Adding special salt", Page 25
5	Rinse aid refill indicator	Rinse aid system → "Adding rinse aid", Page 26
6	Water supply display	Display for water supply
7	Programme buttons and addi- tional functions	Programmes → "Programmes", Page 17 Additional functions → "Additional functions", Page 19
8	Start button Start	Starting the programme → "Starting the programme", Page 33

#### en Familiarising yourself with your appliance

9	Setup 3 sec. button	If you press <sup>Setup 3 sec.</sup> for approx. 3 seconds, you can open the basic set- tings. → "Changing basic settings", Page 37
10	Remote Start 🗅	→ "Remote Start в`", Page 38
11	Timer programming and set- ting buttons	Setting timer programming $\rightarrow$ Page 33 Changing basic settings
12	Door handle 1	Open the appliance door.
13	Programme sequence display	The programme sequence display shows the current cycle of the appli- ance, e.g. washing, rinsing or drying.

Symbol

Description

display.

WLAN home network, the

symbol lights up on the

#### Symbols on the display <sup>1</sup>

The display shows the following symbols depending on the model. See here for an explanation.

Symbol	Description		→ "Home Connect ",
	If the symbol for machine care lights up on the display, run machine care. $\rightarrow$ "Machine Care $\stackrel{\scriptstyle {}_{\scriptstyle \sim}}{=}$ ", Page 39		Page 37         The symbols show the current cycle of the appliance, e.g. washing ✓, rinsing          minsing          minsing <td< td=""></td<>
*	If the rinse aid refill indic- ator lights up on the dis- play, top up with rinse aid. → "Adding rinse aid", Page 26	Ŀ	If you have activated the electronic start timer, the symbol lights up on the display. → "Setting timer program- ming", Page 33
S If the special salt refill in- dicator lights up on the		<b> → </b>	If you have started a pro- gramme, the symbol lights up on the display.
	display, add special salt to the dispenser for spe- cial salt just before the programme starts. $\rightarrow$ "Adding special salt", Page 25		If the water inflow or drainage malfunctions, the symbol lights up or flashes on the display. $\rightarrow$ "Troubleshooting",
If the appliance is connected to a wireless			Page 43

<sup>&</sup>lt;sup>1</sup> Depending on the appliance specifications

## 6 Programmes

You can find an overview of the programmes that can be selected here. Different programmes, which can be found on the control panel of your appliance, are available depending on the appliance configuration.

The running time may vary depending on the programme selected. The running time depends on the water temperature, the quantity of tableware, the level of soiling and the Additional function  $\rightarrow$  *Page 19* selected. The running time and energy consumption will increase if the rinse aid system is switched off or if rinse aid needs to be added.

The consumption values can be found in the quick reference guide. The consumption values relate to normal conditions and a water hardness of 16 - 20  $^{\circ}$ E. Different influencing factors such as water temperature or pipe pressure may result in deviations.

Programme	Use	Programme sequence
C Intensive 70°	<ul> <li>Tableware:</li> <li>Pots and pans, non-fragile tableware and cutlery</li> <li>Level of soiling:</li> <li>Stubborn, burned or dried-on food remnants containing starch and protein</li> </ul>	Intensive: Pre-Rinse Cleaning 70 °C Intermediate rinse Final rinse 62 °C Dry
Auto 45-65°	<ul> <li>Tableware:</li> <li>Mixed tableware and cutlery Level of soiling:</li> <li>Common household food rem- nants lightly dried on</li> </ul>	<ul> <li>Sensor-controlled:</li> <li>Optimised by sensors depending on the soiling of the washing water.</li> </ul>
Eco 50°	<ul> <li>Tableware:</li> <li>Mixed tableware and cutlery Level of soiling:</li> <li>Common household food rem- nants lightly dried on</li> </ul>	Most economical pro- gramme: Pre-Rinse Cleaning 50 °C Intermediate rinse Final rinse 41 °C Drying
Ŷ Silence 50	<ul> <li>Tableware:</li> <li>Mixed tableware and cutlery Level of soiling:</li> <li>Common household food rem- nants lightly dried on</li> </ul>	Reduced noise: Pre-Rinse Cleaning 50 °C Intermediate rinse Final rinse 58 °C Dry

Programme	Use	Programme sequence
Glass 40°	<ul> <li>Tableware:</li> <li>Delicate tableware, cutlery, temperature-sensitive plastics, glasses and stemware</li> <li>Level of soiling:</li> <li>Lightly adhering fresh food remnants</li> </ul>	Particularly gentle: Pre-Rinse Cleaning 40 °C Intermediate rinse Final rinse 56 °C Dry
ि। Speed 60°	<ul> <li>Tableware:</li> <li>Mixed tableware and cutlery Level of soiling:</li> <li>Common household food rem- nants lightly dried on</li> </ul>	Time-optimised: Cleaning 60 °C Intermediate rinse Final rinse 58 °C Dry
( <sup>Ĉ</sup> ⊔ Speed 45°	<ul> <li>Tableware:</li> <li>Delicate tableware, cutlery, temperature-sensitive plastics and glasses</li> <li>Level of soiling:</li> <li>Lightly adhering fresh food remnants</li> </ul>	Time-optimised: Cleaning 45 °C Intermediate rinse Final rinse 50 °C
⊡ <sup>™</sup> Machine Care	Use only if appliance is unloaded.	Machine Care 70 °C
5.7	-	_
Favourite	→ "Favourite ☆", Page 18	

**Note:** The relatively long running time in the Eco 50 ° programme is due to longer soaking and drying times. This results in optimal consumption values.

#### 6.1 Information for test institutes

Test institutes are provided with information for comparability tests, e.g. according to EN60436.

These are the conditions for conducting the tests, however they are not the results or consumption values. Request by e-mail to:

dishwasher@test-appliances.com The product number (E-Nr.) and the production number (FD) are required here. They can be found on the rating plate on the appliance door.

#### 6.2 Favourite 🕸

You can save a combination of a programme and an additional function to the  $rac{l}{\sim}$  button.

Save the programme via the Home Connect app or on the appliance.

The pre-rinse program is saved to this button at the factory. Pre-rinse is suitable for all types of tableware. The tableware undergoes intermediate cleaning via cold rinsing. When programmes have been downloaded and on delivery of the appliance, the name of the programme will be displayed in the app. The display alternately shows "AP:P" and the remaining running time.

**Tip:** You can use the Home Connect app to download additional programmes and save them to the  $\frac{1}{24}$  button.<sup>1</sup>

## Saving Favourite $\precsim$ on the appliance

- 1. Press ().
- 2. Press the right programme button.
- **3.** Press the button for the relevant additional function.

- **4.** Press ☆ for 3 seconds.
- The selected programme and the additional function will flash.
- ✓ ☆ flashes.
- The programme and the additional function are saved.

**Tip:** To reset the programme to the pre-rinse programme stored at the factory, use the Home Connect app<sup>1</sup> or reset your appliance to the factory settings.

## 7 Additional functions

You can find an overview of the additional functions that can be selected here. Different additional functions, which can be found on the control panel of your appliance, are available depending on the appliance configuration. You can select certain additional functions depending on the programme.

Symbol	Additional func- tion	Use
1/2	Half Load	<ul> <li>Switch on with small loads.</li> <li>It is recommended adding less detergent to the detergent dispenser than for a full machine load.</li> <li>The running time is shortened.</li> <li>Water and energy consumption are reduced.</li> </ul>
	IntensiveZone	<ul> <li>Switch on with mixed loads containing table- ware with different soiling levels, e.g. place very soiled pots and pans in the bottom bas- ket and normally soiled tableware in the top basket.</li> <li>The spray pressure in the bottom basket is increased and the maximum programme temperature maintained longer. This will in- crease the running time and energy con- sumption.</li> </ul>

<sup>&</sup>lt;sup>1</sup> Depending on the appliance specifications

Symbol	Additional func- tion	Use
=(*)	VarioSpeedPlus	<ul> <li>The run time is shortened by 15% to 75%<sup>1</sup> depending on the rinse programme.</li> <li>The additional function can be activated before the start of the programme and at any time when the programme is running.</li> <li>Energy and water consumption are increased.</li> <li>If you select this additional function, automatic door opening → <i>Page 34</i> is deactivated.<sup>1</sup></li> </ul>


### 8 Features

You can find an overview of the possible features of your appliance and how to use them here.

These features depend on the model of your appliance.

#### 8.1 Top basket

Arrange cups, glasses and small items of tableware in the top basket.




You can adjust the height of the top basket to make room for larger items of tableware.

## Adjusting top basket with side levers


To wash large items of tableware in the baskets, adjust the shelf position of the top basket.

- 1. Pull out the top basket.
- To prevent the basket from suddenly dropping down, hold the side of the basket by the top edge.
- **3.** Press in the levers on the right and left on the outside of the basket.



<sup>&</sup>lt;sup>1</sup> Depending on the appliance specifications

**4.** Raise or lower the basket evenly to the right level.




Check that the basket is level on both sides.

- 5. Release the levers.
- ✓ The basket clicks into position.
- 6. Slide the basket back in.

#### 8.2 Etagere


Use the cutlery shelf and space underneath for small cups and glasses or for large items of cutlery, e.g. cooking spoons or serving cutlery.



If you do not need the cutlery shelf, you can fold it up.

#### 8.3 glassZone


Use the glassZone in the top basket to clean all types of glasses gently yet thoroughly.



#### Setting glassZone

**Note:** Consumption will increase if you operate your appliance with the glassZone switched on.


- **1.** Pull out the top basket.
- 2. Set the slider to ON or OFF.




3. Push in the top basket.

#### 8.4 Bottom basket

Arrange pans and plates in the bottom basket.




Large plates up to a diameter of 31 cm can be arranged in the bottom basket as shown.



## 8.5 Folding prongs

Use the folding prongs to position tableware securely, e.g. plates.




You can fold the prongs down to position pans, bowls and glasses better.<sup>1</sup>

#### Folding down prongs<sup>1</sup>

If you do not need the prongs, fold them down.

1. Push the lever forwards ① and fold down the prongs ②.




- **2.** To use the prongs again, fold them back up.
- The prongs audibly click into position.

<sup>&</sup>lt;sup>1</sup> Depending on the appliance specifications

#### 8.6 Cutlery drawer

Arrange cutlery in the cutlery drawer.



Arrange cutlery with the points and sharp edges downwards.

#### 8.7 Basket heights

Set the baskets at the right height.

#### Appliance height 81.5 cm with cutlery drawer

Level	Top basket	Bottom basket	
1 max. ø	16 cm	30 cm/31 cm <i>→Page 22</i>	
2 max. ø	18.5 cm	27.5 cm	
3 max. ø	21 cm	25 cm	

# 9 Before using for the first time

#### 9.1 Performing the initial configuration

On initial start-up or after a reset to the factory settings, you will need to make settings.

**Tip:** Connect your appliance to a mobile device. You can conveniently change all settings via the Home Connect app. → "Home Connect ", Page 37

**Requirement:** The appliance has been installed and connected.  $\rightarrow$  *Page 11* 

**1.** Add special salt.  $\rightarrow$  *Page 25* 

- **2.** Add rinse aid.  $\rightarrow$  *Page 26*
- **3.** Switch on the appliance.  $\rightarrow$  Page 32
- **4.** Setting the water softening system. → *Page 24*
- Set the amount of rinse aid to be dispensed. → Page 27
- **6.** Add detergent  $\rightarrow$  *Page 28*.
- 7. Start the Programme with the highest cleaning temperature without tableware. → Page 33 To remove any marks from water or other residues, we recommend you operate the appliance without tableware before using it for the first time.

**Tip:** You can change these settings and other Basic settings  $\rightarrow$  *Page 34* at any time.

### 10 Water softening system

Hard water leaves limescale on the tableware as well as the washing tank, and parts of the appliance may become blocked.

To ensure good dishwashing results, you can treat the water with special salt and the water softening system. To avoid damage to the appliance, water with a hardness above 9 °E must be softened.

#### 10.1 Overview of water hardness settings

You can find an overview of the water hardness values that can be selected here.

You can find out how hard your water is from your local water company or by using a water hardness tester.

Hardness range	mmol/l	Setting value
Soft	0 - 1.1	H:00
Soft	1.2 - 1.4	H:01
Medium	1.5 - 1.8	H:02
Medium	1.9 - 2.1	H:03
Medium	2.2 - 2.9	H:04
Hard	3.0 - 3.7	H:05
Hard	3.8 - 5.4	H:06
Hard	5.5 - 8.9	H:07
	Soft Soft Medium Medium Medium Hard Hard	Soft         0 - 1.1           Soft         1.2 - 1.4           Medium         1.5 - 1.8           Medium         1.9 - 2.1           Medium         2.2 - 2.9           Hard         3.0 - 3.7           Hard         3.8 - 5.4

**Note:** Set the water hardness determined on your appliance.

→ "Setting the water softening system", Page 24

With a water hardness of 0 - 8 °E you can dispense with special salt for dishwashers and switch off the water softening system.

→ "Switching off the water softening system", Page 25

#### 10.2 Setting the water softening system

Set the water hardness on your appliance.

- Determine the water hardness and the appropriate setting value.
   → "Overview of water hardness settings", Page 24
- 2. Press ().
- **3.** To open the basic settings, press Setup <sup>3</sup> sec. for 3 seconds.
- ✓ The display shows H:xx.
- The display shows set.
- 4. Press or + repeatedly until the right water hardness has been set. The value H:04 is set at the fact-ory.
- 5. To save the settings, press Setup 3 sec. for 3 seconds.
- The water softening system has been set.

#### 10.3 Special salt

You can use special salt to soften water.

#### Adding special salt

If the special salt refill indicator lights up, add special salt to the dispenser for special salt just before the programme starts. The consumption of special salt depends on the water hardness. The higher the water hardness, the greater the consumption of special salt.

#### ATTENTION

Detergent may damage the water softening system.

 Only fill the dispenser of the water softening system with special dishwasher salt.


Special salt for dishwashers can damage the tub due to corrosion.

- To make sure that any special salt that escapes is washed out of the tub, add the special salt to the dispenser for special salt immediately before the programme starts.
- **1.** Unscrew the lid of the dispenser for special salt and remove.
- 2. On initial start-up: Fill the dispenser right up with water.
- **3. Note:** Only use special salt for dishwashers.

Do not use salt tablets.

Do not use table salt.

Add the special salt to the dispenser.



Funnel a 1

Fill the dispenser right up with special salt. The water in the dispenser is displaced and forced out.

4. Place the lid back on the dispenser and turn to close.

## 10.4 Switching off the water softening system

If you find the special salt refill indicator irritating, e.g. when using combined detergents with salt replacement substances, you can switch the indicator off.

#### Note

To avoid damage to the appliance, only switch off the water softening system in the following cases:

 The water hardness is max. 26 °E and you are using a combined detergent with salt replacement substances. According to the manufacturers, combined detergents with salt replacement substances can generally only be used up to a water hardness of 26 °E without adding special salt.

<sup>&</sup>lt;sup>1</sup> Depending on the appliance specifications

- The water hardness is 0 8 °E. You do not need to use special salt.
- 1. Press ().
- 2. To open the basic settings, press Setup 3 sec. for 3 seconds.
- The display shows H:xx.
- The display shows set.
- **3.** Press or + repeatedly until the display shows H:00.
- 4. To save the settings, press Setup 3 sec. for 3 seconds.
- The water softening system is switched off and the salt refill indicator is deactivated.

**Note:** When switching from combined detergents with salt replacement substances to separate detergents, please make sure to set the water softening system to the right water hardness again.

 $\rightarrow$  "Setting the water softening system", Page 24

## 10.5 Regeneration of the water softening system

In order to obtain fault-free function of the water softening system, the appliance performs regeneration of the water softening system at regular intervals.

Regeneration of the water softening system takes place before the end of the main rinse cycle in all programmes. It will increase the run time and consumption values, e.g. water and electricity.

#### Overview of consumption values with regeneration the water softening system

Here you can find an overview of the maximum additional running time and consumption values during regeneration of the water softening system.

Regeneration of the water<br/>softening system after x<br/>washing programmes6Additional running time in<br/>minutes6

Additional water consump- 5 tion in litres

Additional power consump- 0.05 tion in kWh

The consumption values specified are laboratory measurements determined in accordance with the currently applicable standard using the Eco  $50^{\circ}$  programme and with the factory value of the water hardness set to 16 - 20 °E.

## 11 Rinse aid system

#### 11.1 Rinse aid


For optimum drying results, use rinse aid.

Only use rinse aid for domestic dishwashers.


#### Adding rinse aid

If the rinse aid refill indicator lights up, top up with rinse aid. Only use rinse aid for domestic dishwashers.

1. Press the catch on the lid of the dispenser for rinse aid ① and lift ②.



2. Add rinse aid up to the max mark.



- **3.** If rinse aid spills out, remove it from the tub. Spilled rinse aid can cause excessive frothing during the wash cycle.
- **4.** Close the lid of the dispenser for rinse aid.
- ✓ The lid clicks into position.

## 11.2 Setting the amount of rinse aid

If there are streaks or water marks on tableware, change the amount of rinse aid.

- 1. Press ().
- 2. To open the basic settings, press Setup 3 sec. for 3 seconds.
- ✓ The display shows H:xx.
- The display shows set.
- **3.** Press Setup <sup>3</sup> sec. repeatedly until the display shows the value r:05 set at the factory.
- 4. Press or + repeatedly until the right amount of rinse aid has been set.
  - A low setting adds less rinse aid during the wash cycle and reduces streaking on tableware.
  - A higher setting adds more rinse aid during the wash cycle,

reduces water marks and improves the drying result.

- 5. To save the settings, press Setup 3 sec. for 3 seconds.
- The amount of rinse aid to be dispensed has been set.

## 11.3 Switching the rinse aid system off

If you find the rinse aid refill indicator irritating, e.g. when using combined detergents with a rinse aid component, you can switch the rinse aid system off.

**Tip:** The function of rinse aid is limited with combined detergents. You will generally get better results using rinse aid.

- 1. Press ().
- 2. To open the basic settings, press Setup 3 sec. for 3 seconds.
- ✓ The display shows H:xx.
- The display shows set.
- **3.** Press Setup 3 sec. repeatedly until the display shows the value r:05 set at the factory.
- **4.** Press or + repeatedly until the display shows r:00.
- 5. To save the settings, press Setup 3 sec. for 3 seconds.
- The rinse aid system is switched off and the rinse aid refill indicator is deactivated.

**Note:** When switching from combined detergents with a rinse aid component to separate detergents, please make sure to set the rinse aid system to the right amount of rinse aid again.

→ "Setting the amount of rinse aid", Page 27

## 12 Detergent

#### 12.1 Suitable detergents

Only use detergents that are suitable for dishwashers. Both separate and combined detergents are suitable. For optimum washing and drying results, use separate detergent, adding Special salt  $\rightarrow$  *Page 25* and Rinse aid  $\rightarrow$  *Page 26* separately.

Modern, powerful detergents mainly use a low-alkaline formulation with enzymes. Enzymes break down starch and remove protein. Oxygenbased bleaching agents are generally used to remove coloured marks, e.g. tea or ketchup.

**Note:** Follow the manufacturer's instructions for each detergent.

**Tip:** Suitable detergents are available online via our website or from Customer Service  $\rightarrow$  *Page 51*.

#### Tabs

Tabs are suitable for all cleaning functions and do not need to be measured out.

With shorter programmes tabs sometimes do not dissolve entirely and leave residues of detergent. This may impair the cleaning effect.

#### Powder detergent

Powder detergent is recommended for shorter programmes. The dosage can be adjusted to the level of soiling.

#### Liquid detergent

Liquid detergent works faster and is recommended for shorter programmes without PreRinse.

Sometimes liquid detergent may leak out despite the detergent dispenser being closed. This is not a fault and is non-critical if you remember the following:

- Only choose a programme without PreRinse.
- Do not select timer programming for starting the programme.

The dosage can be adjusted to the level of soiling.

#### Separate detergents

Separate detergents are products that do not contain components other than detergent, e.g. powder detergent or liquid detergent.

With powder and liquid detergent the dosage can be individually adjusted to the level of soiling of the table-ware.

For better washing and drying results and to avoid damage to the appliance, please additionally use Special salt  $\rightarrow Page \ 25$  and Rinse aid  $\rightarrow Page \ 26$ .

#### **Combined detergent**

Besides conventional separate detergents, a number of products are available with additional functions. These products contain not only detergent but also rinse aid and salt replacement substances (3in1) and, depending on the combination (4in1, 5in1, ...), additional components such as glass protection or stainless steel cleaner.

According to the manufacturers, combined detergents generally only function up to a water hardness of 26 °E. With a water hardness above 26 °E you will need to add special salt and rinse aid. For the best washing and drying results we recommend using special salt and rinse aid from a water hardness of 17 °E. If you are using combined detergent, the washing programme is adjusted automatically to ensure the best possible washing and drying result.

#### 12.2 Unsuitable detergents

Do not use detergent which could cause damage to the appliance or present a risk to health.

#### Hand washing-up liquid

Hand washing-up liquid can cause increased frothing and damage the appliance.

#### **Detergent containing chlorine**

Chlorine residue on tableware may present a risk to health.

#### 12.3 Information on detergents

Follow the instructions on detergents in everyday use.


- Detergents marked as "organic" or "ecological" (environmentally friendly) generally contain lower levels of active agents or completely dispense with certain substances. The cleaning effect may be restricted here.
- Set the rinse aid and the water softening system to the separate detergent or combined detergent in use.
- According to the manufacturers, combined detergents with salt replacement substances can only be used up to a certain water hardness, usually 26 °E, without adding special salt. For the best washing and drying results we recommend using special salt from a water hardness of 17 °E.
- To prevent sticking, only touch detergents in a water-soluble pouch

with dry hands and only ever place them in a dry detergent dispenser.

- Even if the rinse aid and special salt refill indicators light up, washing programmes will run properly with combined detergents.
- The function of rinse aid is limited with combined detergents. You will generally get better results using a separate rinse aid.
- Use tablets with a special drying performance.

#### 12.4 Adding detergent

- **1.** To open the detergent dispenser, press the locking latch.
- **2.** Add the detergent to the dry detergent dispenser.




If you are using tablets, one is enough. Insert the tablets in a horizontal position.

If you are using powder or liquid detergent, follow the manufacturer's instructions and quantities for dosage in the detergent dispenser.

20 ml – 25 ml detergent is sufficient for normal soiling. If tableware is only lightly soiled, slightly less than the amount of detergent specified is usually sufficient.

- en Tableware
- **3.** Close the lid of the detergent dispenser.



- ✓ The lid clicks into position.
- The detergent dispenser will open automatically at the optimum time during the programme. Powder or liquid detergent will spread around the washing tank and dissolve there. Tablets will fall into the tab-

let collecting tray and dissolve in the right dosage. In order to ensure that tablets can dissolve evenly, do not place any other objects in the tablet collecting tray.

**Tip:** If you use powder detergent and select a program with pre-rinse, you can also add a little detergent to the interior door of the appliance.

## 13 Tableware

Only clean tableware that is suitable for dishwashers.

**Note:** Decorated glassware and parts made of aluminium or silver may fade or discolour with dishwashing. Delicate types of glass may turn cloudy after a few washing cycles.

#### 13.1 Damage to glass and tableware

Only put glasses and china in the dishwasher if it is marked as dishwasher-safe by the manufacturer. Avoid damage to glass and tableware.

Cause	Recommendation
<ul> <li>The following tableware is not dishwasher-safe:</li> <li>Items of cutlery and tableware made from wood</li> <li>Decorated glassware, antique and hand-crafted tableware</li> <li>Plastic parts not resistant to heat</li> <li>Tableware made from copper or tin</li> <li>Tableware soiled with ash, wax, lubricating grease or paint</li> <li>Very small items of tableware</li> </ul>	Only put tableware in the dishwasher if it is marked as dishwasher-safe by the manufacturer.
The chemical composition of deter-	Use a detergent marked by the manu-
gent causes damage.	facturer as gentle on tableware.
Highly caustic alkaline or highly acidic	If you are using highly caustic alkaline
cleaning solutions, in particular com-	or highly acidic cleaning agents, in par-
mercial or industrial cleaners, are not	ticular commercial or industrial clean-
safe to use in the dishwasher with alu-	ing agents, do not put aluminium parts
minium.	in the dishwasher interior.


Cause	Recommendation
The water temperature of the pro- gramme is too high.	Select a programme with lower temper- atures.
	After the programme has ended, take glassware and cutlery out of the appli-

ance without delay.

#### 13.2 Arrange tableware

Arrange tableware correctly to optimise the dishwashing result and prevent damage to both the appliance and tableware.


**Note:** Load the baskets so that no projecting items of tableware interfere with closing of the door. Projecting items of tableware may push the appliance door open during the programme, so allowing steam to escape and water to leak out around the door. This could damage your kitchen units.



#### Tips

- Using the appliance allows you to save energy and water compared to washing-up by hand.
- See our website for examples of how to load your appliance efficiently.
- To save energy and water, load the machine with the number of place settings specified (standard load with tableware and cutlery).
   → "Technical specifications", Page 52

• For better washing and drying results, position items with curves or recesses at an angle so water can run off.




**1.** Remove large remnants of food from tableware.

To save resources, do not prerinse tableware under running water.

- 2. Observe the following when arranging tableware:
  - Put heavily soiled tableware in the bottom basket, e.g. pans.
     The more powerful the spray jet, the better the dishwashing result will be.
  - To prevent damage to tableware, arrange it so it is stable and cannot tip over.
  - To prevent injury, arrange cutlery with the points and sharp edges facing down.
  - Position containers with the openings facing down so no water can collect in them.
  - Do not block the spray arms make sure that they can turn freely.

- Arrange the cutlery drawer so that cutlery items do not project beyond the upper edge of the cutlery drawer. Cutlery items that project beyond the upper edge of the cutlery drawer will touch the tub when inserted and may block the top spray arm. If you have a cutlery drawer with shelves that fold down at the sides, use the shelves for large cutlery items.<sup>1</sup>
- Do not place small parts in the tablet collecting tray and do not block it with tableware so as not to obstruct the lid of the detergent dispenser.



### 13.3 Removing tableware

#### ⚠ WARNING Risk of injury!

Hot tableware can cause burns to the skin. When hot, tableware is sensitive to shock, may crack and can result in injury.

- When the programme has ended, do not empty the appliance until the tableware has cooled down for a while.
- **1.** To prevent water dripping on the tableware, unload it starting at the bottom and working up.

Check the washing tank and accessories for soiling and clean if necessary.
 → "Cleaning and servicing", Page 39

## 14 Basic operation

#### 14.1 Switching on the appliance

#### ► Press ①.

The Eco 50  $^\circ$  programme is set by default.

The Eco 50° programme is especially environmentally friendly and ideal for normally soiled tableware. It is the most efficient programme for the combination of energy/water consumption for this type of tableware and evidences conformity with the EU Ecodesign Directive.

If you do not perform any actions on the appliance for 10 minutes, the appliance will automatically switch off.

### 14.2 Setting a programme

To adjust the washing programme to the soiling level of the tableware, select a suitable programme.

**Requirement:** The appliance door is closed.

- Press the right programme button.
- The programme is set and the programme button flashes.
- The remaining running time of the programme appears on the display.

<sup>&</sup>lt;sup>1</sup> Depending on the appliance specifications

#### 14.3 Setting additional functions

You can set additional functions to complete the washing programme selected.

**Note:** The additional functions which can be used depend on the programme selected.

- Press the button for the relevant additional function.
  - → "Additional functions", Page 19
- The additional function is set and the additional function button flashes.

#### 14.4 Setting timer programming

You can delay the start of the programme by up to 24 hours.

- **1.** Press  $\bigcirc$  or +  $\bigcirc$ .
- "00h:01m" appears on the display.
- **2.** Use  $\bigcirc$  or  $+ \bigcirc$  to set the required start time for the programme.
- 3. Press Start.
- This activates time preselection.

**Tip:** To deactivate timer programming, press  $- \bigcirc$  or  $+ \bigcirc$  repeatedly until "00h:00m" appears in the display.

#### 14.5 Starting the programme

- Press Start.
- The programme has ended when the display shows "00h:00m".

#### Notes

 If you want to add more tableware while the appliance is running, do not use the tablet collecting tray as a handle for the top basket. You might touch the partially dissolved tablet.  You can only change a programme when running if you cancel it.

→ "Terminate programme", Page 34

 The appliance switches off automatically 1 minute after the end of the programme to save energy. If you open the appliance door immediately after the programme has ended, the appliance will switch off after 4 seconds.

#### 14.6 Activating button lock

The button lock prevents the appliance from being operated accidentally or incorrectly while running.

- ► Press 🖘 for approx. 3 seconds.
- The button lock is activated and will be automatically deactivated at the end of the programme.
- The display shows "CL" when the appliance is running.
- The button lock remains activated with a power failure.

#### 14.7 Deactivate button lock

► Press 🖘 for approx. 3 seconds.

#### 14.8 Interrupting programme

**Note:** When you open the appliance door once the appliance has heated up, leave the door slightly ajar for a few minutes and then close it. This will help prevent excess pressure building up in the appliance and stop the appliance door bursting open.

- 1. Press ().
- The programme is saved and the appliance switches off.
- 2. Press () to resume the programme.

#### 14.9 Terminate programme

To end a programme early or to switch from a programme that has already started, you will need to cancel it first.

- Press Reset 4 sec. for approx. 4 seconds.
- The programme is terminated and the appliance is reset. All LEDs light up for approx. 1 minute.
- As soon as the LEDs are off, the display shows "00h:01m" and the residual water is pumped out.
- The programme is cancelled and ends after approx. 1 minute.

#### 14.10 Switching off appliance

- **1.** Please note the information on Safe use  $\rightarrow$  Page 9.
- 2. Press ().

**Tip:** If you press <sup>()</sup> during the wash cycle, the programme currently running will be interrupted. When you switch the appliance back on, the programme continues automatically.

## 15 Basic settings

You can configure the basic settings for your appliance to meet your needs.

#### **15.1 Overview of the basic settings**

The basic settings depend on the features of your appliance.

Basic setting	Display text	Selection	Description
Water hardness	H:04 <sup>1</sup>	H:00 - H:07	Set the water softening sys- tem to your water hardness. → "Setting the water softening system", Page 24 Level H:00 switches the water softening system off.
Rinse aid dis- pensing	r:05 <sup>1</sup>	r:00 - r:06	Set the amount of rinse aid to be dispensed. Switch the rinse aid system off with level r:00.
Sensor setting	SE:00 1	SE:00 - SE:02	Set the water sensor for identifying soiling. → "Sensors", Page 10
Extra Dry	d:00 <sup>1</sup>	d:00 - d:01	The temperature is increased during the final rinse, which improves the drying result. This may increase the run time slightly. <b>Note:</b> Not suitable for delicate items of tableware.

<sup>&</sup>lt;sup>1</sup> Factory setting (may vary according to model)

Basic setting	Display text	Selection	Description
			Switch Extra Dry on "d:01" or off "d:00".
Hot water	A:00 <sup>1</sup>	A:00 - A:01	Set cold water or hot water connection. Only set the ap- pliance to hot water if this can be prepared with little en- ergy and a suitable installa- tion is available, e.g. solar heating system with circula- tion line. The water temperat- ure should be at least 40 °C and max. 60 °C. Switch hot water on "A:01" or off "A:00".
Start programme	SP:01 <sup>1</sup>	SP:00 - SP:01	<ul> <li>Set a default programme for when the appliance is switched on.</li> <li>With the setting "SP:00", the last programme selected is set by default when the appliance is switched on.</li> <li>With the setting "SP:01", the Eco 50° programme is set by default when the appliance is switched on.</li> </ul>
Tone volume	SL:02 <sup>1</sup>	SL:00 -SL:03	Adjustment of tone volume. Level "SL:00" switches the signal tone off. If the Eco drying function is activated, the end of the pro- gramme is not indicated by an audible signal tone.
Button volume	bL:02 <sup>1</sup>	bL:00 - bL:03	Set the button volume during operation. Level "bL:00" switches the button tones off.
autoOpen Dry	o:01 <sup>1</sup>	o:00 - o:02	Activate or deactivate auto- matic opening of the appli- ance door during the drying phase.

<sup>&</sup>lt;sup>1</sup> Factory setting (may vary according to model)

Basic setting	Display text	Selection	Description
			<ul> <li>If the function has been activated, the running time may increase.</li> <li>The following settings are possible:</li> <li>With the setting "o:00" automatic door opening is deactivated in all programmes.</li> <li>With the setting "o:01" automatic door opening is activated in all programmes.</li> <li>With the setting "o:01" automatic door opening is activated in all programmes.</li> <li>With the setting "o:02" automatic door opening is activated only in the Eco 50°C programme.</li> <li>→ "autoOpen Dry", Page 11</li> </ul>
Wi-Fi	Cn:00	Cn:00 - Cn:01	Switch the wireless network connection on or off. Level "Cn:00" switches the wireless network connection off. This basic setting is not avail- able until you have connected the appliance with the Home Connect app. $\rightarrow$ "Home Connect ", Page 37
Remote Start	rc:01	rc:00 - rc:02	<ul> <li>Activate or deactivate .</li> <li>→ "Remote Start □", Page 38</li> <li>The following settings are possible:</li> <li>With the setting "rc:00", the function is permanently deactivated.</li> <li>With the setting "rc:01", the function can be selected via the □ button.</li> <li>→ "Activating Remote Start □", Page 38</li> <li>With the setting "rc:02", the function is permanently activated.</li> </ul>

Basic setting	Display text	Selection	Description
			This basic setting is not avail- able until after you have con- nected the device with the Home Connect app. $\rightarrow$ "Home Connect ", Page 37
Factory setting	rE:	Start with + Y:ES Confirm with +	Restore changed settings to the factory settings. The settings for initial start-up must be configured.

#### 15.2 Changing basic settings

**Tip:** Connect your appliance to a mobile device. You can conveniently change all settings via the Home Connect app.

- → "Home Connect ", Page 37
- 1. Press ().
- 2. To open the basic settings, press Setup 3 sec. for 3 seconds.
- ✓ The display shows H:xx.
- The display shows set.
- **3.** Press Setup 3 sec. repeatedly until the display shows the required setting.
- Press or + repeatedly until the display shows the right value. You can change several settings.
- **5.** To save the settings, press Setup 3 sec. for 3 seconds.

# **16 Home Connect**

This appliance is network-capable. Connect your appliance to a mobile device to control its functions via the Home Connect app.

The Home Connect services are not available in every country. The avail-

ability of the Home Connect function depends on the availability of Home Connect services in your country. You can find information about this at: *www.home-connect.com*. To be able to use Home Connect, you must first set up the connection to the WLAN home network (Wi-Fi<sup>1</sup>) and to the Home Connect app. The Home Connect app guides you through the entire login process. Follow the instructions in the Home Connect app to configure the settings.

**Tip:** Please also follow the instructions in the Home Connect app.

**Note:** Please note the safety precautions in this instruction manual and make sure that they are also observed when operating the appliance via the Home Connect app.

→ "Safety", Page 3

# 16.1 Setting up Home Connect

#### Requirements

- The appliance is receiving signals from the WLAN home network (Wi-Fi) at its installation location.
- The appliance door is closed.

<sup>&</sup>lt;sup>1</sup> Wi-Fi is a registered trademark of the Wi-Fi Alliance.

1. Scan the following QR code.



You can install the Home Connect app and connect your appliance via the QR code.

**2.** Follow the instructions in the Home Connect app.

# 16.2 Remote Start

You can use the Home Connect app to start the appliance with your mobile device.

**Tip:** If you select "rc:02" in the Basic settings  $\rightarrow$  *Page 36* of this function, the function is permanently activated and you can start your appliance with a mobile device at any time.

#### Activating Remote Start D

When you have selected "rc:01" in the basic settings of this function, activate the function on your appliance.

#### Requirements

- The appliance is connected to your WLAN home network.
- The appliance is connected to the Home Connect app.
- "rc:01" is selected in the Basic settings → Page 36 of this function.
- A programme is selected.
- Press D.
   If you open the appliance door, the function is automatically deactivated.
- ✓ □ button lights up.

**Tip:** To deactivate the function, press  $\vec{D}$ .

# 16.3 Smart Start<sup>1</sup>

Smart Start automatically determines the optimal time for the programme to start.

You can use the Home Connect app to activate or deactivate the function.

#### Activating Smart Start

#### Requirements

- Smart Start is activated via the Home Connect app.
- Preferences for time and energy are set in the Home Connect app.
- 1. Press 🕛.
- ✓ "E:nG" lights up in the display.
- The display shows the optimal start time and the duration of the selected programme.
- 2. Press Start.
- Smart Start is active.
- The programme starts as soon as the optimal time is reached.

**Tip:** Deactivate the function a single time by pressing  $\mathfrak{O}$ .

## 16.4 Data protection

Please see the information on data protection.

The first time your appliance is registered on a home network connected to the Internet, your appliance will transmit the following types of data to the Home Connect server (initial registration):

 Unique appliance identification (consisting of appliance codes as well as the MAC address of the Wi-Fi communication module installed).

<sup>&</sup>lt;sup>1</sup> Depending on the appliance specifications

- Security certificate of the Wi-Fi communication module (to ensure a secure data connection).
- The current software and hardware version of your appliance.
- Status of any previous reset to factory settings.

This initial registration prepares the Home Connect functions for use and is only required when you want to use the Home Connect functions for the first time.

**Note:** Please note that the Home Connect functions can only be utilised with the Home Connect app. Information on data protection can be retrieved in the Home Connect app.

# 17 Cleaning and servicing

To keep your appliance working efficiently for a long time, it is important to clean and maintain it carefully.

## 17.1 Cleaning the tub

#### ⚠ WARNING Risk of harm to health!

Using detergents containing chlorine may result in harm to health.

 Never use detergents containing chlorine.

## 17.4 Machine Care 🛱

Deposits, e.g. from remnants of food and limescale, can cause your appliance to malfunction. To avoid such faults and reduce odours, we recommend cleaning your appliance at regular intervals.

Machine Care combined with machine care products and machine cleaners is the right programme for the care of your appliance.

**Tip:** You can get our tested and approved Dishwasher Care and Machine Cleaner for Dishwashers online at *https://www.siemens-home.bsh-group.com/store* or from customer service.

Machine Care is a programme which removes various deposits in one washing cycle. Cleaning takes place in two phases:

- **1.** Remove any coarse soiling in the interior with a damp cloth.
- 2. Add detergent to the detergent dispenser.
- **3.** Select the programme with the highest temperature.
- Start the programme without tableware. → Page 33

### 17.2 Cleaning products

Only use suitable cleaning products to clean your appliance.

→ "Safe use", Page 9

### 17.3 Tips on appliance care

Follow the tips on appliance care to make sure your appliance functions properly at all times.

Action	Benefit
Wipe the door seals, the front of the dishwasher and the control panel regularly using a damp cloth and wash- ing-up liquid.	This ensures the parts of the appli- ance will remain clean and hy- gienic.
If the appliance is not going to be used for a while, leave the door slightly ajar.	This will prevent unpleasant odours.

Phase	Removal of	Detergent	Placement
1	Grease and limes- cale	Liquid machine care product or machine descaler in powder form.	Appliance interior, e.g. bottle hung in the cut- lery basket or powder in the interior.
2	Food remnants and deposits	Machine cleaner	Detergent dispenser

To ensure optimum cleaning performance, the programme doses the detergents independently of each another during the relevant cleaning phase. Correct placement of the detergents is necessary here. Run Machine Care without tableware if the indicator for Machine Care lights up on the control panel or if advised to do so by the display. The indicator will go out after you have run Machine Care. If your appliance does not have a reminder function, we recommend performing Machine Care every 2 months.

#### **Running Machine Care**

#### Notes

- Run the Machine Care programme without any tableware in the dishwasher.
- Only use machine care products and machine cleaners specially designed for dishwashers.
- Make sure that there are no aluminium parts, e.g. extractor hood grease filters or aluminium pans, in the interior of the appliance.
- If you have not run Machine Care after 3 washing cycles, the indic-

ator for Machine Care will go out automatically.


- For optimum cleaning performance, ensure the correct placement of cleaners.
- Follow the safety instructions given on the packagings of the machine care products and machine cleaners.
- Activate the function.
   → "glassZone", Page 21
- 1. Remove any coarse soiling in the interior with a damp cloth.
- 2. Clean the filters.
- **3.** Place the machine care product in the appliance interior. Only use machine care products specially designed for dishwashers.
- 4. Pour the machine cleaner into the detergent dispenser until it is filled completely.

Do not place any additional machine cleaner in the appliance interior.

- **5.** Press 🗳.
- 6. Press Start.
- Machine Care is run.
- Once the programme has ended, the indicator for Machine Care goes out.

# 17.5 Filter system

The filter system removes coarse soiling from the dishwashing cycle.




- 1 Micro filter
- 2 Fine filter

3 Coarse filter


### **Cleaning filters**

Soiling in the dishwashing water may block the filters.


- **1.** After each wash check the filters for residue.
- Turn the coarse filter anticlockwise
   and remove the filter system 2.
  - Check that no foreign objects fall into the sump.



**3.** Pull down the micro filter to remove.



 Press the locking catches ① together and lift the coarse filter out ②.




5. Clean the filter elements under running water.

Carefully clean the rim of dirt between the coarse and the fine filter.

**6.** Re-assemble the filter system. Make sure that the locking catches on the coarse filter click into position.

- en Cleaning and servicing
- **7.** Insert the filter system into the appliance and turn the coarse filter clockwise.
  - Make sure that the arrow markings match up.




**Tip:** Connect your appliance to a mobile device. The Home Connect app will tell you as soon as you need to clean the filters.

→ "Home Connect ", Page 37

## 17.6 Cleaning spray arms


Limescale and soiling in the dishwashing water may block the nozzles and bearings on the spray arms. Clean the spray arms regularly.

- **1.** Take out the cutlery drawer.<sup>1</sup>
- Press the top spray arm → Page 13
   ① up and rotate anticlockwise as far as possible ②.




The top spray arm is unlocked.

- **3.** Remove the top spray arm downwards.
- 4. Unscrew the upper spray arm ① and pull down to remove ②.




5. Pull up the lower spray arm to remove.



- 6. Check the outlet nozzles on the spray arms for blockages under running water and remove any foreign objects.
- 7. Insert the lower spray arm.
- The spray arm clicks into position.
- 8. Insert the upper spray arm and screw it firmly in place.

<sup>&</sup>lt;sup>1</sup> Depending on the appliance specifications

- 9. Insert the top spray arm.
  - Push the top spray arm up ① and rotate clockwise as far as possible ②.



The top spray arm is locked.
 10.Insert the cutlery drawer.<sup>1</sup>


# 17.7 Cleaning glassZone

Limescale and soiling from the dishwashing water can block the nozzles.


**Note:** Always operate the appliance with the glassZone fitted.

1. Pull out the top basket.

2. Pull the tab on the glassZone up ① and forwards ②.



- 3. Set the slider to ON.
- 4. Clean under running water.
- 5. Place the glassZone in the top basket and lock in position ①.



Check that the mounts are in the correct position.

- The glassZone audibly clicks into position <sup>(2)</sup>.
- 6. Push in the top basket.

# 18 Troubleshooting

You can rectify minor faults on your appliance yourself. Read the troubleshooting information before contacting after-sales service. This will avoid unnecessary costs.

**Tip:** You can find further information and explanations on troubleshooting online by scanning the QR code on the title page and on our website siemenshome.bsh-group.com.

<sup>&</sup>lt;sup>1</sup> Depending on the appliance specifications

# 

#### **Risk of electric shock!**

Improper repairs are dangerous.

- Repairs to the appliance should only be carried out by trained specialist staff.
- Only use genuine spare parts when repairing the appliance.
- If the power cord or the appliance power cable of this appliance is damaged, it must be replaced with a special power cord or special appliance power cable, which is available from the manufacturer or its Customer Service.

Fault	Cause and troubleshooting
Display "Check water supply" flashes	<ul> <li>A technical fault is present.</li> <li>1. Press <sup>(1)</sup>.</li> <li>2. Unplug the appliance or switch off the fuse.</li> <li>3. Wait at least 2 minutes.</li> <li>4. Insert the mains plug of the appliance in a socket or switch on the fuse.</li> <li>5. Switch the appliance on.</li> <li>6. If the problem occurs again: <ul> <li>Press <sup>(1)</sup>.</li> <li>Turn off the water tap.</li> <li>Pull out the mains plug.</li> <li>Contact Customer Service → Page 51 and give the error code.</li> </ul> </li> </ul>
E:30-00 will light up alternately.	<ul> <li>Water protection system is activated.</li> <li>1. Turn off the water tap.</li> <li>2. Call Customer Service → Page 51.</li> </ul>
E:31-00 will light up alternately.	Water protection system is activated. <b>1.</b> Turn off the water tap. <b>2.</b> Call Customer Service $\rightarrow$ Page 51.
E:32-00 will light up alternately or indicator for water supply lights	Supply hose is kinked. • Install the inlet hose without kinks. Water tap is turned off.
up.	<ul> <li>Turn on the water tap.</li> <li>Water tap is jammed or furred up.</li> <li>Turn on the water tap.</li> <li>The flow rate must be at least 10 l/min when the water supply is open.</li> </ul>

Fault	Cause and troubleshooting
E:32-00 will light up alternately or indicator for water supply lights up.	<ul> <li>The filters in the water connection of the supply or AquaStop hose are blocked.</li> <li>1. Switch off the appliance.</li> <li>2. Pull out the mains plug.</li> <li>3. Turn off the water tap.</li> <li>4. Unscrew the water connection.</li> <li>5. Remove the filter from the inlet hose</li> <li>Image: Constant of the supply of the supplication of the super supplication of the supp</li></ul>
E:34-00 will light up alternately.	Water is continuously running into the appliance. <b>1.</b> Turn off the water tap. <b>2.</b> Call Customer Service → <i>Page 51</i> .
E:61-02 will light up alternately.	<ul> <li>Not an appliance fault. Wastewater pump is blocked or the cover of the wastewater pump is loose.</li> <li>1. Clean the wastewater pump. → "Clean wastewater pump", Page 49</li> <li>2. Secure the cover of the wastewater pump so it clicks into position. → "Clean wastewater pump", Page 49</li> </ul>
E:61-03 will light up alternately. Water is not drained.	<ul> <li>Not an appliance fault. Siphon connection is still closed or the wastewater hose is kinked or blocked.</li> <li>1. Check the connection to the siphon and open if necessary.</li> <li>2. Install wastewater hose without kinks.</li> <li>3. Remove residues.</li> </ul>

Fault	Cause and troubleshooting
E:61-03 will light up alternately. Water is not drained.	
	<ul> <li>Not an appliance fault. Wastewater pump is blocked or the cover of the wastewater pump is loose.</li> <li>1. Clean the wastewater pump.</li> <li>→ "Clean wastewater pump", Page 49</li> <li>2. Secure the cover of the wastewater pump so it clicks into position.</li> <li>→ "Clean wastewater pump", Page 49</li> </ul>
E:92-40 will light up alternately.	<ul> <li>Filters are soiled or blocked.</li> <li>Clean the filters.</li> <li>→ "Cleaning filters", Page 41</li> </ul>
All LEDs lit up or flashing.	<ul> <li>A software update is possibly installing.</li> <li>1. Wait until the software update has been installed. This process can take approx. 30 minutes.</li> <li>2. If the appliance is not ready to use after 30 minutes, perform a reset.</li> <li>Press the main switch button for approx. 4 seconds.</li> <li>Your appliance is resetting.</li> </ul>

Fault	Cause and troubleshooting
All LEDs lit up or flashing.	<ul> <li>Electronics have detected a fault.</li> <li>1. Press the main switch button for approx. 4 seconds. → "Controls", Page 14 The appliance is reset and restarted.</li> <li>2. If the problem occurs again: <ul> <li>Switch off the appliance.</li> <li>Pull out the mains plug or switch off the fuse in the fuse box.</li> <li>Wait at least 2 minutes.</li> <li>Switch on the fuse in the fuse box or insert the mains plug.</li> <li>Switch the appliance on.</li> </ul> </li> <li>3. If the problem occurs again: <ul> <li>Contact customer service.</li> <li><i>"Customer Service", Page 51</i></li> </ul> </li> </ul>
Remnants of food on tableware.	<ul> <li>Tableware is placed too close together or basket is overfilled.</li> <li>1. Arrange tableware with sufficient space in between. The spray jets must reach the surfaces of the tableware.</li> <li>2. Avoid points of contact.</li> </ul>
	<ul> <li>Spray arm rotation is blocked.</li> <li>Arrange tableware so that it does not obstruct spray arm rotation.</li> <li>Spray arm nozzles are blocked.</li> <li>Clean the spray arms.</li> <li>→ "Cleaning spray arms", Page 42</li> </ul>
	Filters are soiled. <ul> <li>Clean the filters.</li> <li>→ "Cleaning filters", Page 41</li> </ul>

Fault	Cause and troubleshooting			
Remnants of food on tableware.	<ul> <li>Filters are inserted incorrectly and/or not engaged.</li> <li>1. Insert the filters properly. <ul> <li>→ "Filter system", Page 41</li> </ul> </li> <li>2. Engage the filters.</li> <li>Washing programme selected too weak.</li> <li>► Select a more intensive washing programme.</li> </ul>			
	<ul> <li>→ "Programmes", Page 17</li> <li>Adjust the sensitivity of the sensors.</li> <li>→ "Sensors", Page 10</li> </ul>			
	<ul> <li>Tableware has been precleaned too intensely. The sensors chose a weaker programme. Stubborn soiling cannot be entirely removed.</li> <li>Only remove large remnants of food and do not prerinse tableware.</li> <li>Adjust the sensitivity of the sensors.</li> <li>→ "Sensors", Page 10</li> </ul>			
	<ul> <li>Tall narrow receptacles in corner areas are not rinsed adequately.</li> <li>Do not position tall narrow receptacles at too great an angle or in corner areas.</li> </ul>			
	<ul> <li>Top baskets on right and left are not set to same height.</li> <li>▶ Set the upper basket on the left and right to the same height.</li> <li>→ "Top basket", Page 20</li> </ul>			
Removable streaks are present on glasses, glassware	<ul> <li>Amount of rinse aid to be dispensed is set too high.</li> <li>Set the rinse aid system to a lower setting.</li> <li>→ "Setting the amount of rinse aid", Page 27</li> </ul>			
with a metallic appear- ance and cutlery.	<ul> <li>No rinse aid has been added.</li> <li>Add rinse aid.</li> <li>→ "Adding rinse aid", Page 26</li> </ul>			
	<ul> <li>Detergent residue is present in the final rinse. Lid of the detergent dispenser is blocked by tableware items and will not open fully.</li> <li>1. Arrange tableware in the top basket tableware so the tab collecting tray is not obstructed by tableware. → "Arrange tableware", Page 31 Items of tableware are blocking the dispenser lid.</li> <li>2. Do not place tableware or fragrance dispensers in the tablet collecting tray.</li> </ul>			

Fault	Cause and troubleshooting
Removable streaks are present on glasses, glassware with a metallic appear- ance and cutlery.	<ul> <li>Tableware has been precleaned too intensely. The sensors chose a weaker programme. Stubborn soiling cannot be entirely removed.</li> <li>Only remove large remnants of food and do not prerinse tableware.</li> <li>Adjust the sensitivity of the sensors. → "Sensors", Page 10</li> </ul>
Rust spots on cutlery.	Cutlery is not sufficiently rust-resistant. Knife blades are often more severely affected. • Use rust-resistant tableware.
	Cutlery may also rust if washed together with rusting items. ► Do not wash rusting items.
	<ul><li>Salt content in washing water is too high.</li><li>1. Remove any spilled special salt from the tub.</li><li>2. Screw the cap of the special salt dispenser on tight.</li></ul>
Detergent residue is present in the deter- gent dispenser or the tablet collecting tray.	<ul> <li>Spray arms were blocked by tableware so detergent was not rinsed out.</li> <li>Check that the spray arms are not blocked and can rotate freely.</li> </ul>
	<ul> <li>Detergent dispenser was damp when detergent was added.</li> <li>Only add detergent to a detergent dispenser when dry.</li> </ul>
Special salt refill indicator lights up.	Insufficient special salt. ► Add Special salt → <i>Page 25</i> .
	<ul><li>Sensor does not detect special salt tablets.</li><li>Do not use special salt tablets.</li></ul>

#### 18.1 Clean wastewater pump

Large remnants of food or foreign bodies can block the waste water pump. As soon as the rinsing water no longer drains properly, the waste water pump must be cleaned.


#### ⚠ WARNING Risk of injury!

Sharp and pointed objects or fragments of glass may block the waste water pump and cause injury.

 Remove any foreign bodies carefully.

- 1. Disconnect the appliance from the mains.
- 2. Remove the top and bottom basket.
- 3. Remove the filter system.
- **4.** Scoop out any water. Use a sponge if necessary.

- en Transportation, storage and disposal
- **5.** Prise off the pump cover using a spoon and grip it by the crosspiece.



- **6.** Lift the pump cover inwards at an angle and remove.
- You can now reach the impeller with your hand.
- **7.** Remove any remnants of food and foreign bodies in the area of the impeller.
- 8. Insert the pump cover ① and press down ②.



- The pump cover clicks into position.
- 9. Install the filter system.
- 10.Insert the top and bottom basket.
- **11.**Connect the appliance to the mains.

# 19 Transportation, storage and disposal

#### 19.1 Removing the appliance

- **1.** Disconnect the appliance from the mains power supply.
- 2. Turn off the water tap.
- **3.** Detach the drainage connection.
- 4. Detach the drinking water connection.
- **5.** Loosen any screws fastening the appliance to cabinet parts.
- 6. Remove the base panel if fitted.
- 7. Pull the appliance out carefully, along with the hose behind it.

# 19.2 Protect appliance from frost

If there is a risk of frost where the appliance will be standing, e.g. in a holiday home, empty the appliance completely.

 Empty the appliance.
 → "Transporting the appliance", Page 50

#### 19.3 Transporting the appliance

To avoid damage to the appliance, empty it before transporting.

**Note:** Always transport the appliance upright to prevent residual water getting into the machine's controls and damaging the appliance.

- **1.** Remove tableware from the appliance.
- 2. Secure loose parts.
- **3.** Switch on the appliance.  $\rightarrow$  *Page 32*
- 4. Select the programme with the highest temperature.
  - → "Programmes", Page 17
- **5.** Start the programme.  $\rightarrow$  *Page 33*

 To drain the appliance, terminate the programme after approx.
 4 minutes.

→ "Terminate programme", Page 34

- **7.** Switch off the appliance.  $\rightarrow$  Page 34
- 8. Turn off the tap.
- **9.** To empty the residual water out of the appliance, detach the supply hose and let the water drain out.

#### 19.4 Disposing of old appliance

Valuable raw materials can be reused by recycling.

# WARNING Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.
- **1.** Unplug the appliance from the mains.
- 2. Cut through the power cord.
- Dispose of the appliance in an environmentally friendly manner. Information about current disposal methods are available from your specialist dealer or local authority.



This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE). The guideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.

# 20 Customer Service

Function-relevant genuine spare parts according to the corresponding Ecodesign Order can be obtained from Customer Service for a period of at least 10 years from the date on which your appliance was placed on the market within the European Economic Area.

**Note:** Under the terms of the manufacturer's warranty the use of Customer Service is free of charge.

Detailed information about the warranty period and the warranty conditions in your country is available via the QR code on the enclosed document on service contacts and warranty conditions, from our customer service or on our website.

If you contact Customer Service, you will require the product number (E-Nr.), the production number (FD) and the consecutive numbering (Z-Nr.) of your appliance.

You can find the contact details for our customer service via the QR code on the enclosed document on service contacts and warranty conditions or on our website.

#### 20.1 Product number (E-Nr.), production number (FD) and consecutive numbering (Z-Nr.)

You can find the product number (E-Nr.), the production number (FD) and

the consecutive numbering (Z-Nr.) on the appliance's rating plate.

The rating plate is located inside the appliance door.

→ "Familiarising yourself with your appliance", Page 13

Make a note of your appliance's details and the Customer Service telephone number to find them again quickly.

# 20.2 AQUA-STOP guarantee

In addition to warranty claims against the seller under the purchase agreement and in addition to our manufacturer's warranty, we offer compensation under the following conditions.

If our Aqua-Stop system is defective and causes water damage, we will make good the damage for private users. To ensure protection from water damage, the appliance

21 Technical specifications

must be connected to the power supply.

- The liability guarantee is valid for the service life of the appliance.
- A claim can only be made under the guarantee if the appliance has been correctly installed and connected with Aqua-Stop according to our instructions: this also includes correctly fitting the Aqua-Stop extension (genuine accessory). Our guarantee does not cover defective supply lines or fittings up to the Aqua-Stop connection on the tap.
- If your appliance is fitted with Aqua-Stop, you can in principle leave your appliance unattended during operation and the tap turned on afterwards. The tap only needs to be turned off if you are away from home for a long period, e.g. on holiday for several weeks.

Weight	Max.: 60 k	g
Voltage	220 - 240	V, 50 Hz or 60 Hz
Power rating	2000 - 240	00 W
Fuse	10 - 16 A	
Water pressure		kPa (0.5 bar) 00 kPa (10 bar)
Inlet rate	Min. 10 l/n	nin
Water temperature Cold water Hot water		max.: 60 °C
Capacity 14 place se		ettings
More information about your model		This web address is linked to the offi- cial EU EPREL product database

can be found online at https:// eprel.ec.europa.eu/qr/22257631. EL product database.

<sup>&</sup>lt;sup>1</sup> Only applies to countries in the European Economic Area

#### 21.1 Information regarding Free and Open Source Software

This product includes software components that are licensed by the copyright holders as free or open source software.

The applicable licence information is stored on your home appliance. You can also access the applicable licence information via your Home Connect app: "Profile -> Legal information -> Licence Information".<sup>1</sup> You can download the licence information on the brand product website. (Please search on the product website for your appliance model and additional documents). Alternatively, you can request the relevant information from ossrequest@bshg.com or BSH Hausgeräte GmbH, Carl-Wery-Str. 34, 81739 Munich, Germany. The source code will be made available to you on request. Please send your request to ossrequest@bsha.com or BSH Hausgeräte GmbH, Carl-Wery-Str.34, 81739 Munich, Germany. Subject: "OSSREQUEST" The cost of performing your request will be charged to you. This offer is valid for three years from the date of purchase or at least as long as we offer support and spare parts for the relevant appliance.

# 22 Declaration of Conformity

BSH Hausgeräte GmbH hereby declares that the appliance with Home Connect functionality conforms to the essential requirements and other relevant provisions of Directive 2014/53/EU.

A detailed RED Declaration of Conformity can be found online at siemenshome.bsh-group.com among the additional documents on the product page for your appliance.

# CE Hereby

Hereby, BSH Hausgeräte GmbH declares that the appliance with Home Connect functionality is in compliance with relevant statutory requirements.<sup>2</sup> A detailed Declaration of Conformity can be found online at siemens-home.bshgroup.com/uk/ among the additional documents on the product page for your appliance.<sup>2</sup>

# 

2.4 GHz band (2400–2483.5 MHz): Max. 100 mW 5-GHz band (5150–5350 MHz + 5470–5725 MHz): max. 180 mW

<b>e</b> E	ЗE	BG	CZ	DK	DE	EE	IE	EL	ES

<sup>&</sup>lt;sup>1</sup> Depending on the appliance specifications

<sup>&</sup>lt;sup>2</sup> Only applies to Great Britain

#### en Declaration of Conformity

	FR	HR	IT	CY	LI	LV	LT	LU	HU	
	MT	NL	AT	PL	PT	RO	SI	SK	FI	_
	SE	NO	СН	TR	IS	UK (NI)				
5 GHz	z WLAN	(Wi-Fi):	For inc	door use	e only.					_
AL BA MD ME MK RS UK UA										
5 GHz WLAN (Wi-Fi): For indoor use only.										

# 22.1 Statement of Compliance for Great Britain

The full Statement of Compliance according to the Product Security and Telecommunications Infrastructure (Security Requirements for Relevant Connectable Products) Regulations 2023 can be found online at www.siemens-home.bsh-group.com/ uk/home among the additional documents on the product page for your appliance.

#### **Product type**

This statement of compliance covers the products described in this information for use whose model identifier group is seen on the title page. The full model identifier is made up of the characters before the slash in the product number (E no.) which can be found on the rating plate. Alternatively, you can also find the model identifier in the first line of the UK Energy Label.

#### Name and address of manufacturer

BSH Hausgeräte GmbH, Carl-Wery-Strasse 34, 81739 München, Germany

This statement of compliance is prepared by the manufacturer.

The manufacturer, BSH Hausgeräte GmbH deems that it has complied with

- provision 5.1-1 of ETSI EN 303 645 v2.1.1 and, where relevant, provision 5.1-2 of ETSI EN 303 645 v2.1.1;
- provision 5.2-1 of ETSI EN 303 645 v2.1.1;
- provision 5.3-13 of ETSI EN 303 645 v2.1.1.

#### Support period

BSH Hausgeräte GmbH will provide security updates that are necessary to maintain the main functions free of charge until at least 28/02/2034.

EN Manufactured by BSH Hausgeräte GmbH under the trademark licence of Siemens AG

Valid within Great Britain: Imported to Great Britain by BSH Home Appliances Ltd. Grand Union House Old Wolverton Road Wolverton, Milton Keynes MK12 5PT United Kingdom

#### **BSH Hausgeräte GmbH** Carl-Wery-Straße 34 81739 München, GERMANY siemens-home.bsh-group.com



9001992848 (050424) 650 A1