
NEFF
cook. create. inspire.



Extractor hood

[en] User manual and installation instructions

**D63IDF1S0 D83IDF1S0 D83IDF1S0B D63IDF1S0B**

**You can find additional information and explanations online.
Scan the QR code on the title page.**



# Table of contents

**INFORMATION FOR USE**

**1 Safety ..... 2**
**2 Avoiding material damage ..... 4**
**3 Environmental protection and saving energy ..... 4**
**4 Operating modes ..... 5**
**5 Familiarising yourself with your appliance ..... 5**
**6 Before using for the first time ..... 5**
**7 Basic operation ..... 5**
**8 Cleaning and servicing ..... 6**
**9 Troubleshooting ..... 7**
**10 Disposal ..... 8**
**11 Customer Service ..... 8**
**12 Accessories ..... 8**
**13 Test information ..... 8**

**14 INSTALLATION INSTRUCTIONS ..... 9**
**14.4 Secure installation ..... 10**

## ⚠ 1 Safety

Observe the following safety instructions.

### 1.1 Definition of the signal words

This is where you can find explanations for the safety signal words used in this manual.

**⚠ WARNING**
This indicates that death or serious injuries may occur as a result of non-observance of this warning.

**ATTENTION**
This indicates that damage to the appliance or other material damage may occur as a result of non-compliance with this warning.

**Note:** This alerts you to important information.

### 1.2 General information

- Read this instruction manual carefully.
- Keep the instruction manual and the product information safe for future reference or for the next owner.
- Do not connect the appliance if it has been damaged in transit.

### 1.3 Intended use

The appliance can only be used safely if it is correctly installed according to the safety instructions. The installer is responsible for ensuring that the appliance works perfectly at its installation location.

Only use this appliance:
- For extracting cooking vapour.
- in private households and in enclosed spaces in a domestic environment.
- Up to an altitude of 4000 m above sea level.

### 1.4 Restriction on user group

This appliance may be used by children aged 8 or over and by people who have reduced physical, sensory or mental abilities or inadequate experience and/or knowledge, provided that they are supervised or have been instructed on how to use the appliance safely and have understood the resulting dangers.
Do not let children play with the appliance.
Children must not perform cleaning or user maintenance unless they are at least 15 years old and are being supervised.
Keep children under the age of 8 years away from the appliance and power cable.

### 1.5 Safe use

**⚠ WARNING – Risk of fire!**
Fatty deposits in the grease filters may catch fire.
- ▸ Never operate the appliance without a grease filter.
- ▸ Clean the grease filters regularly.
- ▸ Never work with naked flames close to the appliance (e.g. flambéing).
- ▸ Do not install the appliance near a solid fuel heating appliance (e.g. wood- or coal-burning) unless the heating appliance has a

sealed, non-removable cover. There must be no flying sparks.

Hot oil and fat ignites very quickly.

- ▸ Always supervise hot oil and fat.
- ▸ Never extinguish burning oil or fat with water. Switch off the hotplate. Extinguish flames carefully using a lid, fire blanket or something similar and leave to cool down.

Fatty deposits in the grease filters may catch fire.

- ▸ Clean the grease filters regularly.

### ⚠ WARNING – Risk of suffocation!

Children may put packaging material over their heads or wrap themselves up in it and suffocate.


- ▸ Keep packaging material away from children.
- ▸ Do not allow children to play with packaging material.

Children may breathe in or swallow small parts, causing them to suffocate.

- ▸ Keep small parts away from children.
- ▸ Do not let children play with small parts.

### ⚠ WARNING – Risk of poisoning!

Risk of poisoning from flue gases being drawn back in. Room-air-dependent heat-producing appliances (e.g. gas, oil, wood or coal-operated heaters, continuous flow heaters or water heaters) obtain combustion air from the room in which they are installed and discharge the exhaust gases into the open through an exhaust gas system (e.g. a chimney). With the extractor hood switched on, air is extracted from the kitchen and the adjacent rooms. Without an adequate supply of air, the air pressure falls below atmospheric pressure. Toxic gases from the chimney or the extraction shaft are sucked back into the living space.



- ▸ Always ensure adequate fresh air in the room if the appliance is being operated in exhaust air mode at the same time as a room-air-dependent heat-producing appliance is being operated.
- ▸ It is only possible to safely operate the appliance if the pressure in the room in which the heating appliance is installed does not fall below 4 Pa (0.04 mbar). This can be achieved whenever the air needed for combustion is able to enter through openings that cannot be sealed, for example in doors, windows, incoming/exhaust air wall boxes or by other technical means. An incoming/exhaust air wall box alone is not sufficient to ensure compliance with the limit.
- ▸ In any case, consult a competent person (e.g. responsible chimney sweep). They are able to assess the house's entire ventilation setup and will suggest the suitable ventilation measures to you.
- ▸ Unrestricted operation is possible if the appliance is operated exclusively in circulating-air mode.

Using a gas cooking appliance leads to a build-up of heat, moisture and combustion products in the room where the appliance is installed.

- ▸ Switch on the extractor hood when using a gas cooking appliance.

### ⚠ WARNING – Risk of burns!

The accessible parts of the appliance become hot during operation.

- ▸ Never touch these hot parts.
- ▸ Keep children at a safe distance.

The appliance becomes hot during operation.

- ▸ Allow the appliance to cool down before cleaning.

### ⚠ WARNING – Risk of injury!

Components inside the appliance may have sharp edges.

- ▸ Carefully clean the appliance interior.

Items placed on the appliance may fall off.

- ▸ Do not place any objects on the appliance.

Changes to the electrical or mechanical assembly are dangerous and may lead to malfunctions.

- ▸ Do not make any changes to the electrical or mechanical assembly.

Risk of injury when opening and closing the hinges.

- ▸ Keep your hands away from the hinges.

The light emitted by LED lights is very dazzling, and can damage the eyes (risk group 1).

- ▸ Do not look directly into the switched-on LED lights for longer than 100 seconds.

Improper repairs are dangerous.

- ▸ Repairs to the appliance should only be carried out by trained specialist staff.

- If the appliance is defective, call Customer Service.
  → *"Customer Service", Page 8*

**⚠ WARNING – Risk of electric shock!**
If the appliance or the power cord is damaged, this is dangerous.
- Never operate a damaged appliance.
- Never pull on the power cord to unplug the appliance. Always unplug the appliance at the mains.
- If the appliance or the power cord is damaged, immediately unplug the power cord or switch off the fuse in the fuse box.
- Call customer service. →*Page 8*

Improper repairs are dangerous.
- Repairs to the appliance should only be carried out by trained specialist staff.
- Only use genuine spare parts when repairing the appliance.
- If the power cord of this appliance is damaged, it must be replaced by trained specialist staff.

An ingress of moisture can cause an electric shock.
- Before cleaning, pull out the mains plug or switch off the fuse in the fuse box.
- Do not use steam- or high-pressure cleaners to clean the appliance.
- Do not use the appliance with damp hands.

Penetrating moisture may cause an electric shock.
- Do not use wet sponge cloths.

**⚠ WARNING – Risk of explosion!**
Highly caustic alkaline or highly acidic cleaning agents in conjunction with aluminium parts in the interior of the appliance may cause explosions.
- Never use highly caustic alkaline or highly acidic cleaning agents. In particular, do not use commercial or industrial cleaning agents in conjunction with aluminium parts, e.g. grease filter on extractor hoods.

# 2 Avoiding material damage

**ATTENTION**
Condensate may cause corrosion damage.
- To prevent condensation from building up, switch on the appliance during cooking.

If moisture gets into the controls, this may result in damage.
- Never clean controls with a wet cloth.

Incorrect cleaning damages the surfaces.
- Follow the cleaning instructions.
- Do not use harsh or abrasive detergents.
- Clean stainless steel surfaces in the direction of the finish only.
- Never clean controls with stainless steel cleaners.

Condensation that flows back in may damage the appliance.
- To prevent condensate from returning, fit the exhaust air pipe with a 1° gradient from the appliance.

If you put incorrect stress on the design elements, they may break off.
- Do not pull design elements.
- Do not place objects on the design elements or hang objects from them.

There is a risk of surface damage if you do not peel off the protective film.
- Remove the protective film from all parts of the appliance before using for the first time.

Painted surfaces are easily damaged.
- Follow the cleaning instructions.
  → *"Cleaning the appliance", Page 6*
- Ensure that the painted surfaces are not scratched.

A falling glass front may cause damage.
- Close the glass front carefully.
- Do not let the glass front fall.
- Protect the glass front from impacts.

# 3 Environmental protection and saving energy

## 3.1 Disposing of packaging

The packaging materials are environmentally compatible and can be recycled.
- Sort the individual components by type and dispose of them separately.

## 3.2 Saving energy

If you follow these instructions, your appliance will use less power.

Adjust the fan speed to the amount of steam produced during cooking.
- ✔ The lower the fan speed, the less energy is consumed.

If cooking produces large amounts of steam, select a higher fan speed in good time.
- ✔ The odours are distributed around the room less.

Switch off the lighting if it is no longer required.
- ✔ When the lighting is switched off, it does not consume any energy.

Clean or replace the filters at regular intervals.
✔ The effectiveness of the filter is retained.

Put the cooking lid on.
✔ The cooking vapours and condensation are reduced.

Only use the additional functions if required.
✔ Switching off additional functions reduces power consumption.

# 4 Operating modes

You can use your appliance in air extraction mode or circulating-air mode.

## 4.1 Air extraction mode

The air which is drawn in is cleaned by the grease filters and conveyed to the exterior by a pipe system.



The air must not be discharged into a flue that is used for exhausting fumes from appliances burning gas or other fuels (not applicable to appliances that only discharge the air back into the room).
- If the exhaust air is to be conveyed into a non-functioning smoke or exhaust gas flue, you must obtain the consent of the heating engineer responsible.
- If the exhaust air is conveyed through the external wall, a telescopic duct should be used.

## 4.2 Air recirculation

The air which is drawn in is cleaned by the grease filters and an odour filter, and conveyed back into the room.



To bind odours in air recirculation mode, you must install an odour filter. The different options for operating the appliance in air circulation mode can be found in our catalogue. Alternatively, ask your dealer. The required accessories are available from specialist retailers, from our after-sales service or from the online shop.

# 5 Familiarising yourself with your appliance

## 5.1 Control elements

You can use the control panel to configure all functions of your appliance and to obtain information about the operating status.

1 2 3 ☼

| | |
|---|---|
| 1 | Switching fan setting 1 on or off |
| 2 | Switching fan setting 2 on or off |
| 3 | Switching fan setting 3 on or off |
| ☼ | Switching the lighting on or off |

# 6 Before using for the first time

Configure the settings for initial start-up. Clean the appliance and accessories.

## 6.1 Setting an operating mode

Your appliance is set to air extraction mode by default.

**Note:** When using it in circulating-air mode, you require additional accessories.

# 7 Basic operation

## 7.1 Switching on the appliance

▸ Press fan setting 1, 2 or 3.
✔ The appliance starts at the selected fan setting.

## 7.2 Switching off the appliance

▸ Press the selected fan setting again.
✔ The ventilation system switches off.

## 7.3 Lighting

### Switching on the lighting

The lighting can be switched on and off independently of the ventilation system.

▸ Press ☼.

### Switching off the lighting

- ▸ Press ☼.
- ✔ The lighting switches off.

# 8 Cleaning and servicing

## 8.1 Cleaning products

You can obtain suitable cleaning products from after-sales service or the online shop.

⚠ **WARNING – Risk of electric shock!**
An ingress of moisture can cause an electric shock.
- ▸ Before cleaning, pull out the mains plug or switch off the fuse in the fuse box.
- ▸ Do not use steam- or high-pressure cleaners to clean the appliance.
- ▸ Do not use the appliance with damp hands.

⚠ **WARNING – Risk of burns!**
The appliance becomes hot during operation.
- ▸ Allow the appliance to cool down before cleaning.

**ATTENTION**
Unsuitable cleaning products may damage the surfaces of the appliance.
- ▸ Do not use harsh or abrasive detergents.
- ▸ Do not use cleaning products with a high alcohol content.
- ▸ Do not use hard scouring pads or cleaning sponges.
- ▸ Only use glass cleaners, glass scrapers or stainless steel care products if recommended in the cleaning instructions for the relevant part.
- ▸ Wash sponge cloths thoroughly before use.

## 8.2 Cleaning the appliance

Clean the appliance as specified. This will ensure that the different parts and surfaces of the appliance are not damaged by incorrect cleaning or unsuitable cleaning products.

⚠ **WARNING – Risk of explosion!**
Highly caustic alkaline or highly acidic cleaning agents in conjunction with aluminium parts in the interior of the appliance may cause explosions.
- ▸ Never use highly caustic alkaline or highly acidic cleaning agents. In particular, do not use commercial or industrial cleaning agents in conjunction with aluminium parts, e.g. grease filter on extractor hoods.

⚠ **WARNING – Risk of electric shock!**
An ingress of moisture can cause an electric shock.
- ▸ Before cleaning, pull out the mains plug or switch off the fuse in the fuse box.
- ▸ Do not use steam- or high-pressure cleaners to clean the appliance.
- ▸ Do not use the appliance with damp hands.

⚠ **WARNING – Risk of burns!**
The appliance becomes hot during operation.
- ▸ Allow the appliance to cool down before cleaning.

⚠ **WARNING – Risk of injury!**
Components inside the appliance may have sharp edges.
- ▸ Carefully clean the appliance interior.

1. Observe the information regarding the cleaning agents.
   → *"Cleaning products", Page 6*
2. Clean as follows, depending on the surface:
   - ▸ Clean stainless steel surfaces in the direction of the finish using a sponge cloth and hot soapy water.
   - ▸ Clean painted surfaces using a damp sponge cloth and hot soapy water.
   - ▸ Clean aluminium using a soft cloth and glass cleaner.
   - ▸ Clean plastic using a soft cloth and glass cleaner.
   - ▸ Clean glass using a soft cloth and glass cleaner.
3. Dry with a soft cloth.
4. Apply a thin layer of the stainless steel cleaning product to stainless steel surfaces using a soft cloth. You can obtain stainless steel cleaning products from the after-sales service or the online shop.

## 8.3 Cleaning controls and lights

⚠ **WARNING – Risk of electric shock!**
Penetrating moisture may cause an electric shock.
- ▸ Do not use wet sponge cloths.


1. Observe the information regarding the cleaning agents.
   → *"Cleaning products", Page 6*
2. Clean using a damp sponge cloth and hot soapy water.
3. Dry with a soft cloth.

## 8.4 Grease filter

### Removing the grease filter

1. Switch off the appliance.
2. **ATTENTION –** Falling grease filters may damage the hob below.
   - ▸ Cover the hob to prevent damage.

   Open the glass front and hold it with one hand.
3. Open the locks on the grease filters.



4. Remove the grease filters from the holders.
   To prevent grease from dripping, hold the grease filter horizontally.

### Cleaning grease filters manually

The grease filters filter the grease from the cooking vapour. Regularly cleaned grease filters guarantee a high level of grease removal. We recommend cleaning the grease filters every two months.

**⚠ WARNING – Risk of fire!**
Fatty deposits in the grease filters may catch fire.
- Clean the grease filters regularly.

**Requirement:** The grease filters have been removed.

→ *"Removing the grease filter", Page 6*

1. Observe the information regarding the cleaning agents.
   → *"Cleaning products", Page 6*
2. Soak the grease filter in hot soapy water.
   Use special grease solvent for stubborn dirt. You can obtain grease solvents from customer service or the online shop.
3. Use a brush to clean the grease filters.
4. Rinse the grease filters thoroughly.
5. Allow the grease filters to drain.

### Cleaning grease filters in the dishwasher

The grease filters filter the grease from the cooking vapour. Regularly cleaned grease filters guarantee a high level of grease removal. We recommend cleaning the grease filters every two months.

**⚠ WARNING – Risk of fire!**
Fatty deposits in the grease filters may catch fire.
- Clean the grease filters regularly.

**ATTENTION**
The grease filters may become damaged if they are squeezed in the dishwasher.
- Do not squeeze the grease filters.

**Note:** When cleaning the grease filter in the dishwasher, light discolouration may occur. This discolouration has no effect on the performance of the metal grease filters.

**Requirement:** The grease filters have been removed.

→ *"Removing the grease filter", Page 6*

1. Observe the information regarding the cleaning agents.
   → *"Cleaning products", Page 6*
2. Place the grease filters loosely into the dishwasher. Do not clean heavily soiled grease filters with utensils. Use special grease solvent for stubborn dirt. You can obtain grease solvents from customer service or the online shop.
3. Start the dishwasher.
   Select a temperature of no more than 70 °C.
4. Allow the grease filters to drain.

### Fitting the grease filters

**ATTENTION**
Falling grease filters may damage the hob below.
- Cover the hob to prevent damage.

1. Open the glass front and hold it with one hand.
2. Insert the grease filters.
3. Fold the grease filters upwards and engage the locks.
4. Ensure that the locks engage.
5. Close the glass front.

# 9 Troubleshooting

You can rectify minor faults on your appliance yourself. Read the troubleshooting information before contacting after-sales service. This will avoid unnecessary costs.

**⚠ WARNING – Risk of injury!**
Improper repairs are dangerous.
- Repairs to the appliance should only be carried out by trained specialist staff.
- If the appliance is defective, call Customer Service.
  → *"Customer Service", Page 8*

**⚠ WARNING – Risk of electric shock!**
Improper repairs are dangerous.
- Repairs to the appliance should only be carried out by trained specialist staff.
- Only use genuine spare parts when repairing the appliance.
- If the power cord of this appliance is damaged, it must be replaced by trained specialist staff.

## 9.1 Malfunctions

| Fault | Cause and troubleshooting |
|---|---|
| The appliance is not working. | The mains plug of the power cord is not plugged in.<br>- Connect the appliance to the power supply. |
| | The circuit breaker in the fuse box has tripped.<br>- Check the circuit breaker in the fuse box. |
| | There has been a power cut.<br>- Check whether the lighting in your room or other appliances are working. |
| The LED lighting does not work. | Different causes are possible.<br>- Defective LED lights may be replaced by the manufacturer, their customer service or a qualified technician (electrician) only. |

| Fault | Cause and troubleshooting |
|---|---|
| The LED lighting does not work. | ▸ Call Customer Service →*Page 8*. |

# 10 Disposal

## 10.1 Disposing of old appliance

Valuable raw materials can be reused by recycling.

1. Unplug the appliance from the mains.
2. Cut through the power cord.
3. Dispose of the appliance in an environmentally friendly manner.
   Information about current disposal methods are available from your specialist dealer or local authority.



This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE).
The guideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.

# 11 Customer Service

Function-relevant genuine spare parts according to the corresponding Ecodesign Directive can be obtained from Customer Service for a period of at least 10 years from the date on which your appliance was placed on the market within the European Economic Area. Furthermore, our Customer Service will continue to provide you with other function-relevant and storable genuine spare parts for up to 15 years from the date on which your appliance was placed on the market.
For more information, please contact our Customer Service team.

**Note:** Under the terms of the manufacturer's warranty the use of Customer Service is free of charge.

Detailed information about the warranty period and the warranty conditions in your country is available via the QR code on the enclosed document on service contacts and warranty conditions, from our customer service or on our website.

You can find the contact details for our customer service via the QR code on the enclosed document on service contacts and warranty conditions or on our website.

## 11.1 Product number (E-Nr.) and production number (FD)

If you contact Customer Service, you will require the product number (E-Nr.) and the production number (FD), which you can find on the appliance's rating plate.

Depending on the model, the rating plate can be found:

- Inside the appliance (remove grease filters for access).
- On top of the appliance.

Make a note of your appliance's details and the Customer Service telephone number to find them again quickly.

# 12 Accessories

You can buy accessories from the after-sales service, from specialist retailers or online. Only use original accessories, as these have been specifically designed for your appliance.
Accessories vary from one appliance to another. When purchasing accessories, always quote the exact product number (E no.) of your appliance. →*Page 8*

You can find out which accessories are available for your appliance in our catalogue, in the online shop or from our after-sales service.
*www.neff-home.com*

# 13 Test information

This information has been produced to facilitate the inspection of the appliance.

- Measured in accordance with EN 61591.
- The appliance is operated in its as-delivered condition.
- Ensure that the filters do not move during the measurement (by changing the appliance position to the installation position).

# 14 Installation instructions


Observe this information when installing the appliance.



mm

## 14.1 Included with the appliance

After unpacking all parts, check for any damage in transit and completeness of the delivery.






* Depending on the appliance type, this is not included in the scope of delivery.


**Note:** The retaining bracket for the flue duct and the small silver and black screws are included in the scope of delivery but are not required for flue-free air recirculation appliances.


## 14.2 Dimensions

You will find the dimensions of the appliance here










## 14.3 Safety clearances

Comply with the safety clearances for the appliance.





For Australia and New Zealand the minimum safety clearance above electrical cooktops must be 600 mm.

## 14.4 Secure installation

Follow these safety instructions when installing the appliance.

**⚠ WARNING – Risk of poisoning!**

Risk of poisoning from flue gases being drawn back in. Room-air-dependent heat-producing appliances (e.g. gas, oil, wood or coal-operated heaters, continuous flow heaters or water heaters) obtain combustion air from the room in which they are installed and discharge the exhaust gases into the open through an exhaust gas system (e.g. a chimney). With the extractor hood switched on, air is extracted from the kitchen and the adjacent rooms. Without an adequate supply of air, the air pressure falls below atmospheric pressure. Toxic gases from the chimney or the extraction shaft are sucked back into the living space.



- Always ensure adequate fresh air in the room if the appliance is being operated in exhaust air mode at the same time as a room-air-dependent heat-producing appliance is being operated.
- It is only possible to safely operate the appliance if the pressure in the room in which the heating appliance is installed does not fall below 4 Pa (0.04 mbar). This can be achieved whenever the air needed for combustion is able to enter through openings that cannot be sealed, for example in doors,

windows, incoming/exhaust air wall boxes or by other technical means. An incoming/exhaust air wall box alone is not sufficient to ensure compliance with the limit.
- ▸ In any case, consult a competent person (e.g. responsible chimney sweep). They are able to assess the house's entire ventilation setup and will suggest the suitable ventilation measures to you.
- ▸ Unrestricted operation is possible if the appliance is operated exclusively in circulating-air mode.

Risk of poisoning from flue gases (e.g. carbon monoxide) being drawn back in.
- ▸ If an extractor hood with an open-flued heat production source is installed, the power supply for the extractor hood must be provided with a suitable safety switch.

Risk of poisoning from flue gases being drawn back in.
- ▸ Do not emit the exhaust air into a smoke or exhaust gas flue that is in operation.
- ▸ Do not emit the exhaust air into a shaft that is used to ventilate installation rooms for heat-producing appliances.
- ▸ If the exhaust air is to be conveyed into a smoke or exhaust gas flue, you must obtain the consent of the heating engineer responsible.

**⚠ WARNING – Risk of suffocation!**

Children may put packaging material over their heads or wrap themselves up in it and suffocate.
- ▸ Keep packaging material away from children.
- ▸ Do not allow children to play with packaging material.

**⚠ WARNING – Risk of fire!**

The grease deposits in the grease filter may catch fire.
- ▸ Never work with naked flames close to the appliance (e.g. flambéing).
- ▸ Do not install the appliance near a heat-producing appliance for solid fuel (e.g. wood or coal) unless a closed, non-removable cover is present. There must be no flying sparks.
- ▸ The specified safety clearances must be complied with in order to prevent a build-up of heat.
- ▸ Observe the specifications for your cooking appliances. If the installation instructions for the cooking appliances specify a different clearance, the larger of the two must always be provided for. If gas hobs and electric hobs are operated together, the largest specified clearance applies.

**⚠ WARNING – Risk of injury!**

Components inside the appliance may have sharp edges.
- ▸ Wear protective gloves.

The appliance may fall down if it has not been properly fastened in place.
- ▸ All fastening components must be fixed firmly and securely in place.

Risk of injury from glass splinters.
- ▸ Protect the filter cover against impact.
- ▸ Do not drop the filter cover.
- ▸ Wear protective goggles during installation.

The appliance is heavy.
- ▸ The appliance must not be fitted directly onto plasterboard or similar lightweight materials.
- ▸ To ensure correct installation, you must use a material which is sufficiently stable and suitable for both the structural conditions and the weight of the appliance.

Changes to the electrical or mechanical assembly are dangerous and may lead to malfunctions.
- ▸ Do not make any changes to the electrical or mechanical assembly.

Risk of injury when opening and closing the hinges.
- ▸ Keep your hands away from the hinges.

**⚠ WARNING – Risk of electric shock!**

Sharp-edged components inside the appliance may damage the connecting cable.
- ▸ Do not kink or trap the connecting cable.

If the appliance or the power cord is damaged, this is dangerous.
- ▸ Never operate a damaged appliance.
- ▸ Never pull on the power cord to unplug the appliance. Always unplug the appliance at the mains.
- ▸ If the appliance or the power cord is damaged, immediately unplug the power cord or switch off the fuse in the fuse box.
- ▸ Call customer service. →*Page 8*

Improper repairs are dangerous.
- ▸ Repairs to the appliance should only be carried out by trained specialist staff.
- ▸ Only use genuine spare parts when repairing the appliance.
- ▸ If the power cord of this appliance is damaged, it must be replaced by trained specialist staff.

Incorrect installation is dangerous.
- ▸ Connect and operate the appliance only in accordance with the specifications on the rating plate.
- ▸ Connect the appliance to a power supply with alternating current only via a properly installed socket with earthing.
- ▸ The protective conductor system of the domestic electrical installation must be properly installed.
- ▸ Never equip the appliance with an external switching device, e.g. a timer or remote control.
- ▸ When the appliance is installed, the mains plug of the power cord must be freely accessible. If free access is not possible, an all-pole isolating switch must be installed in the permanent electrical installation according to the conditions of Overvoltage Category III and according to the installation regulations.
- ▸ When installing the appliance, check that the power cable is not trapped or damaged.

## 14.5 General information

Follow these general instructions during the installation.
- For the installation, observe the currently valid building regulations and the regulations of the local electricity and gas suppliers.
- When discharging the exhaust air, the official and legal regulations, such as the regional building code., must be observed.
- In order to freely access the appliance for servicing, select an easy-to-reach installation site.
- The surfaces of the appliance are sensitive. Avoid damaging them during installation.

## 14.6 Instructions for the electrical connection

In order to safely connect the appliance to the electrical system, follow these instructions.

⚠ **WARNING – Risk of electric shock!**
It must always be possible to disconnect the appliance from the electricity supply. The appliance must only be connected to a protective contact socket that has been correctly installed.
- ▸ The mains plug for the mains power cable must be easily accessible after the appliance is installed.
- ▸ If this is not possible, an all-pole isolating switch must be integrated into the permanent electrical installation according to the conditions of overvoltage category III and according to the installation regulations.
- ▸ The permanent electrical installation must only be wired by a professional electrician. We recommend installing a residual-current circuit breaker (RCCB) in the appliance's power supply circuit.

Sharp-edged components inside the appliance may damage the connecting cable.
- ▸ Do not kink or trap the connecting cable.

- The connection data can be found on the rating plate. → *Page 8*
- The connecting cable is approx. 1.30 m long.
- This appliance complies with the EC interference suppression regulations.
- The appliance complies with protection class 2 and has an earth connection for functional purposes. Only connect the appliance using the power cord that is fitted at the factory.
- Do not connect the appliance to the power supply during installation.
- Ensure that the protection against contact is guaranteed during installation.

## 14.7 Information on the installation situation

- Install this appliance on the kitchen wall.
- To install additional special accessory parts, observe the enclosed installation instructions.
- The width of the extractor hood must correspond at least with the width of the hob.
- To optimally detect the cooking vapours, install the appliance in the middle of the hob.

## 14.8 Instructions for the exhaust air pipe

The appliance manufacturer does not provide any warranty for faults attributable to the pipeline.
- Use a short, straight exhaust air pipe with as large a pipe diameter as possible.
- Long, rough exhaust air pipes, many pipe bends or small pipe diameters reduce the suction power and increase the fan noise.
- Use an exhaust pipe that is made of non-combustible material.
- To prevent condensate from returning, fit the exhaust pipe with a 1° gradient from the appliance.

### Flat ducts

Use flat ducts with an inner cross-section that corresponds to the diameter of the round pipes:
- Diameter of 150 mm corresponds to approx. 177 cm².
- Diameter of 120 mm corresponds to approx. 113 cm².
- Use sealing strips for different pipe diameters.
- Do not use any flat ducts with sharp bends.

## 14.9 Instructions for the air extraction mode

For air extraction mode, a one-way flap should be installed.

**Notes**
- If a one-way flap is not included with the appliance, one can be ordered from a specialist retailer.
- If the exhaust air is conveyed through the external wall, a telescopic duct should be used.

## 14.10 Installation


### Checking the wall

1. Check whether the wall is vertical and has sufficient load-bearing capacity.
   The maximum weight of the appliance is 12 kg.
2. Drill the hole depth in accordance with the length of the screws.
3. Use the enclosed screws and wall plugs.
   The enclosed screws and wall plugs are suitable for use with solid brickwork. Use suitable fixing material for other structures, e.g. plasterboard, porous concrete, poroton bricks.
4. Install the appliance with a fixing material which is sufficiently stable and has been adjusted accordingly for both the structural conditions and the weight of the appliance.
5. Check the cut-out area for existing cables of other appliances.


### Preparing the wall

1. Observe the information on the installation situation.
   →*Page 12*
2. Ensure that there are no electrical wires, gas pipes or water pipes in the area where holes are to be drilled.
3. Cover the hob to prevent damage.
4. Determine the position of the extractor hood and lightly mark where the lower edge of the appliance should be on the wall.
   - ▸ Determine the centre of the hob.
   - ▸ Comply with the safety clearances for the hob.

   We recommend fitting the extractor hood in such a way that the lower edge of the glass panel is in line with the lower edges of the adjacent wall-hung cabinets.
5. To make the installation easier, apply and secure the packaging section that is used as the template to the line that is marked out.




6. For the installation with the flue cover, separate the template along the marked cut line.
7. Place the detached part at the required position. Observe the entire length of the flue duct.
8. Drill the 8 mm diameter holes to a depth of 80 mm for the fastenings.




9. Remove the template.
10. Insert the wall plugs flush with the wall.

### Installing the appliance

⚠ **WARNING – Risk of injury!**

Components inside the appliance may have sharp edges.


- ▸ Wear protective gloves.

**ATTENTION**


If the glass flap is opened too far and the hinges overstretch, the appliance may be damaged.

- ▸ Do not push the glass flap upwards beyond the end stop.
- ▸ Do not overstretch the hinges.

1. Remove the angle bracket for the flue duct.
2. Screw in two fastening screws with washers to approx. 5 mm.





3. Attach the appliance.



4. Open the glass flap.
5. Remove the filter.

6. Align the appliance horizontally using screws and screw it in tightly.
7. Screw in the safety screw with the washer.




8. Remove the protective film from the grease filters and insert the grease filters into the appliance.
9. Close the glass flap.
10. Connect the appliance to the power supply.

## Piping

**Note:** If you are using an aluminium pipe, smooth the connection area beforehand.

We recommend air extraction ducting with an exhaust air pipe diameter of 150 mm.
If the diameter of the air extraction ducting is less than 150 mm, you need a reducer piece available separately from a specialist retailer.

**Establishing the exhaust air connection (exhaust air pipe, 120 mm diameter)**

1. Secure the reducing connector to the air-pipe connector. [1]
2. Secure the exhaust air pipe to the reducing connector.
3. Establish the connection to the exhaust air opening.
4. Seal the joints.

**Establishing the exhaust air connection (exhaust air pipe, 150 mm diameter)**


1. Secure the exhaust pipe to the air pipe connector.
2. Establish the connection to the exhaust air opening.
3. Seal the joints.

## Installing the flue duct


⚠ **WARNING – Risk of injury!**
Components inside the appliance may have sharp edges.
▸ Wear protective gloves.

⚠ **WARNING – Risk of electric shock!**
Sharp-edged components inside the appliance may damage the connecting cable.
▸ Do not kink or trap the connecting cable.

1. **Note:** In air recirculation, the circulating-air guide must be installed before the flue duct section is installed. You can find information about installing the circulating-air guide in the installation instructions for the accessory.
   Where present, remove the protective film from the flue duct.
2. Mount the flue duct ① and use the 2 screws to screw it to the sides of the retaining bracket ②.




3. **Note:** To prevent scratches, lay soft towels over the edges of the outer flue duct to protect the surface. Place the lower flue duct on the appliance and pull it slightly apart. ①
4. Put the lower flue duct over the upper flue duct. ②




5. Carefully remove the towels.

## Removing the appliance

1. Remove the flue duct.
2. Disconnect the appliance from mains power supply.
3. Disconnect the exhaust air pipe.
4. Remove the filter.
5. Loosen the safety screw.
6. Loosen the screws for the appliance bracket slightly but do not undo them fully.
7. Remove the appliance from the wall.
8. Loosen the angle bracket for the flue duct.

[1] Depending on the appliance type, this is not included in the scope of delivery.

Valid within Great Britain:
Imported to Great Britain by
BSH Home Appliances Ltd.
Grand Union House
Old Wolverton Road
Wolverton, Milton Keynes
MK12 5PT
United Kingdom

Register your product online
**neff-home.com**

**BSH Hausgeräte GmbH**
Carl-Wery-Straße 34
81739 München, GERMANY

**9002064608** (060721)
en