

# Thermador.\*

# THERMADOR DISHWASHERS Wash Cycles & Cycle Options

Thermador Radiance Collection Dishwashers offer a wide array of wash cycles and options to personalize your cleaning and drying for any occasion.

Please refer to your Owner's Manual to learn what Wash Cycles and Cycle Options your Dishwasher has.

# Wash Cycles

#### Auto

The smartest cycle on your dishwasher, Auto offers flexible soil sensing, making it perfect for mixed dishware and various types of food soil.

#### Hand Wash\*

Hand Wash Gentle cleaning of your most precious dishes at lower temperatures.

#### Glass\*°

This cycle cleans at a lower temperature, making it ideal for stemware, glasses and other delicate items. Tip: for best results, use less detergent and only powder or liquid detergent.

# Machine Care\*°

Use a Dishwasher cleaning detergent with no dishes to keep your machine clean and ready to use.

### Normal

This cycle is recommended for regular daily use when you need to run a full load of soiled dishes, like after dinner with friends.

#### Pots & Pans

Best for cleaning items with baked-on food or grease, or that would otherwise normally require soaking.

#### 1 Hour\*

This wash cycle is great for lightly soiled dishes, reducing the overall wash time to 1 hour.

#### Quick

Clean lightly soiled dishes quickly with a reduced overall wash time of just 30-35 minutes.

#### Favorite\*

Save a combination of a Cycle and an Option for convenient use on your control panel.

#### Rinse°

Use this cycle if you need to rinse dishes to avoid odors. Uses less water than hand rinsing and is very low energy.

\* Available on select Models ° Available through the Home Connect® app ©2024 BSH HOME APPLIANCES CORPORATION, ALL RIGHTS RESERVED

# **Remote Start**

Activate or deactivate remote start, dishwasher must be paired with Home Connect® to be used. See instruction manual for setup.

# Zone Control\*

Lower spray arm provides intensive cleaning for dishware in the specified zone of the lower rack. Specify up to 4 customized lower rack cleaning zones to meet your needs from Heavy, Normal or Light. This allows Custom settings available via the Home Connect® app.

# Save Time\*°

This option ensures the same final temperatures as the underlying cycle, while heating up the dishes more quickly, saving time without sacrificing wash and dry performance. Selecting this option also increases energy consumption while reducing cycle time.

### Sanitize

NSF Certified to remove up to 99.9% of bacteria. This option increases the temperature (up to 162 degrees) and retains it for an extra long time to obtain a defined disinfecting performance. Continuous use of this function increases the hygiene status, and is ideal for cleaning items such as cutting boards and baby bottles.

# Powerboost®\*

Perfect for a mixed load. You can wash very soiled pots and pans in the lower rack together with normally soiled utensils in the upper rack. The spray pressure in the lower rack is intensified, and the rinsing temperature is increased slightly.

#### Half Load\*

Reduce water consumption when washing small, lightly soiled loads that fill approximately half or less of the dishwasher's capacity. You can arrange the smaller amount of dishes for the half load anywhere you want when using this cycle option, as there are no placement restrictions.

# StarDry<sup>™</sup> with Zeolite\*

An exclusive Thermador drying solution, StarDry<sup>™</sup> ensures the ultimate results for your dishware needs, even those more difficult to dry plastic items.

# ExtraDry\*

The final rinse uses a higher temperature, which improves the drying result and ensures that plastic parts dry better (use caution if utensils are delicate). The cycle time and energy consumption may increase slightly.

# Customize Your Clean with Smart Cycle

Achieve optimal cleaning results according to your specific needs.

 Specify what items are in your dishwasher
Select how dirty your dishes are
Specify what your priorities are from Dryness to Sanitization
Save as a favorite on the control panel, or push continue to start the suggested cycle/option combination

Access Smart Cycle via the Home Connect® app.

