

Thermador® Ovens and Ranges Firmware Update



More Partners

With this update, you'll be able to experience a wide variety of Home Connect® Partners that seamlessly elevate your daily life. Ask **Alexa** to preheat your oven, get a notification on your **Fitbit** smartwatch when your oven program is complete, or send commands directly to the appliance from recipes in **SideChef**.

New Features

- **Dark Mode***: Improves contrast and visibility of certain oven/range displays. See list below for models not included in this update.
- **Permanent Remote Start****: Set your oven so you can start your oven remotely without needing to re-confirm on the appliance first. See list below for models not included in this update.
- **Warming Drawer*****: Remotely monitor & control your warming drawer (Combination oven models only).
- **Preheat Notifications**: Receive notifications on your app or via partners when preheat is complete.

Additional Features & Improvements

- Send heating modes directly to the oven from recipes within the Home Connect® app
- Set a kitchen timer in the Home Connect® app
- Remotely activate your oven's cleaning modes****
- Set Sabbath oven programs through the app
- Select and remotely control automatic dish programs on Thermador® Steam Ovens
- Timestamp of Remote Start activation will be shown in the app.
- Opening the door while using the Manual Remote Start feature disables Remote Start setting
- Set your appliance clock via the Home Connect® Automatic time setting
- Extended the Kitchen Timer and Oven Timer elapsed sound
- Default Signal Sound Volume is now set to max level
- Preheat and Program Progress visualization enhancements
- Simplified recipe instructions
- Water tank 24-hours reminder for steam ovens added

If you have any questions or concerns regarding this update, please reach out to our 24/7 customer support team: [1-800-735-4328](tel:1-800-735-4328) or service.us@home-connect.com.

***Following SKUs do not support this feature:** PRD606WCG, PRD606WEG, PRD606WCSG, PRD606WESG, PRD48WISGU, PRD48WCSGU, PRD48WLSGU, PRD48WDSGU, PRD486WIGU, PRD484WCGU, PRD486WLGU, PRD486WDGU, PRG486WLG, PRG486WDG, PRD48WCSGC, PRD48WDSGC, PRD48WISGC, PRDWLSGC, PRD486WDGC, PRD486WIGC

****Following SKUs do not support this feature via Over the Air update:** PRD486WLHU, PRD486WDHU, PRG486WLH, PRG486WDH, PRD606WC, PRD606WEG, PRD606WCSG, PRD606WESG

*****Following SKUs support this feature:** PODMCW31W, MEDMCW31W

********By selecting "Permanent Remote Start," you can start and operate at any time without pressing any buttons on your appliance. Permanent Remote Start does not apply to Cleaning Modes. **WARNING** – Do not store any objects in the appliance that could be damaged during use or operation or could pose a fire hazard! Caution should always be used when utilizing the remote start functionality.