BOSCH FRANK

Ergo**Mixx**, Ergo**Mixx** Style Maxo**Mixx** MSM8, MS8 MSZV6FS1 MSZV6FSG1 MSZV6FSG2 MSZV8FS1 1 x 1 x 1 x 3x1.2l 3 x 1.2 l 3x1.2l 3x3.8l 3x3.8l 3x3.8l 1x1.2l 1x1.2l 2x1.2l 1x1.2l

Zipper bags and containers are BPA free.

Discover more vacuum accessories:



Vacuum zipper bags 10 x 1.2 l MSZV0FB1

Vacuum zipper bags 10 x 3.8 l MSZV0FB3



Tritan™ vacuum container 2 x 1.2 l MSZV0FC2



Tritan™ vacuum container 0.91 & 1.21 & 1.71 MSZV0FC3



Glass vacuum container 1.2 l MSZV0FCG1



Tritan™ 2Go bottle 0.5 l MMZV0BT1



Tritan™ vacuum storage box 0.75 l MMZV0SB0



Tritan™ vacuum storage box 1.5 l MMZV0SB1

Get more information: www.bosch-home.com




Upgrade to freshness



Fresh vacuum system

Easily turn your Bosch hand blender into a powerful vacuum device.







Powerful vacuum pump, black

Powerful vacuum pump, white

Reusable **vacuum zipper bags**, tear-resistant, sous vide suitable, freezer- and dishwasher-safe

 $\textbf{Tritan}^{\textbf{m}} \ \textbf{vacuum container},$

freezer-, microwave- and dishwasher-safe

Glass vacuum container, freezer-, microwave-, oven- and

dishwasher-safe









Easy

to go





Prepare

- Prepare meals for the whole week
- Faster marinating
- Suitable for sous-vide

Store

- Store with reusable containers + bags
- Organise your fridge, freezer or pantry
- Prevent freezer burn



* Stored in vacuum container and bags in refrigerator, compared to ordinary non-vacuum storage methods, study conducted by an independent laboratory 09/2018, 06/2019 and 12/2019.





- Prolong the shelf life
- Preserve taste, texture and nutrients
- Reduce food waste

