







8001380457 (060629)















mm











**tr** Kurulum talimatları  
**ar** تعليمات التركيب  
**en** Installation instructions





**ka** ინსტალაციის ინსტრუქციები  
**az** Quraşdırma təlimatları





























Torx  
T 20















Torx  
T 20






Torx  
T 20












Torx  
T 20






SW22














Torx  
T 20















Torx  
T 20







SW22





A series of horizontal lines for writing, starting from a vertical margin line on the left and extending across the page.

