Programme Chart

Type of laundry	Amount of laundry, up to:	Programme	Additional functions	Degree of dirt / Advice
Hard-wearing fabrics made from cotton or linen, heat-resistant fabrics	4,5 kg		None	Light to normal
			u <u>→</u> → , ,	Negligible to light
			"\""	Additional rinsing cycle
			" 🕞 "	Reduced spin speed
			"Ø"	The laundry is left in the final rinsing water
		≅ Koch/Bunt 60 °C (60 °C Intensive Stains)	None	Stained
		\L/ + Koch/Bunt 60 °C (60 °C Cottons + Linens with Prewash)	None	Intensive
		⑥ 以 Koch/Bunt 90 °C (90 °C Cottons + Linens)	None	Intensive
Easy-care fabrics made from cotton, synthetics or blended fabrics	2,0 kg	♣ Pflegeleicht 30, 40*, 60 °C (30, 40, 60 °C Easy-care)	None	Light to normal
			u \→ → y n	Negligible to light
			"\""	Additional rinsing cycle
			" 🕞 "	Reduced spin speed
(30) (40) (30)			" Ø "	Reduced spin speed The laundry is left in the final rinsing water
Sensitive, easy-care fabrics made from cotton, synthetics, silk or blended fabrics (e.g. net curtains)	2,0 kg	☐ Fein 30 °C (30 °C Delicates/Silk)	None	Light to normal
			"\ →→ "	Negligible to light
			" "	Additional rinsing cycle
			" 🕞 "	Reduced spin speed
			" Ø "	The laundry is left in the final rinsing water
Washable fabrics made from wool or wool basis	2,0 kg	8 Wolle 30* °C (30 °C Woollens)	None	Light to normal
			"\ ``` "	Negligible to light
			"***"	Additional rinsing cycle
			" 💮 "	Reduced spin speed
			" & "	The laundry is left in the final rinsing water

Programme options

Programme selector	Notes / Application			
Spülen 👑 (Rinse)	Separate rinsing cycle with subsequent spin cycle for easy-care fabrics. Rinsing of hand-washed laundry or for starching.			
Schleudern © (Spin)	Separate spin cycle. Washing solution or rinsing water is drained prior to spinning. Spinning of hand-washed laundry.			
Abpumpen 🛶 (Drain)	Draining of the rinsing water after a programme with "S". Gentle treatment of sensitive laundry.			

^{*} Programme setting for test in accordance or in conformity with EN 60 456 and IEC 60 456.


More detailed information can be found in the operating and installation instructions. Please read these carefully and observe the safety instructions.





Quick-reference instructions

Please read and observe these operating and installation instructions carefully before using the washing machine for the first time.


SIEMENS

























As required







At the end of the programme





