
### en Installation instructions

### en Contents

Installing the appliance	3	Aligning the appliance	3
Changing over the door hinges	3	Ventilation	3

# Installing the appliance



Please fold out the illustrated last page.

Install the appliance in a dry, well ventilated room. The installation location should neither be exposed to direct sunlight nor near a heat source, e.g. a cooker, radiator, etc. If installation next to a heat source is unavoidable, use a suitable insulating plate or observe the following minimum distances to a heat source:

3 cm to an electric cooker. 30 cm to an oil or solid-fuel cooker.

Appliances with fitted handles must be situated at least 55 mm from the wall on the hinge side so that the door can be opened by 90°.

# Changing over the door hinges

We recommend that you have the door hinges changed over by our customer service.

Before changing over the hinges, pull out the mains plug or disconnect the fuse.

# Attention! Carefully place the appliance on its back.

Installation in numerical sequence.

1. Changing over the door hinges. Fig. 11/A/B/C

2. Changing the door handle.

Fig. 11/D

## Aligning the appliance

#### Fig. 2

Place the appliance in the designated location and align.


Adjust the height-adjustable feet with a wrench.


### Ventilation


### Fig. 3


The air on the rear panel of the appliance heats up. The warm air must be able to escape. Otherwise, the refrigerator must work harder. This will increase the power consumption.


Therefore: Never cover or block ventilation openings!


















































1/C







Subject to alterations.