

Overview of programmes

Programme/Type of laundry/Information	Settings
Name of the programme Brief explanation of the programme and for which fabrics it is suitable.	Max. load; * Reduced load for speed Perfect  setting Temperature Spin speed (depending on model) Possible programme settings
Cottons Hard-wearing fabrics, heat-resistant fabrics made of cotton or linen. Cottons + Prewash : Divide detergent between compartments I and II Note : The speed Perfect  setting is suitable as a short programme for lightly soiled laundry.	Max. 7 kg / 4* kg  - 90 °C  ... 1400 rpm eco Perfect  , speed Perfect  ,  (Easy Iron),  (Rinse Plus)
Easy-Care Textiles made of synthetic or blended fabrics. Easy-Care + Prewash : Divide the detergent between compartments I and II	Max. 3.5 kg  - 60 °C  ... 1200 rpm eco Perfect  , speed Perfect  ,  (Easy Iron),  (Rinse Plus)
Mix A mixed load of fabrics made of cotton and synthetic fabrics	Max. 3.5 kg  - 40 °C  ... 1400 rpm eco Perfect  , speed Perfect  ,  (Easy Iron),  (Rinse Plus)
Delicate/Silk For delicate, washable fabrics, e.g. made of silk, satin, synthetic fibres or blended fabrics (e.g. silk blouses, silk scarves) Note : Use a detergent that is suitable for machine-washing delicates or silk.	Max. 2 kg  - 40 °C  ... 800 rpm eco Perfect  , speed Perfect  ,  (Easy Iron),  (Rinse Plus)

Programme/Type of laundry/Information	Settings
 Wool Hand- or machine-washable fabrics that are made of wool or contain wool; Particularly gentle wash programme to prevent shrinkage of laundry, with longer programme breaks (fabrics rest in the detergent solution)	Max. 2 kg  - 40 °C  ... 800 rpm -
Notes ■ Wool is of animal origin, e.g.: Angora, alpaca, llama, sheep. ■ Use a detergent that is suitable for machine-washing wool.	
 Rinse / Spin Programme for spinning or rinsing.	Max. 7 kg -
Note: If you do not want to spin and instead want to rinse, select the additional programme setting  (Rinse Plus).	 ... 1400 rpm  (Easy Iron)
 Empty the rinsing water, e.g. after setting  (without final spin)	Max. 7 kg -
	 ... 1400 rpm -
Super 15' Extra-short programme of approx. 15 minutes, suitable for small items of lightly soiled laundry	Max. 2 kg  - 40 °C  ... 1200 rpm -
Jeans/Dark Wash Dark fabrics made of cotton and dark easy-care fabrics Turn laundry inside-out before washing.	Max. 3.5 kg  - 40 °C  ... 1200 rpm eco Perfect  , speed Perfect   (Easy Iron),  (Rinse Plus)
Hygiene Hardwearing textiles made of cotton or linen.	Max. 7 kg/ 5* kg  - 60 °C
Note: Especially suitable for increased hygienic demands or particularly sensitive skin on account of prolonged washing at a defined temperature, with a higher water level and longer rinsing cycle	 ... 1400 rpm eco Perfect  , speed Perfect   (Easy Iron),  (Rinse Plus)
Dessous For delicate, washable underwear e.g. made of velvet, lace, Lycra, silk or satin.	Max. 1 kg  - 40 °C  ... 600 rpm eco Perfect  , speed Perfect   (Easy Iron),  (Rinse Plus)

Programme/Type of laundry/Information	Settings
Shirts/Business	Max. 2 kg
Non-iron shirts/Blouses made of cotton, linen, synthetics fibres or blended fabrics.	☼ - 60 °C
Note: Wash shirts/blouses made of delicates/silk in Delicates/silk programme.	Ø ... 800 rpm
	eco Perfect  , speed Perfect  ,  (Easy Iron),  (Rinse Plus)
Outdoor/Water proofing	Max. 1 kg
Washing followed by impregnation of weatherproof and outdoor clothing with membrane coating and water-resistant textiles;	Ø ... 800 rpm
Notes	eco Perfect  , speed Perfect  ,  (Rinse Plus)
■ Use special detergents suitable for machine wash. Dosage according to manufacturer's instructions: ■ Pour into dispenser II special detergent and ■ textile guard agent (max. 170 ml) into dispenser . ■ The laundry must not be treated with fabric softener. ■ Before washing, remove all fabric softener residue from detergent drawer (all dispensers).	



Consumption values table

Programme duration, residual moisture, energy and water consumption for the main washing programmes (approximate information)

Programme	Load	Energy consumption*	Water*	Programme duration*
Cottons 20 °C	7 kg	0.26 kWh	73 l	2 1/2 h
Cottons 40 °C	7 kg	0.98 kWh	73 l	2 3/4 h
Cottons 60 °C	7 kg	1.12 kWh	73 l	2 3/4 h
Cottons 90 °C	7 kg	2.19 kWh	83 l	2 3/4 h
Easy-Care 40 °C	3.5 kg	0.64 kWh	58 l	1 3/4 h
Mix 40 °C	3.5 kg	0.54 kWh	51 l	1 h
Delicate/Silk 30 °C	2 kg	0.19 kWh	35 l	3/4 h
Wool 30 °C	2 kg	0.17 kWh	40 l	3/4 h

Programme	Approximate information on the residual moisture**		
	WM14...	WM12...	WM10..
	Max. 1400 rpm	Max. 1200 rpm	Max. 1000 U/rpm
Cotton	48 %	53 %	62 %
Easy-Care	40 %	40 %	40 %
Delicate/Silk	30 %	30 %	30 %
Wool	45 %	45 %	45 %
* The values may deviate from the specified values depending on the following factors: water pressure and hardness; water inlet temperature; type, amount and soiling of laundry; detergent used; fluctuations in the power supply; and additional functions selected.			
** Information on residual moisture based on programme-dependent spin speed limits and maximum loads.			

Most efficient programmes for cotton fabrics

The following programmes are suitable for cleaning normally soiled cotton fabrics and are the most efficient with respect to combined energy and water consumption.

Standard programmes for Cottons in accordance with the directive (EU) no. 1015/2010		
Programme + Temperature + Button	Load	Programme duration
Cottons + 60 °C + eco Perfect	7 kg	4 h
Cottons + 60 °C + eco Perfect	3.5 kg	4 h
Cottons + 40 °C + eco Perfect	3.5 kg	4 h
Programme setting for testing and energy labelling in accordance with Directive 2010/30/EU with cold water (15 °C). The specification of the programme temperature is based on the temperature stated on the care label in the fabrics. The actual washing temperature may deviate from the stated programme temperature for energy-saving reasons.		

Notes

- This additional sheet is a part of your operating and installation instructions. Retain all documentation for subsequent use.
- Much more important information can be found in your operating and installation instructions.

WM12Q45XME / ...

9001024992 (9410)

