


Overview of programmes

Programme/Type of laundry/Information	Settings
Name of the programme	Max. load;
Brief explanation of the programme and for which fabrics it is suitable.	* Reduced load for Speed Perfect =  setting
	Temperature
	Spin speed (depending on model)
	Possible programme settings
Cottons	Max. 7 kg/4* kg
Hard-wearing fabrics, heat-resistant fabrics made of cotton or linen.	 - 90 °C
Cottons + Prewash: Divide detergent between compartments I and II	 ... 1400 rpm
Note: The Speed Perfect =  setting is suitable as a short programme for lightly soiled laundry.	Eco Perfect  , Speed Perfect =  , Easy-iron  , Rinse Plus 
Easy-Care	Max. 3.5 kg
Textiles made of synthetic or blended fabrics.	 - 60 °C
Easy-Care + Prewash: Divide the detergent between compartments I and II	 ... 1200 rpm
	Eco Perfect  , Speed Perfect =  , Easy-iron  , Rinse Plus 
Mix	Max. 3.5 kg
A mixed load of fabrics made of cotton and synthetic fabrics	 - 40 °C
	 ... 1400 rpm
	Eco Perfect  , Speed Perfect =  , Easy-iron  , Rinse Plus 
Delicate/Silk	Max. 2 kg
For delicate, washable fabrics, e.g. made of silk, satin, synthetic fibres or blended fabrics (e.g. silk blouses, silk scarves)	 - 40 °C
Note: Use a detergent that is suitable for machine-washing delicates or silk.	 ... 800 rpm
	Eco Perfect  , Speed Perfect =  , Easy-iron  , Rinse Plus 

Programme/Type of laundry/Information	Settings
Wool  <p>Hand- or machine-washable fabrics that are made of wool or contain wool; Particularly gentle wash programme to prevent shrinkage of laundry, with longer programme breaks (fabrics rest in the detergent solution)</p> <p>Notes</p> <ul style="list-style-type: none"> ■ Wool is of animal origin, e.g.: Angora, alpaca, llama, sheep. ■ Use a detergent that is suitable for machine-washing wool. 	Max. 2 kg  - 40 °C  ... 800 rpm -
Rinse  Spin  <p>Programme for spinning or rinsing.</p> <p>Note: If you do not want to spin and instead want to rinse, select the additional programme setting Rinse Plus .</p>	Max. 7 kg -  ... 1400 rpm  Easy-iron 
Empty  <p>the rinsing water, e.g. after setting  (Rinse Stop)</p>	Max. 7 kg -  ... 1400 rpm -
SuperQuick 15' <p>Extra-short programme of approx. 15 minutes, suitable for small items of lightly soiled laundry</p>	Max. 2 kg  - 40 °C  ... 1200 rpm -
Dark Wash <p>Dark fabrics made of cotton and dark easy-care fabrics Turn laundry inside-out before washing.</p>	Max. 3.5 kg  - 40 °C  ... 1200 rpm Eco Perfect  , Speed Perfect  , Easy-iron  , Rinse Plus 
Shirts/Blouses <p>Non-iron shirts/Blouses made of cotton, linen, synthetics fibres or blended fabrics.</p> <p>Note: Wash shirts/blouses made of delicates/silk in Delicates/silk programme.</p>	Max. 2 kg  - 60 °C  ... 800 rpm Eco Perfect  , Speed Perfect  , Easy-iron  , Rinse Plus 
Down Wear <p>Machine-washable textiles filled with down, pillows, blankets or duvets.</p> <p>Note: Wash large items individually. Use mild detergent. Meter detergent sparingly.</p>	Max. 2 kg  - 60 °C  ... 1200 rpm Eco Perfect  , Speed Perfect  , Rinse Plus 

Programme/Type of laundry/Information	Settings
Sports, Fitness Fabrics made of microfibre for sport and leisure	Max. 2 kg ※ - 40 °C … 800 rpm
Notes	Laundry must not be treated with fabric softener. Before washing, clean the detergent drawer thoroughly (all compartments) to remove fabric softener residue.
Anti-allergy (Hygiene) Hardwearing textiles made of cotton or linen.	Max. 7 kg/ 5* kg ※ - 60 °C … 1400 rpm
Note: Especially suitable for increased hygienic demands or particularly sensitive skin on account of prolonged washing at a defined temperature, with a higher water level and longer rinsing cycle	Eco Perfect ☺, Speed Perfect =⊕, Easy-iron ☒, Rinse Plus ☐

Consumption values table

Programme duration, residual moisture, energy and water consumption for the main washing programmes (approximate information)

Programme	Load	Energy consumption*	Water*	Programme duration*
Cottons 20 °C	7 kg	0.26 kWh	73 l	2 1/2 h
Cottons 40 °C	7 kg	0.98 kWh	73 l	2 3/4 h
Cottons 60 °C	7 kg	1.12 kWh	73 l	2 3/4 h
Cottons 90 °C	7 kg	2.19 kWh	83 l	2 3/4 h
Easy-Care 40 °C	3.5 kg	0.64 kWh	58 l	1 3/4 h
Mix 40 °C	3.5 kg	0.54 kWh	51 l	1 h
Delicate/Silk 30 °C	2 kg	0.19 kWh	35 l	3/4 h
Wool 30 °C	2 kg	0.17 kWh	40 l	3/4 h

Programme	Approximate information on the residual moisture**		
	WA...28...	WA...24...	WA...20...
	Max. 1400 rpm	Max. 1200 rpm	Max. 1000 U/rpm
Cotton	48 %	53 %	62 %
Easy-Care	40 %	40 %	40 %

* The values may deviate from the specified values depending on the following factors: water pressure and hardness; water inlet temperature; type, amount and soiling of laundry; detergent used; fluctuations in the power supply; and additional functions selected.

** Information on residual moisture based on programme-dependent spin speed limits and maximum loads.

Programme	Approximate information on the residual moisture**		
	WA...28...	WA...24...	WA...20...
	Max. 1400 rpm	Max. 1200 rpm	Max. 1000 U/rpm
Delicate/Silk	30 %	30 %	30 %
Wool	45 %	45 %	45 %

* The values may deviate from the specified values depending on the following factors: water pressure and hardness; water inlet temperature; type, amount and soiling of laundry; detergent used; fluctuations in the power supply; and additional functions selected.

** Information on residual moisture based on programme-dependent spin speed limits and maximum loads.

Most efficient programmes for cotton fabrics

The following programmes are suitable for cleaning normally soiled cotton fabrics and are the most efficient with respect to combined energy and water consumption.

Standard programmes for Cottons in accordance with the directive (EU) no. 1015/2010

Programme + Temperature + Button	Load	Programme duration
Cottons + 60 °C + Eco Perfect ☺	7 kg	4 h
Cottons + 60 °C + Eco Perfect ☺	3.5 kg	4 h
Cottons + 40 °C + Eco Perfect ☺	3.5 kg	4 h

Programme setting for testing and energy labelling in accordance with Directive 2010/30/EU with cold water (15 °C).
The specification of the programme temperature is based on the temperature stated on the care label in the fabrics. The actual washing temperature may deviate from the stated programme temperature for energy-saving reasons.

Notes

- This additional sheet is a part of your operating and installation instructions.
Retain all documentation for subsequent use.
- Much more important information can be found in your operating and installation instructions.

WAQ2445XME / ...

9001025002 (9410)

