

Connect your oven to the future.

Installation guide



Welcome to the connected home!

Congratulations on your new smart appliance with Home Connect, designed to simplify your life and make it more enjoyable.*

Home Connect helps you to manage your home appliances with ease and comfort, providing a variety of functions beyond simple remote control.

The Home Connect app gives you important and useful information about your home appliance, allowing you to customize and trigger certain functionalities and actions. Furthermore, the app offers support on how to properly maintain your home appliance and also inspires with a variety of recipes. Explore our ecosystem of partners and gain even more functionalities and services.

Home Connect opens up a world of possibilities exceeding your expectations of a home appliance.

^{*} The availability of the Home Connect function depends on the availability of Home Connect services in your country. Home Connect services are not available in every country. You can find more information on this at www.home-connect.com

Explore: With the Home Connect app you can...



Manage your appliance

In the app's appliance section you have an overview of your connected home appliances, offering a variety of functions beyond simple remote control. Monitor the home appliance's progress, change or pause programs, change settings, trigger actions, and receive notifications.



Be inspired

The recipe section provides a variety of inspiring recipes, tips and videos, that will make cooking and baking even more enjoyable.



Get support

The service section gives helpful information on how to maintain and operate your home appliance properly.



Discover even more benefits

We are constantly expanding our ecosystems of partners. Please refer to www.home-connect.com for an overview of all partners.

Let's get started!

What you need

- 1 Your oven that is connected to the power supply and switched on.
- 2 A smartphone or tablet with the latest version of the iOS or Android operating system.
- 3 Your oven within range of your home network's Wi-Fi signal.
- 4 The name (SSID) and password (key) of your Wi-Fi home network.
- 5 These installation instructions.

Important information:

Data security: Home Connect values customer data, ensuring the transfer of data is encrypted. Home Connect utilizes a variety of security measures, which are periodically reviewed. For further information visit www.home-connect.com.

Appliance safety: To ensure safe operation of your appliance with Home Connect functionality, please consult the safety information in the appliance instruction manual.

Step 1: Download the Home Connect app and create a user account

- 1 Open the App Store (Apple devices) or Google Play Store (Android devices) on your smartphone or tablet.
- 2 | Search for the "Home Connect" app in the store's search and install it.

Home Connect app: Home Connect

- 3 Open the app and register to create a Home Connect user account.
- 4 Write down your Home Connect account credentials (user account and password), you will need them later.
- The app will guide you through the steps of adding your appliance to Home Connect. It will refer to this guide only when needed.

Step 2: Connect your oven to your home network

- 1 Your oven must be installed properly and turned on.
- 2 Open your Home Connect app to add your oven. Select "Add appliance".
- 3 Please follow the directions in the app and refer to this guide only when prompted to by the app.

Information:

We are constantly working to improve the Home Connect app, which may lead to differences in the setup steps. Please rely on the instructions in the latest version of the Home Connect app to quide you through the setup process.

Step 2.1: Connect your oven to your WLAN home network (Wi-Fi) with WPS

Please enter step 2.1 only when prompted to by the app. The following steps describe operations at the home appliance itself.

1 Press the "menu" field on your oven.



- 2 Press "Home Connect Assistant" on your oven.
- ✓ The display now shows "Network connection Automatic".



- 3 Activate the WPS function on your home network router within the next 2 minutes.
- After a few seconds, "Network connection Successful" appears on your oven's display.



4 | Follow the instructions in the app.

Information:

If the connection could not be established within 2 minutes, make sure your oven is within the range of your WLAN home network (Wi-Fi).

For some appliances the WPS mode is also called "automatic mode"

Step 2.2: Connect your oven to your WLAN home network (Wi-Fi) step by step

Please enter step 2.2 only when prompted to by the app. The following steps describe operations at the home appliance itself.

1 Press the "menu" field on your oven.



- 2 Press "Home Connect Assistant" on your oven.
- 3 To start connecting manually, press "Manually connect".



The appliance opens a temporary Wi-Fi network named "HomeConnect" for 5 minutes with the password "HomeConnect".

Using this temporary Wi-Fi network, the app will transfer the name (SSID) and the password of your home network to the oven, thereby enabling the oven to connect to your home network.

4 Follow the instructions in the app.

Information:

For some appliances the step-by-step mode is also called "SAP mode" or "manual mode".

If the step-by-step mode does not work please check:

- Your appliance is in the range of the WLAN home network (Wi-Fi).
- Your smartphone/tablet is connected to your WLAN home network (Wi-Fi).
- Your smartphone/tablet and appliance are connected to the same WLAN home network (Wi-Fi).

Step 3: Connect your oven to the Home Connect app

Please enter step 3 only when prompted to by the app. The following steps describe operations at the home appliance itself.

1 Press "Connect with app" on your oven.



- 2 | Follow the instructions in the app.
- 3 Once successfully logged in, press "End assistant" on your oven.



Information:

If the connection could not be established make sure your smartphone/tablet is within range of you WLAN home network (Wi-Fi).

Home Connect opens up a world of possibilities, exceeding your expectations of a home appliance.

To learn more about smart home appliances with Home Connect and our partner ecosystem, visit www.home-connect.com

These installation instructions are available in additional languages on the website for your appliance brand.



If you have any questions, just visit us at www.home-connect.com.



Home Connect is a service provided by Home Connect GmbH.

Apple App Store and iOS are Apple Inc. trademarks. Google Play Store and Android are Google Inc. trademarks. Wi-Fi is a Wi-Fi Alliance trademark.

