


## Overview of programmes

Programme/type of laundry/information	Settings
<b>Name of programme</b> Brief explanation of the programme and the items for which it is suitable.	Max. load; temperature Max. Spin speed (- - - = Rinse Stop, 0 = no spin cycle, draining only) Additional programme settings
<b>Cottons</b> Hard-wearing items and heat-resistant items made of cotton or linen * The <b>Speed</b> setting is suitable as a short programme for small loads of lightly soiled laundry.	Max. 8 kg/5* kg; 20, 40, 60, 90 °C Max. 1400 rpm Speed/Eco (≡☼/☼)
<b>Cottons</b> ◻ Hard-wearing items and heat-resistant items made of cotton or linen; energy-optimised washing that works by reducing the temperature while achieving a comparable washing result to the <b>Cottons</b> programme. <b>Note:</b> . The actual washing temperature may differ from the stated programme temperature for energy-saving reasons; the washing performance corresponds to the selected temperature.	Max. 8 kg; 40, 60 °C Max. 1400 rpm -
<b>Cottons + Prewash</b> Hard-wearing items and heat-resistant items made of cotton or linen; Pour detergent into compartments <b>I</b> and <b>II</b> .	Max. 8 kg; 40 °C Max. 1400 rpm Speed/Eco (≡☼/☼)
<b>Rinse</b> Extra rinse with configurable spin speed	-; - Max. 1400 rpm -
<b>Spin / Drain</b> Extra spin with configurable spin speed. If only draining is required, set the spin speed to 0. <b>Note:</b> . The "Ready in" time display is only updated once the programme has started.	-; - Max. 1400 rpm -
<b>Easy-Care</b> Items made of synthetic materials or blended fabrics	Max. 4 kg; 30, 40 °C Max. 1200 rpm Speed/Eco (≡☼/☼)
* Reduced load with the <b>Speed</b> setting ** Max. spin speed, depending on the selected programme and model	

Programme/type of laundry/information	Settings
 <b>Wool</b> Hand- or machine-washable items that are made of wool or contain wool; particularly gentle wash programme to prevent laundry from shrinking, with longer pauses in the programme (during which the items rest in the water)	Max. 2 kg; 30 °C Max. 800 rpm -
<b>Notes</b> <ul style="list-style-type: none"> <li>■ Wool is of animal origin, e.g. angora, alpaca, llama, sheep.</li> <li>■ Use a detergent that is suitable for machine-washing wool.</li> </ul>	
<b>Delicates / Silk</b> For delicate, washable items, e.g. made of silk, satin, synthetic or blended fabrics (e.g. silk blouses, silk scarves)	Max. 2 kg; 30 °C Max. 800 rpm Speed/Eco (≡🔄/🌀)
<b>Note:</b> . Use a detergent that is suitable for machine-washing delicate fabrics or silk.	
<b>Mixed Load</b> Mixed load of cottons and synthetic fabrics	Max. 4 kg; 40 °C Max. 1400 rpm Speed/Eco (≡🔄/🌀)
<b>Night Wash</b> Especially quiet programme for washing during the night; suitable for items made from cotton, linen, and synthetic and blended fabrics	Max. 2/3.5 kg; 40 °C Max. 1200 rpm Speed/Eco (≡🔄/🌀)
<b>Notes</b> <ul style="list-style-type: none"> <li>■ End signal deactivated</li> <li>■ Reduced final spin speed set by default</li> </ul>	
* Reduced load with the <b>Speed</b> setting ** Max. spin speed, depending on the selected programme and model	



## Consumption values table

(approximate values)

Programme	Load	Energy consumption*	Water consumption*	Length of programme*
Cottons 20 °C	8 kg	0,26 kWh	85 l	2 ¾ h
Cottons 40 °C	8 kg	0,99 kWh	85 l	3 ¼ h
Cottons 60 °C	8 kg	1,16 kWh	85 l	2 ¾ h
Cottons <40°C**	4 kg	0,44 kWh	37 l	4 ¼ h
Cottons <60°C**	4 kg	0,74 kWh	37 l	4 ½ h
Cottons <60°C**	8 kg	0,85 kWh	55 l	4 ½ h
Cottons 90 °C	8 kg	2,01 kWh	95 l	2 ¾ h
Easy-Care 40 °C	4 kg	0,71 kWh	62 l	2 h
Mixed Load 40 °C	4 kg	0,57 kWh	45 l	1 ¼ h
Delicates / Silk	2 kg	0,19 kWh	34 l	¾ h
Wool	2 kg	0,21 kWh	40 l	¾ h

Programme	Approximate residual moisture***		
	WIW28...	WIW24...	WIW20...
	Max. 1400 rpm	Max. 1200 rpm	Max. 1000 rpm
Cottons	53%	58%	68%
Easy-Care	40%	40%	40%
Delicates / Silk	30%	30%	30%
Wool	45%	45%	45%

Values determined in accordance with EN60456:2011.

\* The observed values may differ from the indicated values due to the influence of water pressure, hardness and inlet temperature, ambient temperature, type, amount and soiling of laundry, detergent used, fluctuations in the power supply and any additional functions selected.

\*\* Programme setting at maximum speed for testing and energy labelling in accordance with Directive 2010/30/EU with cold water (15 °C).

These programmes are suitable for cleaning normally soiled cotton items and are the most efficient in terms of combined energy and water consumption.

The stated programme temperature is based on the temperature indicated on the care label for the laundry. The actual washing temperature may differ from the stated programme temperature for energy-saving reasons; the washing performance meets legal requirements.

\*\*\* The stated residual moisture is based on the maximum spin speed and load of each individual programme.

**en** Supplementary sheet for the installation and operating instructions

**WIW28300GB**

**9001266816 (9702)**

