



## You must note the following

### Electrical connection

The appliance must only be connected to a earthing contact socket that has been correctly installed. A socket must only be installed or the power cable replaced if this is carried out by a qualified electrician, and in accordance with the appropriate regulations.

The appliance must only be connected using the power cable provided. Connect the power cable to the back of the appliance. Connecting cables with various plug types are available from after-sales service.

No multi-plugs, multiple connectors or extension leads may be used. Overloading causes a risk of fire.

If the plug can no longer be reached after the installation, a partition must be provided in the phases in the permanent electrical installation in accordance with the installation regulations.

### Fitted units

The fitted cabinet must not have a back panel behind the appliances. There should be a gap of at least 35 mm between the wall and the cabinet base as well as the rear panel of the cabinet situated above.

Do not install the appliance behind the door of a unit.

Ventilation slots and intake openings must not be covered.

Read the information in the installation instructions for the appliance installed above.

### Installing the appliance

Connect the appliance to the mains. Then align the appliance flush with the units and screw it in place.

**Note:** Ensure that the connector lead does not become trapped or bent. After installation, the connector lead must not be in contact with the back or the base of the appliance.

After installation, the connector lead must not be in contact with the back or the base of the appliance.

## יש לשים לב לדברים הבאים

### חיבור חשמלי

יש לחבר את המכשיר רק לשקע בעל הארקה שהותקן כהלכה. שקע יותקן או שכבל החשמל יוחלף רק על-ידי חשמלאי מוסמך, ובהתאם לתקנות המתאימות.

יש לחבר את המכשיר לחשמל באמצעות כבל החשמל המסופק בלבד. חברו את כבל החשמל אל גב המכשיר.

ניתן להשיג כבלי חשמל המצוידים במגוון תקעים במרכז שירות הלקוחות.

אין להשתמש במספר תקעים, מחברים או כבלים מאריכים. עומס יתר עלול לגרום לשריפה.

אם לא ניתן להגיע לתקע לאחר ההתקנה, יש לספק מחיצה בפזות בהתקנה החשמלית הקבועה, בהתאם לתקנות ההתקנה.

### התקנה בארון

הארון להתקנה לא יכול להיות בעל לוח אחורי שימוקם מאחורי המכשירים. צריך להיות מרווח של 35 מ"מ לפחות בין הקיר לבסיס הארון, וכן ללוח האחורי של הארון הממוקם למעלה.

אין להתקין את המכשיר מאחורי דלת הארון.

אין לכסות את חריצי האוורור ואת פתחי כניסת האוויר.

קראו את המידע בהוראות ההתקנה עבור המכשיר המותקן למעלה.

### התקנת המכשיר

חברו את המכשיר אל החשמל. לאחר מכן ישרו את משטח המכשיר עם משטחי הארונות והבריגו אותו למקומו.

**הערה:** ודאו שהכבל לא נתפס ואינו מתעקם. לאחר ההתקנה, אין להניח לכבל לגעת בגב המכשיר או בבסיס המכשיר.

לאחר ההתקנה, אין להניח לכבל לגעת בגב המכשיר או בבסיס המכשיר.



