



Siemens Home Appliances, the world renowned premium German brand stands for outstanding engineering achievements, characterized by intelligent design, innovation, creativity, perfection and precision. For more than 160 years, Siemens Home Appliances has provided a continuous flow of innovations improving people's lives. "Progress in the service of mankind" was the aspiration of the company's founder Werner von Siemens. With this goal in mind, Siemens Home Appliances engineers continuously endeavour to optimize home appliances for water and energy efficiency.

The tested and approved Cleaning and Care Collection from Siemens Home Appliances aims to bring lasting benefits to your precious appliances with lifespan extension and top performance. Intensive testing on the Collection can assure you of a worry-free application on appliances and dedicated inside out cleaning results as a blessing. We do believe there is nothing more heart-warming than indulge your family time while you can simply leaving your appliances in our good hand.


Website: www.siemens-home.com.hk
E-mail: siemens.hk.service@bshg.com
Parts Hotline: (852) 2388 7538

Customer Care Centre
3/F, North Block, Skyway House, 3 Sham Mong Road, Tai Kok Tsui,
Kowloon, Hong Kong

Right of technical modification reserved, delivery subject to availability, colors of actual products may vary from illustrations.
® Registered trademark.

©2015 BSH Home Appliances Limited. All rights reserved.
All contents and information contained in this catalogue are proprietary to BSH Home Appliances Limited and are subject to copyright protection. Reproduction, republication, redistribution or unauthorized use of any content or information contained in this catalogue is expressly prohibited without the prior written consent of BSH Home Appliances Limited. Printed in Hong Kong 12. 2015

BSH Home Appliances Limited
Manufacturer's Service for Siemens Home Appliances



SIEMENS



Fresh Laundry, Make it Everlasting.
Cleaning and Care

siemens-home.com.hk

Siemens. The future moving in.

Tips for laundry care



Before Washing

Loading of Laundry

Please make sure the loading does not exceed the maximum capacity of the machines. Overloading would lead to higher chance of spare parts depreciation and affect the lifespan of appliances. This also causes poor washing cleaning result as there is insufficient space inside the drum for washing.

Empty the Pockets

To avoid loose particles from trapping at periphery of washing drum or hitting the appliances during high speed rotation, which would damage your laundry or appliances, those objects such as coins should be taken out from laundry before washing. You are also suggested to buckle all buttons or zippers and flip clothes before putting them into the drum.

Use of Detergents

Please use suitable detergent with appropriate dose. Unsuitable detergent or overdose detergent may result in a prolonged washing period. This causes extra energy consumption as well as decrease of cleaning efficiency. Meanwhile, the accumulated residue outside the drum would lead to a hygienic alert.

Choose of Water Temperature

Enzyme of detergents reacts much better at temperature above 30°C, which brings you the best results of cleaning. If this temperature could apply to your fabric (please check the clothing label), you could choose related washing programme so as to get the best cleaning result and to save detergent and energy.

After Washing

Boot Gasket Handling

Moist may be formed at the boot gasket after laundry. Please wipe the boot gasket with dry cloth and leave the door open for a while to ventilate interior part of appliances thoroughly, so as to avoid mold, bacteria or odour. This could extend lifespan of appliances.

Filter Cleaning

Regular cleaning of filter can ensure its highest cleaning performance and preventing bacteria and odour. (Please refer to operation manual for details)

Drum Cleaning

By operating the washer with the 90°C programme with empty drum every 3-4 weeks, the high-temperature water would flow through the periphery of washing drums. This can help to dissolve the debris at the outer part of drum, and remove bacteria or odour. For thorough and through cleaning, you are recommended to use our descaler and cleaner of washing machine. (Please refer to the products details at this leaflet)

Detergent Dispenser Cleaning

Please dilute concentrated softener and rinse the detergent dispenser regularly before use in order to avoid siphon blockage and over-dosed detergent from accumulation at the there. (Please refer to operation manual for details)

Washing Machine Cleaner

Quick Descaler for Washing Machines and Dishwashers



Model	00311610	00311506
Features	<ul style="list-style-type: none"> • Stable for removing deposits from the appliance – including detergent • Prevent unpleasant odours from developing by bacteria and ensures a clean interior of the washing machine • Avoid clothes from being polluted at the second time • Tested and approved product by manufacturer which brings you the best caring solutions 	<ul style="list-style-type: none"> • Effectively remove harmful limescale deposits from your appliances • Avoid negative impact from water quality to extend the lifetime of appliances • Tested and approved product by manufacturer which brings you the best caring solutions
Usage Frequency	1 pack every 3 months is recommended	Washing Machine: Depends on the water hardness on the local area, recommend to use every 3-6 months Dishwasher: Use annually

To Shop:

- Call Parts Hotline: (852) 2388 7538
- Visit Customer Care Centre



Find out more on our Cleaning and Care Collection

